

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>ALFA ROMEO</b>											
<b>145 1994 2000</b>											
1.4	AR 33501	1351	66	1994	1996	X	X	X	X	X	X
1.4 TS 16V	AR 33503	1370	76	1996	2000	X	X	X	X	X	X
1.6	AR 33201	1596	76	1994	1996	X	X	X	X	X	X
1.6 TS 16V	AR 67601	1598	88	1996	2000	X	X	X	X	X	X
1.7 16V	AR 33401	1712	95	1994	1996	X	X	X	X	X	X
1.8 TS 16V	AR 32201	1747	106	1998	2000	X	X	X	X	X	X
1.8 TS 16V	AR 67106	1747	103	1996	1998	X	X	X	X	X	X
1.9 JTD	AR 32302	1910	77	1998	2000	X	X	X	X	X	X
1.9 TD	AR 33601	1929	66	1994	1999	X	X	X	X	X	X
1.9 TD	AR 67501	1929	66	1994	1999	X	X	X	X	X	X
2.0 TS 16V	AR 32301	1970	114	1998	2000	X	X	X	X	X	X
2.0 TS 16V	AR 67204	1970	110	1996	1998	X	X	X	X	X	X
<b>146 1995 2000</b>											
1.4	AR 33501	1351	66	1994	1996	X	X	X	X	X	X
1.4 TS 16V	AR 33503	1370	76	1996	2000	X	X	X	X	X	X
1.6	AR 33201	1596	76	1994	1996	X	X	X	X	X	X
1.6 TS 16V	AR 32101	1598	88	1996	2000	X	X	X	X	X	X
1.6 TS 16V	AR 67601	1598	88	1996	2000	X	X	X	X	X	X
1.7 16V	AR 33401	1712	95	1994	1996	X	X	X	X	X	X
1.8 TS 16V	AR 32201	1747	106	1998	2000	X	X	X	X	X	X
1.8 TS 16V	AR 67106	1747	103	1996	1998	X	X	X	X	X	X
1.9 JTD	AR 32302	1910	77	1998	2000	X	X	X	X	X	X
1.9 TD	AR 33601	1929	66	1994	1999	X	X	X	X	X	X
1.9 TD	AR 67501	1929	66	1994	1999	X	X	X	X	X	X
2.0 TS 16V	AR 32301	1970	114	1998	2000	X	X	X	X	X	X
2.0 TS 16V	AR 67204	1970	110	1996	1998	X	X	X	X	X	X
<b>147 2000</b>											
1.6 TS	AR 32103	1598	88	2004		X	X	X	X	X	X
1.6 TS	AR 32104	1598	88	2000		X	X	X	X	X	X
1.6 TS	AR 37203	1598	77	2000		X	X	X	X	X	X
1.9 JTD (100)	182 B9.000	1910	74	2002	2005	X	X	X	X	X	X
1.9 JTD (115)	937 A2.000	1910	85	2000	2005	X	X	X	X	X	X
1.9 JTD (115)	937 A7.000	1910	85	2005		X	X	X	X	X	X
1.9 JTD (120)	937 A3.000	1910	88	2005		X	X	X	X	X	X
1.9 JTD 16V (126)	937 A4.000	1910	93	2004	2005	X	X	X	X	X	X
1.9 JTD 16V (136)	192 B1.000	1910	100	2004		X	X	X	X	X	X
1.9 JTD 16V (140)	192 A5.000	1910	103	2002	2004	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>ALFA ROMEO</b>											
<b>147 2000</b>											
1.9 JTD 16V (150)	937 A5.000	1910	110	2004		X	X	X	X	X	X
2.0 TS	AR 32310	1970	110	2000		X	X	X	X	X	X
3.2 V6 GTA	932 A.000	3179	184	2002		X	X	X	X	X	X
<b>155 1992 1997</b>											
1.6 TS 16V	AR 67601	1598	88	1996	1997	X	X	X	X	X	X
1.7 TS	AR 67103	1749	85	1992	1995	X	X	X	X	X	X
1.8 TS	AR 67102	1773	93	1992	1995	X	X	X	X	X	X
1.8 TS 16V	AR 67106	1747	103	1996	1997	X	X	X	X	X	X
2.0 16V Turbo Q4	AR 67203	1995	137	1992	1995	X	X	X	X	X	X
2.0 TD	AR 67502	1929	68	1992	1997	X	X	X	X	X	X
2.0 TS	AR 67202	1995	104	1992	1995	X	X	X	X	X	X
2.0 TS 16V	AR 67204	1970	110	1996	1997	X	X	X	X	X	X
2.5 TD	VM 07B	2500	92	1992	1997	X	X	X	X	X	X
2.5 V6	AR 67301	2492	120	1992	1995	X	X	X	X	X	X
<b>156 1997 2006</b>											
1.6 TS	AR 32102	1598	82	2000	2001	X	X	X	X	X	X
1.6 TS	AR 32103	1598	88	2001	2006	X	X	X	X	X	X
1.6 TS	AR 32104	1598	88	2001	2006	X	X	X	X	X	X
1.6 TS	AR 67601	1598	88	1997	2001	X	X	X	X	X	X
1.8 TS	AR 32201	1747	106	1997	2001	X	X	X	X	X	X
1.8 TS	AR 32205	1747	103	2001	2006	X	X	X	X	X	X
1.9 JTD 16V	192 A5.000	1910	103	2002	2006	X	X	X	X	X	X
1.9 JTD 16V	937 A4.000	1910	103	2003	2006	X	X	X	X	X	X
1.9 JTD 16V	937 A5.000	1910	110	2004	2006	X	X	X	X	X	X
1.9 JTD 8V	937 A2.000	1910	85	2002	2006	X	X	X	X	X	X
1.9 JTD 8V	AR 32302	1910	77	1997	2001	X	X	X	X	X	X
1.9 JTD 8V	AR 37101	1910	81	2001	2002	X	X	X	X	X	X
2.0 JTS	932 A2.000	1970	121	2002	2006	X	X	X	X	X	X
2.0 JTS	937 A1.000	1970	121	2002	2006	X	X	X	X	X	X
2.0 TS	AR 32301	1970	114	1997	2001	X	X	X	X	X	X
2.0 TS	AR 32310	1970	110	2001	2002	X	X	X	X	X	X
2.4 JTD 10V	839 A6.000	2387	103	2001	2002	X	X	X	X	X	X
2.4 JTD 10V	841 C.000	2387	110	2002	2006	X	X	X	X	X	X
2.4 JTD 10V	AR 32501	2387	100	1997	2001	X	X	X	X	X	X
2.4 JTD 20V	841 G.000	2387	129	2003	2006	X	X	X	X	X	X
2.4 JTD 20V	841 M.000	2387	129	2003	2006	X	X	X	X	X	X
2.5 V6 24V	AR 32401	2492	140	1997	2001	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>ALFA ROMEO</b>											
<b>156 1997 2006</b>											
2.5 V6 24V	AR 32405	2492	141	2001	2006	X	X	X	X	X	X
3.2 V6 GTA	932 A.000	3179	184	2002	2006	X	X	X	X	X	X
<b>159 2005</b>											
1.9 JTDm (115)	939 A7.000	1910	85	2005		X	X	X		X	X
1.9 JTDm (120)	939 A1.000	1910	88	2005		X	X	X		X	X
1.9 JTDm 16V (136)	939 A8.000	1910	100	2005		X	X	X		X	X
1.9 JTDm 16V (150)	939 A2.000	1910	110	2005		X	X	X		X	X
1.9 JTS	939 A6.000	1859	117	2005		X	X	X		X	X
2.2 JTS	939 A5.000	2198	136	2005		X	X	X		X	X
2.4 JTDm 20V	939 A3.000	2387	147	2005		X	X	X		X	X
<b>164 1988 1998</b>											
2.0 Super V6 TB	AR 641.01/.02	1996	152	1992	1998	X	X	X	X	X	X
2.0 TS	AR 064.16	1962	105	1988	1993	X	X	X		X	X
2.0 TS	AR 064.20	1962	109	1988	1993	X	X	X	X	X	X
2.0 TS	AR 641.03	1995	106	1993	1998	X	X	X	X	X	X
2.0 Turbo	AR 064.76	1995	123	1988	1993	X	X	X	X	X	X
2.5 Super TD	VM 84B	2500	92	1993	1998	X	X	X		X	X
2.5 TD	VM 84A	2500	86	1988	1993	X	X	X		X	X
3.0 Q4	AR 643.07	2959	168	1993	1998	X	X	X	X	X	X
3.0 Super V6 24V	AR 643.01/.04	2959	152	1992	1998	X	X	X	X	X	X
3.0 Super V6 24V	AR 663.01	2959	155	1992	1995	X	X	X	X	X	X
3.0 Super V6 24V	AR 663.02	2959	155	1995	1998	X	X	X	X	X	X
3.0 V6	AR 064.10/.12	2959	141	1988	1992	X	X	X	X	X	X
3.0 V6 24V Quadrifoglio	AR 643.08	2959	168	1993	1994	X	X	X	X	X	X
3.0 V6 kat.	AR 064.10/.12	2959	138	1988	1992	X	X	X	X	X	X
3.0 V6 Quadrifoglio	AR 643.01	2959	147	1990	1993	X	X	X	X	X	X
<b>166 1999</b>											
2.0 TS	AR 34103	1970	114	1999	2002	X	X	X	X	X	X
2.0 TS	AR 36301	1970	110	2002	2007	X	X	X	X	X	X
2.0 V6 TB	AR 34102	1996	151	1999	2002	X	X	X	X	X	X
2.4 JTD	841 C.000	2387	110	2002	2007	X	X	X	X	X	X
2.4 JTD	AR 34202	2387	100	2000	2002	X	X	X	X	X	X
2.4 JTD	AR 36202	2387	103	2002	2004	X	X	X	X	X	X
2.4 JTDm 20V	841 G.000	2387	129	2003		X	X	X	X	X	X
2.4 JTDm 20V C.A.	841 H.000	2387	129	2003		X	X	X	X	X	X
2.5 V6	AR 34201	2492	140	1999	2002	X	X	X	X	X	X
2.5 V6	AR 36201	2492	138	2002	2005	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays	
<b>ALFA ROMEO</b>												
<b>166 1999</b>												
3.0 V6	AR 34301	2959	166	1999	2002	X	X	X	X	X	X	X
3.0 V6 C.A.	AR 36101	2959	162	2002	2007	X	X	X	X	X	X	X
3.2 V6	936 A.000	3179	177	2003	2007	X	X	X	X	X	X	X
<b>33 1983 1990</b>												
1.3	301.68	1350	63	1986	1988	X	X	X	X	X	X	X
1.3 / 1.3 QV	305.02/305.85	1350	58	1983	1990	X	X	X	X	X	X	X
1.3 S	305.87	1350	63	1988	1989	X	X	X	X	X	X	X
1.5	301.82	1490	70	1983	1988	X	X	X	X	X	X	X
1.5	305.14	1490	70	1983	1988	X	X	X	X	X	X	X
1.5 4x4	305.14	1490	70	1983	1988	X	X	X	X	X	X	X
1.5 4x4	305.20/305.88	1490	70	1985	1988	X	X	X	X	X	X	X
1.5 4x4 Giardinetta	305.08	1490	70	1989	1990	X	X	X	X	X	X	X
1.5 Quadrifoglio	305.04	1490	62	1983	1988	X	X	X	X	X	X	X
1.5 Ti	301.46	1490	77	1984	1990	X	X	X	X	X	X	X
1.7	305.50	1712	87	1986	1990	X	X	X	X	X	X	X
1.7 IE	305.58	1712	79	1988	1990	X	X	X	X	X	X	X
1.8 TD	VM82 A	1779	62	1989	1990	X	X	X	X	X	X	X
<b>33 1990 1994</b>												
1.2	307.43	1186	58	1990	1994	X	X	X	X	X	X	X
1.3 S	307.32	1351	63	1990	1994	X	X	X	X	X	X	X
1.3 Sportwagon 4x4	307.32	1351	63	1990	1994	X	X	X	X	X	X	X
1.4 IE	307.55	1350	66	1990	1994	X	X	X	X	X	X	X
1.4 IE Sportwagon	307.53	1351	65	1990	1994	X	X	X	X	X	X	X
1.5	307.34	1490	63	1990	1994	X	X	X	X	X	X	X
1.5 IE	307.50	1490	71	1990	1994	X	X	X	X	X	X	X
1.5 IE	307.51	1490	70	1990	1994	X	X	X	X	X	X	X
1.5 IE	307.51 A	1490	70	1990	1994	X	X	X	X	X	X	X
1.5 IE Sportwagon	307.51	1490	70	1991	1994	X	X	X	X	X	X	X
1.5 IE Sportwagon	307.51 A	1490	70	1991	1994	X	X	X	X	X	X	X
1.7 IE	307.36	1712	77	1990	1994	X	X	X	X	X	X	X
1.7 IE 16V	307.46/307.47	1712	95	1990	1994	X	X	X	X	X	X	X
1.7 IE 4x4	307.37	1712	79	1990	1994	X	X	X	X	X	X	X
1.7 IE S 16V QV 4	307.46/307.47	1712	95	1992	1994	X	X	X	X	X	X	X
1.8 TD	VM 96 A	1779	62	1990	1994	X	X	X	X	X	X	X
<b>75 1985 1992</b>												
1.6	061.00	1570	81	1985	1990	X	X	X	X	X	X	X
1.6 IE	061.01	1570	79	1990	1992	X	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>ALFA ROMEO</b>											
<b>75 1985 1992</b>											
1.6 IE	061.02	1570	76	1990	1992	X	X	X	X	X	X
1.8	062.02	1779	88	1985	1990	X	X	X	X	X	X
1.8 IE	61.201	1779	90	1988	1992	X	X	X	X	X	X
1.8 IE	061.68	1779	88	1988	1992	X	X	X	X	X	X
1.8 Turbo	061.34	1779	118	1986	1989	X	X	X	X	X	X
1.8 Turbo	61.203	1779	114	1987	1992	X	X	X	X	X	X
2.0	062.12	1962	94	1985	1989	X	X	X	X	X	X
2.0 TD	VM80 A	1995	70	1985	1992	X	X	X	X	X	X
2.0 TS	0.17.13	1962	109	1987	1992	X	X	X	X	X	X
2.0 TS	062.24	1962	109	1987	1992	X	X	X	X	X	X
2.4 TD	VM81A	2393	82	1987	1992	X	X	X	X	X	X
2.5 V6	016.46	2492	115	1987	1992	X	X	X	X	X	X
3.0 V6	061.20	2959	136	1987	1990	X	X	X	X	X	X
3.0 V6	61.503	2959	138	1987	1992	X	X	X	X	X	X
3.0 V6 Quadrifoglio	061.24	2959	136	1990	1992	X	X	X	X	X	X
<b>Brera 2005</b>											
2.2 JTS	939 A5.000	2198	136	2005		X	X	X		X	
2.4 JTD 20V	939 A3.000	2387	147	2005		X	X	X		X	
3.2 JTS	939 A.000	3195	191	2005		X	X	X		X	
<b>Crosswagon 2004</b>											
1.9 JTD 16V Q4	937 A5.000	1910	110	2004		X	X	X		X	
<b>GT 2004</b>											
1.8 TS 16V	AR 32205	1747	103	2005		X	X	X		X	X
1.9 JTD 16V	937 A5.000	1910	110	2004		X	X	X		X	X
2.0 JTS	932 A2.000	1970	119	2005		X	X	X		X	X
2.0 JTS	937 A1.000	1970	121	2004		X	X	X		X	X
3.2 V6	936 A.000	3179	177	2004		X	X	X		X	X
<b>GTV 1995 2005</b>											
1.8 TS	AR 32201	1747	106	1998	2001	X	X	X		X	X
2.0 JTS 16V	937 A1.000	1970	121	2003	2005	X	X	X		X	X
2.0 TS 16V	AR 16201	1970	110	1995	1998	X	X	X		X	X
2.0 TS 16V	AR 32301	1970	114	1998	2001	X	X	X		X	X
2.0 TS 16V	AR 32310	1970	110	2001	2005	X	X	X		X	X
2.0 V6 TB	AR 16202	1996	147	1995	2001	X	X	X		X	X
3.0 V6 24V	AR 16102	2959	165	1996	2001	X	X	X		X	X
3.0 V6 24V	AR 16105	2959	162	2001	2003	X	X	X		X	X
3.2 V6 32V	936 A.000	3179	176	2003	2005	X	X	X		X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagram. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>ALFA ROMEO</b>											
<b>Spider 2006</b>											
2.2 JTS	939 A5.000	2198	136	2006		X	X X	X		X	
3.2 JTS	939 A.000	3195	191	2006		X	X X	X		X	
<b>Spider 1983 1995</b>											
2.0	005.15	1962	94	1983	1990	X	X X X	X		X	X X
2.0	015.88/015.90	1962	94	1990	1995	X	X X X	X		X	X X
<b>Spider 1995 2006</b>											
1.8 TS	AR 32201	1747	106	1998	2001	X	X X X X	X X		X	X X
2.0 JTS 16V	937 A1.000	1970	121	2003		X	X X X X	X		X	X X
2.0 TS 16V	AR 16201	1970	110	1995	1998	X	X X X X	X X		X	X X
2.0 TS 16V	AR 32301	1970	114	1998	2001	X	X X X X	X		X	X X
2.0 TS 16V	AR 32310	1970	110	2001		X	X X X X	X		X	X X
2.0 V6 TB	AR 16202	1996	147	1998	2001	X	X X X X	X X		X	X X
3.0 V6	AR 16101	2959	141	1995	2001	X	X X X X	X X		X	X X
3.0 V6 24V	AR 16105	2959	162	2001	2003	X	X X X X	X		X	X X
3.2 V6 24V	936 A.000	3179	176	2003		X	X X X X	X		X	X X
<b>Sprint 1986 1990</b>											
1.5 Ti	301.46	1490	77	1986	1988	X	X X X X	X		X	X
1.7	305.50	1712	81	1989	1990	X	X X X X	X		X	X
<b>SZ/RZ 1990 1993</b>											
ES30 Cabrio	AR 61501	2959	152	1990	1992	X	X X X X	X		X	X
ES30 Coupe	AR 61501	2959	154	1990	1993	X	X X X X	X		X	X
<b>AUDI</b>											
<b>100 / 200 / V8 1982 1991</b>											
1.8	4B	1781	66	1988	1990	X	X X X X	X X	X X	X	X X
1.8	DR	1781	55	1982	1987	X	X X X X	X		X	X
1.8	DS	1781	66	1982	1991	X	X X X X	X	X X	X	X X
1.8	JW	1781	66	1983	1988	X	X X X X	X	X X	X	X
1.8	NP	1781	66	1985	1990	X	X X X X	X	X X	X	X X
1.8	PH	1781	66	1985	1990	X	X X X X	X X	X X	X	X X
1.8	RS	1781	55	1986	1987	X	X X X X	X	X X	X	X X
1.8	SH	1781	65	1986	1990	X	X X X X	X	X X	X	X X
1.8 quattro	PH	1781	66	1985	1990	X	X X X X	X X	X X	X	X X
2.0	KP	1994	85	1984	1987	X	X X X X	X X	X X	X	X X
2.0	RT	1994	85	1988	1990	X	X X X X	X X	X X	X	X X
2.0	SL	1994	83	1986	1987	X	X X X X	X	X X	X	X X
2.0 D	CN	1986	51	1982	1989	X	X X X X	X	X X	X	X X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays	
<b>AUDI</b>												
<b>100 / 200 / V8</b>	<b>1982</b>	<b>1991</b>										
2.0 TD	NC	1986	74	1988	1990	X	X	X	X	X	X	
2.1 Turbo	JY	2144	134	1983	1987	X	X	X	X	X	X	
2.1 Turbo	KG	2144	134	1983	1988	X	X	X	X	X	X	
2.2	HX	2226	101	1984	1987	X	X	X	X	X	X	
2.2	KU	2226	101	1984	1991	X	X	X	X	X	X	
2.2	KZ	2226	85	1984	1986	X	X	X	X	X	X	
2.2 quattro	KU	2226	101	1984	1984	X	X	X	X	X	X	
2.3	NF	2309	100	1985	1990	X	X	X	X	X	X	
2.3 20V Turbo quattro	3B	2226	162	1989	1990	X	X	X	X	X	X	
2.3 20V Turbo quattro	RR	2226	162	1989	1990	X	X	X	X	X	X	
2.3 quattro	PX	2309	88	1985	1988	X	X	X	X	X	X	
2.3 Turbo quattro	1B	2309	147	1988	1990	X	X	X	X	X	X	
2.3 Turbo quattro	2B	2309	140	1988	1990	X	X	X	X	X	X	
2.3 Turbo quattro	MC	2309	121	1985	1990	X	X	X	X	X	X	
2.4 D	3D	2370	60	1989	1990	X	X	X	X	X	X	
2.5 TDi	1T	2460	88	1990	1990	X	X	X	X	X	X	
3.6 V8	PT	3562	184	1990	1992	X	X	X	X	X	X	
4.2 V8	ABH	4172	206	1992	1993	X	X	X	X	X	X	
<b>100 / A6</b>	<b>1991</b>	<b>1997</b>										
1.6	ABB	1595	75	1992	1993	X	X	X	X	X	X	
1.8 20V (A6)	ADR	1781	92	1995	1997	X	X	X	X	X	X	
1.9 TDi (A6)	1Z	1896	66	1994	1997	X	X	X	X	X	X	
2.0	AAD	1984	85	1991	1993	X	X	X	X	X	X	
2.0	AAE	1984	74	1991	1995	X	X	X	X	X	X	
2.0	ABK	1984	85	1993	1997	X	X	X	X	X	X	
2.0 16V	ACE	1984	103	1992	1997	X	X	X	X	X	X	
2.3	AAR	2309	98	1991	1997	X	X	X	X	X	X	
2.3 quattro	AAR	2309	98	1991	1997	X	X	X	X	X	X	
2.4 D	AAS	2370	60	1991	1995	X	X	X	X	X	X	
2.5 TDi	AAT	2460	85	1991	1997	X	X	X	X	X	X	
2.5 TDi	ABP	2460	85	1991	1992	X	X	X	X	X	X	
2.5 TDi (A6)	AEL	2461	103	1996	1997	X	X	X	X	X	X	
2.6 V6	ABC	2598	110	1992	1997	X	X	X	X	X	X	
2.6 V6 quattro	ABC	2598	110	1992	1997	X	X	X	X	X	X	
2.8 V6	AAH	2771	128	1991	1997	X	X	X	X	X	X	
2.8 V6 30V (A6)	ACK	2771	142	1995	1996	X	X	X	X	X	X	
2.8 V6 quattro	AAH	2771	128	1991	1997	X	X	X	X	X	X	

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>AUDI</b>											
<b>100 / A6</b>	<b>1991</b>	<b>1997</b>									
S4 / S6 2.2	AAN	2226	169	1991	1997	X	X	X	X	X	X
S4 4.2	ABH	4172	213	1992	1994	X	X	X	X	X	X
S6 4.2 V8	AEC	4172	213	1994	1997	X	X	X	X	X	X
<b>80</b>	<b>1992</b>	<b>1995</b>									
1.6	ABB	1595	75	1990	1994	X	X	X	X	X	X
1.6	ABM	1595	51	1992	1994	X	X	X	X	X	X
1.6	ADA	1595	74	1993	1995	X	X	X	X	X	X
1.8	PM	1781	66	1991	1995	X	X	X	X	X	X
1.9 TD	AAZ	1896	55	1991	1995	X	X	X	X	X	X
1.9 TDi	1Z	1896	66	1991	1995	X	X	X	X	X	X
2.0	ABK	1984	85	1991	1995	X	X	X	X	X	X
2.0	ABT	1984	66	1991	1995	X	X	X	X	X	X
2.0 16V	ACE	1984	103	1992	1995	X	X	X	X	X	X
2.0 16V quattro	ACE	1984	103	1992	1995	X	X	X	X	X	X
2.0 quattro	ABK	1984	85	1991	1995	X	X	X	X	X	X
2.3	NG	2309	98	1991	1995	X	X	X	X	X	X
2.6 V6	ABC	2598	110	1992	1995	X	X	X	X	X	X
2.6 V6 quattro	ABC	2598	110	1992	1995	X	X	X	X	X	X
2.8 V6	AAH	2771	128	1991	1995	X	X	X	X	X	X
2.8 V6 quattro	AAH	2771	128	1991	1995	X	X	X	X	X	X
S2	3B	2226	169	1990	1995	X	X	X	X	X	X
S2	ABY	2226	169	1993	1995	X	X	X	X	X	X
<b>80 / 90</b>	<b>1986</b>	<b>1991</b>									
1.6	PP	1595	51	1986	1991	X	X	X	X	X	X
1.6	RN	1595	51	1986	1987	X	X	X	X	X	X
1.6	RNA	1595	51	1986	1987	X	X	X	X	X	X
1.6 D	JK	1588	40	1986	1989	X	X	X	X	X	X
1.6 D	JKA	1588	37	1986	1989	X	X	X	X	X	X
1.6 TD	RA	1588	59	1986	1989	X	X	X	X	X	X
1.6 TD	SB	1588	59	1987	1991	X	X	X	X	X	X
1.8	DZ	1781	82	1986	1991	X	X	X	X	X	X
1.8	JN	1781	66	1986	1991	X	X	X	X	X	X
1.8	JV	1781	66	1986	1988	X	X	X	X	X	X
1.8	NE	1781	66	1986	1991	X	X	X	X	X	X
1.8	PM	1781	66	1988	1991	X	X	X	X	X	X
1.8	PV	1781	79	1986	1991	X	X	X	X	X	X
1.8	RU	1781	55	1986	1991	X	X	X	X	X	X

Legend: N = new, X = present



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>AUDI</b>											
<b>80 / 90</b>	<b>1986</b>	<b>1991</b>									
1.8	SF	1781	65	1986	1990	X	X	X	X	X	X
1.8 quattro	DZ	1781	82	1986	1991	X	X	X	X	X	X
1.9	SD	1847	83	1986	1988	X	X	X	X	X	X
1.9 D	1Y	1896	48	1989	1991	X	X	X	X	X	X
2.0	3A	1984	83	1988	1991	X	X	X	X	X	X
2.0	AAD	1984	83	1990	1991	X	X	X	X	X	X
2.0	NM	1994	82	1988	1991	X	X	X	X	X	X
2.0	PS	1994	85	1987	1991	X	X	X	X	X	X
2.0 16V	6A	1984	101	1989	1991	X	X	X	X	X	X
2.0 16V quattro	6A	1984	101	1990	1991	X	X	X	X	X	X
2.0 quattro	3A	1984	83	1988	1991	X	X	X	X	X	X
2.0 quattro	AAD	1984	83	1990	1991	X	X	X	X	X	X
2.3	KV	2309	100	1986	1991	X	X	X	X	X	X
2.3	NG	2309	100	1987	1991	X	X	X	X	X	X
2.3 20V	7A	2309	125	1988	1991	X	X	X	X	X	X
2.3 20V quattro	7A	2309	125	1988	1991	X	X	X	X	X	X
2.3 quattro	NG	2309	100	1987	1991	X	X	X	X	X	X
2.3 quattro	NG	2309	100	1989	1991	X	X	X	X	X	X
<b>A2 2000 2005</b>											
1.2 TDi	ANY	1191	45	2001	2005	X	X	X	X	X	X
1.4 16V	AUA	1390	55	2000	2003	X	X	X	X	X	X
1.4 16V	BBY	1390	55	2002	2005	X	X	X	X	X	X
1.4 TDi	AMF	1422	55	2000	2005	X	X	X	X	X	X
1.4 TDi	ATL	1422	66	2004	2005	X	X	X	X	X	X
1.4 TDi	BHC	1422	55	2003	2005	X	X	X	X	X	X
1.6 FSi	BAD	1598	81	2002	2005	X	X	X	X	X	X
<b>A3 1997 2003</b>											
1.6	AEH	1595	74	1996	2001	X	X	X	X	X	X
1.6	AKL	1595	74	1997	2003	X	X	X	X	X	X
1.6	APF	1595	74	1999	2001	X	X	X	X	X	X
1.6	BAH	1598	74	2003	2003	X	X	X	X	X	X
1.6	BFQ	1595	75	2002	2003	X	X	X	X	X	X
1.6	AVU	1595	75	2000	2003	X	X	X	X	X	X
1.8 20V	AGN	1781	92	1996	2001	X	X	X	X	X	X
1.8 20V	APG	1781	92	1999	2003	X	X	X	X	X	X
1.8 20V Turbo	AGU	1781	110	1996	2003	X	X	X	X	X	X
1.8 20V Turbo	AJQ	1781	132	1998	2001	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagram. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>AUDI</b>											
<b>A3 1997 2003</b>											
1.8 20V Turbo	APP	1781	132	1999	2001	X	X	X	X	X	X
1.8 20V Turbo	AQA	1781	132	1998	2002	X	X	X	X	X	X
1.8 20V Turbo	ARX	1781	110	2000	2003	X	X	X	X	X	X
1.8 20V Turbo	ARY	1781	132	2000	2003	X	X	X	X	X	X
1.8 20V Turbo	ARZ	1781	110	1999	2001	X	X	X	X	X	X
1.8 20V Turbo	AUM	1781	110	2000	2003	X	X	X	X	X	X
1.8 20V Turbo	AUQ	1781	132	2000	2003	X	X	X	X	X	X
1.9 TDi	AGR	1896	66	1996	2001	X	X	X	X	X	X
1.9 TDi	AHF	1896	81	1997	2003	X	X	X	X	X	X
1.9 TDi	ALH	1896	66	1997	2002	X	X	X	X	X	X
1.9 TDi	ASV	1896	81	1999	2002	X	X	X	X	X	X
1.9 TDi	ASZ	1896	96	2000	2003	X	X	X	X	X	X
1.9 TDi	ATD	1896	74	2001	2003	X	X	X	X	X	X
1.9 TDi	AXR	1896	74	2001	2003	X	X	X	X	X	X
S3	AMK	1781	154	2000	2003	X	X	X	X	X	X
S3	APY	1781	154	1998	2001	X	X	X	X	X	X
S3	BAM	1781	165	2001	2003	X	X	X	X	X	X
<b>A3 2003</b>											
1.6 8V	BGU	1595	75	2003		X	X	X	X	X	N
1.6 FSi 16V	BAG	1598	85	2004	2005	X	X	X	X	X	N
1.6 FSi 16V	BLP	1598	85	2005		X	X	X	X	X	N
1.9 TDi 8V	BKC	1896	77	2004		X	X	X	X	X	N
2.0 FSi 16V	AXW	1984	110	2003	2004	X	X	X	X	X	N
2.0 FSi 16V	BHD	1984	110	2004	2005	X	X	X	X	X	N
2.0 FSi 16V	BLX	1984	110	2005		X	X	X	X	X	N
2.0 FSi 16V	BLY	1984	110	2005		X	X	X	X	X	N
2.0 FSi 16V	BMB	1984	110	2004		X	X	X	X	X	N
2.0 TDi 16V	AZV	1968	100	2003		X	X	X	X	X	N
2.0 TDi 16V	BKD	1968	103	2004		X	X	X	X	X	N
2.0 TFSi 16V	AXX	1984	147	2005		X	X	X	X	X	N
3.2 VR6	BDB	3189	184	2004		X	X	X	X	X	N
<b>A4 2001 2005</b>											
1.6 8V	ALZ	1595	75	2001	2005	X	X	X	X	X	X
1.8 20V Turbo	AVJ	1781	110	2001	2003	X	X	X	X	X	X
1.8 20V Turbo	BEX	1781	140	2002	2004	X	X	X	X	X	X
1.8 20V Turbo	BFB	1781	120	2002	2005	X	X	X	X	X	X
1.9 TDi	AVB	1896	74	2001	2004	X	X	X	X	X	X

Legend: N = new, X = present

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>AUDI</b>											
<b>A4 2001 2005</b>											
1.9 TDi	AVF	1896	96	2001	2004	X	X	X	X	X	X
1.9 TDi	AWX	1896	96	2001	2004	X	X	X	X	X	X
1.9 TDi	BKE	1896	85	2005	2005	X	X	X	X	X	X
2.0 16V FSi	AWA	1984	110	2002	2005	X	X	X	X	X	X
2.0 20V	ALT	1984	96	2001	2005	X	X	X	X	X	X
2.4 V6 30V	AMM	2393	120	2001	2004	X	X	X	X	X	X
2.4 V6 30V	BDV	2393	125	2001	2004	X	X	X	X	X	X
2.5 TDi V6 24V	AKE	2496	132	2001	2003	X	X	X	X	X	X
2.5 TDi V6 24V	AYM	2496	114	2001	2003	X	X	X	X	X	X
2.5 TDi V6 24V	BCZ	2496	120	2004	2004	X	X	X	X	X	X
2.5 TDi V6 24V	BDG	2496	120	2003	2005	X	X	X	X	X	X
2.5 TDi V6 24V	BDH	2496	132	2002	2004	X	X	X	X	X	X
2.5 TDi V6 24V	BFC	2496	120	2002	2003	X	X	X	X	X	X
2.5 TDi V6 24V Quattro	BAU	2496	132	2003	2004	X	X	X	X	X	X
3.0 V6 30V	ASN	2976	162	2001	2005	X	X	X	X	X	X
3.0 V6 30V	BBJ	2976	160	2001	2005	X	X	X	X	X	X
S4 4.2 V8 40V	BBK	4163	253	2003	2005	X	X	X	X	X	X
<b>A4 2005</b>											
1.6 8V	ALZ	1595	75	2005		X	X	X		X	X
1.8 20V Turbo	BFB	1781	120	2005		X	X	X		X	X
1.9 TDi	BKE	1896	85	2005	2006	X	X	X		X	X
1.9 TDi DPF	BRB	1896	85	2006		X	X	X		X	X
2.0 16V FSi Turbo	BGB	1984	147	2005	2005	X	X	X	N	X	X
2.0 16V FSi Turbo	BUL	1984	162	2005		X	X	X		X	X
2.0 16V FSi Turbo	BWE	1984	147	2005		X	X	X		X	X
2.0 20V	ALT	1984	96	2005		X	X	X		X	X
2.0 TDi 16V	BLB	1968	103	2005		X	X	X		X	X
2.0 TDi 16V	BNA	1968	100	2005		X	X	X		X	X
2.0 TDi 16V DPF	BRD	1968	125	2006		X	X	X		X	X
2.0 TDi 16V DPF	BRE	1968	103	2006		X	X	X		X	X
2.0 TDi 8V DPF	BPW	1968	103	2005		X	X	X		X	X
2.0 TDi 8V DPF	BRC	1986	100	2005		X	X	X		X	X
2.5 TDi V6	BDG	2496	120	2005		X	X	X		X	X
2.7 TDi V6	BPP	2698	132	2006		X	X	X		X	X
3.0 TDi V6	BKN	2967	150	2005		X	X	X		X	X
3.0 V6 30V	ASN	2976	162	2005	2006	X	X	X		X	X
3.0 V6 30V	BBJ	2976	160	2005		X	X	X		X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance		Techn. Drawings		Motor Manag.		Wiring Diagr.		Service Reset		Repair Times		
						Identification	Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	Fuses & Relays					
<b>AUDI</b>																		
<b>A4 2005</b>																		
3.2 V6 24V FSi	AUK	3123	188	2005		X	X	X		X				X	X		X	X
<b>A4 1994 2001</b>																		
1.6	ADP	1595	76	1994	1997	X	X	X	X	X	X	X	X	X	X	X	X	X
1.6	AHL	1595	74	1996	1999	X	X	X	X	X	X	X	X	X	X		X	X
1.6	ALZ	1595	75	2000	2001	X	X	X	X	X	X		X	X		X	X	
1.6	ANA	1595	74	1998	2000	X	X	X	X	X		X	X	X		X	X	
1.6	ARM	1595	74	1998	2001	X	X	X	X	X		X	X	X		X	X	
1.8 20V	AFY	1781	88	1995	2001	X	X	X	X			X	X	X	X	X	X	
1.8 20V	APT	1781	92	1999	2001	X	X	X	X	X		X	X	X		X	X	
1.8 20V	ARG	1781	92	1998	2001	X	X	X	X	X		X	X	X		X	X	
1.8 20V	AVV	1781	92	2000	2001	X	X	X	X	X			X	X		X	X	
1.8 20V	ADR	1781	92	1994	1999	X	X	X	X	X	X	X	X	X	X	X	X	
1.8 20V Turbo	AEB	1781	110	1995	1999	X	X	X	X	X	X	X	X	X	X	X	X	
1.8 20V Turbo	AJL	1781	132	1997	2001	X	X	X	X	X	X	X	X	X		X	X	
1.8 20V Turbo	ANB	1781	110	1999	2001	X	X	X	X	X		X	X	X		X	X	
1.8 20V Turbo	APU	1781	110	1998	2001	X	X	X	X	X		X	X	X		X	X	
1.8 20V Turbo	ARK	1781	110	1998	1999	X	X	X	X	<b>N</b>	X	X	X	X		X	X	
1.8 20V Turbo	AWT	1781	110	2000	2001	X	X	X	X	X			X	X		X	X	
1.8 20V Turbo quattro	AEB	1781	110	1995	1999	X	X	X	X	X	X	X	X	X	X	X	X	
1.8 20V Turbo quattro	AJL	1781	132	1997	2001	X	X	X	X	X	X	X	X	X		X	X	
1.9 TDi	1Z	1896	66	1994	2000	X	X	X	X	X	X	X	X	X	X	X	X	
1.9 TDi	AFF	1896	55	1996	2000	X	X	X	X	X		X	X	X	X	X	X	
1.9 TDi	AFN	1896	81	1996	2000	X	X	X	X	X	X	X	X	X	X	X	X	
1.9 TDi	AHH	1896	66	1997	2001	X	X	X	X	X	X	X	X	X		X	X	
1.9 TDi	AHU	1896	66	1996	2001	X	X	X	X	X	X	X	X	X		X	X	
1.9 TDi	AJM	1896	85	1998	2001	X	X	X	X	X		X	X	X		X	X	
1.9 TDi	ATJ	1896	85	2000	2001	X	X	X	X	X			X	X		X	X	
1.9 TDi	AVG	1896	81	1999	2001	X	X	X	X	X		X	X	X		X	X	
2.4 V6 30V	AGA	2393	121	1997	1998	X	X	X	X	X	X	X	X	X		X	X	
2.4 V6 30V	ALF	2393	121	1997	1999	X	X	X	X	<b>N</b>	X	X	X	X		X	X	
2.4 V6 30V	AML	2393	121	1998	2001	X	X	X	X	X		X	X	X		X	X	
2.4 V6 30V	AMM	2393	120	2000	2001	X	X	X	X	X			X	X		X	X	
2.4 V6 30V	APZ	2393	120	1998	2000	X	X	X	X	X		X	X	X		X	X	
2.4 V6 30V	AJG	2393	121	1997	1999	X	X	X	X	X	X	X	X	X		X	X	
2.4 V6 30V	ARJ	2393	121	1998	2001	X	X	X	X	X	X	X	X	X		X	X	
2.4 V6 30V quattro	AGA	2393	121	1997	1998	X	X	X	X	X	X	X	X	X		X	X	
2.4 V6 30V quattro	APS	2393	121	1998	2001	X	X	X	X	X	X	X	X	X		X	X	

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>AUDI</b>											
<b>A4 1994 2001</b>											
2.5 V6 TDi	AFB	2496	110	1997	2001	X	X	X	X	X	X
2.5 V6 TDi	AKN	2496	110	1998	2001	X	X	X	X	X	X
2.5 V6 TDi quattro	AFB	2496	110	1997	2001	X	X	X	X	X	X
2.6 V6	ABC	2598	110	1994	1998	X	X	X	X	X	X
2.6 V6 quattro	ABC	2598	110	1994	1998	X	X	X	X	X	X
2.8 V6	AAH	2771	128	1994	1998	X	X	X	X	X	X
2.8 V6 30V	ACK	2771	142	1996	1999	X	X	X	X	X	X
2.8 V6 30V	ALG	2771	142	1997	1999	X	X	X	X	X	X
2.8 V6 30V	AMX	2771	142	1998	2001	X	X	X	X	X	X
2.8 V6 30V	APR	2771	142	1998	2000	X	X	X	X	X	X
2.8 V6 30V	AQD	2771	142	1998	2000	X	X	X	X	X	X
2.8 V6 30V	ATX	2771	140	1999	2001	X	X	X	X	X	X
2.8 V6 quattro	AAH	2771	128	1994	1998	X	X	X	X	X	X
RS4	ASJ	2671	280	2000	2001	X	X	X	X	X	X
RS4	AZR	2671	280	2000	2001	X	X	X	X	X	X
S4	AGB	2671	195	1997	2001	X	X	X	X	X	X
<b>A6 1997 2004</b>											
1.8 20V	AJP	1781	92	1998	2000	X	X	X	X	X	X
1.8 20V	AQE	1781	92	1999	2002	X	X	X	X	X	X
1.8 20V	ARH	1781	92	1999	2002	X	X	X	X	X	X
1.8 20V Turbo	AEB	1781	110	1997	1999	X	X	X	X	X	X
1.8 20V Turbo	AJL	1781	132	1997	2001	X	X	X	X	X	X
1.8 20V Turbo	ANB	1781	110	1999	2002	X	X	X	X	X	X
1.8 20V Turbo	APU	1781	110	1998	2002	X	X	X	X	X	X
1.8 20V Turbo	AWT	1781	110	2000	2004	X	X	X	X	X	X
1.9 TDi	AFN	1896	81	1997	2002	X	X	X	X	X	X
1.9 TDi	AJM	1896	85	2001	2001	X	X	X	X	X	X
1.9 TDi	AVF	1896	96	2001	2004	X	X	X	X	X	X
1.9 TDi	AVG	1896	81	1999	2001	X	X	X	X	X	X
1.9 TDi	AWX	1896	96	2001	2004	X	X	X	X	X	X
2.0 20V	ALT	1984	96	2001	2004	X	X	X	X	X	X
2.4 V6 30V	AGA	2393	121	1997	1999	X	X	X	X	X	X
2.4 V6 30V	AJG	2393	121	1997	1999	X	X	X	X	X	X
2.4 V6 30V	ALF	2393	121	1997	1999	X	X	X	X	X	X
2.4 V6 30V	ALW	2393	100	1997	2000	X	X	X	X	X	X
2.4 V6 30V	AML	2393	121	2000	2002	X	X	X	X	X	X
2.4 V6 30V	AMM	2393	120	2000	2004	X	X	X	X	X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>AUDI</b>											
<b>A6 1997 2004</b>											
2.4 V6 30V	APC	2393	115	1998	2001	X	X	X	X	X	X
2.4 V6 30V	APS	2393	121	1998	2002	X	X	X	X	X	X
2.4 V6 30V	APZ	2393	121	1998	2002	X	X	X	X	X	X
2.4 V6 30V	ARJ	2393	121	1998	2002	X	X	X	X	X	X
2.4 V6 30V	ARN	2392	100	1999	2001	X	X	X	X	X	X
2.4 V6 30V	ASM	2393	100	2000	2004	X	X	X	X	X	X
2.4 V6 30V	BDV	2393	125	2001	2004	X	X	X	X	X	X
2.5 V6 TDi	AFB	2496	110	1997	2001	X	X	X	X	X	X
2.5 V6 TDi	AKE	2496	132	1999	2003	X	X	X	X	X	X
2.5 V6 TDi	AKN	2496	110	1998	2002	X	X	X	X	X	X
2.5 V6 TDi	AYM	2496	114	2001	2004	X	X	X	X	X	X
2.5 V6 TDi	BAU	2496	132	2003	2004	X	X	X	X	X	X
2.5 V6 TDi	BCZ	2496	120	2003	2004	X	X	X	X	X	X
2.5 V6 TDi	BDG	2496	120	2003	2004	X	X	X	X	X	X
2.5 V6 TDi	BDH	2496	132	2003	2004	X	X	X	X	X	X
2.5 V6 TDi	BFC	2496	120	2002	2003	X	X	X	X	X	X
2.7 V6 30V	BES	2671	184	2002	2004	X	X	X	X	X	X
2.7 V6 30V Biturbo	AJK	2671	169	1998	2004	X	X	X	X	X	X
2.7 V6 30V Biturbo	ARE	2671	184	2000	2003	X	X	X	X	X	X
2.7 V6 30V Biturbo	AZA	2671	169	2000	2002	X	X	X	X	X	X
2.8 V6 30V	ACK	2771	142	1997	1999	X	X	X	X	X	X
2.8 V6 30V	AGE	2771	132	1997	2002	X	X	X	X	X	X
2.8 V6 30V	ALG	2771	142	1997	2000	X	X	X	X	X	X
2.8 V6 30V	AMX	2771	142	2000	2002	X	X	X	X	X	X
2.8 V6 30V	APR	2771	142	1998	2001	X	X	X	X	X	X
2.8 V6 30V	AQD	2771	142	1998	2002	X	X	X	X	X	X
2.8 V6 30V	ATX	2771	140	1999	2001	X	X	X	X	X	X
3.0 V6 30V	ASN	2976	162	2001	2004	X	X	X	X	X	X
3.0 V6 30V	BBJ	2976	160	2001	2004	X	X	X	X	X	X
3.7 V8 40V	AQG	3697	191	1999	2004	X	X	X	X	X	X
4.2 V8 40V	ARS	4172	220	1999	2002	X	X	X	X	X	X
4.2 V8 40V	ASG	4172	220	2000	2004	X	X	X	X	X	X
RS6	BCY	4172	331	2002	2004	X	X	X	X	X	X
S6	ANK	4172	250	2000	2004	X	X	X	X	X	X
S6	AQJ	4172	250	1999	2002	X	X	X	X	X	X
<b>A6 2005</b>											
2.0 TDi 16V	BLB	1968	103	2005		X	X	X	N	X	N

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays					
<b>AUDI</b>																
<b>A6 2005</b>																
2.0 TDi 16V	BNA	1968	100	2005	2006	X	X	X	N	X	N	X	X		N	N
2.0 TDi 16V DPF	BRE	1968	103	2005		X	X	X	N	X		X	X		N	X
2.0 TDi 16V DPF	BVG	1968	89	2006		X	X	X	N	X		X	X			
2.0 TFSi 16V	BPJ	1984	125	2006		X	X	X	N	X		X	X			
2.4 V6	BDW	2393	130	2005		X	X	X	N	X	X		X		X	X
2.7 V6 TDi	BPP	2698	132	2005		X	X	X	N	N	N	X	X		N	X
2.7 V6 TDi	BSG	2698	120	2005		X	X	X	N	N	N	X	X		N	
3.0 V6	BBJ	2976	160	2005		X	X	X	N	X		X	X		X	X
3.0 V6 TDi	ASB	2967	171	2005		X	X	X	N	N		X	X			X
3.0 V6 TDi	BMK	2967	165	2005		X	X	X	N	X	X	X	X		X	X
3.0 V6 TDi	BNG	2967	155	2005		X	X	X	N	X	X	X	X		X	X
3.2 V6 FSi	AUK	3123	188	2005		X	X	X	N	X	X	X	X		X	X
4.2 V8	BAT	4163	246	2005		X	X	X	N	X	X		X		X	X
<b>A8 1994 2003</b>																
2.5 V6 TDi	AFB	2496	110	1997	2003	X	X	X	X	N	X	X	X	X	X	X
2.5 V6 TDi	AKE	2496	132	1999	2003	X	X	X	X	N	X	X	X	X	X	X
2.5 V6 TDi	AKN	2496	110	1997	2003	X	X	X	X	N	X	X	X	X	X	X
2.8 V6 12V	AAH	2771	128	1994	1997	X	X	X	X	X	X	X	X	X	X	X
2.8 V6 12V	AEJ	2771	120	1995	1996	X	X	X	X	N		X	X	X	X	X
2.8 V6 30V	ACK	2771	142	1995	1999	X	X	X	X	X	X	X	X	X	X	X
2.8 V6 30V	ALG	2771	142	1997	1999	X	X	X	X	N	X	X	X	X	X	X
2.8 V6 30V	AMX	2771	142	2000	2003	X	X	X	X	N	X	X	X		X	X
2.8 V6 30V	APR	2771	142	1999	2003	X	X	X	X	N	X	X	X	X	X	X
2.8 V6 30V	AQD	2771	142	1999	2001	X	X	X	X	N	X	X	X	X	X	X
3.3 V8 TDi	AKF	3328	165	2000	2003	X	X	X	X	N		X	X	X	X	X
3.7 V8 32V	AEW	3697	169	1995	1999	X	X	X	X	N	X	X	X	X	X	X
3.7 V8 32V	AKJ	3697	169	1997	1999	X	X	X	X	N	X	X	X	X	X	X
3.7 V8 40V	AKC	3697	191	2000	2003	X	X	X	X	N	X	X	X		X	X
3.7 V8 40V	AQG	3697	191	1998	2001	X	X	X	X	N	X	X	X	X	X	X
4.2 V8 32V	AGH	4172	213	1995	1996	X	X	X	X	N		X	X	X	X	X
4.2 V8 32V	AKG	4172	220	1997	1999	X	X	X	X	N	X	X	X	X	X	X
4.2 V8 32V	ABZ	4172	220	1994	2000	X	X	X	X	N	X	X	X	X	X	X
4.2 V8 40V	AQF	4172	191	1998	2001	X	X	X	X	N	X	X	X	X	X	X
4.2 V8 40V	ARU	4172	175	1999	2001	X	X	X	X	N	X	X	X	X	X	X
4.2 V8 40V	AUW	4172	228	2000	2003	X	X	X	X	N	X	X	X		X	X
4.2 V8 40V	AVN	4172	175	2000	2000	X	X	X	X	N		X	X			X
6.0 W12	AZC	5998	309	2001	2003	X	X	X	X	N		X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays						
<b>AUDI</b>																	
<b>A8 1994 2003</b>																	
S8 4.2 V8 32V	AHC	4172	250	1996	1999	X	X	X	X	N	X	X	X	X	X	X	X
S8 4.2 V8 32V	AKH	4172	250	1997	1999	X	X	X	X	N	X	X	X	X	X	X	X
S8 4.2 V8 40V	AQH	4172	264	1999	2001	X	X	X	X	N	X	X	X	X	X	X	X
S8 4.2 V8 40V	AVP	4172	264	2000	2003	X	X	X	X	N	X	X	X	X	X	X	X
<b>A8 2003</b>																	
3.0 V6	ASN	2976	162	2003		X	X	X	X	X	X	X	X	X	X	X	X
3.0 V6	BBJ	2976	160	2004		X	X	X	X	X	X	X	X	X	X	X	X
3.0 V6 TDi	ASB	2967	171	2004		X	X	X	X	X	X	X	X	X	X	X	X
3.0 V6 TDi	BNG	2967	155	2004		X	X	X	X	X	X	X	X	X	X	X	X
3.7 V8	BFL	3697	206	2003		X	X	X	X	X	X	X	X	X	X	X	X
4.0 V8 TDi	ASE	3936	202	2003		X	X	X	X	X	X	X	X	X	X	X	X
4.2 V8	BFM	4172	246	2003		X	X	X	X	X	X	X	X	X	X	X	X
6.0 W12	BHT	5998	331	2004		X	X	X	X	X	X	X	X	X	X	X	X
<b>Allroad 2000 2006</b>																	
2.5 V6 TDi	AKE	2496	132	2000	2003	X	X	X	X	X	X	X	X	X	X	X	X
2.5 V6 TDi	BAU	2496	132	2003	2006	X	X	X	X	X	X	X	X	X	X	X	X
2.5 V6 TDi	BCZ	2496	120	2004	2006	X	X	X	X	X	X	X	X	X	X	X	X
2.5 V6 TDi	BDG	2496	120	2003	2006	X	X	X	X	X	X	X	X	X	X	X	X
2.5 V6 TDi	BDH	2496	132	2003	2006	X	X	X	X	X	X	X	X	X	X	X	X
2.5 V6 TDi	BFC	2496	120	2002	2006	X	X	X	X	X	X	X	X	X	X	X	X
2.7 V6 Biturbo	ARE	2671	184	2000	2002	X	X	X	X	X	X	X	X	X	X	X	X
2.7 V6 Biturbo	BES	2671	184	2003	2006	X	X	X	X	X	X	X	X	X	X	X	X
4.2 V8	BAS	4163	220	2002	2006	X	X	X	X	X	X	X	X	X	X	X	X
<b>Coupe/Cabriolet 1989 2001</b>																	
Cabriolet 2.0	ABK	1984	85	1991	2001	X	X	X	X	X	X	X	X	X	X	X	X
Cabriolet 2.3	NG	2309	98	1991	2001	X	X	X	X	X	X	X	X	X	X	X	X
Cabriolet 2.6 V6	ABC	2598	110	1994	2001	X	X	X	X	X	X	X	X	X	X	X	X
Cabriolet 2.8 V6	AAH	2771	128	1992	2001	X	X	X	X	X	X	X	X	X	X	X	X
Coupe 2.0	ABK	1984	85	1991	1996	X	X	X	X	X	X	X	X	X	X	X	X
Coupe 2.0 16V	ACE	1984	103	1992	1996	X	X	X	X	X	X	X	X	X	X	X	X
Coupe 2.3	NG	2309	98	1991	1996	X	X	X	X	X	X	X	X	X	X	X	X
Coupe 2.3 20V	7A	2309	125	1990	1996	X	X	X	X	X	X	X	X	X	X	X	X
Coupe 2.3 20V quattro	7A	2309	125	1989	1991	X	X	X	X	X	X	X	X	X	X	X	X
Coupe 2.6 V6	ABC	2598	110	1992	1996	X	X	X	X	X	X	X	X	X	X	X	X
Coupe 2.6 V6 quattro	ABC	2598	110	1992	1996	X	X	X	X	X	X	X	X	X	X	X	X
Coupe 2.8 V6	AAH	2771	128	1991	1996	X	X	X	X	X	X	X	X	X	X	X	X
Coupe S2	3B	2226	162	1990	1996	X	X	X	X	X	X	X	X	X	X	X	X

Legend: N = new, X = present



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond. Wir.	Diagr.	
<b>AUDI</b>													
<b>Coupe/Cabriolet</b>	<b>1989 2001</b>												
Coupe S2	ABY	2226	169	1993	1996	X	X	X	X	X	X	X	X
<b>N Q7 2007</b>													
N	3.0 TDi	BUG	2967	171	2007	N	N	N			N		N
N	3.0 TDi	BUN	2967	155	2007	N	N	N			N		N
N	3.6 FSi	BHK	3580	206	2007	N	N	N			N		N
N	3.6 FSi	BHL	3580	206	2007	N	N	N			N		N
N	4.2 FSi	BAR	4163	257	2007	N	N	N			N		N
N	4.2 TDi	BTR	4134	230	2007	N	N				N		N
N	5.2 FSi	BGS	5204	309	2007	N	N				N		
N	5.2 FSi	BXA	5204	320	2007	N	N	N			N		
<b>TT 1999 2006</b>													
	1.8 20V Turbo	AJQ	1781	132	1999	2001	X	X	X	X	X	X	X
	1.8 20V Turbo	AMU	1781	165	2000	2002	X	X		X	X		X
	1.8 20V Turbo	APP	1781	132	1999	2001	X	X	X	X	X		X
	1.8 20V Turbo	ARY	1781	132	2000	2006	X	X	X	X	X		X
	1.8 20V Turbo	AUM	1781	110	2001	2003	X	X	X	X	X		X
	1.8 20V Turbo	AUQ	1781	132	2000	2006	X	X	X	X	X		X
	1.8 20V Turbo	BAM	1781	165	2000	2006	X	X	X	X	X		X
	1.8 20V Turbo	APX	1781	165	1999	2002	X	X	X	X	X	X	X
	3.2 V6	BHE	3189	184	2003	2006	X	X	X	X	X		X
	3.2 V6	BPF	3189	184	2004	2006	X	X	X	X	X		X
<b>BMW</b>													
<b>1 E87, E81 2004</b>													
	116i	N45 B16	1596	85	2004	2007	X	X	X	X	X	X	X
N	116i	N45 B16 TU2uL	1995	90	2007		N	N	N	N	N		N
	118d	M47 D20 TU2uL	1995	90	2004	2007	X	X	X	X	X		X
	118d	N47 D20	1995	105	2007		X	X	N	N	N		X
N	118i	N43 B20	1995	95	2007		N	N	N	N	N		N
	118i	N46 B20	1995	95	2005	2007	X	X	N	X	N		X
N	118i	N46 B20 TU2uL	1995	105	2007		N	N	N	N	N		N
	120d	M47 D20 TU2oL	1995	120	2004	2007	X	X	X	X	X		X
	120d	N47 D20	1995	130	2007		X	X	N	X	N		X
N	120i	N43 B20	1995	125	2007		N	N	N	N	N		N
	120i	N46 B20	1995	110	2004	2007	X	X	X	X	X		X
N	120i	N46 B20 TU2oL	1995	125	2007		N	N	N	N	N		N
N	130i	N52 B30	2996	195	2005	2007	N	N	N	N	N		N
N	130i	N52K B30	2999	195	2007		N	N	N	N	N		N

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>BMW</b>											
<b>3 E30 1982 1994</b>											
316	M10 B18	1766	66	1982	1987	X	X	X	X	X	X
316i	M10 B18	1766	77	1987	1989	X	X	X	X	X	X
316i	M40 B16	1596	73	1988	1990	X	X	X	X	X	X
316i Cabrio	M40 B16	1596	73	1988	1993	X	X	X	X	X	X
316i Touring	M40 B16	1596	73	1991	1994	X	X	X	X	X	X
318i	M10 B18	1766	77	1982	1994	X	X	X	X	X	X
318i	M40 B18	1796	84	1987	1992	X	X	X	X	X	X
318i Cabrio	M40 B18	1796	83	1990	1993	X	X	X	X	X	X
318i Touring	M40 B18	1796	83	1989	1994	X	X	X	X	X	X
318is	M42 B18	1796	100	1989	1991	X	X	X	X	X	X
320i	M20 B20	1990	95	1982	1987	X	X	X	X	X	X
320i	M20 B20	1990	95	1987	1992	X	X	X	X	X	X
320i Cabrio	M20 B20	1990	95	1986	1993	X	X	X	X	X	X
320i Touring	M20 B20	1990	95	1988	1991	X	X	X	X	X	X
320is	S14 B20	1991	141	1988	1991	X	X	X	X	X	X
323i	M20 B23	2316	110	1982	1987	X	X	X	X	X	X
324d	M21 D24W	2443	63	1985	1988	X	X	X	X	X	X
324d	M21 D24W	2443	63	1988	1991	X	X	X	X	X	X
324td	M21 D24WA	2443	85	1987	1991	X	X	X	X	X	X
324td Touring	M21 D24WA	2443	85	1988	1993	X	X	X	X	X	X
325e	M20 B27	2693	95	1984	1988	X	X	X	X	X	X
325i	M20 B25	2494	126	1983	1992	X	X	X	X	X	X
325i Cabrio	M20 B25	2494	126	1987	1993	X	X	X	X	X	X
325i Touring	M20 B25	2494	126	1987	1993	X	X	X	X	X	X
325iX	M20 B25	2494	126	1985	1991	X	X	X	X	X	X
325iX Touring	M20 B25	2494	125	1988	1993	X	X	X	X	X	X
M3	S14 B23	2302	143	1985	1991	X	X	X	X	X	X
M3 Cabrio	S14 B23	2302	143	1988	1991	X	X	X	X	X	X
<b>3 E36 1990 2001</b>											
<b>N</b> 316g	M43 B16	1596	75	1994	1999	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
316i	M43 B16	1596	75	1993	2000	X	X	X	X	X	X
316i (73/75 kW)	M40 B16	1596	73	1990	1994	X	X	X	X	X	X
316i Compact	M43 B19 TU	1895	77	1999	2001	X	X	X	X	X	X
318i	M43 B18	1796	85	1993	2001	X	X	X	X	X	X
318i (83/85 kW)	M40 B18	1796	83	1990	1994	X	X	X	X	X	X
318is	M42 B18	1796	103	1993	1996	X	X	X	X	X	X
318is	M44 B19	1895	103	1996	2001	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays
<b>BMW</b>												
<b>3 E36 1990 2001</b>												
318tds	M41 D17	1665	66	1994	2001	X	X	X	X	X	X	X
320i	M50 B20	1990	110	1990	1995	X	X	X	X	X	X	X
320i	M52 B20	1991	110	1994	2001	X	X	X	X	X	X	X
323i	M52 B25	2494	125	1995	2000	X	X	X	X	X	X	X
<b>N</b> 323ti Compact	M52 B25 TU	2494	125	1999	2001	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
325i	M50 B25	2494	141	1990	1996	X	X	X	X	X	X	X
325td	M51 D25	2498	85	1991	1999	X	X	X	X	X	X	X
325tds	M51 D25	2498	105	1992	1996	X	X	<b>N</b>	X	<b>N</b>	X	<b>N</b>
325tds	M51 D25 TU	2498	105	1996	2000	X	X	X	<b>N</b>	X	X	X
328i	M52 B28	2793	142	1995	2001	X	X	X	X	X	X	X
M3	S50 B30	2990	210	1992	1996	X	X	X	X	X	X	X
M3	S50 B32	3201	236	1995	2000	X	X	X	X	X	X	X
<b>N</b> M3 GT	S50 B30	3000	217	1995	1996	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
<b>3 E46 1998 2005</b>												
<b>N</b> 316 Ci	M43 B16 TU	1596	77	1999	2002	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
316i	N42 B18	1796	85	2002	2005	X	X	X	X	X	X	X
316i	N46 B18	1796	85	2004	2006	X	X	X	X	<b>N</b>	X	X
316i, Ci	M43 B19 TU	1895	77	1999	2003	X	X	X	X	X	X	X
316i, Ci	N40 B16	1596	77	2002	2004	X	X	X	X	X	X	X
316i, Ci	N45 B16	1596	85	2004	2005	X	X	X	X	X	X	X
316ti	N40 B16	1596	77	2002	2004	X	X	X	X	X	X	X
316ti	N42 B18	1796	85	2001	2005	X	X	X	X	X	X	X
316ti	N45 B16	1596	85	2004	2005	X	X	X	X	X	X	X
<b>N</b> 316ti	N46 B18	1796	85	2004	2006	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
318d	M47 D20	1951	85	2001	2004	X	X	X	X	X	X	X
318d	M47 D20 TU	1995	85	2003	2006	X	X	X	X	X	X	X
318i, Ci	M43 B19 TU	1895	87	1998	2002	X	X	X	X	X	X	X
318i, Ci	N42 B20	1995	105	2001	2005	X	X	X	X	X	X	X
318i, Ci	N46 B20	1995	105	2004	2006	X	X	X	X	X	X	X
318td	M47 D20 TU	1995	85	2003	2006	X	X	X	X	X	X	X
318ti	N42 B20	1995	105	2001	2005	X	X	X	X	X	X	X
<b>N</b> 318ti	N46 B20	1995	105	2004	2006	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
320d	M47 D20	1951	100	1998	2002	X	X	X	X	X	X	X
320d, Cd	M47 D20 TU	1995	110	2001	2006	X	X	X	X	X	X	X
320i, Ci	M52 B20 TU	1991	110	1998	2001	X	X	X	X	X	X	X
320i, Ci	M54 B22	2171	125	2000	2006	X	X	X	X	X	X	X
320td	M47 D20 TU	1995	110	2001	2006	X	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays
<b>BMW</b>												
<b>3 E46 1998 2005</b>												
323i, Ci	M52 B25 TU	2494	125	1998	2001	X	X	X	X	X	X	X
325i, Ci	M54 B25	2494	141	2000	2006	X	X	X	X	X	X	X
325ti	M54 B25	2494	141	2000	2005	X	X	X	X	X	X	X
325xi	M54 B25	2494	141	2000	2006	X	X	X	X	X	X	X
328i, Ci	M52 B28 TU	2793	142	1998	2001	X	X	X	X	X	X	X
330d	M57 D30	2926	135	1999	2004	X	X	X	X	X	X	X
330d, Cd	M57 D30 TU	2993	150	2003	2006	X	X	X	X	X	X	X
330i, Ci	M54 B30	2979	170	2000	2006	X	X	X	X	X	X	X
330xd	M57 D30	2926	135	2000	2004	X	X	X	X	X	X	X
330xd	M57 D30 TU	2993	150	2003	2006	X	X	X	X	X	X	X
330xi	M54 B30	2979	170	2000	2006	X	X	X	X	X	X	X
M3	S54 B32	3246	252	2000	2007	X	X	N	X	X	N	X
M3 CSL	S54 B32	3246	265	2003	2004	X	X	N	X	N	N	X
<b>3 E90, E91, E92, E93 2005</b>												
316i	N45 B16	1596	85	2005	2007	X	X	N	X	N	X	X
318d	M47 D20 TU2uL	1995	90	2005	2007	X	X	X	X	N	X	X
N 318d	N47 D20	1995	105	2007		N	N	N	N	N	X	X
318i	N46 B20	1995	95	2005		X	X	X	X	X	X	X
N 318i	N46 B20 TU2uL	1995	105	2007		N	N	N	N	N	X	X
320d	M47 D20 TU2oL	1995	120	2005	2007	X	X	X	X	X	X	X
N 320d	N47 D20	1995	130	2007		N	N	N	N	N	X	X
320i	N46 B20	1995	110	2005	2007	X	X	X	X	X	X	X
320i	N46 B20 TU2oL	1995	125	2007		X	N	X	N	N	N	X
N 320i Coupe	N43 B20	1995	125	2007		N	N	N	N	N	X	X
320Si	N45 B20S	1997	127	2006	2006	X	N	N	N	N	X	X
N 323i	N52 B25	2497	130	2005	2007	N	N	N	N	N	X	X
N 323i	N52K B25	2497	130	2007		N	N	N	N	N	X	X
N 325d	M57 D25 T2	2993	145	2006		N	N	N	N	N	X	X
325i, Xi	N52 B25	2497	160	2005	2007	X	X	X	X	X	X	X
N 325i, Xi	N52K B25	2497	160	2007		N	N	N	N	N	N	X
330d, Xd	M57 D30 T2	2993	170	2005		X	X	X	X	X	X	X
330i, Xi	N52 B30	2996	190	2005	2007	X	X	X	X	X	X	X
N 330i, Xi	N52K B30	2996	200	2007		N	N	N	N	N	N	X
N 335d	M57 D30 T2 TOP	2993	210	2006		N	N	N	N	N	N	X
N 335i, Xi	N54 B30o0	2979	225	2006		N	N	N	N	N	N	X
<b>5 E34 1987 1997</b>												
N 518g	M43 B18	1796	85	1994	1996	N	N	N	N	N	N	N

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>BMW</b>											
<b>5 E34 1987 1997</b>											
518i	M43 B18	1796	85	1994	1996	X	X	X	X	X	X
518i (83/85 kW)	M40 B18	1796	83	1989	1994	X	X	X	X	X	X
520i	M20 B20M	1990	95	1987	1991	X	X	X	X	X	X
520i	M50 B20	1990	110	1990	1993	X	X	X	X	X	X
520i	M50 B20	1991	110	1992	1996	X	X	X	X	X	X
524td	M21 D24	2443	85	1987	1992	X	X	X	X	X	X
525i	M20 B25M	2494	125	1987	1991	X	X	X	X	X	X
525i	M50 B25	2494	141	1989	1996	X	X	X	X	X	X
525ix	M50 B25	2494	141	1991	1996	X	X	X	X	X	X
525td	M51 D25	2498	85	1993	1996	X	X	X	X	X	X
525tds	M51 D25	2498	105	1991	1996	X	X	X	X	X	X
530i	M30 B30M	2986	138	1987	1991	X	X	X	X	X	X
530i	M60 B30	2997	160	1991	1997	X	X	X	X	X	X
535i	M30 B35M	3430	155	1987	1993	X	X	X	X	X	X
540i	M60 B40	3982	210	1992	1996	X	X	X	X	X	X
M5	S38 B36	3535	232	1988	1992	X	X	X	X	X	X
M5	S38 B38	3795	250	1992	1995	X	X	X	X	X	X
<b>5 E39 1995 2003</b>											
520d	M47 D20 (20 4 D1)	1951	100	1999	2003	X	X	X	X	X	X
520i	M52 B20 (20 6 S3)	1991	110	1996	1999	X	X	X	X	X	X
520i	M52 B20 TU (20 6 S4)	1991	110	1998	2003	X	X	X	X	X	X
520i	M54 B22 (22 6 S1)	2171	125	2000	2003	X	X	X	X	X	X
523i	M52 B25 (25 6 S3)	2494	125	1996	1999	X	X	X	X	X	X
523i	M52 B25 TU (25 6 S4)	2494	125	1998	2003	X	X	X	X	X	X
525d	M57 D25 (25 6 D1)	2497	120	1999	2003	X	X	X	X	X	X
525i	M54 B25 (25 6 S5)	2494	141	2000	2003	X	X	X	X	X	X
<b>N</b> 525td	M51 D25 (25 S T1)	2499	85	1997	2000	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
525tds	M51 D25 (25 6 T1)	2499	105	1996	2000	X	X	X	X	X	X
528i	M52 B28 (28 6 S1)	2793	142	1996	1999	X	X	X	X	X	X
528i	M52 B28 TU (28 6 S2)	2793	142	1998	2001	X	X	X	X	X	X
530d	M57 D30 (30 6 D1)	2926	142	1998	2003	X	X	X	X	X	X
530i	M54 B30 (30 6 S3)	2979	170	2000	2003	X	X	X	X	X	X
535i	M62 B35 (35 8 S1)	3498	173	1997	2003	X	X	X	X	X	X
540i	M62 B44 (44 8 S1)	4398	210	1996	1999	X	X	X	X	X	X
540i	M62 B44 TU (44 8 S2)	4398	210	1998	2003	X	X	X	X	X	X
M5	S62 B50 (50 8 S1)	4941	294	1998	2003	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays
<b>BMW</b>												
<b>5 E60, E61 2002</b>												
	520d	M47 D20 T2	1995	120	2005	2008	X	X	X	X	N	X
N	520d	N47 D20	1997	130	2007		N	N	N	N	N	N
	520i	M54 B22	2171	125	2002	2006	X	X	X	X	N	X
N	523i	N53 B25	2497	140	2007		N	N	N	N	N	N
	523i, Li	N52 B25	2497	130	2005	2007	X	X	N	X	N	X
	525d	M57 D25 TU	2497	130	2002	2007	X	X	X	X	N	X
N	525d	M57 D30 T2	2993	145	2007		N	N	N	N	N	N
	525i	M54 B25	2494	141	2002	2005	X	X	X	X	N	X
	525i, Xi	N52 B25	2497	160	2005	2007	X	X	N	X	N	X
N	525i, Xi	N53 B25	2497	160	2007		N	N	N	N	N	N
	530d	M57 D30 TU	2993	160	2002	2006	X	X	X	X	N	X
	530d, Xd	M57 D30 T2	2993	170	2005	2007	X	X	N	X	N	X
N	530d, Xd	M57 D30 T2	2993	173	2007		N	N	N	N	N	N
	530i	M54 B30	2979	170	2002	2005	X	X	X	X	N	X
	530i, Li, Xi	N52 B30	2996	190	2005	2007	X	X	N	X	N	X
N	530i, Xi	N53 B30	2996	200	2007		N	N	N	N	N	N
	535d	M57 D30 T2 TOP	2993	210	2007		X	X	N	X	N	N
	535d	M57 D30 TU TOP	2993	200	2004	2007	X	X	X	X	N	X
	540i	N62 B40 o1	4000	225	2005		X	X	N	X	N	X
	545i	N62 B44	4398	245	2002	2005	X	X	X	X	N	X
	550i	N62 B48 o1	4799	270	2005		X	X	N	X	N	X
	M5	S85 B50	4999	373	2005	2008	X	X	N	X	N	X
<b>7 E32 1986 1994</b>												
	730i	M30 B30M	2986	138	1986	1994	X	X	X	X	X	X
	730i	M60 B30	2997	160	1991	1994	X	X	X	X	X	X
	735i	M30 B35M	3430	155	1986	1993	X	X	X	X	X	X
	740i	M60 B40	3982	210	1992	1995	X	X	X	X	X	X
	750i	M70 B50	4988	220	1987	1994	X	X	X	X	X	X
<b>7 E38 1994 2001</b>												
	725tds	M51 D25	2499	105	1996	1999	X	X	X	X	X	X
	728i, iL	M52 B28	2793	142	1995	1998	X	X	X	X	X	X
	728i, iL	M52TU B28	2793	142	1998	2001	X	X	N	X	N	X
	730d	M57 D30	2926	142	1998	2001	X	X	X	X	N	X
	730i, iL	M60/1 B30	2997	160	1994	1997	X	X	X	X	N	X
	735i, iL	M62 B35	3498	173	1996	1999	X	X	X	X	N	X
N	735i, iL	M62 B35 TU	3498	175	1998	2001	N	N	N	N	N	N
	740d	M67	3901	180	1999	2001	X	X	X	X	N	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays	
<b>BMW</b>												
<b>7 E38 1994 2001</b>												
	740i, iL	M60/2 B40	3982	210	1994	1996	X	X	X	X	X	X
	740i, iL	M62 B44	4398	210	1995	1999	X	X	X	X	X	X
<b>N</b>	740i, iL	M62 B44 TU	4398	210	1998	2001	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
	750i, iL, L7	M73 B54	5379	240	1994	1998	X	X	X	X	X	X
<b>N</b>	750i, iL, L7	M73 B54 TU	5379	240	1998	2001	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
<b>7 E65, E66 2001</b>												
	730d	M57 D30 TU	2993	160	2002	2005	X	X	<b>N</b>	X	<b>N</b>	X
<b>N</b>	730d, Ld	M57 D30 T2	2993	170	2005		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
	730i, Li	M54 B30	2979	170	2002	2005	X	X	<b>N</b>	X	<b>N</b>	X
<b>N</b>	730i, Li	N52 B30	2996	190	2005		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
	735i, Li	N62 B36	3600	200	2001	2005	X	X	X	X	X	X
	740d	M67 D39	3901	190	2002	2005	X	X	<b>N</b>	X	<b>N</b>	X
<b>N</b>	740i, Li	N62 B40 o1	4000	225	2005		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
	745i, Li	N62 B44	4398	245	2001	2005	X	X	X	X	X	X
<b>N</b>	750i, Li	N62 B48 o1	4799	270	2005		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
	760i, Li	N73 B60	5972	327	2003		X	X	<b>N</b>	X	<b>N</b>	X
<b>8 E31 1989 1999</b>												
	840Ci	M60 B40	3982	210	1993	1996	X	X	X	X	X	X
	840Ci	M62 B44	4398	210	1995	1999	X	X	X	X	X	X
	850Ci	M73 B54	5379	240	1994	1999	X	X	X	X	X	X
	850CSi	S70 B56	5576	280	1992	1997	X	X	X	X	X	X
	850i	M70 B50M	4988	220	1989	1995	X	X	X	X	X	X
<b>X3 E83 2004</b>												
	2.0d	M47 D20 T2oL	1995	110	2004	2007	X	X	X	X	X	X
	2.0d	N47 D20	1995	130	2007		X	X	<b>N</b>	X	<b>N</b>	X
<b>N</b>	2.0i	N46 B20	1995	110	2005		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
	2.5i	M54 B25	2494	141	2004	2007	X	X	X	X	X	X
<b>N</b>	2.5si	N52 B25 o1	2497	160	2006		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
<b>N</b>	3.0d	M57 D30 T2	2993	160	2005		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
	3.0d	M57 D30 TU	2993	150	2004	2006	X	X	X	X	X	X
	3.0i	M54 B30	2979	170	2004	2007	X	X	X	X	X	X
<b>N</b>	3.0sd	M57 D30 T2 TOP	2993	210	2006		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
<b>N</b>	3.0si	N52 B30 o1	2996	200	2006		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
<b>X5 E53 2000 2007</b>												
	3.0d	M57 D30	2926	135	2001	2004	X	X	X	X	X	X
	3.0d	M57 D30 TU	2993	160	2003	2007	X	X	X	X	X	X
	3.0i	M54 B30	2979	170	2000	2007	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>BMW</b>											
<b>X5 E53 2000 2007</b>											
4.4i	M62 B44 TU	4398	210	2000	2004	X	X	X	X	X	X
4.4i	N62 B44	4398	235	2003	2007	X	X	N	X	N	X
4.6is	M62 B46	4619	255	2001	2004	X	X	X	X	X	X
4.8is	N62 B48S	4799	265	2004	2007	X	N	N	X	N	X
<b>Z1 E30 1987 1992</b>											
2.5	M20 B25	2494	129	1987	1992	X	X	X	X	X	X
<b>Z3 E36 1996 2002</b>											
1.8i	M43 B18	1796	85	1996	1999	X	X	X	X	X	X
1.9i	M43 B19 TU	1895	87	1998	2002	X	X	N	X	N	X
1.9i	M44 B19	1895	103	1996	2000	X	X	X	X	X	X
2.0i	M52 B20 TU	1991	110	1999	2001	X	X	N	X	N	X
2.2i	M54 B22	2171	125	2000	2002	X	X	N	X	N	X
2.8i	M52 B28	2793	141	1997	1999	X	X	X	X	X	X
2.8i	M52 B28 TU	2793	142	1998	2001	X	X	N	X	N	N
3.0i	M54 B30	2979	170	2000	2002	X	X	N	X	N	X
M Roadster/Coupe	S50 B32	3201	236	1997	2001	X	X	X	X	X	X
N M Roadster/Coupe	S54 B32	3246	239	2000	2002	N	N	N	N	N	N
<b>Z4 E85, E86 2003</b>											
N 2.0i	N46 B20	1995	110	2005		N	N	N		N	N
2.2i	M54 B22	2171	125	2003	2007	X	X	N		N	X
2.5i	M54 B25	2494	141	2003		X	X	N		N	X
N 2.5i	N52 B25 u0	2497	130	2006		N	N	N		N	N
N 2.5si	N52 B25 o0	2497	160	2006		N	N	N		N	N
3.0i	M54 B30	2979	170	2003	2007	X	X	N		N	X
N 3.0si	N52 B30 o0	2996	195	2006		N	N	N		N	N
N M Coupe	S54 B32	3246	252	2006		N	N	N		N	N
<b>BUICK</b>											
<b>Century 1994 1997</b>											
3.1 V6	L82	3135	119	1994	1997			X			
<b>Le Sabre 1992 1999</b>											
3.8 V6	L36	3791	145	1992	1999			X			X
<b>Park Avenue 1996 2005</b>											
3.8 V6	L36	3791	150	1996	2005			X			X
3.8 V6 Supercharger	L67	3791	179	1996	2005			X			X
<b>Regal 1996 2004</b>											
3.8 V6	L36	3791	145	1996	2004			X			X

Legend: N = new, X = present



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>BUICK</b>											
<b>Regal 1996 2004</b>											
3.8 V6 Supercharger	L67	3791	179	1997	2004		X				X
<b>Riviera 1995 1999</b>											
3.8 V6 Supercharger	L67	3791	179	1996	1999		X				
<b>Skylark 1991 1999</b>											
2.4 16V	LD9	2392	112	1995	1999		X				
3.1 V6	L82	3135	117	1994	1999		X				
<b>CADILLAC</b>											
<b>Catera 1994 2001</b>											
3.0 V6	L81	2962	149	1994	2001		X				X
<b>Eldorado 1992 2002</b>											
4.6	L37	4565	224	1995	2002		X				X X
4.6	LD 8	4565	224	1992	2002		X				X X
<b>Seville 1992 2004</b>											
4.6	L37	4565	224	1995	2004		X				X X
4.6	LD 8	4565	224	1992	2004		X				X X
<b>CHEVROLET (DAEWOO)</b>											
<b>Captiva 2006</b>											
2.0 VCDi	Z20S	1991	110	2006		X	X	X	N	X	X
2.4	Z24SED	2405	100	2006		X	X	X	N	X	
3.2 V6	10 HMA H	3195	169	2006		X	X	X	N	X	
<b>Epica 2006</b>											
2.0	Z20XED	1993	105	2006		X	X	X		X	
2.5	Z25SED	2492	115	2006		X	X	X	N		
<b>Espero 1995 2000</b>											
1.5 16V	A15MF	1498	66	1995	2000	X	X	X	X	X	X X
1.8	C18LE	1796	70	1995	2000	X	X	X	X	X	X X
2.0	C20LE	1998	77	1995	2000	X	X	X	X	X	X X
<b>Evanda 2002 2006</b>											
2.0 16V	T20SED	1998	96	2002	2006	X	X	X	X	X	X
<b>Kalos Aveo 2002</b>											
1.2	B12S1	1150	53	2002		X	X	X	X	X	X X
1.4	F14S3	1399	61	2002		X	X	X	X	X	X X
1.4 16V	F14D3	1399	69	2002	2007	X	X	X	X	X	X X
<b>Lacetti 2003</b>											
1.4 16V	F14D	1399	70	2003		X	X	X	X	X	X X
1.6 16V	F16D	1598	80	2003		X	X	X	X	X	X X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diagram Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diagram Fuses & Relays

**CHEVROLET (DAEWOO)**

<b>Lacetti 2003</b>																
1.8 16V	T18SED	1799	90	2003		X	X	X	X	X				X		X
<b>Lanos 1997 2003</b>																
1.3	A13SMS	1349	55	1997	2003	X	X	X	X	X	X			X		X
1.5	A15SMS	1498	63	1997	2003	X	X	X	X	X	X			X		X
1.6 16V	A16DMS	1598	78	1997	2003	X	X	X	X	X	X			X		X
<b>Leganza 1997 2002</b>																
2.0 16V	X20SED	1998	98	1997	2002	X	X	X	X	X	X			X		X
<b>Matiz 1998 2005</b>																
0.8	F8CV	796	38	1998	2005	X	X	X	X	X	X			X		X
1.0	B10S1	995	87	2002	2005	X	X	X	X	X	N			X		X
<b>Matiz 2005</b>																
0.8	F8CV	796	38	2005		X	X	X		X	N			X		X
1.0	B10S1	995	49	2005		X	X	X		X	N			X		X
<b>Nexia Cielo 1995 2001</b>																
1.5	G15MF	1498	55	1995	1998	X	X	X	X	X	N			X		X
1.5 16V	A15MF	1498	66	1995	1998	X	X	X	X	X				X		X
<b>Nubira 1997 2003</b>																
1.6 16V	A16DMS	1598	76	2001	2003	X	X	X	X	X				X		X
1.6 16V	A16DMS	1598	78	1997	2001	X	X	X	X	X	X			X		X
1.8 16V	C18SED	1799	90	2001	2003	X	X	X	X	X						X
2.0	X20NED	1998	82	2001	2003	X	X	X	X	X				X		X
2.0 16V	T20SED	1998	93	2001	2003	X	X	X	X	X				X		X
2.0 16V	X20SED	1998	98	1997	2001	X	X	X	X	X	X			X		X
<b>Nubira 2003</b>																
1.4 16V	F14D	1399	70	2003	2006	X	X	X	X	X				X		X
1.6 16V	F16D	1598	80	2003		X	X	X	X	X				X		X
1.8 16V	T18SED	1799	90	2003		X	X	X	X	X				X		X
<b>Tacuma Rezzo 2000</b>																
1.6 16V	A16DMS	1598	77	2002		X	X	X	X	X				X		
1.8	F18S2	1761	72	2000	2002	X	X	X	X	X				X		X
2.0 16V	C20SED	1998	94	2000	2005	X	X	X	X	X	X			X		X
2.0 16V	T20SED	1998	89	2002		X	X	X	X	X				X		X
<b>CHEVROLET (USA)</b>																
<b>Camaro 1995 2002</b>																
3.8 V6	L36	3791	149	1995	2002										X	X
5.7 V8	LS1	5665	227	1998	2002										X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diag. Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diagn. Fuses & Relays

**CHEVROLET (USA)**

Make description	Model description	From	To	Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diag. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagn.	Fuses & Relays
<b>Caprice Impala 1990 1996</b>																
	V8 4.3				L 99	4321	149	1990	1996	X	X			X		X
	V8 5.7				LT 1	5733	194	1990	1996	X	X			X		X
<b>Cavalier 1994 2005</b>																
	2.2				LN2-4	2196	90	1994	2002		X					X
	2.4 16V				LD9	2392	112	1996	2002		X					
<b>Corvette 1997 2004</b>																
	5.7 V8				LS1	5665	254	1997	2004		X					X
<b>Lumina 1994 2001</b>																
	3.8 V6				L36	3791	149	1994	2001		X				X	X
<b>Malibu 1996 2003</b>																
	2.4 16V				LD9	2392	112	1996	2003		X					X
	3.1 V6				L82	3146	112	1996	2003		X					X
<b>Venture Trans Sport 1996 2005</b>																
	3.4 V6				LA1	3350	134	1996	2005		X					X

**CHRYSLER**

<b>300 C 2004</b>																
	2.7				EER	2736	142	2004		X	X	X	X	X		X
	3.5 V6				EGG	3518	186	2004		X	X	X	X	X		X
	5.7 HEMI				EZB	5654	250	2004		X	X	X	X	X		X
	SRT-8				ESF	6063	316	2006		X	X	X	X	X		X
<b>300 M 1998 2004</b>																
	2.7 V6 24V				EER	2736	150	1998		X	X	X	X	X		X
	3.5 V6 24V				EGG (ECG)	3518	185	1998		X	X	X	X	X		X
<b>Crossfire 2004</b>																
	3.2 V6 18V				EGX	3199	160	2004		X	X	X	X	X		X
	3.2 V6 18V SRT				EGX	3199	160	2004		X	X	X	X	X		X
<b>Neon 2000 2003</b>																
	2.0 16V				2.0L SOHC	1996	98	1999	2004	X	X	X	X	X		X
<b>PT Cruiser 2001</b>																
	1.6 16V				EJD	1598	85	2001		X	X	X	X	X		X
	2.0 16V				ECC	1995	100	2001	2004	X	X	X	X	X		X
	2.2 16V CRD				EDJ	2148	89	2002		X	X	X	X	X		X
	2.4 16V				EDZ	2429	105	2001		X	X	X	X	X		X
	2.4 16V GT Turbo				EDV	2429	164	2003		X	X	X	X	X		X
<b>Stratus 1995 2001</b>																
	2.0 16V				2.0 DOHC	1996	104	2000	2001	X	X	X	X	X		X

Legend: N = new, X = present

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagram ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays
<b>CHRYSLER</b>												
<b>Stratus 1995 2001</b>												
2.0 16V	ECB	1996	96	1995	2001	X	X	X	X	X	X	X
2.4 16V	EDZ	2425	112	1995	2001	X	X	X	X	X	X	X
2.5 V6 24V	EEB	2495	118	1995	2001	X	X	X	X	X	X	X
<b>Vision 1993 1997</b>												
3.5 V6 24V	T/V6-215	3523	157	1993	1997	X	X	X			X	X
<b>Voyager 1989 1996</b>												
2.5 i	EDM	2501	71	1989	1995	X	X	X	X	X	X	X
3.0 i V6	EFA	2972	103	1989	1995	X	X	X	X	X	X	X
3.3 i V6	EGA	3301	110	1990	1995	X	X	X	X	X	X	X
3.8 i V6	EGA	3778	121	1989	1995	X	X	X	X	X	X	X
<b>Voyager 1995 2001</b>												
2.0	ECB	1996	98	1997	2001	X	X	X	X	X	X	X
2.4	EDZ	2429	111	1995	2001	X	X	X	X	X	X	X
2.5 TD	ENC	2500	85	1995	2001	X	X	X	X	X	X	X
3.0	EFA	2972	112	1995	2001	X	X	X	X	X	X	X
3.3	EGA	3301	116	1995	2001	X	X	X	X	X	X	X
3.8	EGH	3778	122	1995	2001	X	X	X	X	X	X	X
<b>Voyager 2001</b>												
2.4	EDZ	2425	118	2001		X	X	X	X		X	X
2.5 CRD	ENJ	2499	105	2001		X	X	X	X		X	X
3.3	EGA	3294	134	2001		X	X	X	X		X	X
<b>CITROEN</b>												
<b>AX 1987 1996</b>												
1.0	TU9 (C1A/C3A)	954	30	1987	1989	X	X	X	X	X	X	
1.0i	TU9M (CDY)	954	33	1993	1996	X	X	X	X	X	X	X
1.0i	TU9M/Z (CDZ)	954	37	1991	1996	X	X	X	X	X	X	X
1.1	TU1 (H1A/H1B)	1124	40	1987	1989	X	X	X	X	X	X	
1.1i	TU1M (HDZ/HDY)	1124	44	1991	1991	X	X	X	X	X	X	X
1.1i	TU1M (HDZ/HDY)	1124	44	1991	1996	X	X	X	X	X	X	X
1.3 Sport	TU (M4A)	1294	69	1987	1991	X	X	X	X	X	X	X
1.4	TU3A/K (K1G)	1360	50	1988	1989	X	X	X	X	X	X	
1.4	TU3A/N (K1A/K1B)	1360	47	1987	1989	X	X	X	X	X	X	
1.4	TU3M (K2A)	1360	61	1988	1989	X	X	X	X	X	X	
1.4 D	TUD3 (K9A/K9Y)	1360	38	1991	1996	X	X	X	X	X	X	X
1.4 D	TUD3 (K9A)	1360	38	1988	1991	X	X	X	X	X	X	X
1.4 GTi	TU3J2 (KFZ)	1360	69	1991	1996	X	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>CITROEN</b>											
<b>AX 1987 1996</b>											
1.4 GTi	TU3J2/K (K6B)	1360	69	1990	1991	X	X	X	X	X	X
1.4i	TU3FM (KDY)	1360	55	1989	1991	X	X	X	X	X	X
1.4i	TU3FMC (KDX)	1360	55	1991	1996	X	X	X	X	X	X
1.4i 4x4	TU3FM (KDY)	1360	55	1991	1996	X	X	X	X	X	X
1.5 D	TUD5 (VJZ/VJY)	1527	42	1994	1996	X	X	X	X	X	X
<b>Berlingo 1996</b>											
1.1i	TU1JP/L4 (HFX)	1124	44	2001		X	X	X	X	X	X
1.1i	TU1M+ (HDY)	1124	44	1996	2002	X	X	X	X	X	X
1.1i	TU1M+ (HDZ)	1124	44	1996	2002	X	X	X	X	X	X
1.4	TU3.2K (K5A)	1360	51	1996	2002	X	X	X	X	X	X
1.4i	TU3JP (KFX)	1360	55	1996	2000	X	X	X	X	X	X
1.4i	TU3JP/L4 (KFW)	1360	55	2000		X	X	X	X	X	X
1.6i 16V	TU5JP4 (NFU)	1587	80	2002		X	X	X	X	X	X
1.8 D	XUD7 (A9A)	1769	43	1996	2000	X	X	X	X	X	X
1.8i	XU7JB (LFX)	1761	66	1998	2002	X	X	X	X	X	X
1.9 D	DW8 (WJZ)	1868	51	1999	2002	X	X	X	X	X	X
1.9 D	DW8B (WJY)	1868	51	2000		X	X	X	X	X	X
1.9 D	XUD9A (D9B)	1905	51	1996	2000	X	X	X	X	X	X
1.9 D	XUD9Y (DJY)	1905	50	1996	2000	X	X	X	X	X	X
2.0 HDi	DW10TD (RHY)	1997	66	1999		X	X	X	X	X	X
<b>BX 1982 1994</b>											
14	150A	1360	45	1982	1988	X	X	X	X	X	X
14	150C/150F/150J	1360	52	1982	1988	X	X	X	X	X	X
14	TU3A (K1G)	1360	47	1988	1990	X	X	X	X	X	X
14i	TU3M (KDY)	1360	55	1992	1993	X	X	X	X	X	X
14i	TU3M (KDZ)	1360	55	1988	1989	X	X	X	X	X	X
15 / 16	B9A/B1A/A	1580	58	1988	1989	X	X	X	X	X	X
16	171A/171B/C/Z	1580	66	1982	1988	X	X	X	X	X	X
16	XU52C (B2C)	1580	69	1989	1994	X	X	X	X	X	X
16i	180Z/XU5J	1580	76	1986	1989	X	X	X	X	X	X
16i	XU5M (BDY)	1580	65	1989	1994	X	X	X	X	X	X
17 D	161A/ XU7D	1769	44	1985	1994	X	X	X	X	X	X
17 Turbo D	XU7DTE (A8A)	1769	66	1988	1994	X	X	X	X	X	X
19	XU92C (D2A)	1905	75	1986	1989	X	X	X	X	X	X
19 4x4	XU92C (D2E)	1905	78	1986	1994	X	X	X	X	X	X
19 D	XU9DA (DJZ)	1905	47	1990	1994	X	X	X	X	X	X
19 D	XUD9 (162)	1905	47	1983	1989	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>CITROEN</b>											
<b>BX 1982 1994</b>											
19 D	XUD9A (D9B)	1905	51	1990	1994	X	X	X	X	X	X
19 GTi	XU9J2 (D6A)	1905	90	1986	1989	X	X	X	X	X	X
19 GTi	XU9JAZ (DKZ)	1905	88	1988	1994	X	X	X	X	X	X
19 GTi 16V	XU9J4 (D6C)	1905	118	1990	1994	X	X	X	X	X	X
19 GTi 16V	XU9J4 (D6C)	1905	118	1987	1989	X	X	X	X	X	X
19 GTi 16V	XU9J4 (DFW)	1905	108	1986	1994	X	X	X	X	X	X
19i	XU9J1 (DFZ)	1905	76	1986	1989	X	X	X	X	X	X
19i	XU9M (DDZ)	1905	80	1990	1991	X	X	X	X	X	X
19i 4x4	XU9J1 (DFZ)	1905	75	1986	1989	X	X	X	X	X	X
19i 4x4	XU9J2 (D6D)	1905	89	1990	1994	X	X	X	X	X	X
19i 4x4	XU9M (DDZ)	1905	80	1990	1994	X	X	X	X	X	X
<b>C1 2005</b>											
1.0 12V	384F (CFA)	998	50	2005		X	X	X	N	X	X
1.4 HDi	DV4TD (8HT)	1398	40	2005		X	X	X	N	X	X
<b>C2 2003</b>											
1.1 8V	TU1JP (HFX)	1124	44	2003		X	X	X	N	X	X
1.4 8V	TU3JP (KFV)	1360	54	2003		X	X	X	N	X	X
1.4 HDi 8V	DV4TD (8HX)	1398	50	2003		X	X	X	N	X	X
1.6 16V	TU5JP4 (NFU)	1587	80	2003		X	X	X	N	X	X
<b>C25 1981 1994</b>											
1000 1.8	XM7T/169B	1796	50	1981	1994	X	X	X	X		X
1000 1.9 D	XUD/D9B	1905	51	1990	1994	X	X	X	X		X
1000 2.5 D	CRD93L/U25/661	2500	54	1981	1994	X	X	X	X		X
1300 2.0	XN1T/170B	1971	56	1981	1994	X	X	X	X		X
1300 2.5 D	CRD93L/U25/661	2500	54	1984	1994	X	X	X	X		X
1400 2.0	XN1T/170B	1971	56	1981	1994	X	X	X	X		X
1400 1.9 D	XUD/D9B	1905	51	1990	1994	X	X	X	X		X
1400 2.5 Turbo D	CRD93LS/U25/673	2500	70	1987	1994	X	X	X	X		X
1400 4x4 2.5 D	CRD93/L/U25/661	2500	54	1989	1994	X	X	X	X		X
1400 4x4 2.5 Turbo D	CRD93LS/U25/673	2500	70	1989	1994	X	X	X	X		X
1500 2.0	XN1T/170B	1971	56	1981	1994	X	X	X	X		X
1500 2.5 D	CRD93L/U25/661	2500	54	1981	1994	X	X	X	X		X
1800 2.0	XN1TA/170C	1971	62	1989	1994	X	X	X	X		X
1800 2.5 D	CRD93L/U25/661	2500	54	1989	1994	X	X	X	X		X
1800 Turbo D	CRD93LS/U25/673	2500	70	1989	1994	X	X	X	X		X
Combi 2.5 D	CRD93L/U25/661	2500	54	1982	1994	X	X	X	X		X
Combi 1.8	XM7T/169B	1796	50	1982	1994	X	X	X	X		X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>CITROEN</b>											
<b>C25 1981 1994</b>											
Combi 1.9 D	XUD/D9B	1905	51	1990	1994	X	X	X	X		X
Combi 2.0	XN1T/170B	1971	56	1982	1994	X	X	X	X		X
Combi 2.5 Turbo D	CRD93LS/U25/673	2500	70	1989	1994	X	X	X	X		X
Combi 4x4 2.5 D	CRD93L/U25/661	2500	54	1989	1994	X	X	X	X		X
Combi 4x4 2.5 Turbo D	CRD93LS/U25/673	2500	70	1989	1994	X	X	X	X		X
<b>C3 2002</b>											
1.1 8V	TU1JP (HFX)	1124	44	2002		X	X	X	X	X	X
1.4 16V	ET3J4 (KFU)	1361	65	2004		X	X	X	X		N
1.4 8V	TU3JP (KFV)	1360	54	2002		X	X	X	X	X	X
1.4 HDi 16V	DV4TED4 (8HY)	1398	66	2002	2006	X	X	X	X	X	X
1.4 HDi 8V	DV4TD (8HX)	1398	50	2002	2006	X	X	X	X	X	X
1.4 HDi 8V	DV4TD (8HZ)	1398	50	2006		X	X	X	X	N	
1.6 16V	TU5JP4 (NFU)	1587	80	2002		X	X	X	X	X	X
1.6 HDi 16V	DV6ATED4 (9HX)	1560	66	2006		X	X	X	X	N	N
1.6 HDi 16V (FAP)	DV6TED4 (9HZ)	1560	80	2006		X	X	X	X	N	N
<b>C4 2005</b>											
1.4 16V	ET3J4/E4 (KFU)	1360	65	2005		X	X	X	X	X	X
1.6 16V	TU5JP4/E4 (NFU)	1587	80	2005		X	X	X	X	X	X
1.6 HDi 16V 110	DV6TED4/E3 (9HY)	1560	80	2005		X	X	X	X	N	X
1.6 HDi 16V 110 FAP	DV6TED4/E4 (9HZ)	1560	80	2005		X	X	X	X	N	X
1.6 HDi 16V 90	DV6ATED4/E4 (9HX)	1560	66	2005		X	X	X	X	N	X
2.0 16V	EW10A/E4 (RFJ)	1997	103	2005		X	X	X	X	N	X
2.0 16V	EW10J4/E4 (RFN)	1997	99	2005		X	X	X	X	N	X
2.0 16V 180 VTS	EW10J4S/E4 (RFK)	1997	130	2005		X	X	X	X	N	X
2.0 HDi 16V 138 FAP	DW10BTED4/E4 (RHR)	1997	100	2005		X	X	X	X	X	X
<b>N C4 Picasso 2007</b>											
N 1.6 16V HDi	DV6TED4 (9HY)	1560	80	2007		N	N	N	N	N	N
N 1.6 16V HDi FAP	DV6TED4 (9HZ)	1560	80	2007		N	N	N	N	N	N
N 1.8 16V	EW7A (6FY)	1749	92	2007		N	N	N	N	N	N
N 2.0 16V	EW10A (RFJ)	1998	103	2007		N	N	N	N	N	N
N 2.0 16V HDi FAP	DW10BTED4 (RHJ)	1997	100	2007		N	N	N	N	N	N
N 2.0 16V HDi FAP	DW10BTED4 (RHR)	1997	100	2007		N	N	N	N	N	N
<b>C5 2001</b>											
N 1.6 HDi 16V	DV6TED4 (9HY)	1560	80	2005		N	N	N	N	N	N
1.6 HDi 16V FAP	DV6TED4 (9HZ)	1560	80	2005		X	X	X	X	N	X
N 1.8 16V	EW7A (6FY)	1749	92	2006		N	N	N	N	N	N
1.8 16V	EW7J4 (6FZ)	1749	85	2001	2005	X	X	X	X	X	X

Legend: N = new, X = present

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays		
<b>CITROEN</b>														
<b>C5 2001</b>														
1.8 16V	EW7J4 (6FZ)	1749	85	2005	2006	X	X	X	X	X	N	X	X	X
2.0 16V	EW10A (RFJ)	1997	103	2005		X	X	X	X	X	N	X	X	X
2.0 16V	EW10J4 (RFN)	1997	100	2001	2005	X	X	X	X	X	X	X	X	X
2.0 16V HPi	EW10D (RLZ)	1998	103	2001	2005	X	X	X	X	X	X	X	X	X
2.0 HDi 16V FAP	DW10BTED4 (RHR)	1997	100	2005		X	X	X	X	X	N	X	X	X
2.0 HDi 8V	DW10ATED (RHZ)	1997	80	2001	2005	X	X	X	X	X	X	X	X	X
2.0 HDi 8V	DW10TD (RHY)	1997	66	2001	2005	X	X	X	X	X	X	X	X	X
2.0 HDi 8V 110 FAP	DW10ATED (RHS)	1997	79	2002	2005	X	X	X	X	X	X	X	X	X
N 2.2 HDi 16V FAP	DW12BTED4 (4HP)	2179	120	2006		N	N	N	N	N	N	N		
N 2.2 HDi 16V FAP	DW12BTED4 (4HR)	2179	120	2007		N	N	N	N	N	N	N		
N 2.2 HDi 16V FAP	DW12BTED4 (4HS)	2179	125	2007		N	N	N	N	N	N	N		
N 2.2 HDi 16V FAP	DW12BTED4 (4HT)	2179	125	2006		N	N	N	N	N	N	N		
2.2 HDi 16V FAP	DW12TED4 (4HX)	2179	98	2001	2005	X	X	X	X	X	X	X	X	X
2.2 HDi 16V FAP	DW12TED4 (4HX)	2179	98	2005	2006	X	X	X	X	X	N	X	X	X
3.0 V6 24V	ES9A (XFV)	2946	155	2005		X	X	X	X	X	N	X	X	X
3.0 V6 24V	ES9J4S (XFX)	2946	152	2001	2005	X	X	X	X	X	X	X	X	X
<b>C6 2006</b>														
2.2 HDi	DW12 (4HT)	2179	125	2007		X	X				X			
2.7 V6 HDi	D17DT (UHZ)	2720	150	2006		X	X				X			
3.0 V6	ES9A (XFV)	2946	155	2006		X	X				X			
<b>C8 2002</b>														
2.0 16V	EW10J4 (RFN)	1997	100	2002		X	X	X	X	X	X	X	X	X
2.0 HDi 16V	DW10ATED4 (RHT)	1997	79	2002		X	X	X	X	X	X	X	X	X
2.2 16V	EW12J4 (3FZ)	2231	116	2002		X	X	X	X	X	X	X	X	X
2.2 HDi 16V	DW12ATED4 (4HW)	2179	94	2002		X	X	X	X	X	X	X	X	X
2.9 V6 24V	ES9J4S (XFW)	2946	150	2002		X	X	X	X	X	X	X	X	X
<b>CX 1985 1992</b>														
2.0	829A	1995	77	1989	1992	X	X	X	X	X			X	
2.2	J6T /A500	2165	85	1985	1990	X	X	X	X	X			X	
2.5 GTi Turbo	M25 /662/666	2500	122	1985	1992	X	X	X	X	X			X	
2.5 TGI	M25	2500	89	1989	1992	X	X	X	X	X			X	
2.5 TRD TURBO 2	M25/669	2482	88	1987	1989	X	X	X	X	X			X	
2.5D	M25/648	2500	70	1983	1987	X	X	X	X	X			X	
<b>Evasion Synergie 1994 2002</b>														
1.8 8V	XU7JP (LFW)	1761	72	1997	1999	X	X	X	X	X	X	X	X	X
1.8 8V	XU7JP/Z (LFZ)	1761	74	1998	2002	X	X	X	X	X	X	X	X	X
1.9 Turbo D	XUD9BTF (DHX)	1905	66	1999	2001	X	X	X	X	X	X	X	X	X



Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>CITROEN</b>											
<b>Evasion Synergie 1994 2002</b>											
1.9 Turbo D	XUD9TF (D8B)	1905	67	1994	1998	X	X	X	X	X	X
2.0 16V	EW10J4 (RFN)	1998	100	2001	2002	X	X	X	X	X	X
2.0 16V	XU10J4R (RFV)	1998	97	1998	2002	X	X	X	X	X	X
2.0 8V	XU10J2C (RFU)	1998	89	1994	2002	X	X	X	X	X	X
2.0 8V Turbo CT	XU10J2TE (RGX)	1998	108	1994	2002	X	X	X	X	X	X
2.0 HDi 16V	DW10ATED4/L3 (RHW)	1997	81	2001	2002	X	X	X	X	X	X
2.0 HDi 8V	DW10ATED (RHZ)	1997	80	1999	2001	X	X	X	X	X	X
2.1 TD 12V	XUD11BTE (P8C)	2088	80	1996	1999	X	X	X	X	X	X
<b>Jumper Relay 1994 2002</b>											
1000/10Q/27/270 1.9 D	XUD9AU (D9B)	1905	51	1994	2001	X	X	X	X	X	X
1000/10Q/27/270 1.9 Turbo D	XUD9UTF (D8C)	1905	67	1994	2001	X	X	X	X	X	X
1000/10Q/27/270 1.9 Turbo D	XUD9UTF (DHX)	1905	67	1994	2001	X	X	X	X	X	X
1000/10Q/27/270 2.0i	XU10J2U (RFX)	1998	80	1994	2001	X	X	X	X	X	X
10Q/27/270 1.9 D	XUD9AU (DJY)	1905	50	1997	2002	X	X	X	X	X	X
10Q/27/270 2.0i 4x4	XU10J2U (RFX)	1998	80	1995	1997	X	X	X	X	X	X
10Q/27/270 2.5 Turbo D 4x4	DJ5T (T8A)	2445	76	1994	1998	X	X	X	X	X	X
10Q/27/270 2.8 D	8140.63 (SOFIM)	2798	64	2000	2002	X	X	X	X	X	X
10Q/27/270 2.8 HDi	8140.43S (SOFIM)	2798	94	2001	2002	X	X	X	X	X	X
10Q/27/270 2.8 TDi	8940.43 (SOFIM)	2798	90	2000	2001	X	X	X	X	X	X
1400/14Q/31/310 1.9 D	XUD9AU (D9B)	1905	51	1994	2001	X	X	X	X	X	X
1400/14Q/31/310 1.9 Turbo D	XUD9UTF (D8C)	1905	67	1994	2001	X	X	X	X	X	X
1400/14Q/31/310 1.9 Turbo D	XUD9UTF (DHX)	1905	67	1994	2001	X	X	X	X	X	X
1400/14Q/31/310 2.0i	XU10J2U (RFX)	1998	80	1995	1997	X	X	X	X	X	X
1400/14Q/31/310 2.5 D	DJ5 (T9A)	2445	63	1994	2001	X	X	X	X	X	X
1400/14Q/31/310 2.5 TDi	DJ5TED (THX)	2445	79	1997	2001	X	X	X	X	X	X
1400/14Q/31/310 2.5 Turbo D	DJ5T (T8A)	2445	76	1994	1998	X	X	X	X	X	X
1400/14Q/31/310 2.5 Turbo D	DJ5T (THZ)	2445	76	1994	1998	X	X	X	X	X	X
14Q/31/310 1.9 D	XUD9AU (DJY)	1905	50	1997	2002	X	X	X	X	X	X
14Q/31/310 2.0i 4x4	XU10J2U (RFX)	1998	80	1995	1997	X	X	X	X	X	X
14Q/31/310 2.5 D 4x4	DJ5 (T9A)	2445	63	1994	2001	X	X	X	X	X	X
14Q/31/310 2.5 Turbo D 4x4	DJ5T (T8A)	2445	76	1994	1998	X	X	X	X	X	X
14Q/31/310 2.8 D	8140.63 (SOFIM)	2798	64	2000	2002	X	X	X	X	X	X
14Q/31/310 2.8 HDi	8140.43S (SOFIM)	2798	94	2001	2002	X	X	X	X	X	X
14Q/31/310 2.8 TDi	8940.43 (SOFIM)	2798	90	2000	2001	X	X	X	X	X	X
1800/18Q/35/350 2.0i	XU10J2U (RFX)	1998	80	1995	1997	X	X	X	X	X	X
1800/18Q/35/350 2.5 D	DJ5 (T9A)	2445	63	1994	2001	X	X	X	X	X	X
1800/18Q/35/350 2.5 TDi	DJ5TED (THX)	2445	79	1997	2001	X	X	X	X	X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>CITROEN</b>											
<b>Jumper Relay 1994 2002</b>											
1800/18Q/35/350 2.5 Turbo D	DJ5T (T8A)	2445	76	1994	1998	X	X	X	X	X	X
1800/18Q/35/350 2.5 Turbo D	DJ5T (THZ)	2445	76	1994	1998	X	X	X	X	X	X
18Q/35/350 2.0i 4x4	XU10J2U (RFW)	1998	80	1995	1997	X	X	X	X	X	X
18Q/35/350 2.5 D 4x4	DJ5 (T9A)	2445	63	1994	2001	X	X	X	X	X	X
18Q/35/350 2.5 Turbo D 4x4	DJ5T (T8A)	2445	76	1994	2001	X	X	X	X	X	X
18Q/35/350 2.8 D	8140.63 (SOFIM)	2798	64	2000	2002	X	X	X	X	X	X
18Q/35/350 2.8 HDi	8140.43S (SOFIM)	2798	94	2001	2002	X	X	X	X	X	X
18Q/35/350 2.8 TDi	8940.43 (SOFIM)	2798	90	2000	2001	X	X	X	X	X	X
<b>Jumper II Relay II 2002 2006</b>											
2.0	XU10J2U (RFL)	1998	81	2002	2006	X	X	X	X	X	X
2.0 CNG	XU10J2U	1998	70	2002	2006	X	X	X	X	X	X
2.0 HDi	DW10UTD (RHV)	1997	62	2002	2006	X	X	X	X	X	X
2.0 LPG	XU10J2U (RFL)	1998	81	2002	2006	X	X	X	X	X	X
2.2 HDi	DW12UTED (4HY)	2179	74	2002	2006	X	X	X	X	X	X
2.8 HDi	8140.43S (SOFIM)	2798	94	2002	2006	X	X	X	X	X	X
2.8 HDi Power	8140.43N (SOFIM)	2798	107	2004	2006	X	X	X	X	X	X
<b>Jumper III Relay III 2006</b>											
2.2 HDi	P22DTE (4HU)	2198	88	2006		X	X			X	
2.2 HDi	P22DTE (4HV)	2198	74	2006		X	X	X		X	
3.0 HDi	F30DT	2998	115	2006		X	X			X	
<b>Jumpy Dispatch 1995 2007</b>											
1.6	220A.2000	1581	58	1995	2001	X	X	X	X	X	X
1.9 D	DW8 (WJZ)	1868	51	1999	2007	X	X	X	X	X	X
1.9 D	DW8B/D (WJY)	1868	51	2002	2007	X	X	X	X	X	X
1.9 D	XUD9A (D9B)	1905	51	1995	2000	X	X	X	X	X	X
1.9 Turbo D	XUD9BTF (DHX)	1905	68	1997	2007	X	X	X	X	X	X
1.9 Turbo D	XUD9TFL (D8B)	1905	68	1995	1999	X	X	X	X	X	X
2.0 16V	EW10J4 (RFN)	1997	100	2001	2007	X	X	X	X	X	X
2.0 HDi	DW10ATED (RHZ)	1997	80	2001	2007	X	X	X	X	X	X
2.0 HDi	DW10BTED (RHX)	1997	69	2001	2007	X	X	X	X	X	X
2.0 HDi 16V	DW10ATED4 (RHW)	1997	80	2001	2007	X	X	X	X	X	X
<b>Jumpy II Dispatch II 2006</b>											
1.6 HDi	DV6UTED4 (9HU)	1560	66	2006		X	X			X	
2.0 HDi 16V	DW10BTED4 (RHR)	1997	100	2006		X	X			X	
2.0 HDi 16V	DW10UTED4 (RHJ)	1997	88	2006		X	X			X	
2.0 HPi	EW10A (RFJ)	1997	103	2006		X	X			X	

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays
<b>CITROEN</b>												
<b>Picasso 1999 2007</b>												
1.6	TU5JP/L4 (NFV)	1587	70	2001	2007	X	X	X	X	X	X	X
1.6	TU5JP+/L3 (NFZ)	1587	66	1999	2001	X	X	X	X	X	X	X
1.6 HDi 16V	DV6TED4 (9HY)	1560	80	2004	2007	X	X	X	X	X	X	X
1.8 16V	EW7J4 (6FZ)	1749	85	1999	2007	X	X	X	X	X	X	X
2.0 16V	EW10J4/L4 (RFN)	1997	100	2001	2007	X	X	X	X	X	X	X
2.0 HDi	DW10TD (RHY)	1997	66	1999	2007	X	X	X	X	X	X	X
<b>Saxo 1996 2005</b>												
1.0i	TU9M (CDY)	954	33	1996	2001	X	X	X	X	X	X	X
1.0i	TU9M (CDZ)	954	37	1996	2001	X	X	X	X	X	X	X
1.1i	TU1JP/L4 (HFX)	1124	44	2001	2005	X	X	X	X	X	X	X
1.1i	TU1M+ (HDY)	1124	40	1996	2001	X	X	X	X	X	X	X
1.1i	TU1M+ (HDZ)	1124	44	1996	2001	X	X	X	X	X	X	X
1.4i	TU3JP (KFX)	1360	55	1996	2002	X	X	X	X	X	X	X
1.4i	TU3JP/L4 (KFW)	1360	55	2001	2005	X	X	X	X	X	X	X
1.5 D	TUD5 (VJY)	1527	40	2001	2002	X	X	X	X	X	X	X
1.5 D	TUD5 (VJZ)	1527	42	1996	2002	X	X	X	X	X	X	X
1.5 D	TUD5B (VJX)	1527	42	2001	2005	X	X	X	X	X	X	X
1.6i	TU5JP (NFZ)	1587	65	1996	2001	X	X	X	X	X	X	X
1.6i 16V VTS	TU5J4 (NFX)	1587	87	1996	2005	X	X	X	X	X	X	X
1.6i VTR	TU5JP (NFZ)	1587	65	1996	2001	X	X	X	X	X	X	X
1.6i VTR	TU5JP+/L4 (NFT)	1587	74	2002	2005	X	X	X	X	X	X	X
<b>Xantia 1993 2001</b>												
1.6i	XU5JP (BFZ)	1580	65	1993	2001	X	X	X	X	X	X	X
1.8i	XU7JB (LFX)	1761	66	1998	2001	X	X	X	X	X	X	X
1.8i	XU7JP (L6A)	1761	74	1995	1998	X	X	X	X	X	X	X
1.8i	XU7JP (LFZ)	1761	74	1993	1998	X	X	X	X	X	X	X
1.8i 16V	XU7JP4 (LFY)	1761	81	1996	2001	X	X	X	X	X	X	X
1.9 D	XUD9A (D9B)	1905	51	1993	1997	X	X	X	X	X	X	X
1.9 D	XUD9Y (DJZ)	1905	47	1994	1996	X	X	X	X	X	X	X
1.9 Turbo D	XUD9BTF (DHX)	1905	66	1997	2001	X	X	X	X	X	X	X
1.9 Turbo D	XUD9SD (DHW)	1905	55	1998	2000	X	X	X	X	X	X	X
1.9 Turbo D	XUD9TE (DHY)	1905	66	1993	1998	X	X	X	X	X	X	X
1.9 Turbo D	XUD9TF (D8B)	1905	68	1993	1997	X	X	X	X	X	X	X
2.0 HDi	DW10ATED (RHZ)	1997	80	1999	2001	X	X	X	X	X	X	X
2.0 HDi	DW10TD (RHY)	1997	66	1999	2001	X	X	X	X	X	X	X
2.0i	XU10J2C (RFX)	1998	89	1993	1998	X	X	X	X	X	X	X
2.0i 16V	XU10J4 (RFT)	1998	110	1993	1997	X	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>CITROEN</b>											
<b>Xantia 1993 2001</b>											
2.0i 16V	XU10J4D (RFY)	1998	112	1993	1995	X	X	X	X	X	X
2.0i 16V	XU10J4R (RFV)	1998	97	1996	2001	X	X	X	X	X	X
2.0i Turbo CT	XU10J2TE (RGX)	1998	108	1995	1998	X	X	X	X	X	X
2.1 Turbo D	XUD11BTE (P8C)	2088	80	1995	1999	X	X	X	X	X	X
3.0i V6 24V	ES9J4 (XFZ)	2946	140	1998	2001	X	X	X	X	X	X
<b>XM 1989 2001</b>											
2.0	XU102C (R2A)	1998	84	1989	1994	X	X	X	X	X	X
2.0 Turbo CT	XU10J2 (RGA)	1998	107	1993	1994	X	X	X	X	X	X
2.0 Turbo CT	XU10J2TE (RGX)	1998	108	1995	2001	X	X	X	X	X	X
2.0i	XU10J2 (R6A)	1998	94	1989	1994	X	X	X	X	X	X
2.0i	XU10J2 (RFZ)	1998	79	1992	1995	X	X	X	X	X	X
2.0i	XU10M (RDZ)	1998	81	1989	1994	X	X	X	X	X	X
2.0i 16V	XU10J4R (RFV)	1998	97	1995	2001	X	X	X	X	X	X
2.1 D	XUD11A (P9A)	2138	60	1989	1994	X	X	X	X	X	X
2.1 Turbo D	XUD11ATE (P8A)	2088	81	1989	1994	X	X	X	X	X	X
2.1 Turbo D	XUD11ATE (P8B)	2088	81	1995	1998	X	X	X	X	X	X
2.5 Turbo D	DK5 ATE (THY)	2446	95	1995	2000	X	X	X	X	X	X
3.0i 24V	ES9J4 (XFZ)	2946	140	1998	2001	X	X	X	X	X	X
3.0i V6	ZPJ (SFZ)	2975	123	1989	1994	X	X	X	X	X	X
3.0i V6	ZPJ (UFZ)	2963	123	1993	1998	X	X	X	X	X	X
3.0i V6 24V	ZPJ4 (SFZ)	2975	147	1989	1994	X	X	X	X	X	X
3.0i V6 24V	ZPJ4 (UKZ)	2963	147	1993	1998	X	X	X	X	X	X
<b>Xsara 1997 2004</b>											
1.4	TU3JP (KFW)	1360	55	2000	2004	X	X	X	X	X	X
1.4	TU3JP (KFX)	1360	55	1997	2000	X	X	X	X	X	X
1.4 HDi	DV4TD (8HZ)	1398	50	2003	2004	X	X	X	X	X	X
1.5 D	TUD5 (VJY)	1527	40	1999	2000	X	X	X	X	X	X
1.5 D	TUD5 (VJZ)	1527	42	1997	2000	X	X	X	X	X	X
1.6	TU5JP (NFZ)	1587	65	1997	2000	X	X	X	X	X	X
1.6 16V	TU5JP4 (NFU)	1587	80	2000	2004	X	X	X	X	X	X
1.8	XU7JB (LFX)	1761	66	1997	2000	X	X	X	X	X	X
1.8	XU7JP (LFZ)	1761	74	1997	2000	X	X	X	X	X	X
1.8 16V	XU7JP4 (LFY)	1761	81	1997	2000	X	X	X	X	X	X
1.8 D	XUD7/L3 (A9A)	1769	43	1998	1999	X	X	X	X	X	X
1.9 D	DW8 (WJY)	1868	51	2000	2003	X	X	X	X	X	X
1.9 D	DW8 (WJZ)	1868	51	1999	2000	X	X	X	X	X	X
1.9 D	XUD9A (DJY)	1905	50	1997	2000	X	X	X	X	X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>CITROEN</b>											
<b>Xsara 1997 2004</b>											
1.9 SD	XUD9BSD (DHV)	1905	55	1997	2000	X	X	X	X	X	X
1.9 TD	XUD9TE (DHY)	1905	66	1997	2000	X	X	X	X	X	X
2.0 16V	EW10J4 (RFN)	1998	100	2001	2004	X	X	X	X	X	X
2.0 16V	XU10J4R (RFV)	1998	97	1999	2000	X	X	X	X	X	X
2.0 16V	XU10J4RS (RFS)	1998	120	1998	2000	X	X	X	X	X	X
2.0 HDi	DW10ATED (RHZ)	1997	80	2002	2004	X	X	X	X	X	X
2.0 HDi	DW10TD (RHY)	1997	66	1999	2000	X	X	X	X	X	X
<b>Xsara Coupe 1997 2004</b>											
1.4	TU3JP (KFW)	1360	55	2000	2004	X	X	X	X	X	X
1.4	TU3JP (KFX)	1360	55	1997	2000	X	X	X	X	X	X
1.4 HDi	DV4TD (8HZ)	1398	50	2003	2004	X	X	X	X	X	X
1.6	TU5JP (NFZ)	1587	65	1997	2000	X	X	X	X	X	X
1.6 16V	TU5JP4 (NFU)	1587	80	2001	2004	X	X	X	X	X	X
1.8	XU7JB (LFX)	1761	66	1997	2000	X	X	X	X	X	X
1.8	XU7JP (LFZ)	1761	74	1997	2000	X	X	X	X	X	X
1.8 16V	XU7JP4 (LFY)	1761	81	1997	2000	X	X	X	X	X	X
1.8 D	XUD7/L3 (A9A)	1769	43	1997	1998	X	X	X	X	X	X
1.9 D	DW8 (WJZ)	1868	51	1999	2000	X	X	X	X	X	X
1.9 D	DW8B (WJY)	1868	51	2000	2003	X	X	X	X	X	X
1.9 D	XUD9A (DJY)	1905	50	1997	2000	X	X	X	X	X	X
1.9 SD	XUD9BSD (DHV)	1905	55	1997	2000	X	X	X	X	X	X
1.9 TD	XUD9TE (DHY)	1905	66	1997	2000	X	X	X	X	X	X
2.0 16V	EW10J4 (RFN)	1998	100	2001	2004	X	X	X	X	X	X
2.0 16V	XU10J4RS (RFS)	1998	120	1997	2000	X	X	X	X	X	X
2.0 16V	XU10J4RS (RFS)	1998	120	2000	2002	X	X	X	X	X	X
2.0 HDi	DW10TD (RHY)	1997	80	1999	2000	X	X	X	X	X	X
<b>ZX 1991 1998</b>											
1.1	TU1/K (H1A)	1124	44	1991	1997	X	X	X	X	X	X
1.1i	TU1M L/Z (HDY)	1124	40	1992	1994	X	X	X	X	X	X
1.1i	TU1M L/Z (HDZ)	1124	44	1992	1997	X	X	X	X	X	X
1.1i	TU1M+ L3 (HDZ)	1124	44	1997	1998	X	X	X	X	X	X
1.4	TU3-2K (K2D)	1360	55	1991	1997	X	X	X	X	X	X
1.4 D	TUD3 L (K9A)	1360	39	1994	1996	X	X	X	X	X	X
1.4 D	TUD3 Y (K9Y)	1360	37	1996	1998	X	X	X	X	X	X
1.4i	TU3JP (KFX)	1360	75	1997	1998	X	X	X	X	X	X
1.4i	TU3M L/Z (KDY)	1360	55	1992	1994	X	X	X	X	X	X
1.4i	TU3MC L/Z (KDX)	1360	55	1992	1997	X	X	X	X	X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>CITROEN</b>											
<b>ZX 1991 1998</b>											
1.5 D	TUD5 L3 (VJZ)	1527	42	1997	1998	X	X	X	X	X	X
1.6i	XU5JP L/Z (BFZ)	1580	65	1993	1998	X	X	X	X	X	X
1.6i	XU5M3 L/Z (BDY)	1580	65	1992	1994	X	X	X	X	X	X
1.6i	XU5M4 K (B4A)	1580	65	1991	1994	X	X	X	X	X	X
1.8 D	XUD7 L/W3 (A9A)	1769	44	1993	1998	X	X	X	X	X	X
1.8i	XU7JP L/Z (LFZ)	1761	74	1993	1998	X	X	X	X	X	X
1.8i	XU7JP/K (L6A)	1761	74	1994	1998	X	X	X	X	X	X
1.8i 16V	XU7JP4 L3 (LFY)	1761	81	1997	1998	X	X	X	X	X	X
1.9 D	XUD9 Y (DJZ)	1905	47	1992	1995	X	X	X	X	X	X
1.9 D	XUD9A L (D9B)	1905	51	1992	1998	X	X	X	X	X	X
1.9 D	XUD9A Y/L3 (DJY)	1905	50	1995	1998	X	X	X	X	X	X
1.9 TD	XUD9TE L (D8A)	1905	67	1992	1998	X	X	X	X	X	X
1.9 TD	XUD9TE Y (DHY)	1905	66	1992	1998	X	X	X	X	X	X
1.9i	XU9JA L/Z (DKZ)	1905	88	1992	1994	X	X	X	X	X	X
1.9i	XU9JA/K (D6E)	1905	94	1991	1994	X	X	X	X	X	X
2.0i	XU10J2C L/Z (RFX)	1998	89	1992	1998	X	X	X	X	X	X
2.0i	XU10J2C/K (R6D)	1998	89	1994	1998	X	X	X	X	X	X
2.0i 16V	XU10J4D L/Z (RFT)	1998	110	1995	1997	X	X	X	X	X	X
2.0i 16V	XU10J4D L/Z (RFY)	1998	112	1992	1995	X	X	X	X	X	X
2.0i 16V	XU10J4RS (RFS)	1998	120	1996	1998	X	X	X	X	X	X
<b>DACIA</b>											
<b>Logan 2005</b>											
1.4 MPi	K7J-710	1390	55	2005		X	X	X	X	X	X
1.5 dCi	K9K-790	1461	48	2006		X	X	X	X	X	X
1.5 dCi	K9K-792	1461	50	2006		X	X	X	X	X	X
1.6 MPi	K7M-710	1598	64	2005		X	X	X	X	X	X
<b>DAIHATSU</b>											
<b>Applause 1989 2001</b>											
1.6	HD-C	1589	67	1989	1992	X	X	X	X	X	X
1.6i	HD-E	1589	77	1989	2001	X	X	X	X	X	X
1.6i 4X4	HD-E	1589	77	1989	2001	X	X	X	X	X	X
<b>Charade 1983 1987</b>											
1.0	CB 22	993	38	1983	1987	X	X	X	X	X	X
1.0 D	CL 10	993	27	1983	1987	X	X	X	X	X	X
1.0 TD	CL 50/60	993	34	1985	1987	X	X	X	X	X	X
1.0 TX Turbo	CB 50	993	50	1983	1987	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>DAIHATSU</b>											
<b>Charade 1987 1993</b>											
1.0	CB 23/36	993	38	1987	1993	X	X	X	X	X	X
1.0 D	CL 11	993	27	1987	1993	X	X	X	X	X	X
1.0 GTi	CB 80	993	74	1987	1993	X	X	X	X	X	X
1.0 TD	CL 50/61	993	35	1987	1993	X	X	X	X	X	X
1.0 Turbo	CB61	993	50	1987	1993	X	X	X	X	X	X
1.3 16V	HC-C	1295	56	1988	1993	X	X	X	X	X	X
1.3 4-WD 16V	HC	1295	66	1989	1993	X	X	X	X	X	X
1.3i 16V	HC-E	1295	66	1989	1993	X	X	X	X	X	X
<b>Charade 1993 2001</b>											
1.0	CB-C	993	38	1993	2001	X	X	X	X	X	X
1.3i 16V	HC-E	1296	62	1993	2001	X	X	X	X	X	X
1.5i 16V	HE-E	1499	66	1996	2001	X	X	X	X	X	X
1.6i 16V	HD-E	1589	77	1993	2001	X	X	X	X	X	X
<b>Cuore Mira 1985 1990</b>											
850, 44 Domino	ED 10	846	32	1985	1990	X	X	X	X	X	X
<b>Cuore Mira 1990 1995</b>											
850, Domino	ED 10	847	30	1990	1995	X	X	X	X	X	X
<b>Cuore Mira 1995 1998</b>											
850	ED 10	847	30	1995	1998	X	X	X	X	X	X
850i	ED 20	847	32	1995	1998	X	X	X	X	N	X
<b>N Cuore Mira 1998 2003</b>											
N 1.0 12V DOHC	EJ-DE	989	40	1998	2003	N	N	N	N	N	N
<b>Cuore Max Charade 2005</b>											
1.0 12V DVVT	EJ-VE	989	43	2005		X	N	X	X	X	
1.0 DVVT	EJ-DE	959	41	2005		X	N	X	X	X	X
<b>Feroza Sportrak 1988 2000</b>											
1.6	HD-C	1589	63	1988	1991	X	X	X	X	X	X
1.6i	HD-E	1589	70	1988	1991	X	X	X	X	X	X
1.6i	HD-E	1589	70	1991	2000	X	X	X	X	X	X
<b>Gran Move 1997 2003</b>											
1.5	HE-EG	1499	66	1997	2003	X	X	X	X	X	N
<b>HiJet 1998</b>											
1.3 16V	HC-ES	1296	48	1998		X	X	X	X	X	
<b>N Matera 2007</b>											
N 1.3 16V	K3-VE	1298	64	2007		N	N	N	N	N	
N 1.5 16V	3SZ-VE	1495	76	2007		N	N	N	N	N	

Legend: N = new, X = present

Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diagr. Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diagr. Fuses & Relays

**DAIHATSU**

Make	Model	Year	From	To	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays	
<b>DAIHATSU</b>																	
<b>Move</b>	<b>1997</b>	<b>2003</b>															
	850				ED	847	37	1997	2003	X	X	X	X	X		X	X
<b>Rocky Fourtrak</b>	<b>1985</b>	<b>2001</b>															
	2.0				3Y	1998	65	1985	1989	X	X	X	X	X		X	
	2.2				4Y	2237	65	1992	1993	X	X	X	X	X		X	
	2.8 D				DL40	2765	54	1984	1988	X	X	X	X	X		X	
	2.8 D				DL42	2765	54	1987	1993	X	X	X	X	X		X	
	2.8 D				DL42	2765	54	1993	2003	X	X	X	X	X		X	X
	2.8 TD				DL42	2765	67	1987	1993	X	X	X	X	X		X	
	2.8 TD				DL50	2765	65	1984	1987	X	X	X	X	X		X	
	2.8 TD				DL52	2765	75	1987	1993	X	X	X	X	X		X	
	2.8 TD				DL52	2765	75	1993	2001	X	X	X	X	X		X	X
<b>Sirion</b>	<b>1998</b>	<b>2005</b>															
	1.0 12V				EJ-DE	989	41	1998	2001	X	X	X	X	X		X	X
	1.0 12V				EJ-VE	989	43	2001	2005	X	N	N	X	N			X
	1.3 16V				K3-VE2	1298	75	2001	2005	X	N	N	X	N			X
<b>Sirion 2</b>	<b>2005</b>																
	1.0 12V				1KR-FE	998	51	2005		X	X	X	X	X			X
	1.3 16V				K3-VE	1298	64	2005		X	X	X	X	X		X	X
<b>Terios</b>	<b>1997</b>	<b>2006</b>															
	1.3 16V				HC-EJ	1296	61	1997	2000	X	X	X	X	N		X	X
	1.3 16V				K3-VE	1298	63	2000	2006	X	N	N	X	N			X
<b>N Trevis</b>	<b>2006</b>																
<b>N</b>	1.0 12V DVVT				EJ-VE	989	43	2006		N	N	N		N		N	
<b>Valera</b>	<b>1995</b>	<b>2001</b>															
	1.5i 16V				HE-E	1499	66	1996	2001	X	X	X	X	X			
<b>YRV</b>	<b>2000</b>	<b>2007</b>															
	1.0 12V				EJ-VE	989	43	2000	2007	X	X	X		X		X	
	1.3 16V				K3-VE	1298	64	2000	2007	X	X	X		X		X	
	1.3 16V T				K3-VET	1298	95	2000	2007	X	X	X		X		X	
<b>FIAT</b>																	
<b>Barchetta</b>	<b>1995</b>	<b>2005</b>															
	1.8 16V				183 A1.000	1747	96	1995	2000	X	X	X	X	X		X	X
	1.8 16V				188 A6.000	1747	96	2000	2005	X	X	X	X	X		X	
<b>Brava</b>	<b>1995</b>	<b>2001</b>															
	1.2 16V				182 B2.000	1242	60	1998	2000	X	X	X	X	X		X	X
	1.2 16V				188 A5.000	1242	59	2000	2001	X	X	X	X	X		X	X



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays
<b>FIAT</b>												
<b>Brava</b>	<b>1995</b>	<b>2001</b>										
1.4 12V	182 A3.000	1370	59	1995	1998	X	X	X	X	X	X	X
1.4 12V	182 A5.000	1370	55	1995	1998	X	X	X	X	X	X	X
1.6 16V	182 A4.000	1581	74	1995	2000	X	X	X	X	X	X	X
1.6 16V	182 A6.000	1581	66	1995	1998	X	X	X	X	X	X	X
1.6 16V	182 B6.000	1596	74	2000	2001	X	X	X	X	X	X	X
1.8 16V	182 A2.000	1747	83	1995	2000	X	X	X	X	X	X	X
1.9 D	160 A7.000	1929	48	1995	1998	X	X	X	X	X	X	X
1.9 JTD 100	182 B9.000	1910	74	2000	2001	X	X	X	X	X	X	X
1.9 JTD 105	182 B4.000	1910	77	1998	2000	X	X	X	X	X	X	X
1.9 TD 100	182 A7.000	1910	74	1996	1999	X	X	X	X	X	X	X
1.9 TD 75	182 A8.000	1910	55	1995	2000	X	X	X	X	X	X	X
<b>Bravo</b>	<b>1995</b>	<b>2001</b>										
1.2 16V	182 B2.000	1242	60	1998	2000	X	X	X	X	X	X	X
1.2 16V	188 A5.000	1242	59	2000	2001	X	X	X	X	X	X	X
1.4 12V	182 A3.000	1370	59	1995	1998	X	X	X	X	X	X	X
1.4 12V	182 A5.000	1370	55	1995	1998	X	X	X	X	X	X	X
1.6 16V	178 A8.011	1581	74	1998	1998	X	X	X	X	X	X	X
1.6 16V	182 A4.000	1581	76	1995	2000	X	X	X	X	X	X	X
1.6 16V	182 A6.000	1581	66	1995	1998	X	X	X	X	X	X	X
1.6 16V	182 B6.000	1596	76	2000	2001	X	X	X	X	X	X	X
1.8 16V	182 A2.000	1747	83	1995	2000	X	X	X	X	X	X	X
1.9 D	160 A7.000	1929	48	1995	1998	X	X	X	X	X	X	X
1.9 JTD 100	182 B9.000	1910	74	2000	2001	X	X	X	X	X	X	X
1.9 JTD 105	182 B4.000	1910	77	1998	2000	X	X	X	X	X	X	X
1.9 TD 100	182 A7.000	1910	74	1996	1999	X	X	X	X	X	X	X
1.9 TD 75	182 A8.000	1910	55	1995	2000	X	X	X	X	X	X	X
2.0 20V HGT	182 A1.000	1998	108	1995	1998	X	X	X	X	X	X	X
2.0 20V HGT	182 B7.000	1998	113	1998	2000	X	X	X	X	X	X	X
<b>Bravo</b>	<b>2007</b>											
1.4 16V	192 B2.000	1368	66	2007		X	X	X	X	X	X	X
1.9 Multijet 115	192 B4.000	1910	85	2007		X	X	X	X	X	X	X
1.9 Multijet 120	192 A8.000	1910	88	2007		X	X	X	X	X	X	X
1.9 Multijet 16V	937 A5.000	1910	110	2007		X	X	X	X	X	X	X
<b>Cinquecento</b>	<b>1992</b>	<b>1998</b>										
1100 ie	176 B2.000	1108	40	1994	1998	X	X	X	X	X	X	X
700	170 A.046	704	22	1992	1998	X	X	X	X	X	X	X
900	170 A1.000	903	30	1992	1995	X	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>FIAT</b>													
<b>Cinquecento 1992 1998</b>													
900 ie	1170 A1.046	899	29	1995	1998	X	X	X	X	X	X	X	X
900 ie	170 A1.046	903	29	1992	1995	X	X	X	X	X	X	X	X
<b>Coupe 1994 2002</b>													
1.8 16V	183 A1.000	1747	96	1996	2002	X	X	X	X	X	X	X	X
2.0 16V	836 A3.000	1995	102	1993	1996	X	X	X	X	X	X	X	X
2.0 16V Turbo	175 A1.000	1995	140	1993	1996	X	X	X	X	X	X	X	X
2.0 20V	182 A1.000	1998	108	1996	1998	X	X	X	X	X	X	X	X
2.0 20V	182 B3.000	1998	113	1998	2002	X	X	X	X	X	X	X	X
2.0 20V Turbo	175 A3.000	1998	162	1996	2002	X	X	X	X	X	X	X	X
<b>Croma 1985 1995</b>													
1.6	154 A.048	1585	61	1985	1991	X	X	X	X	X	X	X	X
2.0 CHT	154 A.1000	1995	66	1986	1990	X	X	X	X	X	X	X	X
2.0 ie	154 C3.000	1995	86	1991	1995	X	X	X	X	X	X	X	X
2.0 ie	834 B.000	1995	88	1985	1991	X	X	X	X	X	X	X	X
2.0 ie 16V	154 E1.000	1995	101	1993	1995	X	X	X	X	X	X	X	X
2.0 ie kat	154 C3.046	1995	85	1991	1995	X	X	X	X	X	X	X	X
2.0 Turbo ie	154 A2.000	1995	114	1985	1991	X	X	X	X	X	X	X	X
2.0 Turbo ie	154 C4.000	1995	114	1991	1995	X	X	X	X	X	X	X	X
2.0 Turbo ie	834 C.146	1995	110	1986	1991	X	X	X	X	X	X	X	X
2.0 Turbo ie kat.	154 C4.046	1995	110	1991	1995	X	X	X	X	X	X	X	X
2.4 TD	8144.91	2445	74	1985	1989	X	X	X	X	X	X	X	X
2.5 D	8144.67	2499	55	1985	1990	X	X	X	X	X	X	X	X
2.5 V6	834 G.000	2492	117	1993	1995	X	X	X	X	X	X	X	X
<b>Croma 2005</b>													
1.9 JTD 16V	939 A2.000	1910	110	2005		X	X	X	X	X	X	X	X
1.9 JTD 8V	939 A1.000	1910	88	2005		X	X	X	X	X	X	X	X
2.2 16V	194 A1.000	2198	108	2005		X	X	X	X	X	X	X	X
2.4 JTD 20V	939 A3.000	2387	147	2005		X	X	X	X	X	X	X	X
<b>Doblo 2001</b>													
1.2 8V	223 A5.000	1242	48	2001	2005	X	X	X	X	X	X	X	X
1.3 JTD	188 A9.000	1248	51	2001	2005	X	X	X	X	X	X	X	X
1.6 16V	182 B6.000	1596	76	2002		X	X	X	X	X	X	X	X
1.6 16V Bipower	182 B6.000	1596	68	2002		X	X	X	X	X	X	X	X
1.9 D	223 A6.000	1910	46	2001	2003	X	X	X	X	X	X	X	X
1.9 JTD	182 B9.000	1910	74	2001	2003	X	X	X	X	X	X	X	X
1.9 JTD	223 A7.000	1910	77	2003	2005	X	X	X	X	X	X	X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>FIAT</b>													
<b>Doblo Cargo 2001</b>													
1.2 8V	223 A5.000	1242	48	2001	2005	X	X	X	X	X	X	X	X
1.3 JTD	188 A9.000	1248	51	2001	2005	X	X	X	X	X	X	X	X
1.6 16V	182 B6.000	1596	76	2002		X	X	X	X	X	X	X	X
1.6 16V Bipower	182 B6.000	1596	68	2002		X	X	X	X	X	X	X	X
1.9 D	223 A6.000	1910	46	2001	2003	X	X	X	X	X	X	X	X
1.9 JTD	182 B9.000	1910	74	2001	2003	X	X	X	X	X	X	X	X
1.9 JTD	223 A7.000	1910	77	2003	2005	X	X	X	X	X	X		X
<b>Ducato 1989 1994</b>													
10 1.9 D	149 A1.000	1929	51	1989	1994	X	X	X	X			X	X
10 1.9 Turbo D	280 A1.000	1929	60	1989	1994	X	X	X	X			X	X
10 2.0 (XN1T)	170 B	2000	55	1989	1994	X	X	X	X	X		X	X
10 2.0 (XN1TACP)	170 D	2000	62	1989	1994	X	X	X	X	X		X	X
10 2.5 D	8144.67	2500	55	1989	1994	X	X	X	X			X	X
10 2.5 Turbo D	8140.27	2500	70	1989	1994	X	X	X	X			X	X
14 1.9 Turbo D	280 A1.000	1929	60	1989	1994	X	X	X	X			X	X
14 2.0 (XN1T)	170 B	2000	55	1989	1994	X	X	X	X	X		X	X
14 2.0 (XN1TACP)	170 D	2000	62	1989	1994	X	X	X	X	X		X	X
14 2.5 D	8144.67	2500	55	1989	1994	X	X	X	X			X	X
14 2.5 Turbo D	8140.27	2500	70	1989	1994	X	X	X	X			X	X
4x4 2.5 D	8144.67	2500	55	1989	1994	X	X	X	X			X	X
4x4 2.5 Turbo D	8140.27	2500	70	1989	1994	X	X	X	X			X	X
Maxi 2.0 (XN1TA)	170 C	2000	63	1989	1994	X	X	X	X	X		X	X
Maxi 2.0 (XN1TACP)	170 D	2000	62	1989	1994	X	X	X	X	X		X	X
Maxi 2.5 D	8144.67	2500	55	1989	1994	X	X	X	X			X	X
Maxi 2.5 Turbo D	8140.27	2500	70	1989	1994	X	X	X	X			X	X
<b>Ducato 2002 2006</b>													
2.0 16V	XU10J2U (RFL)	1998	81	2002	2006	X	X	X	X	X	X	X	X
2.0 16V Bipower	XU10J2U (RFL)	1998	71	2003	2006	X	X	X	X	X	X		X
2.0 16V G-power	XU10J2U (RFL)	1998	81	2003	2006	X	X	X	X	X	X		X
2.0 JTD	DW10UTED (RHV)	1997	62	2002	2006	X	X	X	X	X	X	X	X
2.3 JTD	Sofim FIAEO481C	2286	81	2002	2006	X	X	X	X	X	X	X	X
2.8 JTD	Sofim 8140.43S	2800	94	2002	2006	X	X	X	X	X	X	X	X
2.8 JTD Power	Sofim 8140.43N	2800	107	2004	2006	X	X	X	X	X	X		X
<b>Ducato 2006</b>													
2.2 Multijet 100	P22DTE (4HV)	2198	74	2006		X	X	X	X		X		
2.3 Multijet 120	Sofim FIAEO481D	2287	88	2006		X	X	X	X		X		
2.3 Multijet 130	Sofim FIAEO481N	2287	96	2006		X	X	X	X		X		

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>FIAT</b>											
<b>Ducato 2006</b>											
3.0 Multijet 160	Sofim FICEO481D	2999	117	2006		X	X	X		X	
<b>Ducato 1994 2002</b>											
10 1.9 D	DJY	1905	50	1998	2002	X	X	X		X	X X X
10 1.9 TD	DHX	1905	66	1998	2002	X	X	X		X	X X X
10 2.0 DS	230 A2.000	1929	51	1994	1998	X	X	X X X		X	X X X
10 2.0 ie	RFW	1998	80	1994	2002	X	X	X X X		X	X X X
10 2.0 TDS	230 A3.000	1929	60	1994	1998	X	X	X X X		X	X X X
10 2.0 TDS E	230 A4.000	1929	59	1994	1998	X	X	X X X		X	X X X
10 2.5 TDS	8140.47	2500	85	1994	1998	X	X	X X X		X	X X X
10 2.5 TDS E	8140.47R	2500	80	1994	1998	X	X	X X X		X	X X X
10 2.8 D	8140.63	2800	64	1998	2002	X	X	X X X			X X
10 2.8 JTD	8140.43S	2800	94	2000	2002	X	X	X X X			X X
10 2.8 TD id	8140.43	2800	90	1998	2000	X	X	X X X			X X
14 1.9 D	DJY	1905	50	1998	2002	X	X	X			X X
14 1.9 TD	DHX	1905	66	1998	2002	X	X	X		X	X X X
14 2.0 ie	RFW	1998	80	1994	2002	X	X	X X X		X	X X X
14 2.0 TDS	230 A3.000	1929	60	1994	1998	X	X	X X X		X	X X X
14 2.0 TDS E	230 A4.000	1929	59	1994	1998	X	X	X X X		X	X X X
14 2.5 DS	8140.67	2500	62	1994	1998	X	X	X X X		X	X X X
14 2.5 TDS	8140.47	2500	85	1994	1998	X	X	X X X		X	X X X
14 2.5 TDS E	8140.47R	2500	80	1994	1998	X	X	X X X		X	X X X
14 2.8 D	8140.63	2800	64	1998	2002	X	X	X X X			X X
14 2.8 JTD	8140.43S	2800	94	2000	2002	X	X	X X X			X X
14 2.8 TD id	8140.43	2800	90	1998	2000	X	X	X X X			X X
Maxi 2.0 ie	RFW	1998	80	1994	2002	X	X	X X X		X	X X X
Maxi 2.0 TDS E	230 A4.000	1929	59	1994	1998	X	X	X X X			X X
Maxi 2.5 DS	8140.67	2500	62	1994	1998	X	X	X X X		X	X X X
Maxi 2.5 TDS	8140.47	2500	85	1994	1998	X	X	X X X		X	X X X
Maxi 2.5 TDS E	8140.47R	2500	80	1994	1998	X	X	X X X		X	X X X
Maxi 2.8 D	8140.63	2800	64	1998	2002	X	X	X X X			X X
Maxi 2.8 JTD	8140.43S	2800	94	2000	2002	X	X	X X X			X X
Maxi 2.8 TD id	8140.43	2800	90	1998	2000	X	X	X X X			X X
<b>Grande Punto 2006</b>											
1.2	199 A4.000	1242	48	2006		X	X	X X X		X	X X
1.3 Multijet 75	199 A2.000	1248	55	2006		X	X	X X X		X	X X
1.3 Multijet 90	199 A3.000	1248	66	2006		X	X	X X X		X	X X
1.4	350 A1.000	1368	57	2006		X	X	X X X		X	X X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>FIAT</b>											
<b>Grande Punto 2006</b>											
1.4 16V	199 A6.000	1368	70	2006		X	X	X	X	X	X
1.9 Multijet	939 A1.000	1910	88	2006		X	X	X	X	X	X
1.9 Multijet Sport	199 A5.000	1910	96	2006		X	X	X	X	X	X
<b>Idea 2004</b>											
1.2 16V	188 A5.000	1242	59	2004		X	X	X	X	X	X
1.3 Multijet 70	188 A9.000	1248	51	2004		X	X	X	X	X	X
1.3 Multijet 90	199 A3.000	1248	66	2005		X	X	X	X	X	X
1.4 16V	843 A1.000	1368	70	2004		X	X	X	X	X	X
1.4 8V	350 A1.000	1368	57	2005		X	X	X	X	X	X
1.9 Multijet	188 B2.000	1910	74	2004		X	X	X	X	X	X
<b>Marea Weekend / Marengo 1996 2002</b>											
1.2 16V	182 B2.000	1242	60	1999	2000	X	X	X	X	X	X
1.4 12V	182 A3.000	1370	59	1996	1999	X	X	X	X	X	X
1.6 16V	182 A4.000	1581	76	1996	2000	X	X	X	X	X	X
1.6 16V	182 B6.000	1596	76	2000	2002	X	X	X	X	X	X
1.8 16V	182 A2.000	1747	83	1996	2000	X	X	X	X	X	X
1.9 JTD 100	182 B9.000	1910	74	2001	2002	X	X	X	X	X	X
1.9 JTD 105	182 B4.000	1910	77	1999	2000	X	X	X	X	X	X
1.9 JTD 110	186 A6.000	1910	81	2000	2002	X	X	X	X	X	X
1.9 TD 100	182 A7.000	1910	74	1996	1999	X	X	X	X	X	X
1.9 TD 75	182 A8.000	1910	55	1996	2000	X	X	X	X	X	X
2.0 20V	182 A1.000	1998	108	1996	1999	X	X	X	X	X	X
2.0 20V	182 B7.000	1998	113	1999	2000	X	X	X	X	X	X
2.0 20V	185 A8.000	1998	110	2000	2002	X	X	X	X	X	X
2.4 JTD 130	185 A6.000	2387	96	1999	2000	X	X	X	X	X	X
2.4 TD 125	185 A2.000	2387	91	1996	1999	X	X	X	X	X	X
<b>Multipia 1998 2004</b>											
1.6 16V	182 A4.000	1581	76	1998	2001	X	X	X	X	X	X
1.6 16V	182 B6.000	1596	76	2001	2004	X	X	X	X	X	X
1.6 16V Bipower	182 B6.000	1596	68	2001	2004	X	X	X	X	X	X
1.6 16V Blupower	186 A3.000	1581	70	1999	2004	X	X	X	X	X	X
1.6 16V G-power	182 B6.000	1596	76	2002	2004	X	X	X	X	X	X
1.9 JTD 105	182 B4.000	1910	77	1998	2001	X	X	X	X	X	X
1.9 JTD 110	182 A6.000	1910	81	2001	2004	X	X	X	X	X	X
<b>Multipia 2004</b>											
1.6 16V	182 B6.000	1596	76	2004		X	X	X	X	X	X
1.9 JTD 115	186 A8.000	1910	85	2004		X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>FIAT</b>											
<b>Palio Weekend / Strada / Siena 1997 2003</b>											
1.2 8V	188 A4.000	1242	44	2001	2003	X	X	X	X	X	X
1.2 8V (65)	178 E2.000	1242	50	2000	2003	X	X	X	X	X	X
1.2 8V (75)	178 B5.000	1242	54	1997	2001	X	X	X	X	X	X
1.4 8V	178 B2.000	1372	51	1997	2001	X	X	X	X	X	X
1.6 16V	182 B6.000	1596	76	2001	2003	X	X	X	X	X	X
1.6 16V (100)	178 B3.000	1581	74	1997	2001	X	X	X	X	X	X
1.7 TD (70)	176 A3.000	1698	51	1997	2001	X	X	X	X	X	X
1.9 D	223 A6.000	1910	46	2001	2003	X	X	X	X	X	X
<b>Panda 1985 2003</b>											
1.1	187 A1.000	1108	40	2001	2003	X	X	X	X	X	X
1000	156 A2.000	999	33	1985	1990	X	X	X	X	X	X
1000 4x4	156 A2.100	999	32	1986	1995	X	X	X	X	X	X
1000 4x4	156 A3.000	999	37	1986	1995	X	X	X	X	X	X
1000 ie	141 C2.000	999	33	1995	1997	X	X	X	X	X	X
1000 ie	156 A2.246	999	33	1986	1990	X	X	X	X	X	X
1000 ie 4x4	156 A2.246	999	33	1986	1995	X	X	X	X	X	X
1100 ie	156 C.046	1108	37	1991	1995	X	X	X	X	X	X
1100 ie	176 B2.000	1108	40	1995	2001	X	X	X	X	X	X
1100 ie 4x4	176 B2.000	1108	40	1995	2001	X	X	X	X	X	X
1100 ie Selecta	156 C.046	1108	37	1991	1995	X	X	X	X	X	X
1100 ie Selecta	176 B2.000	1108	40	1995	2001	X	X	X	X	X	X
1300 D	156 A5.000	1302	27	1986	1995	X	X	X	X	X	X
750	156 A4.000	769	25	1985	1990	X	X	X	X	X	X
750 Ecobox	156 A4.048	769	25	1987	1990	X	X	X	X	X	X
900 ie	1170 A1.046	899	29	1994	2001	X	X	X	X	X	X
<b>Panda 2003</b>											
1.1	187 A1.000	1108	40	2003		X	X	X	X	X	X
1.2 8V	188 A4.000	1242	44	2003		X	X	X	X	X	X
1.2 8V 4x4	188 A4.000	1242	44	2003		X	X	X	X	X	X
1.3 JTD	188 A8.000	1248	51	2004		X	X	X	X	X	X
<b>Punto 1993 2000</b>											
1.1 55	176 A6.000	1108	40	1993	1995	X	X	X	X	X	X
1.1 55	176 B2.000	1108	40	1995	2000	X	X	X	X	X	X
1.2 60	176 A7.000	1242	43	1993	1995	X	X	X	X	X	X
1.2 60	176 B1.000	1242	44	1994	1995	X	X	X	X	X	X
1.2 60	176 B4.000	1242	44	1995	2000	X	X	X	X	X	X
1.2 75	176 A8.000	1242	54	1993	2000	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>FIAT</b>											
<b>Punto 1993 2000</b>											
1.2 85 16V	176 B9.000	1242	63	1997	2000	X	X	X	X	X	X
1.2 85 16V Cabrio	176 B9.000	1242	63	1997	2000	X	X	X	X	X	X
1.4 GT	176 A4.000	1372	98	1993	1997	X	X	X	X	X	X
1.4 GT	176 B6.000	1372	96	1997	2000	X	X	X	X	X	X
1.6 90	176 A9.000	1581	65	1993	1997	X	X	X	X	X	X
1.6 90 Cabrio	176 A9.000	1581	65	1993	1997	X	X	X	X	X	X
1.7 D 60	176 B3.000	1698	42	1995	1997	X	X	X	X	X	X
1.7 TD 60	176 B7.000	1698	46	1997	2000	X	X	X	X	X	X
1.7 TD 70	176 A3.000	1697	51	1993	2000	X	X	X	X	X	X
1.7 TD 70	176 A5.000	1697	52	1993	1997	X	X	X	X	X	X
<b>Punto 1999</b>											
1.2	188 A4.000	1242	44	1999		X	X	X	X	X	X
1.2 16V	188 A5.000	1242	59	1999		X	X	X	X	X	X
1.3 JTD	188 A9.000	1248	51	2003		X	X	X	X	X	X
1.4 16V	843 A1.000	1368	70	2003		X	X	X	X	X	X
1.8 16V	183 A1.000	1747	96	1999	2001	X	X	X	X	X	X
1.8 16V	183 A6.000	1747	96	2001	2003	X	X	X	X	X	X
1.9 D	188 A3.000	1910	44	1999	2003	X	X	X	X	X	X
1.9 JTD	188 A2.000	1910	59	1999	2003	X	X	X	X	X	X
1.9 JTD 85	188 A7.000	1910	63	2001		X	X	X	X	X	X
<b>Scudo 1995 2007</b>											
1.6	220 A2.000	1581	58	1995	2000	X	X	X	X	X	X
1.9 D	DW8 (WJY)	1868	51	2001	2007	X	X	X	X	X	X
1.9 D	DW8 (WJZ)	1868	51	1998	2001	X	X	X	X	X	X
1.9 D	XUD9A (D9B)	1905	51	1995	2000	X	X	X	X	X	X
1.9 TD	XUD9TF (DHX)	1905	66	1997	2000	X	X	X	X	X	X
1.9 TD	XUD9TF/L (D8B)	1905	68	1995	2000	X	X	X	X	X	X
2.0 16V CF3	EW10J4 (RFN)	1997	100	2000	2007	X	X	X	X	X	X
2.0 JTD	DW10ATED (RHZ)	1997	80	1999	2007	X	X	X	X	X	X
2.0 JTD	DW10BTED (RHX)	1997	69	1999	2007	X	X	X	X	X	X
2.0 JTD 16V	DW10ATED4 (RHW)	1997	80	2001	2007	X	X	X	X	X	X
<b>Sedici 2006</b>											
1.6 16V	M16A	1586	79	2006		X	X	X	X	X	X
1.9 JTD	19DAA	1910	88	2006		X	X	X	X	X	X
<b>Seicento 1998</b>											
1.1	187 A1.000	1108	40	2000		X	X	X	X	X	X
1100 ie	176 B2.000	1108	40	1998	2000	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance		Techn. Drawings		Motor Manag.		Wiring Diagn.		Service Reset		Repair Times		
						Identification	Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagn.	Fuses & Relays					
<b>FIAT</b>																		
<b>Seicento 1998</b>																		
1100 ie Sporting	176 B2.000	1108	40	1998	2000	X	X	X	X	X	X	X	X		X	X	X	
900 ie	1170 A1.046	899	29	1998	2000	X	X	X	X	X	X	X	X		X	X	X	
<b>Stilo 2001</b>																		
1.2 16V	188 A5.000	1242	59	2001	2004	X	X	X	X	X	X	X	X	X			X	X
1.4 16V	192 B2.000	1368	66	2005	2007	X	X	X	X	X			X	X			<b>N</b>	X
1.4 16V	843 A1.000	1368	70	2004	2007	X	X	X	X	X	X	X	X	X			X	X
1.6 16V	182 B6.000	1596	76	2001	2005	X	X	X	X	X	X	X	X	X			X	X
1.6 16V	192 B3.000 (Z16XEP)	1598	77	2005		X	X	X	X	X			X	X				X
1.8 16V	192 A4.000	1747	98	2001	2007	X	X	X	X	X	X	X	X	X			X	X
1.9 16V Multijet 140	192 A5.000	1910	103	2004	2005	X	X	X	X	X	X	X	X	X			X	X
1.9 16V Multijet 150	937 A5.000	1910	110	2005	2007	X	X	X	X	X			X	X			<b>N</b>	X
1.9 JTD 100	192 A9.000	1910	74	2004	2005	X	X	X	X	X			X	X				X
1.9 JTD 115	192 A1.000	1910	85	2001	2005	X	X	X	X	X	X	X	X	X			X	X
1.9 JTD 80	192 A3.000	1910	59	2001	2005	X	X	X	X	X	X	X	X	X			X	X
1.9 Multijet 115	192 B4.000	1910	85	2005	2007	X	X	X	X	X			X	X				X
1.9 Multijet 120	192 A8.000	1910	88	2005		X	X	X	X	X			X	X				X
2.4 20V	192 A2.000	2445	125	2001	2007	X	X	X	X	X	X	X	X	X			X	X
<b>Tempra Marengo 1990 1995</b>																		
1.4	159.A.2000	1372	55	1990	1996	X	X	X	X	X			X	X			X	X
1.4 IE	160.A.1046	1372	51	1992	1994	X	X	X	X	X	X	X	X	X			X	X
1.4 IE	836.A.4000	1372	51	1992	1996	X	X	X	X	X	X	X	X	X			X	X
1.6	159.A.3000	1580	62	1990	1996	X	X	X	X	X	X	X	X	X			X	X
1.6 IE	159.A.3048	1581	55	1992	1996	X	X	X	X	X	X	X	X	X			X	X
1.6 IE	159.A3.046	1580	59	1990	1996	X	X	X	X	X	X	X	X	X			X	X
1.6 IE	835.C.1000	1581	55	1993	1996	X	X	X	X	X	X	X	X	X			X	X
1.7 D	149.B4.000	1697	43	1990	1996	X	X	X	X	X			X	X			<b>N</b>	X
1.8 IE	159.A.4000	1756	79	1990	1993	X	X	X	X	X	X	X	X	X			X	X
1.8 IE	159.A.4046	1756	79	1990	1996	X	X	X	X	X	X	X	X	X			X	X
1.8 IE	835.C2.000	1756	79	1990	1996	X	X	X	X	X	X	X	X	X			X	X
1.8 IE	836.A.5000	1756	74	1990	1996	X	X	X	X	X	X	X	X	X			X	X
1.8 IE	836.A.6000	1756	66	1990	1996	X	X	X	X	X	X	X	X	X			X	X
1.9 D	160.A.7000	1929	48	1990	1996	X	X	X	X	X			X	X			X	X
1.9 TD	160.A.6000	1929	68	1990	1996	X	X	X	X	X			X	X			X	X
1.9 TD cat	160.B.6046	1929	59	1990	1996	X	X	X	X	X			X	X			X	X
1.9 TD cat	160.D.1000	1929	66	1990	1996	X	X	X	X	X			X	X			X	X
2.0 IE	159 A6.046	1995	83	1990	1996	X	X	X	X	X	X	X	X	X			X	X
2.0 Stationwagon 4x4	159.A.6046	1995	83	1991	1996	X	X	X	X	X	X	X	X	X			X	X



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>FIAT</b>											
<b>Tipo</b>	<b>1988</b>	<b>1995</b>									
1.1	160 A3.000	1108	39	1988	1995	X	X	X	X	X	X
1.4	160 A1.000	1372	52	1988	1990	X	X	X	X	X	X
1.4 IE	160 A1.046	1372	52	1989	1995	X	X	X	X	X	X
1.4 Selecta	160 A1.046	1372	52	1991	1995	X	X	X	X	X	X
1.6	160 A2.000	1580	60	1988	1995	X	X	X	X	X	X
1.6 DGT IE	149 C2.046	1585	66	1988	1990	X	X	X	X	X	X
1.6 IE	159 A3.046	1585	56	1990	1995	X	X	X	X	X	X
1.6 IE	835 C1.000	1585	56	1990	1995	X	X	X	X	X	X
1.7 D	149 B4.000	1697	42	1988	1995	X	X	X	X	X	X
1.8 IE	159 A4.000	1756	77	1990	1995	X	X	X	X	X	X
1.8 IE	835 C2.000	1756	77	1990	1995	X	X	X	X	X	X
1.8 IE 16V	160 A5.000	1756	100	1988	1995	X	X	X	X	X	X
1.9 TD	160 A6.000	1929	68	1988	1995	X	X	X	X	X	X
2.0 IE	159 A6.046	1995	107	1990	1995	X	X	X	X	X	X
2.0 IE 16V	160 A8.046	1995	109	1990	1995	X	X	X	X	X	X
2.0 IE 16V	836 A3.000	1995	109	1990	1995	X	X	X	X	X	X
<b>Ulysse 1994 2002</b>											
1.9 TD	XUD9BTF (DHX)	1905	66	1994	2000	X	X	X	X	X	X
1.9 TD	XUD9TF (D8B)	1905	68	1994	2000	X	X	X	X	X	X
2.0	XU10J2 (RFU)	1998	89	1994	2002	X	X	X	X	X	X
2.0 16V	XU10J4R (RFV)	1998	98	1999	2000	X	X	X	X	X	X
2.0 16V CF3	EW10J4 (RFN)	1998	100	2000	2002	X	X	X	X	X	X
2.0 JTD	DW10ATED (RHZ)	1997	80	1999	2000	X	X	X	X	X	X
2.0 JTD 16V	DW10ATED4 (RHW)	1997	80	2000	2002	X	X	X	X	X	X
2.0 Turbo	XU10J2CTE (RGX)	1998	108	1994	2002	X	X	X	X	X	X
2.1 TD	XUD11BTE (P8C)	2088	80	1996	2000	X	X	X	X	X	X
<b>Ulysse 2002</b>											
2.0 16V	EW10J4 (RFN)	1997	100	2002		X	X	X	X	X	X
2.0 JTD 16V	DW10ATED4 (RHW)	1997	80	2002		X	X	X	X	X	X
2.2 JTD 16V	DW12ATED4 (4HW)	2179	94	2002		X	X	X	X	X	X
3.0 V6 24V	ES9J4S (XFW)	2946	150	2002		X	X	X	X	X	X
<b>Uno 1983 1994</b>											
1.3 D	146.B.1000	1301	33	1988	1994	X	X	X	X	X	X
1.4 IE / SELECTA	160.A1.046	1372	51	1989	1994	X	X	X	X	X	X
1.7 D	146.B.2000	1697	43	1989	1994	X	X	X	X	X	X
45	146.A.000/010	903	33	1983	1988	X	X	X	X	X	X
45	156.A.2000	999	32	1985	1988	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>FIAT</b>											
<b>Uno</b>	<b>1983</b>	<b>1994</b>									
45 IE	156.A.2246	999	33	1989	1992	X	X	X	X	X	X
60	146.A.4048	1116	43	1985	1988	X	X	X	X	X	X
60 / 1.1 IE	156.C.046	1108	38	1992	1994	X	X	X	X	X	X
70	149.A.7000	1301	48	1985	1988	X	X	X	X	X	X
70 IE	146.C.1000	1372	51	1990	1994	X	X	X	X	X	X
75 IE (MPI)	138.C.2048	1498	55	1988	1989	X	X	X	X	X	X
75 IE / SELECTA	149.C.1000	1498	55	1990	1994	X	X	X	X	X	X
Turbo IE	146.A.2000	1301	77	1984	1989	X	X	X	X	X	X
Turbo IE	146.A.2046	1301	74	1989	1992	X	X	X	X	X	X
Turbo IE	146.A.8000	1372	82	1989	1994	X	X	X	X	X	X
<b>FORD</b>											
<b>Cougar</b>	<b>1998</b>	<b>2001</b>									
2.0 16V	Zetec-E EBBC	1988	96	1999	1999	X	X	X	X	X	X
2.0 16V	Zetec-E EBBD	1988	96	1999	2000	X	X	X	X	X	X
2.0 16V	Zetec-E EDDBA	1989	96	1998	1999	X	X	X	X	X	X
2.0 16V	Zetec-E EDBB	1988	96	1999	2001	X	X	X	X	X	X
2.5 24V V6	Duratec LCBA	2544	125	1998	1999	X	X	X	X	X	X
2.5 24V V6	Duratec LCBB	2499	125	1999	1999	X	X	X	X	X	X
2.5 24V V6	Duratec LCBC	2499	125	1999	2000	X	X	X	X	X	X
2.5 24V V6	Duratec LCBE	2499	125	2000	2001	X	X	X	X	X	X
2.5 24V V6 (ST200)	Duratec MABA	2499	151	2000	2001	X	X	X	X	X	X
<b>Courier</b>	<b>1996</b>	<b>2002</b>									
1.2 16V	Zetec-SE DHA/B/C/D	1242	55	1996	2002	X	X	X	X	X	X
1.3 8V	Endura-E J4C/J/L	1299	44	1996	2002	X	X	X	X	X	X
1.3 8V	Endura-E JJA/C/E	1299	37	1996	2002	X	X	X	X	X	X
1.4 16V	Zetec-SE FHA/E	1388	66	1996	2002	X	X	X	X	X	X
1.6 16V	Zetec-SE L1T/V	1597	76	1996	2002	X	X	X	X	X	X
1.8 D	Endura-DE RTJ/K	1753	44	1996	2002	X	X	X	X	X	X
<b>Escort</b>	<b>1980</b>	<b>1992</b>									
1.1	GSG/GSG	1117	37	1986	1987	X	X	X	X	X	X
1.3	JLA	1297	44	1986	1990	X	X	X	X	X	X
1.4	FUA	1392	55	1986	1990	X	X	X	X	X	X
1.4i	F6F	1392	52	1987	1990	X	X	X	X	X	X
1.6	LUC	1598	66	1986	1990	X	X	X	X	X	X
1.6	LP2	1597	58	1986	1990	X	X	X	X	X	X
1.6 RS Turbo	LNB	1597	97	1986	1990	X	X	X	X	X	X
1.6 XR3i	LUC	1597	77	1986	1990	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>FORD</b>											
<b>Escort 1980 1992</b>											
1.6D	LTA/LTC	1608	40	1986	1990	X	X	X	X	X	X
1.6i	LJF	1596	77	1990	1990	X	X	X	X	X	X
1.8D	RTD/RTE	1753	44	1988	1990	X	X	X	X	X	X
<b>Escort 1991 2001</b>											
1.3i	ENDURA-E J4B	1298	44	1992	1999	X	X	X	X	X	X
1.3i	HCS J6A	1297	44	1992	1997	X	X	X	X	X	X
1.4i	CVH F6F/F6G	1392	52	1990	1992	X	X	X	X	X	X
1.4i	PTE F4B	1392	55	1992	1999	X	X	X	X	X	X
1.4i	CVH F6F/F6G	1392	52	1990	1992	X	X	X	X	X	X
1.6	CVH LUK/LUJ	1596	66	1990	1992	X	X	X	X	X	X
1.6i	CVH LJF/LJE	1596	77	1990	1992	X	X	X	X	X	X
1.6i	CVH LUK/LUJ	1596	66	1990	1992	X	X	X	X	X	X
1.6i	CVH LJF/LJE	1596	77	1990	1992	X	X	X	X	X	X
1.6i 16V	ZETEC-E L1H	1596	66	1996	1997	X	X	X	X	X	X
1.6i 16V	ZETEC-E L1K	1597	66	1992	1999	X	X	X	X	X	X
1.6i 16V	ZETEC-E L1E	1597	66	1992	1999	X	X	X	X	X	X
1.6i 16V Clipper	ZETEC-E L1E	1597	66	1992	1999	X	X	X	X	X	X
1.6i Cabriolet	CVH LJF/LJE	1596	77	1990	1992	X	X	X	X	X	X
1.8 D	RTD/RTE/F/G/H	1753	44	1990	1999	X	X	X	X	X	X
1.8 D Clipper	RTH	1796	44	1992	1999	X	X	X	X	X	X
1.8 D Stationwagon	RTD/RTE/F/G/H	1753	44	1990	1999	X	X	X	X	X	X
1.8 TD	ENDURA-DE RFD	1753	66	1994	1999	X	X	X	X	X	X
1.8 TD	ENDURA-DE RFK	1753	66	1994	1999	X	X	X	X	X	X
1.8 TD	ENDURA-DE RVA	1753	51	1994	1999	X	X	X	X	X	X
1.8i 16V	ZETEC-E RKC	1796	85	1998	1999	X	X	X	X	X	X
1.8i 16V	ZETEC-E RQB	1796	96	1992	1999	X	X	X	X	X	X
1.8i 16V	ZETEC-E RQB	1796	96	1992	1999	X	X	X	X	X	X
1.8i 16V	ZETEC-E RDA	1796	77	1992	1999	X	X	X	X	X	X
2.0i 16V	DOHC N7A	1998	110	1992	1999	X	X	X	X	X	X
RS 2000	DOHC N7A	1998	110	1992	1999	X	X	X	X	X	X
RS Cosworth	DOHC N5F	1993	162	1990	1994	X	X	X	X	X	X
<b>Fiesta 1995 2002</b>											
1.2i 16V	Zetec-SE DHA	1254	55	1995	2002	X	X	X	X	X	X
1.2i 16V	Zetec-SE DHB	1254	55	1999	2002	X	X	X	X	X	X
1.2i 16V	Zetec-SE DHC	1254	55	1999	2002	X	X	X	X	X	X
1.2i 16V	Zetec-SE DHD	1254	55	1999	2002	X	X	X	X	X	X
1.2i 16V	Zetec-SE DHE	1254	55	2001	2002	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>FORD</b>											
<b>Fiesta</b>	<b>1995</b>	<b>2002</b>									
1.2i 16V	Zetec-SE DHF	1254	55	2001	2002	X	X	X	X	X	X
1.2i 16V	Zetec-SE DHG	1254	55	2001	2002	X	X	X	X	X	X
1.3i	Endura-E IS	1298	37	1995	2002	X	X	X	X	X	X
1.3i	Endura-E J4C	1298	44	1995	2002	X	X	X	X	X	X
1.3i	Endura-E J4J	1298	44	1998	2002	X	X	X	X	X	X
1.3i	Endura-E J4L	1298	44	1999	2002	X	X	X	X	X	X
1.3i	Endura-E J4Q	1289	44	1999	2002	X	X	X	X	X	X
1.3i	Endura-E J4R	1298	44	1999	2002	X	X	X	X	X	X
1.3i	Endura-E J4T	1298	44	1999	2002	X	X	X	X	X	X
1.3i	Endura-E JJA	1298	37	1995	2002	X	X	X	X	X	X
1.3i	Endura-E JJC	1298	37	1998	2002	X	X	X	X	X	X
1.3i	Endura-E JJE	1298	37	1999	2002	X	X	X	X	X	X
1.3i	Endura-E JJJ	1298	37	1999	2002	X	X	X	X	X	X
1.3i	Endura-E JJK	1298	37	1999	2002	X	X	X	X	X	X
1.3i	Endura-E JJM	1298	37	1999	2002	X	X	X	X	X	X
1.4i 16V	Zetec-SE FHA	1388	66	1995	1999	X	X	X	X	X	X
1.4i 16V	Zetec-SE FHC	1388	66	1999	2002	X	X	X	X	X	X
1.4i 16V	Zetec-SE FHE	1388	66	1999	2002	X	X	X	X	X	X
1.6i 16V	Zetec-SE L1T	1595	74	2000	2002	X	X	X	X	X	X
1.6i 16V	Zetec-SE L1V	1595	74	2001	2002	X	X	X	X	X	X
1.8 D	Endura-DE RTJ	1753	44	1995	2002	X	X	X	X	X	X
1.8 D	Endura-DE RTK	1753	44	1995	2002	X	X	X	X	X	X
1.8 D	Endura-DI RTN	1753	55	2000	2002	X	X	X	X	X	X
<b>Fiesta</b>	<b>2002</b>										
1.2 16V	Duratec F8JA	1242	51	2002	2006	X	X	X	X	X	X
1.2 16V	Duratec F8JB	1242	51	2002	2006	X	X	X	X	X	X
1.2 16V	Duratec FUJA	1242	55	2002	2006	X	X	X	X	X	X
1.2 16V	Duratec FUJB	1242	51	2002	2006	X	X	X	X	X	X
1.3 8V	Duratec A9JA	1297	50	2003		X	X	X	X	X	X
1.3 8V	Duratec A9JB	1297	50	2003		X	X	X	X	X	X
1.3 8V	Duratec BAJA	1297	43	2003		X	X	X	X	X	X
1.4 16V	Duratec FXJA	1388	59	2002	2006	X	X	X	X	X	X
1.4 16V	Duratec FXJB	1388	59	2002	2006	X	X	X	X	X	X
1.4 TDCi	Duratorq F6JA	1399	50	2002		X	X	X	X	X	X
1.6 16V	Duratec FYJA	1595	74	2002	2006	X	X	X	X	X	X
1.6 TDCi	Duratorq HHJA	1560	66	2005		X	X	X	X	X	X
1.6 TDCi	Duratorq HHJB	1560	66	2005		X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>FORD</b>											
<b>Fiesta 2002</b>											
2.0 16V	Duratec N4JA	1998	110	2005		X	X	X	X	X	X
2.0 16V	Duratec N4JB	1998	110	2005		X	X	X	X		X
<b>Fiesta 1989 1996</b>											
1.0	HCS TLB	999	33	1989	1995	X	X	X	X	X	X
1.1	HCS GUD/GUE	1118	40	1989	1995	X	X	X	X	X	X
1.1i	HCS G6A	1118	37	1989	1995	X	X	X	X	X	X
1.3i	HCS J6B	1297	44	1989	1995	X	X	X	X	X	X
1.4i	F4A	1392	54	1989	1995	X	X	X	X	X	X
1.6 16V Si	Zetec-E L1E	1597	66	1992	1995	X	X	X	X	X	X
1.6 8V XR2i	CVH LJC/LJD	1597	76	1989	1992	X	X	X	X	X	X
1.6 RS Turbo	CVH LHA	1597	96	1989	1992	X	X	X	X	X	X
1.8 16V XR2i	Zetec-E RQC	1796	96	1992	1995	X	X	X	X	X	X
1.8 D	RTC/RTD/RTG	1753	44	1989	1995	X	X	X	X	X	X
1.8i 16V	Zetec-E RDB	1796	76	1992	1995	X	X	X	X	X	X
<b>Focus 1998 2005</b>											
1.4 16V	Zetec-SE FXDA	1388	55	1998	2001	X	X	X	X	X	X
1.4 16V	Zetec-SE FXDB	1388	55	1998	2001	X	X	X	X	X	X
1.4 16V	Zetec-SE FXDC	1388	55	1998	2001	X	X	X	X	X	X
1.4 16V	Zetec-SE FXDD	1388	55	1998	2001	X	X	X	X	X	X
1.6 16V	Zetec-SE FYDA	1595	74	1998	2000	X	X	X	X	X	X
1.6 16V	Zetec-SE FYDB	1595	74	1998	2001	X	X	X	X	X	X
1.6 16V	Zetec-SE FYDC	1595	74	1998	2000	X	X	X	X	X	X
1.6 16V	Zetec-SE FYDD	1595	74	2001	2005	X	X	X	X	X	X
1.6 16V	Zetec-SE FYDG	1595	74	2000	2005	X	X	X	X	X	X
1.8 16V	Zetec-E EYDA	1796	85	1998	2005	X	X	X	X	X	X
1.8 16V	Zetec-E EYDB	1796	85	2000	2005	X	X	X	X	X	X
1.8 16V	Zetec-E EYDC	1796	85	1998	2005	X	X	X	X	X	X
1.8 16V	Zetec-E EYDE	1796	85	2000	2005	X	X	X	X	X	X
1.8 16V	Zetec-E EYDF	1796	85	2000	2005	X	X	X	X	X	X
1.8 16V	Zetec-E EYDH	1796	85	2000	2005	X	X	X	X	X	X
1.8 16V (LPG)	Zetec-E EYDG	1796	85	2000	2005	X	X	X	X	X	X
1.8 16V (LPG/CNG)	Zetec-E EYDD	1796	85	2000	2005	X	X	X	X	X	X
1.8 TDCi	Duratorq F9DA	1753	85	2000	2005	X	X	X	X	X	X
1.8 TDCi	Duratorq F9DB	1753	85	2000	2005	X	X	X	X	X	X
1.8 TDCi	Duratorq FFDA	1753	74	2002	2005	X	X	X	X	X	X
1.8 TDdi	Endura-DI BHDA	1753	55	1998	2005	X	X	X	X	X	X
1.8 TDdi	Endura-DI BHDB	1753	55	1998	2005	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>FORD</b>											
<b>Focus 1998 2005</b>											
1.8 TDdi	Endura-DI C9DA	1753	66	1998	2005	X	X	X	X	X	X
1.8 TDdi	Endura-DI C9DB	1753	66	1998	2005	X	X	X	X	X	X
1.8 TDdi	Endura-DI C9DC	1753	66	1998	2005	X	X	X	X	X	X
1.8 TDdi	Endura-DI C9DE	1753	66	1998	2005	X	X	X	X	X	X
2.0 16V	Zetec-E EDDA	1988	96	1998	2005	X	X	X	X	X	X
2.0 16V	Zetec-E EDDB	1988	96	2000	2005	X	X	X	X	X	X
2.0 16V	Zetec-E EDDC	1988	96	1998	2005	X	X	X	X	X	X
2.0 16V	Zetec-E EDDD	1988	96	2000	2005	X	X	X	X	X	X
2.0 16V	Zetec-E EDDF	1988	96	1998	2005	X	X	X	X	X	X
2.0 16V	Zetec-E EDDG	1988	96	2000	2005	X	X	X	X	X	X
ST170 2.0 16V	Duratec-ST	1988	127	2002	2005	X	X	X	X	X	X
<b>Focus 2004</b>											
1.4 16V	Duratec ASDA	1388	59	2004		X	X	X	X	N	X
1.4 16V	Duratec ASDB	1388	59	2004		X	X	X	X	N	X
1.6 16V	Duratec HWDA	1596	74	2004		X	X	X	X	N	X
1.6 16V	Duratec HWDB	1596	74	2004		X	X	X	X	N	X
1.6 16V TDCi	Duratorq G8DA	1560	80	2004		X	X	X	X		X
1.6 16V TDCi	Duratorq G8DB	1560	80	2004		X	X	X	X	X	X
1.6 16V Ti-VCT	Duratec HXDA	1596	85	2004		X	X	X	X	N	X
1.8 16V	Duratec-HE QQDB	1798	92	2004		X	X	X	X		X
1.8 16V TDCi	Duratorq KKDA	1753	85	2004		X	X	X	X		X
2.0 16V	Duratec-HE AODA	1998	107	2004		X	X	X	X		X
2.0 16V	Duratec-HE AODB	1998	107	2004		X	X	X	X		X
2.0 16V TDCi	Duratorq G6DA	1998	100	2004		X	X	X	X	X	X
2.0 16V TDCi	Duratorq G6DB	1998	100	2004		X	X	X	X	X	X
2.0 16V TDCi	Duratorq G6DC	1998	98	2004		X	X	X	X	X	X
2.5 20V ST	Duratec HYDA	2522	166	2005		X	X	X	X		X
<b>Focus C-Max 2003</b>											
1.6 16V	Duratec HWDA	1596	74	2003		X	X	X	X		X
1.6 16V Ti-VCT	Duratec HXDA	1596	85	2004		X	X	X	X		X
1.6 TDCi	Duratorq G8DA	1560	80	2003		X	X	X	X	X	X
1.6 TDCi	Duratorq G8DB	1560	80	2003		X	X	X	X		X
1.6 TDCi	Duratorq HHDA	1560	66	2003		X	X	X	X		X
1.8 16V	Duratec-HE CSDA	1798	88	2003		X	X	X	X	X	X
1.8 16V	Duratec-HE CSDB	1798	88	2003		X	X	X	X		X
1.8 16V	Duratec-HE QQDA	1798	92	2004		X	X	X	X		X
1.8 16V	Duratec-HE QQDB	1798	92	2004		X	X	X	X		X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diag. Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diag. Fuses & Relays

**FORD**

**Focus C-Max 2003**

1.8 16V	Duratec-HE QQDC	1798	90	2004		X	X	X	X			X					X
1.8 TDCi	Duratorq KKDA	1753	85	2003		X	X	X	X	N		X				X	X
2.0 16V	Duratec-HE AODA	1998	107	2003		X	X	X	X			X				X	X
2.0 16V	Duratec-HE AODB	1998	107	2004		X	X	X	X			X				X	X
2.0 TDCi	Duratorq G6DA	1998	100	2003		X	X	X	X	X	X	X					X
2.0 TDCi	Duratorq G6DB	1998	100	2004		X	X	X	X			X					X
2.0 TDCi	Duratorq G6DC	1998	98	2004		X	X	X	X			X					X

**Fusion 2002**

1.4 16V	Duratec FXJA	1388	59	2002		X	X	X	X	X	X	X				X	X
1.4 16V	Duratec FXJB	1388	59	2002		X	X	X	X	X	X	X				X	X
1.6 16V	Duratec FYJA	1595	74	2002		X	X	X	X	X	X	X				X	X
1.6 16V	Duratec FYJB	1595	74	2002		X	X	X	X	X	X	X					X

**Galaxy 1995 2000**

1.9 TDi	1Z	1896	66	1996	1996	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	AFN	1896	81	1997	2000	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	AHU	1896	66	1996	1997	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi / PDE	ANU	1896	66	1999	2000	X	X	X	X	X	X	X	X	X	X	X	X
2.0 8V	NSE	1998	85	1995	2000	X	X	X	X	X	X	X	X	X	X	X	X
2.3 16V	Y5B	2295	107	1996	2000	X	X	X	X	X	X	X	X	X	X	X	X
2.8 VR6	AAA	2792	128	1995	1998	X	X	X	X	X	X	X	X	X	X	X	X

**Galaxy 2000 2006**

1.9 TDi	ANU	1896	66	2000		X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	ASZ	1896	96	2003		X	X	X	X			X	X			X	X
1.9 TDi	ASZ1	1896	110	2005		X	X	X	X			X	X			X	X
1.9 TDi	AUY	1896	85	2000		X	X	X	X	X	X	X	X	X	X	X	X
2.0 8V	ZVSA	1998	85	2000		X	X	X	X	X	X	X	X			X	X
2.3 16V	E5SA	2295	107	2000	2003	X	X	X	X	X	X	X	X	X	X	X	X
2.3 16V	E5SB	2295	103	2003		X	X	X	X			X	X			X	X
2.8 VR6	AYL	2792	150	2000		X	X	X	X	X	X	X	X	X	X	X	X

**Galaxy 2006**

1.8 TDCi	Duratorq FFWA	1753	74	2006		X	X	X		X		X	X			N	X
1.8 TDCi	Duratorq QYWA	1753	92	2006		X	X	X		X		X	X			N	X
2.0 16V	Duratec A0WA	1998	107	2006		X	X	X		X		N	X			N	X
2.0 TDCi	Duratorq AZWA	1998	96	2006		X	X	X		X		X	X			N	X
2.0 TDCi	Duratorq QXWA	1998	105	2006		X	X	X		X		X	X			N	X
N 2.3 16V	Duratec SEWA	2261	118	2007		N	N	N		N		N					

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>FORD</b>													
<b>Ka 1997</b>													
1.3 8V	Duratec A9A	1297	51	2002		X	X	X	X	X	X	X	X
1.3 8V	Duratec A9B	1297	51	2002		X	X	X	X	X	X	X	X
1.3 8V	Duratec BAA	1297	44	2002		X	X	X	X	X	X	X	X
1.3 8V	Endura-E J4D	1299	44	1997	2002	X	X	X	X	X	X	X	X
1.3 8V	Endura-E J4M	1299	44	1999	2002	X	X	X	X	X	X	X	X
1.3 8V	Endura-E JJB	1299	37	1997	2001	X	X	X	X	X	X	X	X
1.3 8V	Endura-E JJF	1299	37	1999	2002	X	X	X	X	X	X	X	X
SportKa 1.6 8V	Duratec CDC	1597	70	2002		X	X	X	X	X	X	X	X
SportKa 1.6 8V	Duratec CDB	1597	70	2002		X	X	X	X	X	X	X	X
<b>Maverick 1993 2001</b>													
2.4i	K24E	2389	91	1993	1996	X	X		X	X	X	X	X
2.7 TD	TD27	2663	74	1993	1996	X	X		X	X		X	X
<b>Mondeo 1993 1997</b>													
1.6 16V	L1	1597	66	1993	1997	X	X	X	X	X	X	X	X
1.8 16V	RK	1796	84	1993	1997	X	X	X	X	X	X	X	X
1.8 TD	RF	1753	65	1993	1997	X	X	X	X	X	X	X	X
2.0 16V	NG	1988	102	1993	1997	X	X	X	X	X	X	X	X
2.0 16V 4x4	NG	1988	102	1994	1997	X	X	X	X	X	X	X	X
2.5 24V V6	SEA	2544	160	1994	1997	X	X	X	X	X	X	X	X
<b>Mondeo 1997 2000</b>													
1.6 16V	L1J	1597	66	1997	1998	X	X	X	X	X	X	X	X
1.6 16V	L1L	1597	70	1998	2001	X	X	X	X	X	X	X	X
1.6 16V	L1N	1597	70	1998	2001	X	X	X	X	X	X	X	X
1.6 16V	L1Q	1597	70	1998	2001	X	X	X	X	X	X	X	X
1.8 16V	RKF	1796	85	1998	2001	X	X	X	X	X	X	X	X
1.8 16V	RKH	1796	85	1998	2001	X	X	X	X	X	X	X	X
1.8 16V	RKJ	1796	85	1998	2001	X	X	X	X	X	X	X	X
1.8 16V	RKK	1796	85	1998	2001	X	X	X	X	X	X	X	X
1.8 16V	RKB	1796	85	1997	1998	X	X	X	X	X	X	X	X
1.8 TD TCi	RFN	1753	66	1997	2001	X	X	X	X	X	X	X	X
2.0 16V	NGA	1988	96	1997	1998	X	X	X	X	X	X	X	X
2.0 16V	NGB	1988	96	1998	2001	X	X	X	X	X	X	X	X
2.0 16V	NGC	1988	96	1998	2001	X	X	X	X	X	X	X	X
2.0 16V	NGD	1988	96	1998	2001	X	X	X	X	X	X	X	X
2.5 24V V6	SEA	2544	125	1997	2000	X	X	X	X	X	X	X	X
2.5 24V V6	SEB	2499	125	2000	2000	X	X	X	X	X	X	X	X
2.5 24V V6	SEC	2499	125	2000	2001	X	X	X	X	X	X	X	X



Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagram	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagram	
<b>FORD</b>													
<b>N Mondeo 2007</b>													
N	1.6 16V Ti-VCT	Duratec PNBA	1596	92	2007	N	N	N	N	N	N	N	N
N	1.6 16V Ti-VCT	Duratec RHBA	1596	81	2007	N	N	N	N	N	N	N	N
N	1.8 TDCi 16V	Duratorq FFBA	1753	74	2007	N	N	N	N	N	N	N	N
N	1.8 TDCi 16V	Duratorq QYBA	1753	92	2007	N	N	N	N	N	N	N	N
N	2.0 16V	Duratec-HE A0BA	1998	107	2007	N	N	N	N	N	N	N	N
N	2.0 TDCi 16V DPF	Duratorq AZBA	1998	96	2007	N	N	N	N	N	N	N	N
N	2.0 TDCi 16V DPF	Duratorq QXBA	1998	103	2007	N	N	N	N	N	N	N	N
N	2.3 16V	Duratec-HE SEBA	2261	118	2007	N	N	N	N	N	N	N	N
N	2.5 20V	Duratec-ST HUBA	2522	162	2007	N	N	N	N	N	N	N	N
<b>Mondeo 2000 2007</b>													
	1.8 16V	Duratec-HE CGBA	1796	81	2000	2007	X	X	X	X	X	X	X
	1.8 16V	Duratec-HE CGBB	1796	81	2000	2007	X	X	X	X	X	X	X
	1.8 16V	Duratec-HE CHBA	1796	92	2000	2007	X	X	X	X	X	X	X
	1.8 16V	Duratec-HE CHBB	1796	92	2000	2007	X	X	X	X	X	X	X
	1.8 SCi 16V	Duratec-SCi CFBA	1798	96	2003	2005	X	X	X	X	X	X	X
	2.0 16V	Duratec-HE CJBA	1999	107	2000	2007	X	X	X	X	X	X	X
	2.0 16V	Duratec-HE CJBB	1999	107	2000	2007	X	X	X	X	X	X	X
	2.0 16V TDCi	Duratorq FMBA	1998	96	2001	2007	X	X	X	X	X	X	X
	2.0 16V TDCi	Duratorq FMBB	1998	96	2001	2007	X	X	X	X	X	X	X
	2.0 16V TDCi	Duratorq HJBA	1998	85	2002	2007	X	X	X	X	X	X	X
	2.0 16V TDCi	Duratorq HJBC	1998	85	2002	2007	X	X	X	X	X	X	X
	2.0 16V TDCi	Duratorq N7BA	1998	96	2001	2007	X	X	X	X	X	X	X
	2.0 16V TDdi	Duratorq-Di D5BA	1998	66	2000	2007	X	X	X	X	X	X	X
	2.0 16V TDdi	Duratorq-Di D6BA	1998	85	2000	2003	X	X	X	X	X	X	X
	2.2 16V TDCi	Duratorq QJBA	2198	114	2004	2007	X	X	X	X	X	X	X
	2.2 16V TDCi	Duratorq QJBB	2198	114	2004	2007	X	X	X	X	X	X	X
	2.5 V6 24V	Duratec-VE LCBD	2499	125	2000	2007	X	X	X	X	X	X	X
	3.0 V6 24V	Duratec-SE REBA	2967	150	2003	2007	X	X	X	X	X	X	X
	ST220 (3.0 V6 24V)	Duratec-ST MEBA	2967	166	2003	2007	X	X	X	N	X	X	X
<b>Orion 1983 1990</b>													
	1.3	JPA	1296	51	1983	1986	X	X	X	X	X	X	X
	1.4	FUA	1392	55	1986	1990	X	X	X	X	X	X	X
	1.6	LP2	1597	58	1986	1990	X	X	X	X	X	X	X
	1.6	LPA	1597	58	1983	1986	X	X	X	X	X	X	X
	1.6	LRA/LRB	1598	77	1983	1986	X	X	X	X	X	X	X
	1.6D	LTC	1605	40	1983	1986	X	X	X	X	X	X	X
	1.6i	LR2/LRB	1598	77	1986	1990	X	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>FORD</b>													
<b>Orion</b>	<b>1983</b>	<b>1990</b>											
1.6i	L4B	1597	66	1986	1990	X	X	X	X	X	X	X	X
1.8D	RTE/RTF/RTH	1753	44	1988	1990	X	X	X	X	X	X	X	X
<b>Orion</b>	<b>1990</b>	<b>1993</b>											
1.3i	J6A	1264	44	1990	1993	X	X	X	X	X	X	X	X
1.4	FUH	1392	54	1990	1992	X	X	X	X	X	X	X	X
1.4i	F6F/F6G	1392	52	1990	1993	X	X	X	X	X	X	X	X
1.6i 16V	L1E	1597	66	1992	1993	X	X	X	X	X	X	X	X
<b>Puma</b>	<b>1997</b>	<b>2002</b>											
1.4 16V	Zetec-SE FHD	1388	66	1998	2002	X	X	X	X	X	X	X	X
1.4 16V	Zetec-SE FHF	1388	66	1999	2002	X	X	X	X	X	X	X	X
1.6 16V	Zetec-SE L1W	1595	76	2001	2002	X	X	X	X	X	X	X	X
1.7 16V	Zetec-S VCT MHA	1679	92	1997	2002	X	X	X	X	X	X	X	X
1.7 16V	Zetec-S VCT MHB	1679	92	1999	2002	X	X	X	X	X	X	X	X
<b>Ranger</b>	<b>2001</b>	<b>2007</b>											
2.2	F2	2184	68	1999	2005	X	X	X	X	X	X	X	X
2.5 D	WL	2499	57	1999	2002	X	X	X	X	X	X	X	X
2.5 D	WL-3	2499	62	2001	2007	X	X	X	X	X	X	X	X
2.5 TD	WL-T	2499	80	1999	2007	X	X	X	X	X	X	X	X
2.5 TD	WLT-3	2499	80	2001	2007	X	X	X	X	X	X	X	X
2.6	G6	2606	90	1999	2005	X	X	X	X	X	X	X	X
<b>Scorpio</b>	<b>1994</b>	<b>2000</b>											
2.0i	NSD	1998	85	1994	2000	X	X	X	X	X	X	X	X
2.0i 16V	N3A	1988	100	1994	2000	X	X	X	X	X	X	X	X
2.3i 16V	Y5A	2295	108	1996	2000	X	X	X	X	X	X	X	X
2.5TD	SCB	2500	85	1994	2000	X	X	X	X	X	X	X	X
2.9i V6	BRG	2935	110	1994	2000	X	X	X	X	X	X	X	X
2.9i V6 24V	BOB	2935	152	1994	2000	X	X	X	X	X	X	X	X
<b>Scorpio Granada</b>	<b>1985</b>	<b>1994</b>											
1.8	REC	1796	66	1985	1988	X	X	X	X	X	X	X	X
2.0	N8B/N8D	1998	77	1989	1994	X	X	X	X	X	X	X	X
2.0	N9D/N9B	1998	88	1989	1994	X	X	X	X	X	X	X	X
2.0	NRA/NRC	1993	74	1985	1989	X	X	X	X	X	X	X	X
2.0	NEL/NER	1993	77	1985	1989	X	X	X	X	X	X	X	X
2.4i	ARC	2394	96	1986	1989	X	X	X	X	X	X	X	X
2.4i	PRC/ARD	2394	92	1990	1994	X	X	X	X	X	X	X	X
2.4i kat	ARV/ARD	2394	92	1990	1994	X	X	X	X	X	X	X	X
2.5TD	SFA	2499	68	1989	1994	X	X	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays			
<b>FORD</b>														
<b>Scorpio Granada 1985 1994</b>														
2.5TD	STR SCB	2500	85	1992	1994	X	X	X	X	X	X	X	X	X
2.8i 4x4	PRE	2792	110	1985	1987	X	X	X	X	X	X	X	X	X
2.9i	BRF/BRE	2935	107	1992	1994	X	X	X	X	X	X	X	X	X
2.9i 24V Cosworth	BOA	2935	143	1993	1994	X	X	X	X	X	X	X	X	X
2.9i 24V Cosworth	BOA	2936	143	1991	1994	X	X	X	X	X	X	X	X	X
2.9i 4x4	BRC/BRD	2933	110	1986	1994	X	X	X	X	X	X	X	X	X
<b>Sierra 1982 1989</b>														
1.3	JCT	1294	44	1982	1986	X	X	X	X	X	X	X	X	X
1.6	LSA/LSE/LSF	1597	55	1987	1989	X	X	X	X	X	X	X	X	X
1.6	LCS/LSD	1593	55	1982	1987	X	X	X	X	X	X	X	X	X
1.8	REB/REC/RED	1796	66	1984	1989	X	X	X	X	X	X	X	X	X
1.8i	R2A/R2C	1796	66	1988	1989	X	X	X	X	X	X	X	X	X
2.0	NET/NES	1993	77	1982	1989	X	X	X	X	X	X	X	X	X
2.0i	N4A/NRA	1993	85	1985	1989	X	X	X	X	X	X	X	X	X
2.3 V6	YYT	2294	84	1982	1986	X	X	X	X	X	X	X	X	X
2.3D	XD2P/YTT	2304	49	1982	1989	X	X	X	X	X	X	X	X	X
2.8 XR4i	PRT	2792	110	1982	1985	X	X	X	X	X	X	X	X	X
<b>Sierra 1989 1993</b>														
1.6	LSE	1597	52	1989	1993	X	X	X	X	X	X	X	X	X
1.6i	L6B	1597	59	1989	1993	X	X	X	X	X	X	X	X	X
1.8TD	RFA	1753	55	1989	1993	X	X	X	X	X	X	X	X	X
2.0	N8C	1998	77	1989	1993	X	X	X	X	X	X	X	X	X
2.0i	N9C	1998	88	1989	1993	X	X	X	X	X	X	X	X	X
2.0i 4x4	N9A	1998	92	1989	1993	X	X	X	X	X	X	X	X	X
2.0i 4x4	N9C	1998	88	1989	1993	X	X	X	X	X	X	X	X	X
2.9 XR4x4	B4A	2933	110	1989	1993	X	X	X	X	X	X	X	X	X
2.9 XR4x4	BRD/B4B	2933	107	1989	1993	X	X	X	X	X	X	X	X	X
RS Cosworth 4x4	N5A	1993	162	1989	1993	X	X	X	X	X	X	X	X	X
<b>S-Max 2006</b>														
1.8 TDCi	Duratorq QYWA	1753	92	2006		X	X	X	X	N	X	X	N	X
2.0 16V	Duratec AOWA	1998	107	2006		X	X	X	X	N	X	X	N	X
2.0 TDCi	Duratorq AZWA	1998	96	2006		X	X	X	X	N	X	X	N	X
2.0 TDCi	Duratorq QXWA	1998	105	2006		X	X	X	X	N	X	X	N	X
N 2.3 16V	Duratec SEWA	2261	118	2007		N	N	N	N	N	X	X	N	X
2.5 20V ST	Duratec HYDA	2522	166	2006		X	X	X	X	N	X	X	X	X
<b>Transit 1986 1992</b>														
1.6	LAC	1593	46	1986	1992	X	X	X	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>FORD</b>													
<b>Transit</b>	<b>1986</b>	<b>1992</b>											
1.6	LAT	1593	46	1986	1992	X	X	X	X	X		X	X
2.0	N6T	1994	57	1986	1992	X	X	X	X	X		X	X
2.0	N6TS	1994	60	1986	1992	X	X	X	X				X
2.0	NAT	1994	57	1986	1992	X	X	X	X	X		X	X
2.0	NAV	1994	55	1986	1992	X	X	X	X	X		X	X
2.0	NAW	1994	56	1986	1992	X	X	X	X				X
2.0	NAX	1994	56	1986	1992	X	X	X	X				X
2.5 D	4AB	2496	50	1986	1992	X	X	X	X	X		X	X
2.5 TD	4AE	2496	60	1986	1992	X	X	X	X				X
<b>Transit</b>	<b>1992</b>	<b>1995</b>											
2.0	NBA	1994	66	1992	1995	X	X	X	X	X		X	X
2.0	NCA	1994	72	1992	1995	X	X	X	X	X	X	X	X
2.5 D	4BC	2496	52	1992	1995	X	X	X	X	X		X	X
2.5 D	4DA	2496	59	1992	1995	X	X	X	X	X		X	X
2.5 D	4EA	2496	74	1992	1995	X	X	X	X	X		X	X
2.5 D	4FA	2496	52	1992	1995	X	X	X	X	X		X	X
2.5 D	4GA	2496	63	1992	1995	X	X	X	X	X		X	X
2.9	BRT	2936	107	1992	1995	X	X	X	X	X	X	X	X
<b>Transit</b>	<b>1995</b>	<b>2001</b>											
2.0	DOHC NSF	1998	84	1995	2001	X	X	X	X	X	X	X	X
2.0	DOHC NSG	1998	84	1995	2001	X	X	X	X	X	X	X	X
2.5 D	4FA	2496	51	1995	2001	X	X	X	X	X	X	X	X
2.5 D	4FB	2496	51	1995	2001	X	X	X	X	X	X	X	X
2.5 D	4FC	2496	51	1995	2001	X	X	X	X	X	X	X	X
2.5 D	4FD	2496	51	1997	2001	X	X	X	X	X	X	X	X
2.5 D	4HB	2496	56	1995	2001	X	X	X	X	X	X	X	X
2.5 TCI	4GD	2496	63	1995	2001	X	X	X	X	X	X	X	X
2.5 TD	4EB	2496	74	1995	1997	X	X	X	X	X	X	X	X
2.5 TD	4EC	2496	74	1997	2001	X	X	X	X	X	X	X	X
2.5 TD	4ED	2496	85	1995	2001	X	X	X	X	X	X	X	X
2.5 TD	4GA	2496	63	1995	2001	X	X	X	X	X	X	X	X
2.5 TD	4GB	2496	63	1995	2001	X	X	X	X	X	X	X	X
2.5 TD	4GC	2496	63	1995	2001	X	X	X	X	X	X	X	X
<b>Transit</b>	<b>2006</b>												
2.2 TDCi 110	Duratorq QVFA	2198	81	2006		X	X	X	X	N	X		
2.2 TDCi 130	Duratorq QWFA	2198	96	2006		X	X	X	X	N	X		
2.2 TDCi 85	Duratorq P8FA	2198	62	2006		X	X	X	X	N	X		

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>FORD</b>											
<b>Transit 2006</b>											
2.3 16V	Duratec GZFA	2261	107	2006		X	X X	X X		N X	
2.3 16V	Duratec GZFB	2261	107	2006		X	X X	X X		N X	
2.4 TDCi 100	Duratorq PHFA	2402	74	2006		X	X X	X X N		N X	
2.4 TDCi 115	Duratorq JXFA	2402	85	2006		X	X X	X X N		N X	
2.4 TDCi 140	Duratorq H9FB	2402	103	2006		X	X X	X X N		N X	
<b>Transit 2000 2007</b>											
2.0 TDCi 125	Duratorq F1FA	1998	92	2002	2007	X	X X	X X		X X	
2.0 TDDi 100	Duratorq ABFA	1998	74	2000	2007	X	X X	X X X	X	X X	X X
2.0 TDDi 75	Duratorq D3FA	1998	55	2000	2007	X	X X	X X X	X	X X	X X
2.0 TDDi 85	Duratorq F3FA	1998	63	2000	2007	X	X X	X X X	X	X X	X X
2.3 16V	E5FA	2295	107	2000	2007	X	X X	X X X	X	X X	X X
2.4 TDCi 135	Duratorq H9FA	2402	101	2004	2007	X	X X	X X		N X	
2.4 TDDi 115	Duratorq FXFA	2402	85	2004	2007	X	X X	X X		X	
2.4 TDDi 120	Duratorq D4FA	2402	88	2000	2004	X	X X	X X X	X	X X	X X
2.4 TDDi 120	Duratorq HFFA	2402	88	2000	2007	X	X X	X X X	X	X X	X X
2.4 TDDi 125	Duratorq DOFA	2402	92	2002	2007	X	X X	X X		X	
2.4 TDDi 75	Duratorq F4FA	2402	55	2000	2007	X	X X	X X X	X	X X	X X
2.4 TDDi 90	Duratorq D2FA	2402	66	2000	2007	X	X X	X X X	X	X X	X X
2.4 TDDi 90	Duratorq D2FB	2402	66	2000	2007	X	X X	X X X	X	X X	X X
2.4 TDDi 90	Duratorq HEFA	2402	66	2000	2007	X	X X	X X X	X	X X	X X
<b>Transit Connect Tourneo 2003</b>											
1.8 16V	Duratec EYPA	1796	85	2003		X	X X	X X		X	X
1.8 TDCi	Duratorq HCPA	1753	66	2003		X	X X	X X X	X	X	
1.8 TDDi	Duratorq BHPA	1753	55	2003		X	X X	X X		X	
<b>HONDA</b>											
<b>Accord 1985 1989</b>											
1.6	A16A1	1598	65	1985	1989	X	X X	X X		X	X
2.0	A20A1	1955	78	1985	1989	X	X X	X X		X	X
2.0 16V	B20A8	1958	101	1985	1989	X	X X	X X		X	X
2.0i	F20A4	1955	100	1985	1989	X	X X	X X	X		X
2.0i	A20A4	1955	89	1985	1989	X	X X	X X		X	X
<b>Accord 1989 1993</b>											
2.0	F20A	1996	81	1989	1993	X	X X	X X		X	X
2.0i	F20A	1996	98	1989	1993	X	X X	X X		X	X
2.0i	F20A	1996	110	1989	1993	X	X X	X X		X	X
2.2i	F22A3	2155	110	1989	1993	X	X X	X X		X	X

All Cars 2008Q2

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>HONDA</b>													
<b>Accord</b>	<b>1993</b>	<b>1999</b>											
1.8i	F18A3	1850	85	1996	1999	X	X	X	X	X	X	X	X
2.0i 16V	F20Z1	1997	96	1993	1999	X	X	X	X	X	X	X	X
2.0i 16V	F20Z2	1997	85	1993	1996	X	X	X	X	X	X	X	X
2.2i 16V	F22B5	2156	110	1994	1999	X	X	X	X	X	X	X	X
2.3i 16V	H23A3	2259	116	1993	1996	X	X	X	X	X	X	X	X
<b>Accord</b>	<b>1999</b>	<b>2003</b>											
1.6 16V	D16B6	1590	85	1999	2003	X	X	X	X	X		X	X
1.6 16V	D16B7	1590	85	1999	2003	X	X	X	X	X			N
1.8 16V	F18B2	1850	100	1999	2001	X	X	X	X	X		X	X
1.8 16V	F18B3	1850	100	1999	2003	X	X	X	X	X			N
1.8 16V	F18B4	1850	100	1999	2003	X	X	X	X	X			N
2.0 16V	F20B6	1997	108	1999	2002	X	X	X	X	X		X	X
2.0 TD	20T2N	1994	77	1999	2002	X	X	X	X	X		X	X
2.2 16V Type R	H22A7	2157	157	1999	2003	X	X	X	X	X		X	X
2.3 16V	F23Z5	2254	113	2000	2003	X	X	X	X	X			
<b>Accord</b>	<b>2003</b>												
2.0 16V	K20A6	1998	114	2003	2006	X	X	X	X	X		X	X
2.0 16V	K20Z2	1998	114	2006		X	X	X	X	X			
2.2 i-CTDi	N22A1	2204	103	2004		X	X	X	X	X		X	
2.4 16V	K24A3	2354	140	2003		X	X	X	X	X		X	X
<b>Civic</b>	<b>1995</b>	<b>2001</b>											
1.4i	D14A3	1396	55	1996	1999	X	X	X	X	X		X	X
1.4i	D14A4	1396	66	1996	1999	X	X	X	X	X		X	X
1.4i	D14A5	1395	55	1995	1997	X	X	X	X	X		X	X
1.4i	D14A7	1396	55	1997	2001	X	X	X	X	X			N
1.4i	D14A8	1396	66	1997	2001	X	X	X	X	X			N
1.4i	D14Z1	1396	55	1999	2001	X	X	X	X	X			N
1.4i	D14Z2	1396	66	1999	2001	X	X	X	X	X			N
1.4i	D14Z3	1396	55	1999	2001	X	X	X	X	X			N
1.4i	D14Z4	1396	66	1999	2001	X	X	X	X	X			N
1.4i S	D14A2	1396	66	1995	1997	X	X	X	X	X		X	X
1.5i LS	D15Z6	1493	84	1996	2001	X	X	X	X	X		X	X
1.5i VE	D15Z3	1493	66	1995	1997	X	X	X	X	X		X	X
1.5i VTEC	D15Z8	1493	84	1997	2001	X	X	X	X	X			N
1.6 VTi	B16A2	1595	118	1996	2001	X	X	X	X	X		X	X
1.6i	D16W3	1590	85	1999	2001	X	X	X	X	X			N
1.6i ES	D16Y5	1590	84	1996	2001	X	X	X	X	X		X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>HONDA</b>											
<b>Civic 1995 2001</b>											
1.6i LS	D16Y3	1590	83	1995	1997	X	X	X	X	X	X
1.6i LS	D16Y7	1590	77	1996	2001	X	X	X	X	X	X
1.6i SR	D16B2	1590	85	1997	2001	X	X	X	X	X	N
1.6i SR	D16Y2	1590	93	1995	1997	X	X	X	X	X	X
1.6i SR	D16Y8	1590	92	1996	2001	X	X	X	X	X	X
1.6i VTEC	D16W4	1590	92	1999	2001	X	X	X	X	X	N
1.8 VTi	B18C4	1797	124	1997	2001	X	X	X	X	X	N
2.0i TD	20T2N	1994	77	1998	2001	X	X	X	X	X	N
2.0i TD	20T2R	1994	63	1997	2001	X	X	X	X	X	N
<b>Civic 2006</b>											
1.4	L13A7	1339	61	2006		X	X	X	X	X	
1.8 16V i-Vtec	R18A2	1799	103	2006		X	X	X	X	X	
2.0 16V Type R	K20Z4	1998	148	2007		X	X	X	X	X	
2.2 16V i-CDTi	N22A2	2204	103	2007		X	X	X	X	X	
<b>Civic 1987 1991</b>											
1.3	D13B1	1343	55	1987	1991	X	X	X	X	X	X
1.5	D15B1	1493	69	1987	1991	X	X	X	X	X	X
1.6i	D16A6	1590	80	1987	1991	X	X	X	X	X	X
1.6i	D16A9	1590	95	1987	1991	X	X	X	X	X	X
1.6i 16V	D16Z5	1590	91	1987	1991	X	X	X	X	X	X
1.6i 4x4	D16A6	1590	79	1987	1991	X	X	X	X	X	X
1.6i VTEC	B16A	1590	118	1989	1991	X	X	X	X	X	X
<b>Civic 1991 1995</b>											
1.3 16V	D13B2	1343	55	1991	1995	X	X	X	X	X	X
1.5i 16V	D15B2	1493	66	1991	1995	X	X	X	X	X	X
1.5i 16V	D15B7	1493	75	1994	1995	X	X	X	X	X	X
1.6i 16V	D16Z6	1590	92	1991	1995	X	X	X	X	X	X
1.6i 16V	B16A2	1590	118	1991	1995	X	X	X	X	X	X
<b>Civic 2001 2006</b>											
1.4 16V	D14Z5	1396	66	2001	2006	X	X	X	X	X	X
1.4 16V	D14Z6	1493	66	2001	2006	X	X	X	X	X	X
1.5 16V	D15Y3	1493	68	2001	2006	X	X	X	X	X	X
1.6 16V VTEC	D16V1	1590	81	2001	2006	X	X	X	X	X	X
1.6 16V VTEC	D16W7	1590	81	2001	2006	X	X	X	X	X	X
1.7 16V	D17A3	1668	88	2001	2006	X	X	X	X	X	X
1.7 16V	D17A8	1668	88	2001	2006	X	X	X	X	X	X
1.7 16V CTDi	4EE2	1686	74	2002	2006	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>HONDA</b>											
<b>Civic 2001 2006</b>											
1.7 16V VTEC	D17A2	1668	92	2001	2006	X	X	X	X	X	X
1.7 16V VTEC	D17A4	1668	92	2001	2006	X	X	X	X	X	X
1.7 16V VTEC	D17A9	1668	92	2001	2006	X	X	X	X	X	X
2.0 16V iVTEC	K20A3	1998	118	2003	2006	X	X	X	X	X	X
2.0 16V iVTEC Type R	K20A2	1998	147	2001	2006	X	X	X	X	X	X
<b>Civic Hybrid 2003 2006</b>											
1.3 IMA	LDA1 + MF3	1339	66	2003	2006	X	X	X	X		
<b>Civic Hybrid 2006</b>											
1.3 IMA	LDA2 + MF5	1339	70	2006		X	X	X	X		
<b>Civic Shuttle 1988 1991</b>											
1.4	D14A1	1396	66	1988	1991	X	X	X	X	X	X
1.5 4WD	D15A7	1488	66	1988	1991	X	X	X	X	X	X
1.6i 4WD	D16A7	1590	80	1988	1991	X	X	X	X	X	X
<b>Concerto 1989 1994</b>											
1.4	D14A1	1396	65	1989	1994	X	X	X	X	X	X
1.5	D15B2	1493	67	1989	1994	X	X	X	X	X	X
1.6	D16Z1	1590	77	1989	1994	X	X	X	X	X	X
1.6 4x4	D16Z1	1590	77	1989	1994	X	X	X	X	X	X
1.6i	D16A8	1590	88	1989	1994	X	X	X	X	X	X
<b>CR-V 1997 2002</b>											
2.0i 16V	B20B1	1972	94	1997	2002	X	X	X	X	X	X
2.0i 16V	B20B3	1972	92	1997	2002	X	X	X	X	X	X
2.0i 16V	B20B9	1972	92	1997	2002	X	X	X	X	X	X
2.0i 16V	B20Z1	1972	92	1997	2002	X	X	X	X	X	X
<b>CR-V 2002 2007</b>											
2.0 16V	K20A4	1998	110	2002	2007	X	X	X	X	X	X
2.0 16V	K20A5	1998	110	2002	2007	X	X	X	X	X	X
2.2 16V i-CTDi	N22A2	2204	103	2005	2007	X	X	X	X	X	X
2.4 16V	K24A1	2354	116	2002	2007	X	X	X	X	X	X
<b>CRX 1992 1999</b>											
1.5i 16V	D15B7	1493	76	1992	1999	X	X	X	X	X	X
1.6i 16V	B16A2	1590	118	1992	1999	X	X	X	X	X	X
1.6i 16V	D16Z6	1590	92	1992	1999	X	X	X	X	X	X
<b>FR-V 2005</b>											
1.7 16V	D17A2	1668	92	2005	2007	X	X	X	X	X	X
1.8 16V	R18A1	1799	103	2007		X	X	X	X	X	X



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>HONDA</b>													
<b>FR-V 2005</b>													
2.0 16V	K20A9	1998	110	2005	2007	X	X	X	X	X		X	X
2.2 16V i-CTDi	N22A1	2204	103	2006		X	X	X	X	X			X
<b>HR-V 1999 2006</b>													
1.6i SOHC	D16W1	1590	77	1999	2006	X	X	X	X	X		X	X
1.6i SOHC VTEC	D16W5	1590	91	2000	2006	X	X	X	X	X		X	X
<b>Insight 2000 2005</b>													
1.0i VTec 12V	ECA1 + MF2	995	57	2000	2005	X	X	X		X		X	X
<b>Integra 1985 1989</b>													
1.5	D15A1	1488	56	1985	1989	X	X	X	X	X		X	X
1.6	D16A2	1590	88	1985	1989	X	X	X	X	X		X	X
<b>Jazz 2001</b>													
1.2	L12A1	1246	57	2001		X	X	X	X	X		X	X
1.4	L13A1 / L13A2	1339	61	2001		X	X	X	X	X		X	X
<b>Legend 1987 1990</b>													
2.5 V6	C25A2	2494	127	1987	1990	X	X	X	X	X		X	X
2.7 V6	C27A1	2675	132	1987	1990	X	X	X	X	X		X	X
<b>Legend 1990 1996</b>													
3.2i V6	C32A	3206	151	1990	1996	X	X	X		X		X	X
<b>Logo 1999 2002</b>													
1.3	D13B7	1343	49	1999	2002	X	X	X		X		X	X
<b>Prelude 1987 1991</b>													
2.0	B20A4	1958	81	1987	1991	X	X	X	X	X		X	X
<b>Prelude 1991 1997</b>													
2.0i 16V	F20A4	1996	98	1991	1997	X	X	X	X	X		X	X
2.2i 16V VTEC	H22A	2156	136	1991	1997	X	X	X	X	X		X	X
2.3i 16V	H23A2	2259	118	1991	1997	X	X	X	X	X		X	X
<b>S2000 1999</b>													
2.0 16V	F20C2	1997	177	1999		X	X	X		X			N
<b>Stream 2001 2006</b>													
1.7 iVTEC	D17A2	1668	93	2001	2006	X	X	X	X	X		X	X
2.0 iVTEC	K20A1	1998	116	2001	2006	X	X	X	X	X		X	X
<b>HYUNDAI</b>													
<b>Accent 1998 2003</b>													
1.3	G4EF	1341	63	1998	2003	X	X	X	X	X		X	X
1.5 CRDi	D3EA	1493	60	2002	2003	X	X	X	X	X		X	X
1.5 DOHC	G4EB	1495	75	1998	2003	X	X	X	X	X		X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>HYUNDAI</b>											
<b>Accent 1998 2003</b>											
1.5 SOHC	G4EG	1495	66	1998	2003	X	X	X	X	X	X
<b>Accent Pony, Excel 1994 1998</b>											
1.3i	G4EH	1341	62	1994	1998	X	X	X	X	X	X
1.5i	G4EK	1495	65	1994	1998	X	X	X	X	X	X
1.5i 16V	G4FK	1495	73	1995	1998	X	X	X	X	X	X
<b>Atos 2004</b>											
1.1 12V	G4HD	1085	46	2004		N	N	N		N	
<b>Atos Atoz 1998 2004</b>											
1.0 12V	G4HC	999	40	1998	2002	X	X	X	X	X	X
1.0 12V	G4HC-E	999	43	2002	2004	X	N	N	X	N	X
<b>Coupe Tiburon 1996 2001</b>											
1.6	G4GR	1599	84	1996	2001	X	X	X	X	X	X
2.0	G4GF	1975	102	1996	2001	X	X	X	X	X	X
<b>Coupe Tiburon 2002</b>											
1.6	G4GC	1599	77	2002		X	X	X	X	X	
2.0	G4AC	1975	102	2002		X	X	X	X	X	
2.7 V6	G6BA	2656	123	2002		X	X	X	X	X	X
<b>Elantra 1999 2007</b>											
1.6 16V	G4ED	1599	77	1999	2007	X	X	X	X	X	X
1.8 16V	G4GB	1796	90	1999	2007	X	X	X	X	X	X
2.0 16V	G4GC	1975	104	1999	2007	X	X	X	X	X	X
2.0 CRDi	D4EA	1991	83	2001	2007	X	N	N	X	N	
<b>Excel 1989 1994</b>											
1.5	G4D	1468	53	1989	1992	X	X	X	X	X	X
1.5i	G4D	1468	62	1989	1994	X	X	X	X	X	X
<b>Getz 2002</b>											
1.1	G4HD	1085	46	2002	2005	X	X	X	X	X	X
1.1	G4HD	1085	49	2005		X	X	X	X	X	
1.3	G4EA	1341	60	2002	2005	X	X	X	X	X	X
1.4 16V	G4HE	1399	71	2005		X	X	X	X	X	
1.5 16V	G4EK	1495	77	2002	2005	X	X	X	X	X	X
1.5 CRDi	D3EA	1493	60	2003	2005	X	X	X	X	X	X
1.5 CRDi VGT	D4FA	1493	65	2005		X	X	X	X	X	
1.6 16V	G4ED	1599	78	2005		X	X	X	X	X	
1.6 16V	G4ED	1599	77	2002	2005	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>HYUNDAI</b>											
<b>Grandeur Azera 2005</b>											
N 2.2 CRDi	D4EB	2188	114	2006		N	N	N	N	N	
N 2.7 V6	G6EA	2656	141	2007		N	N	N	N	N	
3.3 V6	G6DB	3342	173	2005		X	X	X	X	X	
3.8 V6	G6DA	3778	194	2005		X	X	X	X	X	
<b>H-1 H-200, Starex, Satellite 1998</b>											
2.4	G4CS	2351	82	1998	2002	X	X	X	X	X	X
2.4 16V	G4JS	2351	99	2002		X	N	N	X	N	
2.5 CRDi	D4CB	2497	103	2004		X	N	N	X	N	
2.5 TCi	D4BH	2476	73	2000	2002	X	X	X	X	X	X
2.5 TCi	D4BH	2476	74	2002		X	N	N	X	N	
2.5 TD	D4BF	2476	59	1998	2002	X	X	X	X	X	X
2.6 D	D4BB	2607	63	1998	2002	X	X	X	X	X	X
<b>H-100 1994 2001</b>											
N 2.4	G4CS	2351	84	1993	1996	N	N	N		N	N
2.4	G4CS	2351	90	1996	2001	X	X	X		X	X
2.5 D	D4BA	2477	57	1993	2001	X	X	X		X	X
2.5 D	D4BX	2477	55	1993	2001	X	X	X		X	X
2.5 TD	D4BF	2477	59	1997	2001	X	X	X		X	X
<b>Lantra 1991 1996</b>											
1.5	G4DJ	1468	55	1991	1993	X	X	X		X	X
1.5i	G4DJ	1468	63	1991	1996	X	X	X		X	X
1.6i 16V	4G61	1596	84	1991	1996	X	X	X		X	X
1.6i 16V Aut.	4G61	1596	84	1991	1996	X	X	X		X	X
1.8i 16V GT	G4CN	1836	93	1992	1996	X	X	X		X	X
<b>Lantra 1996 2001</b>											
1.5 12V	G4GK	1495	65	1996	2001	X	X	X		X	X
1.6 16V	G4GR	1599	84	1996	2001	X	X	X		X	X
1.8 16V	G4GM	1795	94	1996	2001	X	X	X		X	X
2.0 16V	G4GF	1975	102	1996	2001	X	X	X		X	X
<b>Matrix 2002</b>											
N 1.5 CRDi	D3EA	1493	60	2002	2005	N	N	N		N	N
1.5 CRDi VGT	D4FA	1493	75	2005		X	N	N	X	N	
1.6 16V	G4ED	1599	76	2002		X	X	X	X	X	X
1.8 16V	G4GB	1796	90	2002		X	X	X	X	X	X
<b>Pony 1985 1994</b>											
1.2	4G36	1238	41	1978	1982	X	X	X		X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>HYUNDAI</b>											
<b>Pony 1985 1994</b>											
1.3	G4AG	1298	49	1986	1986	X	X	X	X	X	X
1.4	4G33	1439	50	1978	1982	X	X	X	X	X	X
1.5	G4AJ	1468	64	1986	1986	X	X	X	X	X	X
1.5i	G4DJ	1468	62	1989	1994	X	X	X	X	X	X
X2 1.3	4G13	1298	48	1990	1994	X	X	X	X	X	X
X2 1.5i	4G15	1468	62	1990	1994	X	X	X	X	X	X
<b>Santa Fe 2000 2006</b>											
2.0 16V	G4JP	1997	99	2000	2006	X	X	X	X	X	X
2.0 CRDi	D4EA	1991	83	2001	2006	X	N	N	X	N	N
N 2.0 CRDi VGT	D4EA	1991	92	2004	2006	N	N	N	N	N	N
2.4 16V	G4JS	2351	107	2000	2006	X	X	X	X	X	X
2.7 V6 24V	G6BA	2656	125	2000	2006	X	X	X	X	X	X
<b>N Santa Fe 2006</b>											
N 2.2 CRDi	D4EB	2188	114	2006		N	N	N		N	
N 2.7 V6	G6EA	2656	139	2006		N	N	N		N	
<b>Scoupe 1990 1996</b>											
1.5	4G15	1468	57	1990	1992	X	X	X	X	X	X
1.5i	G4D	1468	62	1990	1992	X	X	X	X	X	X
1.5i 12V	G4EK	1495	65	1992	1996	X	X	X	X	X	X
1.5i GT Turbo 12V	G4EK-TC	1495	85	1993	1995	X	X	X	X	X	X
<b>Sonata I 1988 1993</b>											
1.8i	G4CM	1795	70	1988	1993	X	X	X	X	X	X
2.0i	G4CP	1997	75	1988	1993	X	X	X	X	X	X
2.0i 16V	G4CP	1997	96	1991	1993	X	X	X	X	X	X
2.4i	G4CS	2351	84	1988	1991	X	X	X	X	X	X
3.0i V6	G6AT	2972	107	1990	1993	X	X	X	X	X	X
<b>Sonata II 1993 1998</b>											
1.8i	G4CM	1795	72	1993	1998	X	X	X	X	N	X
1.8i 16V	G4CM	1795	93	1993	1998	X	X	X	X	N	X
2.0i	G4CP	1997	77	1993	1996	X	X	X	X	N	X
2.0i	G4CP-M	1997	70	1996	1998	X	X	N	X	N	X
2.0i 16V	G4CP-D	1997	102	1993	1996	X	X	X	X	N	X
2.0i 16V	G4CP-DM	1997	92	1996	1998	X	X	X	X	N	X
3.0i V6	G6AT	2972	107	1993	1998	X	X	X	X	N	X
<b>Sonata III 1998 2001</b>											
2.0 16V	G4JP	1997	100	1998	2001	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>HYUNDAI</b>											
<b>Sonata III 1998 2001</b>											
2.4 16V	G4JS	2351	105	1998	2001	X	X	N	N	X	X
2.5 V6	G6BV	2493	118	1998	2001	X	X	X	N	X	X
<b>Sonata IV 2001 2005</b>											
2.0 16V	G4JP	1977	96	2001	2005	X	X	X	X	X	X
2.4 16V	G4JS	2351	86	2001	2005	X	X	X	X	X	X
2.7 V6	G6BA	2656	126	2001	2005	X	X	X	X	X	X
<b>Sonata V 2005</b>											
N 2.0 16V	G4KA	1998	106	2006		N	N	N	N	N	
N 2.0 CRDi	D4DA	1991	103	2006		N	N	N	N	N	
2.4 16V	G4KC	2359	118	2005		N	N	N	N	N	
3.3 V6 24V	G6DB	3342	171	2005		N	N	N	N	N	
<b>Stellar 1986 1991</b>											
1.4	4G33	1439	50	1983	1986			X	X	X	X
1.4	4G33	1439	50	1986	1991			X	X	X	X
1.6	4G32	1597	55	1984	1986			X	X	X	X
1.6	4G32	1597	55	1986	1991			X	X	X	X
2.0	4G63	1997	61	1983	1986			X	X	X	
2.0	G63B	1997	61	1986	1990			X	X	X	
<b>Terracan 2001</b>											
2.5 TCI	D4BH	2467	74	2001	2004	X	X	X	X	X	
2.9 CRDi	J3	2902	110	2001	2004	X	N	N	X	N	
2.9 CRDi VGT	J3	2902	120	2003		X	N	N	X	N	
3.5 V6 24V	G6CV	3497	143	2001		X	X	X	X	X	
<b>Trajet 1999</b>											
2.0 16V	G4JP	1997	100	1999	2004	X	X	X	X	X	X
N 2.0 16V CVVT	G4JP	1997	103	2004		N	N	N	N	N	N
N 2.0 CRDi	D4EA	1991	83	2000		N	N	N	N	N	N
2.7 V6 24V	G6BA	2656	127	1999		X	X	X	X	X	X
<b>Tucson 2005</b>											
N 2.0 16V	G4GC	1975	104	2005		N	N	N	N	N	
N 2.0 CRDi	D4EA	1991	83	2005		N	N	N	N	N	N
N 2.7 V6 24V	G6BA	2656	129	2005		N	N	N	N	N	N
<b>XG 1999 2005</b>											
2.5 V6 (XG25)	G6BV	2493	120	1999	2003	X	X	X	X	X	
N 2.5 V6 (XG250)	G6BV	2493	120	2003	2005	N	N	N	N	N	
3.0 V6 (XG30)	G6AT	2972	137	1999	2003	X	X	X	X	X	

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>HYUNDAI</b>											
<b>XG 1999 2005</b>											
N 3.0 V6 (XG300)	G6CT	2972	138	2003	2005	N	N	N	N	N	N
N 3.5 V6 (XG350)	G6CU	3497	145	2003	2005	N	N	N	N	N	N
<b>IVECO</b>											
<b>Daily 1989 1996</b>											
30.8	8140.07	2499	55	1989	1996	X	X	X	X	X	X
35.10	8140.27	2499	76	1989	1996	X	X	X	X	X	X
35.10W / 40.10W (4x4)	8140.27S	2499	76	1989	1996	X	X	X	X	X	X
35.12	8140.47	2499	85	1991	1996	X	X	X	X	X	X
35.8	8140.07	2499	55	1989	1996	X	X	X	X	X	X
40.8	8140.07	2499	55	1989	1991	X	X	X	X	X	X
45.10	8140.27	2499	76	1989	1996	X	X	X	X	X	X
49.10	8140.27	2499	76	1989	1996	X	X	X	X	X	X
49.12	8140.47	2499	85	1991	1996	X	X	X	X	X	X
59.12	8140.47	2499	85	1991	1996	X	X	X	X	X	X
A45.12	8140.47	2499	85	1991	1996	X	X	X	X	X	X
<b>Daily 1996 1999</b>											
30.10	8140.23.37	2800	76	1996	1999	X	X	X	X	X	X
30.8	8140.67F	2499	60	1996	1998	X	X	X	X	X	X
35.10	8140.23.37	2800	76	1996	1999	X	X	X	X	X	X
35.10	8140.47R	2499	80	1992	1997	X	X	X	X	X	X
35.10W / 40.10W (4x4)	8140.23.38	2499	76	1996	1999	X	X	X	X	X	X
35.12	8140.43	2800	90	1996	1999	X	X	X	X	X	X
35.8	8140.67F	2499	60	1996	1998	X	X	X	X	X	X
40.10 / A40.10 / A40.10P	8140.23.37	2800	76	1996	1999	X	X	X	X	X	X
40.12 / A40.12 / A40.12P	8140.43	2800	90	1996	1999	X	X	X	X	X	X
40.8	8140.67F	2499	60	1996	1999	X	X	X	X	X	X
45.10 / A45.10 / A45.10P	8140.23.37	2800	76	1996	1999	X	X	X	X	X	X
45.12 / A45.12 / A45.12P	8140.43	2800	90	1996	1999	X	X	X	X	X	X
49.10	8140.47R	2499	80	1992	1997	X	X	X	X	X	X
49.10 / A49.10 / A49.10P	8140.23.37	2800	76	1996	1999	X	X	X	X	X	X
49.12	8140.43	2800	90	1996	1999	X	X	X	X	X	X
59.12	8140.43	2800	90	1996	1999	X	X	X	X	X	X
<b>Daily 2006</b>											
29L10 / 35S10	F1AE0481A	2287	71	2006		X	X	X	X	X	
29L12 / 35S12	F1AE0481G	2287	85	2006		X	X	X	X	X	
29L14 / 35S14	F1AE0481H	2287	100	2006		X	X	X	X	X	
35C10	F1AE0481A	2287	71	2006		X	X	X	X	X	

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>IVECO</b>											
<b>Daily 2006</b>											
35C12	F1AE0481G	2287	85	2006		X	X	X	X	X	
35C14	F1AE0481H	2287	100	2006		X	X	X	X	X	
35C15	F1CE0481F	2999	107	2006		X	X	X	X		
35C18	F1CE0481H	2999	129	2006		X	X	X	X		
35S18	F1CE0481H	2999	129	2006		X	X	X	X		
40C10	F1AE0481A	2287	71	2006		X	X	X	X	X	
40C12	F1AE0481G	2287	85	2006		X	X	X	X	X	
40C15	F1CE0481F	2999	107	2006		X	X	X	X		
40C18	F1CE0481H	2999	129	2006		X	X	X	X		
45C15 / 50C15	F1CE0481F	2999	107	2006		X	X	X	X		
45C18 / 50C18	F1CE0481H	2999	129	2006		X	X	X	X		
60C15 / 65C15	F1CE0481F	2999	107	2006		X	X	X	X		
60C18 / 65C18	F1CE0481H	2999	107	2006		X	X	X	X		
<b>Daily 1999 2007</b>											
29L10 / 35S10	F1A E0481A	2287	71	2002	2007	X	X	X	X	X	X
29L11	8140.43C	2798	76	1999	2002	X	X	X	X	X	X
29L11 / 35S11	8140.43B	2798	78	2002	2006	X	X	X	X	X	X
29L12 / 35S12	F1A E0481B	2287	85	2002	2007	X	X	X	X	X	X
29L14 / 35S14	F1A E0481D	2287	100	2002	2007	X	X	X	X	X	X
29L9 / 35S9	8140.43R	2798	66	2002	2005	X	X	X	X	X	X
29L9 / 35S9	8140.63	2798	65	1999	2002	X	X	X	X	X	X
35C10	F1A E0481A	2287	71	2002	2007	X	X	X	X	X	X
35C11	8140.43B	2798	78	2002	2006	X	X	X	X	X	X
35C11	8140.43C	2798	76	1999	2002	X	X	X	X	X	X
35C12	F1A E0481B	2287	85	2002	2007	X	X	X	X	X	X
35C13	8140.43S	2798	92	1999	2006	X	X	X	X	X	X
35C14	F1A E0481D	2287	100	2002	2007	X	X	X	X	X	X
35C14	F1C E0481A	2998	100	2005	2007	X	X	X	X	X	X
35C15	8140.43N	2798	107	2002	2006	X	X	X	X	X	X
35C17	F1C E0481B	2998	122	2005	2007	X	X	X	X	X	X
35C9	8140.43R	2798	66	2002	2005	X	X	X	X	X	X
35C9	8140.63	2798	65	1999	2002	X	X	X	X	X	X
35S11	8140.43C	2798	76	1999	2002	X	X	X	X	X	X
35S13	8140.43S	2798	92	1999	2006	X	X	X	X	X	X
35S15	8140.43N	2798	107	2002	2006	X	X	X	X	X	X
35S17	F1C E0481B	2998	122	2005	2007	X	X	X	X	X	X
40C10	F1A E0481A	2287	71	2002	2007	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>IVECO</b>											
<b>Daily 1999 2007</b>											
40C11	8140.43B	2798	78	2002	2006	X	X	X	X	X	X
40C11	8140.43C	2798	76	1999	2002	X	X	X	X	X	X
40C12	F1A E0481B	2287	85	2002	2007	X	X	X	X	X	X
40C13	8140.43S	2798	92	1999	2006	X	X	X	X	X	X
40C14	F1C E0481A	2998	100	2005	2007	X	X	X	X	X	X
40C15	8140.43N	2798	107	2002	2006	X	X	X	X	X	X
40C17	F1C E0481B	2998	122	2005	2007	X	X	X	X	X	X
40C9	8140.43R	2798	66	2002	2005	X	X	X	X	X	X
40C9	8140.63	2798	65	1999	2002	X	X	X	X	X	X
45C11 / 50C11	8140.43B	2798	78	2002	2006	X	X	X	X	X	X
45C11 / 50C11	8140.43C	2798	76	1999	2002	X	X	X	X	X	X
45C13 / 50C13	8140.43S	2798	92	1999	2006	X	X	X	X	X	X
45C14 / 50C14	F1C E0481A	2998	100	2005	2007	X	X	X	X	X	X
45C15 / 50C15	8140.43N	2798	107	2002	2006	X	X	X	X	X	X
45C17 / 50C17	F1C E0481B	2998	122	2005	2007	X	X	X	X	X	X
60C14 / 65C14	F1C E0481A	2998	100	2005	2007	X	X	X	X	X	X
60C15 / 65C15	8140.43N	2798	107	2002	2006	X	X	X	X	X	X
60C17 / 65C17	F1C E0481B	2998	122	2005	2007	X	X	X	X	X	X
<b>JAGUAR</b>											
<b>S-Type X200 1999</b>											
V6 2.5L	AJ-V6	2497	150	2002		X	X	X	X	X	X
V6 2.7L D	D-V6	2720	153	2004		X	X	X	X	X	
V6 3.0L	FC AJ-V6	2967	179	1999	2002	X	X	X	X	X	X
V6 3.0L	GC AJ-V6	2967	179	2002		X	X	X	X	X	X
V8 4.0L	AJ-28	3996	209	1999	2002	X	X	X	X	X	X
V8 4.2L	AJ-33	4196	224	2002		X	X	X	X	X	X
V8 4.2L Super Charged R	AJ-33	4196	298	2002		X	X	X	X	X	X
<b>XJ X350 2003</b>											
V6 3.0L	AJ-V6	2967	179	2003		X	X				
V8 3.5L	AJ-33	3555	196	2003		X	X				
V8 4.2L	AJ-33	4196	224	2003		X	X				
V8 4.2L Super Charged (XJR)	AJ-33	4196	298	2003		X	X				
<b>XJ 12 X300 1994 1997</b>											
V12 6.0	8E	5993	229	1994	1997	X	X	X	X		X
<b>XJ 12 XJ40 1993 1994</b>											
V12 6.0	8C	5993	229	1993	1994	X	X	X	X		X



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>JAGUAR</b>											
<b>XJ 6 X300</b>	<b>1994</b>	<b>1997</b>									
V6 3.2	AJ16	3239	155	1994	1997	X	X	X	X		X
V6 4.0	AJ16	3980	177	1994	1997	X	X	X	X		X
V6 4.0 Super Charged (XJR)	AJ16	3980	235	1994	1997	X	X	X	X		X
<b>XJ 6 XJ40</b>	<b>1986</b>	<b>1994</b>									
2.9	AJ6	2919	123	1986	1990	X	X	X	X		X
3.2	AJ6	3239	149	1990	1994	X	X	X	X		X
3.6	AJ6	3590	165	1986	1990	X	X	X	X		X
4.0	AJ6	3890	175	1989	1994	X	X	X	X		X
<b>XJ 8 X308</b>	<b>1998</b>	<b>2002</b>									
V8 3.2	AJ26	3248	179	1998	2002	X	X	X	X		X
V8 4.0	AJ26	3996	216	1998	2002	X	X	X	X		X
V8 4.0 Super Charged (XJR)	AJ26	3996	276	1998	2002	X	X	X	X		X
<b>X-Type X400</b>	<b>2001</b>										
2.0 D	FMB	1998	96	2003		X	X	X	X		
2.2 D	QJB	2198	114	2005		X	X	X	X		
V6 2.0L	YB AJ-V6	2099	117	2001	2005	X	X	X	X		X
V6 2.5L	XB AJ-V6	2495	145	2001		X	X	X	X		X
V6 3.0L	WB AJ-V6	2967	172	2001		X	X	X	X		X
<b>JEEP</b>											
<b>Cherokee</b>	<b>1991</b>	<b>2001</b>									
2.5	HX	2464	89	1991	2001	X	X	X	X		X
2.5 TD	425CLIRX (23B)	2499	85	1995	2001	X	X	X	X		X
4.0	MX	3966	135	1991	2001	X	X	X	X		X
<b>Cherokee</b>	<b>2001</b>										
2.4	ED1	2429	108	2001	2006	X	X	X	X		X
2.5 CRD	R2516K4(ENJ)	2499	105	2001	2005	X	X	X	X		X
2.8 CRD	R2816K4.05A (ENR)	2776	110	2002	2005	X	X	X	X		X
2.8 CRD	R2816K5A	2776	120	2005		X	X	X	X		X
3.7 V6	EKG	3700	155	2001		X	X	X	X		X
<b>Grand Cherokee</b>	<b>1992</b>	<b>1999</b>									
2.5 TD	425CLIRX (23B)	2499	85	1992	1999	X	X	X	X		X
4.0	MX	3966	135	1992	1999	X	X	X	X		X
5.2 V8	M5.2LT	5211	158	1992	1999	X	X	X	X		X
5.9 V8	M5.9LT	5899	169	1998	1999	X	X	X	X		X
<b>Wrangler</b>	<b>1996</b>	<b>2006</b>									
2.4	HX	2464	90	1996		X	X	X			X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>JEEP</b>													
<b>Wrangler 1996 2006</b>													
4.0	MX	3966	135	1996		X	X	X				X	X
<b>KIA</b>													
<b>Besta 1994 2003</b>													
2.2 D	HW	2184	48	1994	2003	X	X	X	X	X		X	X
<b>Carens 1999 2002</b>													
1.8 DOHC	TBD	1794	93	1999	2002	X	X	X	X	X		X	X
<b>Carnival Sedona 1999 2006</b>													
2.5 V6	GV6	2497	110	2001	2006	X	X	X	X	X			X
2.5 V6	KV6	2497	121	1999	2001	X	X	X	X	X			X
2.9 CRDi	KJ TCi	2902	106	2001	2006	X	X	X	X	X			X
2.9 TDi	J3 TCi	2902	93	1999	2001	X	X	X	X	X			X
<b>Cerato 2004</b>													
1.6	G4GD	1599	77	2004		X	X	X	X	X			X
2.0	G4GC	1975	105	2004		X	X	X	X	X			X
2.0 D	D4DA	1991	82	2004		X	X	X	X	X			X
<b>Clarus Credos 1996 2000</b>													
1.8i 16V	T8 DOHC	1793	85	1996	2000	X	X	X	X	X		X	X
2.0i 16V	FE DOHC	1998	98	1996	2000	X	X	X	X	X		X	X
<b>Magentis Optima 2001 2007</b>													
2.0 DOHC	G4JP	1997	100	2001	2007	X	X	X	X	X		X	X
2.5 V6	G6BV	2493	124	2001	2007	X	X	X	X	X		X	X
<b>Opirus 2003</b>													
3.5 V6	G6CU	3497	149	2003		X	X	X	X	X			X
<b>Picanto 2004</b>													
1.0	G4HE	999	45	2004		X	X	X	X	X			X
1.1	G4HG	1086	48	2004		X	X	X	X	X		X	X
1.1 CRDi VGT	D3FA	1120	55	2005		X	X	X	X	X			X
<b>Pregio 2001</b>													
2.5 TCi	D4BH	2476	69	2001		X	X	X	X	X		X	X
2.7 D	J2	2665	61	2001		X	X	X	X	X			X
3.0 D	JTA	2957	63	2001		X	X	X	X	X			X
<b>Pride 1991 2000</b>													
1.1	B1	1139	41	1993	2000	X	X	X	X	X		X	X
1.3	B3	1324	47	1993	2000	X	X	X	X	X		X	X
1.3i 16V	B3	1324	47	1993	2000	X	X	X	X	X		X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>KIA</b>											
<b>Rio 2000 2005</b>											
1.3	A3E	1343	55	2000	2005	X	X	X	X	X	X
1.5	A5D	1493	72	2000	2005	X	X	X	X	X	X
<b>Rio 2005</b>											
1.4	G4EE	1399	71	2005		X	X	X	X	X	X
1.5 D	D4FA	1493	81	2005		X	X	X	X	X	X
1.6 CVVT	G4ED	1599	82	2005		X	X	X	X	X	N X
<b>Sephia 1993 1997</b>											
1.5	B5	1498	74	1993	1997	X	X	X	X	X	X X
1.5 DOHC	B5	1498	74	1993	1997	X	X	X	X	X	X X
1.6 16V	B6	1597	78	1993	1997	X	X	X	X	X	X X
1.6 8V	B6	1597	60	1993	1997	X	X	X	X	X	X X
<b>Sephia II Shuma 1997 2004</b>											
1.5 16V	BFD	1498	59	1998	2003	X	X	X	X	X	X
1.6 16V	A6 DOHC	1594	79	2000	2004	X	X	X	X	X	X
1.8 16V	TED	1793	84	1998	2003	X	X	X	X	X	X
<b>Sorento 2002</b>											
2.4 16V	G4JSG	2351	102	2002		X	X	X	X	X	X
2.5 CRDi	D4CB	2497	103	2002		X	X	X	X	X	X
3.5 V6 24V	6G74	3497	143	2002		X	X	X	X	X	X
<b>Sportage 1994 2003</b>											
2.0	FE SOHC	1998	70	1994	1999	X	X	X	X	X	X X X
2.0 16V	FE DOHC	1998	94	1994	2003	X	X	X	X	X	X X X
2.0 TD	RF-TCi	1998	61	1997	2003	X	X	X	X	X	X X
<b>LADA</b>											
<b>Samara Diva 1984 2005</b>											
1.1	2108.1	1099	41	1984	2003	X	X	X	X	X	X
1.3	2108	1288	48	1984	1996	X	X	X	X	X	X
1.3	2109	1288	48	1986	2005	X	X	X	X	X	X
1.5	2108.3	1499	54	1988	2003	X	X	X	X	X	X
1.5	2109.3	1499	54	1990	2005	X	X	X	X	X	X
<b>LANCIA</b>											
<b>Dedra 1989 1999</b>											
1.6 16V	182 A4.000	1581	76	1998	1999	X	X	X	X	X	X
1.6 IE	159 B9.000	1581	66	1994	1998	X	X	X	X	X	X
1.6 IE	835 A1.000	1581	65	1989	1994	X	X	X	X	X	X X
1.6 IE kat.	835 A1.046	1581	65	1989	1994	X	X	X	X	X	X X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>LANCIA</b>											
<b>Dedra 1989 1999</b>											
1.6 IE kat.	835 C1.000	1581	55	1991	1994	X	X	X	X	X	X
1.8 16V VVT	183 A1.000	1747	96	1996	1999	X	X	X	X	X	X
1.8 IE	835 A2.000	1756	80	1989	1994	X	X	X	X	X	X
1.8 IE	836 A5.000	1756	74	1994	1996	X	X	X	X	X	X
1.8 IE kat.	835 A2.046	1756	77	1989	1994	X	X	X	X	X	X
1.9 Tds	160 D1.000	1929	66	1996	1999	X	X	X	X	X	X
1.9 Tds	835 A4.000	1929	66	1989	1998	X	X	X	X	X	X
2.0 16V	836 A3.000	1995	102	1994	1998	X	X	X	X	X	X
2.0 IE	835 A5.000	1995	86	1989	1994	X	X	X	X	X	X
2.0 IE kat.	835 A5.045/6	1995	83	1989	1994	X	X	X	X	X	X
2.0 IE Turbo	835 A8.000	1995	132	1991	1994	X	X	X	X	X	X
2.0 IE Turbo Integrale	835 A7.000	1995	124	1991	1994	X	X	X	X	X	X
2.0 IE Turbo kat.	835 A8.046	1995	119	1991	1994	X	X	X	X	X	X
<b>Delta 1982 1993</b>											
1.3	831 A2.000	1301	55	1982	1993	X	X	X	X	X	X
1.5	831 B1.000	1498	63	1982	1993	X	X	X	X	X	X
1.6 GT	831 B7.000	1585	80	1986	1993	X	X	X	X	X	X
1.6 GT IE	149 C2.000	1585	66	1986	1993	X	X	X	X	X	X
1.6 HF Turbo IE	831 B3.000	1585	96	1986	1993	X	X	X	X	X	X
1.6 HF Turbo IE	831 B7.046	1585	97	1991	1993	X	X	X	X	X	X
2.0 HF Integrale 16V	831 C5.000/046	1995	137	1987	1992	X	X	X	X	X	X
HF Integrale	831 E5.000	1995	154	1991	1992	X	X	X	X	X	X
HF Integrale 16V	831 D5.000	1995	144	1989	1992	X	X	X	X	X	X
<b>Delta 1993 1999</b>											
1.4	160 A1.046	1372	51	1993	1994	X	X	X	X	X	X
1.4	836 A4.000	1372	51	1994	1999	X	X	X	X	X	X
1.6	835 C1.000	1581	55	1993	1999	X	X	X	X	X	X
1.6 16V	182 A4.000	1581	76	1996	1999	X	X	X	X	X	X
1.8	835 C2.000	1756	76	1993	1996	X	X	X	X	X	X
1.8	835 C4.000	1756	66	1993	1999	X	X	X	X	X	X
1.8	836 A5.000	1756	74	1993	1999	X	X	X	X	X	X
1.8	836 A6.000	1756	66	1993	1999	X	X	X	X	X	X
1.8 16V	182 A2.000	1747	83	1996	1999	X	X	X	X	X	X
1.8 16V	183 A1.000	1747	96	1996	1999	X	X	X	X	X	X
1.9 TD	835 A4.000	1929	66	1994	1996	X	X	X	X	X	X
1.9 TD kat.	160 D1.000	1929	66	1994	1999	X	X	X	X	X	X
2.0 16V CF2	836 A3.000	1995	102	1993	1996	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>LANCIA</b>													
<b>Delta 1993 1999</b>													
2.0 HF 16V Turbo	836 A2.000	1995	137	1993	1999	X	X	X	X	X	X	X	X
<b>Kappa 1995 2000</b>													
2.0 20V	838 A1.000	1998	107	1994	1998	X	X	X	X	X	X	X	X
2.0 20V	838 A6.000	1998	114	1996	2000	X	X	X	X	X	X	X	X
2.0 Turbo 16V	838 A4.000	1995	151	1994	1998	X	X	X	X	X	X	X	X
2.0 Turbo 20V	175 A3.000	1998	162	1998	2000	X	X	X	X	X	X	X	X
2.4 20V	838 A2.000	2446	129	1994	2000	X	X	X	X	X	X	X	X
2.4 JTD	838 A8.000	2387	100	1998	2000	X	X	X	X	X	X	X	X
2.4 TD	838 A3.000	2387	91	1994	1998	X	X	X	X	X	X	X	X
2.4 TD	838 A7.000	2387	91	1996	1998	X	X	X	X	X	X	X	X
3.0 V6 24V	838 B.000	2959	150	1994	2000	X	X	X	X	X	X	X	X
<b>Lybra 1999 2006</b>													
1.6 16V	182 A4.000	1581	76	1999	2001	X	X	X	X	X	X	X	X
1.6 16V	182 B6.000	1596	76	2001	2006	X	X	X	X	X	X	X	X
1.8 16V	839 A4.000	1747	96	1999	2001	X	X	X	X	X	X	X	X
1.8 16V	839 A7.000	1747	96	2001	2006	X	X	X	X	X	X	X	X
1.9 JTD	937 A2.000	1910	85	2001	2006	X	X	X	X	X	X	X	X
1.9 JTD	AR 32302	1910	77	1999	2001	X	X	X	X	X	X	X	X
1.9 JTD	AR 37101	1910	81	2001	2003	X	X	X	X	X	X	X	X
2.0 20V	182 B7.000	1998	113	1999	2001	X	X	X	X	X	X	X	X
2.0 20V	185 A8.000	1998	110	2001	2006	X	X	X	X	X	X	X	X
2.4 JTD	839 A5.000	2387	99	1999	2001	X	X	X	X	X	X	X	X
2.4 JTD	839 A6.000	2387	103	2001	2002	X	X	X	X	X	X	X	X
2.4 JTD	841 C.000	2387	110	2002	2006	X	X	X	X	X	X	X	X
<b>Musa 2004</b>													
1.3 JTD 16V	188 A9.000	1248	51	2004		X	X	X	X	X	X	X	X
1.4 16V	843 A1.000	1368	70	2004		X	X	X	X	X	X	X	X
1.9 JTD	188 B2.000	1910	74	2004		X	X	X	X	X	X	X	X
<b>Phedra 2002</b>													
2.0 16V	EW10J4 (RFN)	1997	100	2002		X	X	X	X	X	X	X	X
2.0 JTD 16V	DW10ATED4 (RHW)	1997	80	2002		X	X	X	X	X	X	X	X
2.2 JTD 16V	DW12ATED4 (4HW)	2179	95	2002		X	X	X	X	X	X	X	X
3.0 V6 24V	ES9J4S (XFW)	2946	150	2002		X	X	X	X	X	X	X	X
<b>Prisma 1982 1991</b>													
1300	831 A2.000	1301	58	1982	1986	X	X	X	X	X	X	X	X
1500	831 A1.000	1498	63	1982	1988	X	X	X	X	X	X	X	X
1600	831 A4.000	1585	77	1982	1988	X	X	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>LANCIA</b>											
<b>Prisma</b>	<b>1982</b>	<b>1991</b>									
1600 IE	831 B7.000	1585	66	1987	1991	X	X	X	X	X	X
1900 D	831 D.000	1929	48	1986	1988	X	X	X	X	X	X
1900 TD	831 D1.000	1929	59	1986	1991	X	X	X	X	X	X
<b>Thema</b>	<b>1984</b>	<b>1995</b>									
2000 16V	834 F1.000	1995	112	1992	1994	X	X	X	X	X	X
2000 IE	154 C.000	1995	88	1989	1989	X	X	X	X	X	X
2000 IE	834 B.000	1995	88	1984	1992	X	X	X	X	X	X
2000 IE	834 B.146	1995	85	1992	1995	X	X	X	X	X	X
2000 IE	834 B1.000	1995	86	1988	1992	X	X	X	X	X	X
2000 IE 16V	834 B2.000	1995	108	1988	1992	X	X	X	X	X	X
2000 IE 16V	834 B2.246	1995	104	1992	1993	X	X	X	X	X	X
2000 IE Turbo	834 C.000	1995	122	1984	1988	X	X	X	X	X	X
2000 IE Turbo 16V	834 C1.000	1995	133	1988	1992	X	X	X	X	X	X
2000 IE Turbo 16V	834 C1.246	1995	130	1989	1994	X	X	X	X	X	X
2000 Turbo 16V	834 F2.000	1995	148	1992	1994	X	X	X	X	X	X
2500 TD	8144.91	2445	74	1985	1988	X	X	X	X	X	X
2500 tds	8144.97	2499	85	1988	1995	X	X	X	X	X	X
2800 V6	834 E.000	2849	110	1984	1992	X	X	X	X	X	X
2800 V6	834 E.146	2849	108	1991	1992	X	X	X	X	X	X
3000 IE V6	834 F.000	2959	126	1992	1995	X	X	X	X	X	X
8.32 Ferrari	F105	2927	158	1987	1991	X	X	X	X	X	X
<b>Thesis</b>	<b>2002</b>										
2.0 20V Turbo	841 E.000	1998	136	2002		X	X	X	X	X	X
2.4 20V	841 D.000	2446	125	2002		X	X	X	X	X	X
2.4 JTD 10V	841 C.000	2387	110	2002		X	X	X	X	X	X
2.4 JTD 20V	841 G.000	2387	129	2003		X	X	X	X	X	X
2.4 JTD 20V Aut.	841 H.000	2387	129	2003		X	X	X	X	X	X
3.0 V6 24V	841 A.000	2959	158	2002		X	X	X	X	X	X
3.2 V6 24V	841 L.000	3179	169	2003		X	X	X	X	X	X
<b>Ypsilon</b>	<b>2003</b>										
1.2 16V	188 A5.000	1242	59	2003		X	X	X	X	X	X
1.2 8V	188 A4.000	1242	44	2003		X	X	X	X	X	X
1.3 JTD 16V	188 A9.000	1248	51	2003		X	X	X	X	X	X
1.4 16V	843 A1.000	1368	70	2003		X	X	X	X	X	X
1.4 8V	843 N2.000	1368	55	2003		X	X	X	X	X	X
<b>Ypsilon Y</b>	<b>1995</b>	<b>2003</b>									
1.1 8V	176 B2.000	1108	40	1997	2000	X	X	X	X	X	X

Legend: N = new, X = present

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>LANCIA</b>											
<b>Ypsilon Y 1995 2003</b>											
1.2 16V	176 B9.000	1242	63	1997	2000	X	X	X	X	X	X
1.2 16V	188 A5.000	1242	59	2000	2003	X	X	X	X	X	X
1.2 8V	188 A4.000	1242	44	2000	2003	X	X	X	X	X	X
1.2 8V	840 A3.000	1242	44	1995	2000	X	X	X	X	X	X
1.4 12V	840 A2.000	1370	59	1995	2000	X	X	X	X	X	X
1.4 12V	840 A4.000	1370	55	1995	2000	X	X	X	X	X	X
<b>Ypsilon Y10 1985 1995</b>											
1.0	156 A2.000	999	33	1985	1989	X	X	X	X	X	X
1.1	156 A.000	1049	41	1985	1989	X	X	X	X	X	X
1.1 Turbo	156 A1.000	1049	63	1985	1989	X	X	X	X	X	X
1.1i / Selectronic	156 C.046	1108	37	1989	1995	X	X	X	X	X	X
1.1i LX	156 C.000	1108	41	1989	1992	X	X	X	X	X	X
1.1i LX 4x4	156 C.000	1108	41	1989	1992	X	X	X	X	X	X
1.3i	146 A5.046	1297	53	1992	1995	X	X	X	X	X	X
1.3i GT	156 B.000	1301	56	1989	1992	X	X	X	X	X	X
<b>Zeta 1994 2001</b>											
2.0 16V	EW10J4 (RFN)	1998	100	2000	2001	X	X	X	X	X	X
2.0 JTD	DW10ATED (RHZ)	1997	80	1999	2001	X	X	X	X	X	X
2.0 JTD 16V	DW10ATED4 (RHW)	1997	80	2001	2001	X	X	X	X	X	X
2.0 Turbo	XU10J2CTE (RGX)	1998	108	1994	2001	X	X	X	X	X	X
2.1 TD	XUD11BTE (P8C)	2088	80	1994	1999	X	X	X	X	X	X
<b>LAND &amp; RANGE ROVER</b>											
<b>Defender 1985</b>											
2.25	2.25	2286	55	1985	1990	X	X	X	X	X	X
2.25 D	10J	2286	44	1985	1990	X	X	X	X	X	X
2.5	2.5	2495	59	1985	1990	X	X	X	X	X	X
2.5	2.5	2495	62	1990	1994	X	X	X	X	X	X
2.5 D	12J	2495	49	1985	1990	X	X	X	X	X	X
2.5 TD	2.5	2495	63	1987	1992	X	X	X	X	X	X
2.5 TD5	10P/15P	2498	90	1999		X	X	X	X	X	X
2.5 TDi 200	200 TDi	2494	80	1992	1994	X	X	X	X	X	X
2.5 TDi 300	23L	2495	83	1994	1999	X	X	X	X	X	X
3.5 V8	15G	3528	85	1985	1990	X	X	X	X	X	X
3.5 V8	15G	3528	114	1992	1996	X	X	X	X	X	X
<b>N Defender II 2007</b>											
N 2.4 D	2.4 D	2402	90	2007		N	N	N	N	N	N

Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diag. Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diag. Fuses & Relays

**LAND & RANGE ROVER**

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diag. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diag.	Fuses & Relays
<b>Discovery I 1989 1999</b>												
2.0 Mpi	20T4	1994	100	1996	1999	X	X	X	X	X	X	X
2.0 Mpi	M16i 20HD	1994	100	1993	1995	X	X	X	X	X	X	X
2.5 TDi 200	12L/21L	2495	83	1989	1994	X	X	X	X	X	X	X
2.5 TDi 300	23L	2495	83	1996	1999	X	X	X	X	X	X	X
3.5 V8	V8	3528	108	1989	1992	X	X	X	X	X	X	X
3.5 V8i	24D	3528	119	1991	1993	X	X	X	X	X	X	X
3.9 V8i	35D/36D	3948	134	1994	1999	X	X	X	X	X	X	X
<b>Discovery II 1999 2004</b>												
2.5 TD5	10P	2498	102	1999	2002	X	X	X	X	X	X	X
2.5 TD5	15P/16P	2498	102	2002	2004	X	X	X	X	X	X	X
4.0 V8	56D	3947	136	1999	2002	X	X	X	X	X	X	X
4.0 V8	94D	3947	136	2002	2004	X	X	X	X	X	X	X
<b>Discovery III 2005</b>												
2.7D V6	276DT	2720	147	2005		X	X	X	X		X	
4.0 V6	406PN	4009	156	2005		X	X	X	X		X	
4.4 V8	448PN	4396	220	2005		X	X	X	X		X	
<b>Freelander 1997 2000</b>												
1.8 16V	18K4F	1796	88	1997	2000	X	X	X	X	X	X	X
2.0 TDi	20T2N	1994	72	1997	2000	X	X	X	X	X	X	X
<b>Freelander 2000 2007</b>												
1.8	K18	1796	86	2000	2007	X	X	X	X	N	X	X
2.0 TD4	TD4	1951	82	2000	2007	X	X	X	X	X	X	X
2.5 V6	KV6	2497	130	2000	2007	X	X	X	X	X	X	X
<b>Freelander II 2007</b>												
N 2.2 TD4		2179	118	2007		N	N	N	N			
N 3.2 i6		3192	171	2007		N	N	N	N			
<b>Range Rover I 1973 1996</b>												
2.4 Turbo D	11A VM Hr 492 HI	2393	82	1986	1992	X	X	X	X	X	X	X
2.5 Tdi 300	300 Tdi	2495	83	1994	1996	X	X	X	X	X	X	X
2.5 Turbo D	95 A VM Hr 4924 HI	2500	89	1992	1994	X	X	X	X	X	X	X
3.5 V8	V8	3528	115	1973	1989	X	X	X	X	X	X	X
3.5 V8i	31D	3528	124	1987	1991	X	X	X	X	X	X	X
3.9 V8i	35D / 36D	3950	134	1989	1996	X	X	X	X	X	X	X
3.9 V8i	37D / 38D	3950	127	1989	1996	X	X	X	X	X	X	X
4.2 V8i Vogue LSE	40D	4275	149	1992	1996	X	X	X	X	X	X	X



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diagr. Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diagr. Fuses & Relays

**LAND & RANGE ROVER**

**Range Rover II 1994 2002**

2.5 TD	256T (M51)	2497	100	1994	2002	X	X	X	X	X				X			X	X
4.0 V8	42D	3950	140	1994	2002	X	X	X	X	X				X			X	X
4.6 V8	46D	4555	166	1994	2002	X	X	X	X	X	X			X			X	X

**Range Rover III 2002**

3.0 TD6	306D1	2924	135	2002		X	X	X		X					X			
4.4 V8	448PN	4398	210	2002		X	X	X		X					X			

**LEXUS**

**GS JZS147 1993 1997**

GS 300 V6 24V	2JZ-GE	2997	156	1993	1997	X	X	X	X	X				X			X	
---------------	--------	------	-----	------	------	---	---	---	---	---	--	--	--	---	--	--	---	--

**GS JZS160 1997 2005**

GS 300 V6 24V	2JZ-GE	2997	161	1997	2005	X	X	X	X	X				X			X	
---------------	--------	------	-----	------	------	---	---	---	---	---	--	--	--	---	--	--	---	--

**IS GXE10 1999 2005**

IS 200 24V	1G-FE	1988	114	1999	2005	X	X	X	X	X	N			X			X	X
IS 300 24V	2JZ-GE	2997	156	2000	2005	X	X	X	X	X	N			X			X	X

**LS UCF10 1988 1993**

LS 400 V8 32V	1UZ-FE	3969	180	1988	1993	X	X	X	X	X				X			X	X
---------------	--------	------	-----	------	------	---	---	---	---	---	--	--	--	---	--	--	---	---

**LS UCF20 1994 2001**

LS 400 V8 24V	1UZ-FE	3969	194	1994	1997	X	X	X	X	X				X			X	X
---------------	--------	------	-----	------	------	---	---	---	---	---	--	--	--	---	--	--	---	---

**LS UCF30 2000 2007**

LS 430 V8 32V	3UZ-FE	4293	207	2000	2007	X	X	X	X	X	X			X			X	
---------------	--------	------	-----	------	------	---	---	---	---	---	---	--	--	---	--	--	---	--

**RX MCU15 2000**

RX 300	1MZ-FE	2995	148	2000		X	X	X	X	X				X			X	
--------	--------	------	-----	------	--	---	---	---	---	---	--	--	--	---	--	--	---	--

**SC UZZ40 2001**

SC 430	3UZ-FE	4293	210	2001		X	X	X	X	X				X			X	
--------	--------	------	-----	------	--	---	---	---	---	---	--	--	--	---	--	--	---	--

**LINCOLN**

**Continental 1995 1998**

4.6 V8	V8-281	4601	194	1995	1998													
--------	--------	------	-----	------	------	--	--	--	--	--	--	--	--	--	--	--	--	--

**Mk VIII 1992 1999**

4.6 V8	99V/V8-281	4601	209	1992	1999													
--------	------------	------	-----	------	------	--	--	--	--	--	--	--	--	--	--	--	--	--

**Town Car 1991 1998**

4.6 V8	99W/V8-281	4601	153	1991	1998													
--------	------------	------	-----	------	------	--	--	--	--	--	--	--	--	--	--	--	--	--

**MAZDA**

**121 1987 1991**

1.1	B1	1138	41	1987	1991	X	X	X	X	X				X			X	
1.3	B3	1323	44	1987	1990	X	X	X	X	X				X			X	

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>MAZDA</b>													
<b>121 1991 1996</b>													
1.3i	B3	1324	40	1991	1996	X	X	X	X	X	X	X	X
1.3i 16 V	B3	1324	54	1990	1996	X	X	X	X	X	X	X	X
<b>121 1996 2002</b>													
1.2 16V	Zetec-SE DHA	1254	55	1996	2002	X	X	X	X	X	X	X	X
1.3	Endura-E J4C	1298	44	1996	2002	X	X	X	X	X	X	X	X
1.3	Endura-E JJA	1298	37	1996	2002	X	X	X	X	X	X	X	X
1.8 D	Endura-DE RTJ	1753	44	1996	2002	X	X	X	X	X	X	X	X
<b>2 2002</b>													
1.2 16V	F8JA	1242	51	2002		X	X	X	X	X	X	X	X
1.2 16V	F8JB	1242	51	2002		X	X	X	X	X	X	X	X
1.2 16V	FUJA	1242	55	2002		X	X	X	X	X	X	X	X
1.2 16V	FUJB	1242	51	2002		X	X	X	X	X	X	X	X
1.4 16V	FXJA	1388	59	2002		X	X	X	X	X	X	X	X
1.4 16V	FXJB	1388	59	2002		X	X	X	X	X	X	X	X
1.4 CiTD	F6JA	1399	50	2002		X	X	X	X	X	X	X	X
1.6 16V	FYJA	1595	74	2002		X	X	X	X	X	X	X	X
<b>3 2003</b>													
1.4 MZR 16V	ZJ	1349	62	2003	2006	X	X	X	X	X	X	X	X
<b>N</b> 1.4 MZR 16V	ZJ	1349	62	2006		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
<b>N</b> 1.6 MZ-CD	Y6	1560	66	2006		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
<b>N</b> 1.6 MZ-CD	Y6	1560	80	2004		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
<b>N</b> 1.6 MZ-CD	Y6	1560	80	2006		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
1.6 MZR 16V	Z6	1598	77	2003	2006	X	X	X	X	X	X	X	X
<b>N</b> 1.6 MZR 16V	Z6	1598	77	2006		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
<b>N</b> 2.0 MZ-CD	RF	1998	105	2006		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
2.0 MZR 16V	LF	1999	110	2003	2006	X	X	X	X	X	X	X	X
<b>N</b> 2.0 MZR 16V	LF	1999	110	2006		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
<b>N</b> 2.3 MZR 16V MPS	L3	2261	191	2007		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
<b>323 1998 2003</b>													
1.3 16V	B3	1323	53	2000	2003	X	X	X	X	X	X	X	X
1.3 16V	B3	1323	54	1998	2000	X	X	X	X	X	X	X	X
1.5 16V	ZL	1498	65	1998	2000	X	X	X	X	X	X	X	X
1.6 16V	ZM	1597	72	2000	2003	X	X	X	X	X	X	X	X
1.8 16V	FP	1840	84	1998	2000	X	X	X	X	X	X	X	X
2.0 16V	FS	1991	66	2000	2003	X	X	X	X	X	X	X	X
2.0 D	RF	1998	52	1998	2000	X	X	X	X	X	X	X	X
2.0 DiTD	RF-T	1998	74	2000	2003	X	X	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagram. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagn. Fuses & Relays
<b>MAZDA</b>											
<b>323 1998 2003</b>											
2.0 TD	RF-T	1998	66	1998	2000	X	X	X	X	X	X
<b>323 1989 1994</b>											
1.3	B3E	1324	50	1989	1992	X	X	X	X	X	X
1.3 16V	B3	1324	50	1989	1994	X	X	X	X	X	X
1.3i 16V	B3	1324	55	1989	1994	X	X	X	X	X	X
1.6	B6E	1586	62	1989	1992	X	X	X	X	X	X
1.6 16V	B6	1598	64	1989	1994	X	X	X	X	X	X
1.6i	B6	1598	65	1989	1994	X	X	X	X	X	X
1.6i 16V	B6	1598	65	1990	1994	X	X	X	X	X	X
1.7 D	PN	1720	40	1989	1994	X	X	X	X	X	X
1.8i 16V	BP DOHC	1840	103	1989	1994	X	X	X	X	X	X
1.8i 16V	BP SOHC	1840	78	1991	1994	X	X	X	X	X	X
1.8i 16V kat.	BP DOHC	1840	96	1989	1994	X	X	X	X	X	X
1.8i 16V kat.	BP DOHC	1840	96	1989	1994	X	X	X	X	X	X
1.8i 16V Turbo 4x4	BP DOHC	1840	122	1991	1994	X	X	X	X	X	X
<b>323 1994 1999</b>											
1.3 16V	B3	1324	54	1994	1999	X	X	X	X	X	X
1.5 16V	Z5	1489	65	1994	1999	X	X	X	X	X	X
1.7 TD	4EE1-T	1686	60	1995	1997	X	X	X	X	X	X
1.8 16V	BP	1840	84	1994	1999	X	X	X	X	X	X
2.0 D	RF	1998	52	1996	1999	X	X	X	X	X	X
2.0 V6 GT 24V	KF	1995	106	1994	1999	X	X	X	X	X	X
<b>5 2005</b>											
1.8 16V MZR	L8	1798	85	2005		X	X	N	N	N	N
2.0 16V MZR	LF	1999	107	2005		X	X	N	N	N	N
2.0 CiTD	RF	1998	81	2005		X	X	N	N	N	N
2.0 CiTD	RF	1998	105	2005		X	X	N	N	N	N
<b>6 2002</b>											
1.8 MZR 16V	L8	1798	88	2002	2005	X	X	X	X	X	X
<b>N</b> 1.8 MZR 16V	L8	1798	88	2005		N	N	N	N	N	N
2.0 MZ-CD CiTD 120	RF	1998	88	2002	2005	X	X	X	X	X	X
<b>N</b> 2.0 MZ-CD CiTD 121 DPF	RF	1998	89	2005		N	N	N	N	N	N
2.0 MZ-CD CiTD 136	RF	1998	100	2002	2005	X	X	X	X	X	X
2.0 MZ-CD CiTD 143 DPF	RF	1998	105	2005		X	X	X	X	X	X
2.0 MZR 16V	LF	1999	104	2002	2005	X	X	X	X	X	X
2.0 MZR 16V	LF	1999	108	2005		X	N	N	X	N	N
2.3 MZR 16V	L3	2261	122	2002	2005	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>MAZDA</b>											
<b>6 2002</b>											
N 2.3 MZR 16V	L3	2261	122	2005		N	N	N	N	N	N
N 2.3 MZR 16V MPS	L3	2261	191	2006		N	N	N	N	N	N
<b>626 1997 2003</b>											
1.8 16V	FP	1840	74	2000	2003	X	X	X	X	X	X
1.8 16V	FPY3	1840	66	1997	2000	X	X	X	X	X	X X
2.0 16V	FSY9	1991	85	1997	2003	X	X	X	X	X	X X
2.0 DiTD	RF-T	1998	66	1997	2003	X	X	X	X	X	X X
2.0 DiTD	RF-T Hi-Power	1998	74	1997	2000	X	X	X	X	X	X X
2.0 DiTD	RF-T Hi-Power	1998	81	2000	2003	X	X	X	X	X	X X
2.0 HP	FSY8	1991	100	1997	2003	X	X	X	X	X	X X
<b>626 1992 1998</b>											
1.8i 16V	FP	1840	66	1994	1997	X	X	X	X	X	X X
1.8i 16V	FP	1840	78	1992	1994	X	X	X	X	X	X X
2.0 D Comprex	RF-CX	1998	56	1992	1997	X	X	X	X	X	X X
2.0i 16V	FS	1991	85	1992	1997	X	X	X	X	X	X X
2.5i V6 24V Xerxes	KL	2497	123	1992	1997	X	X	X	X	X	X X
<b>626 (Wagon -&gt;1997) 1987 1992</b>											
1.8 12V	F8	1789	68	1987	1992	X	X	X	X	X	X X
1.8 12V Wagon	F8	1789	68	1987	1997	X	X	X	X	X	X X
2.0 8V Wagon	FE	1998	66	1987	1997	X	X	X	X	X	X X
2.0D	RF-CX	1998	55	1987	1990	X	X	X	X	X	X X
2.0D	RF-N	1998	44	1987	1992	X	X	X	X	X	X X
2.0D Wagon	RF-CX	1998	55	1987	1997	X	X	X	X	X	X X
2.0i 16V 4WS	FE DOHC	1998	109	1987	1992	X	X	X	X	X	X X
2.0i 8V	FE	1998	66	1987	1992	X	X	X	X	X	X X
2.2i	F2	2184	85	1990	1992	X	X	X	X	X	X X
<b>Demio 1998 2003</b>											
1.3 16V	B3	1323	46	1998	2000	X	X	X	X	X	X X
1.3 16V	B3	1323	46	2000	2003	X	X	X	X	X	X X
1.3 16V	B3 Hi-Power	1323	53	1998	2000	X	X	X	X	X	X X
1.5 16V	B5	1498	55	2000	2003	X	X	X	X	X	X X
<b>E-series 1984 1999</b>											
E1800	F8	1789	61	1984	1987	X	X	X	X	X	X X
E2000	FE	1998	63	1984	1987	X	X	X	X	X	X X
E2000	FE	1998	65	1988	1991	X	X	X	X	X	X X
E2000 4x4	FE	1998	63	1984	1987	X	X	X	X	X	X X
E2000 4x4	FE	1998	65	1988	1991	X	X	X	X	X	X X

Legend: N = new, X = present

# All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>MAZDA</b>											
<b>E-series 1984 1999</b>											
E2000 Automatic	FE	1998	65	1988	1991	X	X	X	X	X	X
E2000i	FE CiS	1998	70	1997	1999	X	X	X	X	X	X
E2000i	FE EGi	1998	60	1991	1994	X	X	X	X	X	X
E2000i	FE EGi	1998	70	1994	1997	X	X	X	X	X	X
E2000i 4x4	FE CiS	1998	70	1997	1999	X	X	X	X	X	X
E2000i 4x4	FE EGi	1998	60	1991	1994	X	X	X	X	X	X
E2000i 4x4	FE EGi	1998	70	1994	1997	X	X	X	X	X	X
E2200 D	R2	2184	44	1984	1989	X	X	X	X	X	X X
E2200 D	R2	2184	47	1990	1997	X	X	X	X	X	X
E2200 D	R2	2184	52	1997	1999	X	X	X	X	X	X
<b>MPV 1999 2002</b>											
2.0	FS	1991	90	1999	2002	X	X	X	X	X	X X
2.5 V6	GY	2498	129	1999	2002	X	X	X	X	X	X X
<b>MPV 2002 2005</b>											
2.0 CiTD	MZR-CD (RF Turbo)	1998	100	2002	2005	X	X	X	X	X	X
2.3 16V	L3	2261	104	2002	2005	X	X	X	X	X	X
<b>MX-3 1990 2001</b>											
1.6i 16V	B6	1598	66	1990	1994	X	X	X	X	X	X X
1.6i 16V	B6	1598	81	1994	2001	X	X	X	X	X	X X
1.8i V6 24V	K8	1845	100	1990	2000	X	X	X	X	X	X X
<b>MX-5 1998 2005</b>											
1.6 16V	B6	1597	81	1998	2005	X	X	X	X	X	X
1.8 16V	BP	1839	103	1998	2000	X	X	X	X	X	X
1.8 16V	BP	1839	107	2000	2005	X	X	X	X	X	X
<b>MX-5 / Miata 1990 1998</b>											
1.6i 16V	B6	1598	85	1990	1994	X	X	X	X	X	X X
1.8i 16V	BP	1840	96	1994	1998	X	X	X	X	X	X
<b>MX-6 1991 1997</b>											
2.0i 16V	FS	1991	85	1991	1994	X	X	X	X	X	X X
2.5i V6 24V	KL	2497	123	1991	1997	X	X	X	X	X	X X
<b>Premacy 1999 2005</b>											
1.8 16V	FP	1840	74	1999	2005	X	X	X	X	X	X
1.8 16V HP	FP Hi-Power	1840	85	1999	2001	X	X	X	X	X	X
2.0 TiTD	RF Turbo	1998	66	1999	2001	X	X	X	X	X	X
<b>Tribute 2000</b>											
2.0 16V	Zetec YFD	1989	91	2000	2004	X	X	X	X	X	X X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>MAZDA</b>											
<b>Tribute 2000</b>											
3.0 V6	Duratec AJD	2967	145	2000		X	X	X	X	X	X
<b>Xedos 6 1992 1999</b>											
1.6 16V	B6	1598	84	1992	1995	X	X	X	X	X	X
2.0 V6 24V	KF	1995	103	1995	1999	X	X	X	X	X	N
2.0 V6 24V	KF	1995	106	1992	1995	X	X	X	X	X	X
<b>Xedos 9 1993 2002</b>											
2.0 V6 24V	KF	1995	105	1993	2001	X	X	X	X	X	X
2.5 V6 24V	KL	2497	123	1993	2002	X	X	X	X	X	X
<b>MERCEDES-BENZ</b>											
<b>190 W201 1982 1993</b>											
190	102.921	1997	66	1982	1984	X	X	X	X	X	X
190	102.924	1997	77	1986	1991	X	X	X	X	X	X
190	102.924 (2E-E)	1997	77	1984	1989	X	X	X	X	X	X
190	102.938	1997	63	1982	1984	X	X	X	X	X	X
190D	601.911	1997	53	1983	1988	X	X	X	X	X	X
190D 2.5	602.911	2497	66	1985	1988	X	X	X	X	X	X
190D 2.5 Turbo	602.961	2497	90	1987	1988	X	X	X	X	X	X
190E	102.961	1997	90	1982	1984	X	X	X	X	X	X
190E	102.962	1997	90	1985	1990	X	X	X	X	X	X
190E 1.8	102.910	1797	80	1990	1993	X	X	X	X	X	X
190E 2.3	102.985	2299	97	1986	1988	X	X	X	X	X	X
190E 2.3 16V	102.983	2299	136	1984	1988	X	X	X	X	X	X
190E 2.5 16V	102.990	2498	143	1988	1993	X	X	X	X	X	X
190E 2.6	103.942	2599	118	1986	1988	X	X	X	X	X	X
190E 2.6	103.942	2599	118	1988	1993	X	X	X	X	X	X
<b>200 - 300 W123 1979 1984</b>											
200	102.920	1997	80	1982	1984	X	X	X	X	X	X
200 D	615.940	1998	44	1982	1984	X	X	X	X	X	X
230 E	102.980	2299	100	1982	1984	X	X	X	X	X	X
240 D	616.912	2399	50	1982	1984	X	X	X	X	X	X
300 D	617.912	2998	61	1982	1984	X	X	X	X	X	X
300 TD	617.952	2998	102	1982	1984	X	X	X	X	X	X
<b>200 - 500, E W124 1984 1995</b>											
200 CE	102.963	1997	90	1988	1990	X	X	X	X	X	X
200 CE, Cabrio 16V	111.940	1998	100	1990	1997	X	X	X	X	X	X
200 D, -TD	601.912	1998	53	1984	1995	X	X	X	X	X	X

Legend: N = new, X = present

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays			
<b>MERCEDES-BENZ</b>														
<b>200 - 500, E W124 1984 1995</b>														
200 E, -TE	102.963	1997	87	1985	1992	X	X	X	X	X	X	X	X	X
200 E, -TE 16V	111.940	1998	100	1992	1996	X	X	X	X	X	X	X	X	X
200, -T	102.922	1997	80	1984	1990	X	X	X	X	X	X	X	X	X
220 CE, Cabrio 16V	111.960	2199	110	1990	1996	X	X	X	X	X	X	X	X	X
220 E, -TE 16V	111.960	2199	110	1992	1995	X	X	X	X	X	X	X	X	X
230 CE	102.982	2298	100	1988	1993	X	X	X	X	X	X	X	X	X
230 E, -TE	102.982	2299	100	1984	1992	X	X	X	X	X	X	X	X	X
250 D TURBODIESEL, -TD	602.962	2497	93	1988	1995	X	X	X	X	X	X	X	X	X
250 D, -TD	602.912	2497	66	1984	1989	X	X	X	X	X	X	X	X	X
250 D, -TD	605.911	2497	83	1989	1996	X	X	X	X	X	X	X	X	X
260 E	103.940	2599	122	1984	1992	X	X	X	X	X	X	X	X	X
260 E 4 MATIC	103.943	2599	122	1987	1991	X	X	X	X	X	X	X	X	X
280 E, -TE 24V	104.942	2799	142	1992	1996	X	X	X	X	X	X	X	X	X
300 CE, Cabrio	103.983	2960	132	1988	1992	X	X	X	X	X	X	X	X	X
300 CE-24, Cabrio	104.980	2960	162	1990	1992	X	X	X	X	X	X	X	X	X
300 D TURBODIESEL, -TD	603.960	2996	108	1985	1996	X	X	X	X	X	X	X	X	X
300 D TURBODIESEL, -TD	603.962	2996	108	1989	1996	X	X	X	X	X	X	X	X	X
300 D TURBODIESEL, -TD 4 MATIC	603.963	2996	108	1988	1995	X	X	X	X	X	X	X	X	X
300 D, -TD	603.912	2996	80	1984	1989	X	X	X	X	X	X	X	X	X
300 D, -TD	606.910	2996	100	1989	1995	X	X	X	X	X	X	X	X	X
300 D, -TD 4 MATIC	603.913	2966	80	1987	1995	X	X	X	X	X	X	X	X	X
300 E, -TE	103.980	2962	138	1984	1989	X	X	X	X	X	X	X	X	X
300 E, -TE	103.983	2960	132	1989	1992	X	X	X	X	X	X	X	X	X
300 E, -TE 4 MATIC	103.985	2960	132	1989	1995	X	X	X	X	X	X	X	X	X
300 E-24, -TE-24	104.980	2960	162	1989	1992	X	X	X	X	X	X	X	X	X
320 CE, Cabrio	104.992	3199	162	1992	1996	X	X	X	X	X	X	X	X	X
320 E, TE	104.992	3199	162	1992	1995	X	X	X	X	X	X	X	X	X
400 / 420 E V8	119.975	4196	205	1993	1995	X	X	X	X	X	X	X	X	X
500 E V8	119.974	4973	235	1990	1995	X	X	X	X	X	X	X	X	X
<b>A W168 1998 2005</b>														
140, -L	166.940	1397	60	1998	2005	X	X	X	X	X	X	X	X	X
140, -L	166.960	1598	60	2001	2005	X	X	X	X	X	X	X	X	X
160 CDi	668.940	1689	55	2001	2005	X	X	X	X	X	X	X	X	X
160 CDi	668.941	1689	44	1998	2001	X	X	X	X	X	X	X	X	X
160, -L	166.960	1598	75	1998	2005	X	X	X	X	X	X	X	X	X
170 CDi	668.940	1689	66	1998	2001	X	X	X	X	X	X	X	X	X
170 CDi, -L	668.942	1689	70	2001	2005	X	X	X	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond. Wir.	Diagr.	
<b>MERCEDES-BENZ</b>													
<b>A W168 1998 2005</b>													
190, -L	166.990	1898	92	1999	2005	X	X	X	X	X	X	X	X
<b>A W169 2005</b>													
150	266.920	1498	70	2005		X	X	X	X	X	X	X	X
160 CDi	640.942	1991	60	2005		X	X	X	X	X	X	X	X
170	266.940	1699	85	2005		X	X	X	X	X	X	X	X
180 CDi	640.940	1991	80	2005		X	X	X	X	X	X	X	X
200	266.960	2034	100	2005		X	X	X	X	X	X	X	X
200 CDi	640.941	1991	103	2005		X	X	X	X	X	X	X	X
200 Turbo	266.980	2034	142	2005		X	X	X	X	X	X	X	X
<b>B W245 2005</b>													
150	266.920	1498	71	2005		X	X	X	X	X	X	X	X
170	266.940	1699	86	2005		X	X	X	X	X	X	X	X
180 CDi	640.940	1992	81	2005		X	X	X	X	X	X	X	X
200	266.960	2035	101	2005		X	X	X	X	X	X	X	X
200 CDi	640.941	1992	104	2005		X	X	X	X	X	X	X	X
<b>C W202 1993 2001</b>													
180 T	111.952	1998	95	2000	2001	X	X	X	X	X	X	X	X
180, -T	111.920	1799	90	1993	2001	X	X	X	X	X	X	X	X
180, -T	111.921	1799	90	1993	2000	X	X	X	X	X	X	X	X
200, -T	111.941	1998	100	1993	2001	X	X	X	X	X	X	X	X
200 CDi, -T	611.960	2151	75	1998	2001	X	X	X	X	X	X	X	X
200 Diesel	601.913	1997	55	1993	1996	X	X	X	X	X	X	X	X
200 Diesel, -T	604.915	1997	65	1996	2000	X	X	X	X	X	X	X	X
200 Kompressor T	111.956	1998	121	2000	2001	X	X	X	X	X	X	X	X
200 Kompressor, -T	111.944	1998	141	1995	2000	X	X	X	X	X	X	X	X
200 T	111.952	1998	95	2000	2001	X	X	X	X	X	X	X	X
200, -T	111.945	1998	100	1993	2001	X	X	X	X	X	X	X	X
220	111.961	2199	110	1993	2000	X	X	X	X	X	X	X	X
220 CDI	611.960	2151	92	1997	2000	X	X	X	X	X	X	X	X
220 CDI T	611.960	2151	92	1998	2001	X	X	X	X	X	X	X	X
220 Diesel, -T	604.910	2155	70	1993	2000	X	X	X	X	X	X	X	X
230 Kompressor	111.975	2295	142	1995	2000	X	X	X	X	X	X	X	X
230 Kompressor T	111.975	2295	142	1997	2001	X	X	X	X	X	X	X	X
230, -T	111.974	2295	110	1995	2000	X	X	X	X	X	X	X	X
240 T	112.915	2597	126	2000	2001	X	X	X	X	X	X	X	X
240, -T	112.910	2398	125	1997	2001	X	X	X	X	X	X	X	X
250 Diesel	605.910	2497	83	1993	2000	X	X	X	X	X	X	X	X



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays
<b>MERCEDES-BENZ</b>												
<b>C W202 1993 2001</b>												
250 Turbodiesel, -T	605.960	2497	111	1995	2001	X	X	X	X	X	X	X
280	104.941	2799	142	1993	1997	X	X	X	X	X	X	X
280 (V6), -T	112.920	2799	145	1997	2001	X	X	X	X	X	X	X
43 AMG, -T	113.944	4266	228	1997	2001	X	X	X	X	X	X	X
<b>C W203 2000</b>												
160 Kompressor Coupe	271.921	1796	90	2005		X	X	X			X	X
180 Kompressor, -T, -Coupe	271.946	1796	105	2002		X	X	X			X	X
180, -T, -Coupe	111.951	1998	95	2001		X	X	X	X	X	X	X
200 CDI, -T	611.962	2148	90	2001	2006	X	X	X	X	X	X	X
200 CDI, -T, -Coupe	646.962	2148	90	2006		X	X	X			X	X
200 CDI, -T, -Coupe	646.963	2148	90	2004		X	X	X			X	X
200 CGI Kompressor, -T	271.942	1998	125	2002	2006	X	X	X			X	X
200 Kompressor Coupe	271.942	1998	125	2001		X	X	X			X	X
200 Kompressor, -T, -Coupe	111.955	1998	120	2000	2002	X	X	X	X	X	X	X
200 Kompressor, -T, -Coupe	271.940	1798	120	2002		X	X	X			X	X
220 CDI, -T, -Coupe	611.962	2148	105	2001		X	X	X	X	X	X	X
220 CDI, -T, -Coupe	646.963	2148	110	2004		X	X	X			X	X
230 Kompressor Coupe	111.981	2295	141	2001		X	X	X	X	X	X	X
230 Kompressor, -T, -Coupe	271.948	2295	141	2001		X	X	X			X	X
230, -T, -Coupe	272.920	2496	150	2005		X	X	X			X	X
240 4-Matic, -T	112.916	2597	125	2001	2006	X	X	X		X	X	X
240, -T	112.912	2597	125	2001	2006	X	X	X	X	X	X	X
270 CDI, -T	612.962	2685	125	2001	2006	X	X	X	X	X	X	X
280 4-Matic, T	272.941	3498	170	2005	2006	X	X	X			X	X
280, -T	272.940	2996	170	2005	2006	X	X	X			X	X
30 CDI AMG, -T, -Coupe	612.990	2950	170	2002	2006	X	X	X		X	X	X
32 AMG Kompressor, -T	112.961	3199	260	2001	2006	X	X	X	X	X	X	X
320 4-Matic, -T	112.953	3199	160	2002	2006	X	X	X			X	X
320, -T, -Coupe	112.946	3199	160	2001		X	X	X	X	X	X	X
350 4-Matic, -T	272.970	3498	200	2005	2006	X	X	X			X	X
350, -T, -Coupe	272.960	3498	200	2005		X	X	X			X	X
55 AMG, -T	113.988	5439	270	2005	2006	X	X	X		X	X	X
<b>C W204 2007</b>												
200 Kompressor	271.950	1796	135	2007		X	X				X	
220 CDi	646.881	2148	125	2007		X	X				X	
230 V6	272.921	2496	150	2007		X	X				X	
280 V6	272.947	2996	170	2007		X	X				X	

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays
<b>MERCEDES-BENZ</b>												
<b>C W204 2007</b>												
320 CDI V6	642.960	2987	165	2007		X	X	X	X	X		
350 V6	272.961	3498	200	2007		X	X	X	X	X		
<b>CL W215 1999 2002</b>												
500	113.960	4966	228	1999	2002	X	X	X	X	X	X	X
55 AMG	113.986	5439	265	1999	2001	X	X	X	X	X	X	X
55 AMG Kompressor	113.991	5439	373	1999	2002	X	X	X	X	X	X	X
600	137.970	5786	270	1999	2002	X	X	X	X	X	X	X
600	275.950	5786	368	1999	2002	X	X	X	X	X	X	X
<b>CLK W208 1997 2002</b>												
200	111.945	1998	100	1997	2002	X	X	X	X	X	X	X
200 Cabriolet	111.945	1998	100	1997	2002	X	X	X	X	X	X	X
200 Kompressor	111.944	1998	141	1997	2002	X	X	X	X	X	X	X
200 Kompressor	111.956	1998	121	2000	2002	X	X	X	X	X	X	X
200 Kompressor Cabriolet	111.944	1998	141	1997	2002	X	X	X	X	X	X	X
200 Kompressor Cabriolet	111.956	1998	121	2000	2002	X	X	X	X	X	X	X
230 Kompressor	111.975	2295	142	1997	2002	X	X	X	X	X	X	X
230 Kompressor	111.982	2295	143	2000	2002	X	X	X	X	X	X	X
230 Kompressor Cabriolet	111.975	2295	142	1997	2002	X	X	X	X	X	X	X
230 Kompressor Cabriolet	111.982	2295	143	2000	2002	X	X	X	X	X	X	X
320	112.940	3199	160	1997	2002	X	X	X	X	X	X	X
320 Cabriolet	112.940	3199	160	1997	2002	X	X	X	X	X	X	X
430	113.943	4266	205	1997	2002	X	X	X	X	X	X	X
430 Cabriolet	113.943	4266	205	1998	2002	X	X	X	X	X	X	X
55 AMG	113.984	5439	255	1999	2002	X	X	X	X	X	X	X
55 AMG Cabriolet	113.984	5439	255	2000	2002	X	X	X	X	X	X	X
<b>CLK W209 2002</b>												
200 K	271.940	1796	120	2002		X	X	X	X	X	X	X
200 K	271.942	1796	125	2002		X	X	X	X	X	X	X
240	112.912	2597	125	2002		X	X	X	X	X	X	X
270 CDI	612.967	2685	125	2002		X	X	X	X	X	X	X
320	112.955	3199	160	2002		X	X	X	X	X	X	X
500	113.968	4966	225	2002		X	X	X	X	X	X	X
55 AMG	113.987	5439	270	2002		X	X	X	X	X	X	X
<b>CLS W219 2005</b>												
320 CDI	642.920	2987	167	2005		X	X	X	X	X	X	X
350	272.964	3498	203	2005		X	X	X	X	X	X	X
500	113.967	4966	306	2005		X	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance		Techn. Drawings		Motor Manag.		Wiring Diagr.		Service Reset		Repair Times		
						Identification	Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	Fuses & Relays					
<b>MERCEDES-BENZ</b>																		
<b>CLS W219 2005</b>																		
55 AMG V8 Kompressor	113.990	5439	355	2005		X	X	X	X	X				X	X		X	X
<b>E W210 1996 2002</b>																		
200 CDI	611.961	2149	75	1998	2002	X	X	X	X	X	X			X	X		X	X
200 CDI	611.961	2149	85	1999	2002	X	X	X	X	X	X			X	X		X	X
200 Diesel	604.917	1997	65	1997	1999	X	X	X	X	X	X	X	X	X	X		X	X
200 Kompressor, -T	111.947	1998	141	1997	2000	X	X	X	X	X	X			X	X		X	X
200 Kompressor, -T	111.957	1998	120	2000	2002	X	X	X	X	X	X			X	X			X
200, -T	111.942	1998	100	1996	2001	X	X	X	X	X	X	X	X	X	X		X	X
220 CDI, -T	611.961	2149	92	1998	2002	X	X	X	X	X	X			X	X		X	X
220 Diesel	604.912	2155	70	1996	1999	X	X	X	X	X	X	X	X	X	X		X	X
230, -T	111.970	2295	110	1996	1998	X	X	X	X	X	X	X	X	X	X		X	X
240, -T	112.911	2398	125	1998	1999	X	X	X	X	X	X			X	X		X	X
240, -T	112.914	2597	125	1999	2002	X	X	X	X	X	X			X	X		X	X
250 Diesel, -T	605.912	2497	83	1995	1999	X	X	X	X	X	X	X	X	X	X		X	X
250 Turbodiesel, -T	605.962	2497	110	1997	1999	X	X	X	X	X	X			X	X		X	X
270 CDI, -T	612.961	2687	125	1999	2002	X	X	X	X	X	X			X	X		X	X
280	104.945	2799	142	1996	1997	X	X	X	X	X	X	X	X	X	X		X	X
280, -T	112.921	2799	150	1998	2002	X	X	X	X	X	X	X	X	X	X		X	X
290 Turbodiesel, -T	602.982	2874	95	1996	1999	X	X	X	X	X	X	X	X	X	X		X	X
300 Diesel, -T	606.912	2996	100	1996	1999	X	X	X	X	X	X	X	X	X	X		X	X
300 Turbodiesel, -T	606.962	2996	130	1996	1998	X	X	X	X	X	X	X	X	X	X		X	X
320 CDI, T	613.961	3224	145	1998	2002	X	X	X	X	X	X			X	X		X	X
320, -T	104.995	3199	162	1996	1997	X	X	X	X	X	X	X	X	X	X		X	X
320, -T	112.941	3199	165	1997	1999	X	X	X	X	X	X	X	X	X	X		X	X
420, -T	119.985	4196	205	1996	1997	X	X	X	X	X	X	X	X	X	X		X	X
430, -T	113.940	4266	205	1997	2002	X	X	X	X	X	X	X	X	X	X		X	X
55 AMG, -T	113.980	5439	260	1997	2002	X	X	X	X	X	X			X	X		X	X
<b>E W211 2002</b>																		
200 CDI	646.951	2148	90	2002	2005	X	X	X	X	X	X			X	X		X	X
200 Kompressor	271.943	1796	120	2002	2005	X	X	X	X	X	X			X	X		X	X
200 Kompressor, -T	271.941	1796	120	2002	2005	X	X	X	X	X	X			X	X		X	X
220 CDI, -T	646.961	2148	110	2002	2005	X	X	X	X	X	X			X	X		X	X
220 CDI, -T	646.961	2148	125	2006		X	X	X	X	X	X			X	X		X	X
240 4-Matic, -T	112.917	2597	130	2002	2005	X	X	X	X	X	X			X	X		X	X
240, -T	112.913	2597	130	2002	2005	X	X	X	X	X	X			X	X		X	X
270 CDI	647.961	2685	130	2002	2005	X	X	X	X	X	X			X	X		X	X
270 CDI, -T	647.961	2685	130	2002	2005	X	X	X	X	X	X			X	X		X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>MERCEDES-BENZ</b>											
<b>E W211 2002</b>											
280 4-Matic T	272.944	2996	170	2006		X	X	X	X	X	X
280 CDI 4-Matic V6, -T	642.921	2987	140	2006		X	X	X	X	X	X
280 CDI R6, -T	648.961	3222	140	2004	2005	X	X	X	X	X	X
280 CDI V6, -T	642.920	2987	140	2006		X	X	X	X	X	X
280, -T	272.943	2996	170	2006		X	X	X	X	X	X
320 4-Matic, -T	112.954	3199	165	2003	2005	X	X	X	X	X	X
320 CDI 4-Matic V6, -T	642.921	2987	165	2006		X	X	X	X	X	X
320 CDI R6, -T	648.961	3222	150	2002	2005	X	X	X	X	X	X
320 CDI V6, -T	642.920	2987	165	2006		X	X	X	X	X	X
320, -T	112.949	3199	165	2002	2005	X	X	X	X	X	X
350 4-Matic T	272.972	3498	200	2006		X	X	X	X	X	X
350, -T	272.964	3498	200	2006		X	X	X	X	X	X
400 CDI	628.961	3996	191	2003	2005	X	X	X	X	X	X
420 CDI	629.910	3996	231	2005		X	X	X	X	X	X
500 4-Matic, -T	113.969	4966	225	2003	2005	X	X	X	X	X	X
500, -T	113.967	4966	225	2002	2005	X	X	X	X	X	X
55 AMG Kompressor, -T	113.990	5439	350	2002	2005	X	X	X	X	X	X
<b>G W460 1979 1991</b>											
230G	115.973	2307	66	1979	1989	X	X	X	X	X	X
230GE	102.981	2299	92	1982	1989	X	X	X	X	X	X
230GE	102.987	2298	90	1982	1989	X	X	X	X	X	X
240GD	616.936	2399	53	1979	1991	X	X	X	X	X	X
250GD	602.930	2497	62	1987	1991	X	X	X	X	X	X
280GE	110.994	2746	110	1982	1991	X	X	X	X	X	X
300GD	617.931	2998	65	1979	1991	X	X	X	X	X	X
300GD	617.932	2998	65	1979	1991	X	X	X	X	X	X
<b>G W461 1991</b>											
230GE	102.979	2298	90	1991	1997	X	X	X	X	X	X
230GE	102.981	2298	93	1991	1997	X	X	X	X	X	X
230GE	102.996	2298	92	1991	1997	X	X	X	X	X	X
250GD	602.939	2497	68	1991	1992	X	X	X	X	X	X
290GD	602.942	2874	70	1992	1997	X	X	X	X	X	X
290GD	602.946	2874	72	1992	1997	X	X	X	X	X	X
290GD	602.947	2874	72	1992	1997	X	X	X	X	X	X
290GDT	602.983	2874	88	1997	2001	X	X	X	X	X	X
<b>G W463 1990</b>											
230GE, G230	102.989	2298	93	1990	1997	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagram. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagn. Fuses & Relays
<b>MERCEDES-BENZ</b>											
<b>G W463 1990</b>											
250GD	602.931	2497	69	1990	1997	X	X	X	X	X	X
300GD, G300 Diesel	603.931	2960	83	1990	1997	X	X	X	X	X	X
300GE, G300	103.987	2960	125	1990	1994	X	X	X	X	X	X
350G DT, G350 TD	603.972	3449	100	1992	1997	X	X	X	X	X	X
500GE V, G500	117.965	4973	177	1993	1997	X	X	X	X	X	X
G270 CDI	612.965	2688	115	2002	2006	X	X	X	X	X	X
G300 DT	606.964	2996	130	1996	2000	X	X	X	X	X	X
G320	104.996	3199	155	1994	1997	X	X	X	X	X	X
G320	112.945	3199	158	1997	2006	X	X	X	X	X	X
G400 CDI	628.962	3996	184	2000	2006	X	X	X	X	X	X
G500	113.962	4996	218	1998		X	X	X	X	X	X
G55 AMG	113.982	5439	260	1999	2004	X	X	X	X	X	X
<b>GL X164 2006</b>											
320 CDI 4-MATIC (V6 24V)	642.940	2987	165	2006		X	X	X	X	X	X
420 CDI 4-MATIC (V8 32V)	629.912	3996	225	2007		X	X	X	X	X	X
450 4-MATIC (V8 32V)	273.923	4663	250	2007		X	X	X	X	X	X
500 4-MATIC (V8 32V)	273.963	5461	285	2007		X	X	X	X	X	X
<b>M W164 2006</b>											
280 CDI 4-MATIC (V6 24V)	642.940	2987	140	2005		X	X	X	X	X	X
320 CDI 4-MATIC (V6 24V)	642.940	2987	165	2005		X	X	X	X	X	X
350 4-MATIC (V6 24V)	272.967	3498	200	2005		X	X	X	X	X	X
420 CDI 4-MATIC (V8 32V)	629.912	3997	225	2006		X	X	X	X	X	X
500 4-MATIC (V8 24V)	113.964	4966	225	2005	2007	X	X	X	X	X	X
63 AMG 4-MATIC (V8 24V)	156.980	6209	375	2007		X	X	X	X	X	X
<b>MB 100 W631 1988 1995</b>											
MB 100	616.963	2399	53	1988	1995		X	X			X X
<b>ML W163 1998 2005</b>											
230	111.977	2295	110	1998	2002	X	X	X	X	X	X X
270 CDI	612.963	2685	120	1999	2005	X	X	X	X	X	X X
320	112.942	3199	160	1998	2002	X	X	X	X	X	X X
350	112.970	3724	180	2002	2005	X	X	X	X	X	X X
400 CDI	628.963	3996	184	2002	2005	X	X	X	X	X	X X
430	113.942	4266	200	1998	2002	X	X	X	X	X	X X
500	113.965	4966	215	2002	2005	X	X	X	X	X	X X
55 AMG	113.981	5439	255	2000	2005	X	X	X	X	X	X X
<b>S W220 1999 2005</b>											
280	112.922	2799	150	1999	2002	X	X	X	X	X	X X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays
<b>MERCEDES-BENZ</b>												
<b>S W220 1999 2005</b>												
320	112.944	3199	165	2002	2005	X	X	X	X	X	X	X
320 CDI	613.960	3222	145	2000	2002	X	X	X	X	X	X	X
350	112.972	3724	182	2002	2005	X	X	X	X	X	X	X
350 4-Matic	112.975	3724	182	2002	2005	X	X	X	X	X	X	X
400 CDI	628.960	3996	175	2000	2002	X	X	X	X	X	X	X
430	113.941	4266	205	2002	2005	X	X	X	X	X	X	X
430 4-Matic	113.948	4266	205	2002	2005	X	X	X	X	X	X	X
500	113.960	4966	225	2002	2005	X	X	X	X	X	X	X
500 4-Matic	113.966	4966	225	2002	2005	X	X	X	X	X	X	X
55 AMG	113.986	5439	265	2000	2001	X	X	X	X	X	X	X
55 AMG Kompressor	113.991	5439	368	2002	2005	X	X	X	X	X	X	X
600	137.970	5786	270	1999	2002	X	X	X	X	X	X	X
600	275.950	5786	368	2002	2005	X	X	X	X	X	X	X
S320 CDI	648.960	3222	150	2002	2005	X	X	X	X	X	X	X
<b>S / SEC / CL W140 1991 1999</b>												
280 SE, -SEL	104.944	2799	142	1991	1993	X	X	X	X	X	X	X
300 SD Turbo	603.971	3449	110	1991	1999	X	X	X	X	X	X	X
300 SE	104.944	2799	145	1991	1993	X	X	X	X	X	X	X
300 SE, -SEL	104.990	3199	170	1991	1993	X	X	X	X	X	X	X
300 SE, -SEL	104.994	3199	162	1991	1993	X	X	X	X	X	X	X
400 SE, -SEL	119.971	4196	210	1991	1993	X	X	X	X	X	X	X
400 SE, -SEL	119.981	4196	205	1991	1993	X	X	X	X	X	X	X
500 SE Coupe	119.970	4973	235	1992	1996	X	X	X	X	X	X	X
500 SE Coupe	119.980	4973	235	1992	1996	X	X	X	X	X	X	X
500 SE, -SEL	119.970	4973	235	1991	1993	X	X	X	X	X	X	X
500 SE, -SEL	119.980	4973	235	1991	1993	X	X	X	X	X	X	X
600 SE Coupe	120.980	5987	290	1992	1996	X	X	X	X	X	X	X
600 SE Coupe	120.982	5987	290	1992	1996	X	X	X	X	X	X	X
600 SE, -SEL	120.980	5987	300	1991	1993	X	X	X	X	X	X	X
600 SE, -SEL	120.982	5987	290	1991	1993	X	X	X	X	X	X	X
CL420 Coupe	119.971	4196	205	1996	1999	X	X	X	X	X	X	X
CL420 Coupe	119.981	4196	205	1996	1999	X	X	X	X	X	X	X
CL500 Coupe	119.970	4973	235	1996	1999	X	X	X	X	X	X	X
CL500 Coupe	119.980	4973	235	1996	1999	X	X	X	X	X	X	X
CL600 Coupe	120.980	5987	290	1996	1999	X	X	X	X	X	X	X
CL600 Coupe	120.982	5987	290	1996	1999	X	X	X	X	X	X	X
S280	104.944	2799	145	1993	1999	X	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>MERCEDES-BENZ</b>											
<b>S / SEC / CL W140 1991 1999</b>											
S300 Turbo Diesel	606.961	2996	130	1991	1999	X	X	X	X	X	X
S320	104.990	3199	170	1993	1999	X	X	X	X	X	X
S320	104.994	3199	162	1993	1999	X	X	X	X	X	X
S350 Turbo Diesel	603.971	3449	110	1991	1999	X	X	X	X	X	X
S420 Coupe	119.971	4196	205	1993	1999	X	X	X	X	X	X
S420 Coupe	119.981	4196	205	1992	1996	X	X	X	X	X	X
S500	119.970	4973	235	1993	1999	X	X	X	X	X	X
S500 Coupe	119.970	4973	235	1993	1999	X	X	X	X	X	X
S500 Coupe	119.980	4973	235	1992	1996	X	X	X	X	X	X
S600	120.980	5987	290	1993	1999	X	X	X	X	X	X
S600 Coupe	120.980	5987	290	1993	1999	X	X	X	X	X	X
S600 Coupe	120.982	5987	290	1992	1996	X	X	X	X	X	X
<b>SE / SEL / SEC W126 1979 1992</b>											
260 SE	103.941	2599	122	1985	1991	X	X	X	X	X	X
260 SE	103.943	2597	118	1987	1991	X	X	X	X	X	X
280 S	110.924	2746	115	1979	1982	X	X	X	X	X	X
280 S	110.926	2746	115	1979	1985	X	X	X	X	X	X
280 SE, -SEL	110.987	2746	136	1979	1985	X	X	X	X	X	X
280 SE, -SEL	110.989	2746	136	1979	1985	X	X	X	X	X	X
300 SE, -SEL	103.981	2962	138	1985	1991	X	X	X	X	X	X
380 SE, -SEL	116.961	3839	160	1985	1986	X	X	X	X	X	X
380 SE, -SEL	116.963	3839	150	1979	1983	X	X	X	X	X	X
380 SEC	116.963	3839	150	1984	1985	X	X	X	X	X	X
420 SE, -SEL	116.964	4196	160	1985	1991	X	X	X	X	X	X
420 SE, SEL, SEC	116.965	4196	160	1985	1992	X	X	X	X	X	X
420 SEC	116.964	4196	160	1985	1992	X	X	X	X	X	X
500 SE, -SEL	117.961	4973	177	1979	1985	X	X	X	X	X	X
500 SE, -SEL	117.963	4973	170	1979	1985	X	X	X	X	X	X
500 SE, -SEL	117.964	4973	180	1985	1991	X	X	X	X	X	X
500 SE, -SEL	117.965	4973	170	1979	1985	X	X	X	X	X	X
500 SEC	117.963	4973	170	1981	1991	X	X	X	X	X	X
500 SEC	117.965	4973	195	1985	1991	X	X	X	X	X	X
560 SE, -SEL	117.967	5547	200	1985	1991	X	X	X	X	X	X
560 SEC, -SEL	117.968	5547	220	1985	1992	X	X	X	X	X	X
<b>SL W129 1989 2001</b>											
300SL	103.984	2960	140	1989	1993	X	X	X	X	X	X
300SL 2.8	104.943	2799	170	1993	1999	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>MERCEDES-BENZ</b>											
<b>SL W129 1989 2001</b>											
300SL 24V	104.981	2960	170	1989	1993	X	X	X	X	X	X
300SL 3.2	104.991	3199	170	1993	2000	X	X	X	X	X	X
500SL	119.970	4973	240	1989	1993	X	X	X	X	X	X
500SL	119.972	4973	235	1992	2000	X	X	X	X	X	X
500SL	119.982	4973	235	1995	1999	X	X	X	X	X	X
600SL	120.983	5987	290	1995	1999	X	X	X	X	X	X
SL280	104.944	2799	142	1993	2001	X	X	X	X	X	X
SL280	112.923	2799	150	1997	2001	X	X	X	X	X	X
SL280	112.925	2799	165	1998	2001	X	X	X	X	X	X
SL320	104.990	3199	170	1993	2001	X	X	X	X	X	X
SL320	112.943	3199	165	1997	2001	X	X	X	X	X	X
SL500	113.961	4966	225	1997	2001	X	X	X	X	X	X
SL500	119.960	4973	235	1993	2001	X	X	X	X	X	X
SL600	120.981	5987	290	1993	2001	X	X	X	X	X	X
<b>SL W230 2001</b>											
350	112.973	3724	180	2002		X	X	X	X	X	X
500	113.963	4966	225	2001		X	X	X	X	X	X
55 AMG	113.992	5439	368	2001		X	X	X	X	X	X
600	275.951	5513	368	2002		X	X	X	X	X	X
<b>SLK W170 1996 2004</b>											
200	111.946	1998	100	1996	2000	X	X	X	X	X	X
200 Kompressor	111.943	1998	141	1996	2000	X	X	X	X	X	X
200 Kompressor	111.958	1998	120	2000	2004	X	X	X	X	X	X
230 Kompressor	111.973	2295	142	1996	2000	X	X	X	X	X	X
230 Kompressor	111.983	2295	145	2000	2004	X	X	X	X	X	X
32 AMG Kompressor	112.960	3199	260	2001	2004	X	X	X	X	X	X
320	112.947	3199	160	2000	2004	X	X	X	X	X	X
<b>SLK W171 2004</b>											
200 Kompressor	271.944	1795	120	2004		X	X	X	X	X	X
280	272.942	2998	170	2005		X	X	X	X	X	X
350	272.963	3498	200	2004		X	X	X	X	X	X
55 AMG	113.989	5439	265	2004		X	X	X	X	X	X
<b>Sprinter W901/2/3/4/5 1995 2006</b>											
208 CDI	611.987	2148	60	2000	2006	X	X	X	X	X	X
208 D	601.943	2299	58	1995	2000	X	X	X	X	X	X
210 D	602.980	2874	75	1997	2000	X	X	X	X	X	X
211 CDI	611.981	2148	80	2000	2006	X	X	X	X	X	X

Legend: N = new, X = present



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diagr. Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diagr. Fuses & Relays

**MERCEDES-BENZ**

**Sprinter W901/2/3/4/5 1995 2006**

212 D	602.980	2874	90	1995	2000	X	X	X	X	X				X		X	X
213 CDI	611.983	2148	95	2000	2006	X	X	X	X	X				X	X	X	X
214	111.979	2295	105	1995	2000	X	X	X	X	X				X		X	X
214	111.984	2295	105	2000	2006	X	X	X	X	X				X	X	X	X
308 CDI	611.987	2148	60	2000	2006	X	X	X	X	X				X	X	X	X
308 D	601.943	2299	58	1995	2000	X	X	X	X	X				X		X	X
310 D	602.980	2874	75	1995	2000	X	X	X	X	X				X		X	X
311 CDI	611.981	2148	80	2000	2006	X	X	X	X	X			X	X	X	X	X
312 D	602.980	2874	90	1995	2000	X	X	X	X	X				X		X	X
313 CDI	611.983	2148	95	2000	2006	X	X	X	X	X				X	X	X	X
314	111.984	2295	105	2000	2006	X	X	X	X	X				X	X	X	X
316 CDI	612.981	2685	115	2000	2006	X	X	X	X	X				X	X	X	X
408 CDI	611.987	2148	60	2000	2006	X	X	X	X	X				X	X	X	X
408 D	601.943	2299	58	1996	2000	X	X	X	X	X				X		X	X
410 D	602.980	2874	75	1996	2000	X	X	X	X	X				X		X	X
411 CDI	611.981	2148	80	2000	2006	X	X	X	X	X			X	X	X	X	X
412 D	602.980	2874	90	1996	2000	X	X	X	X	X				X		X	X
413 CDI	611.983	2148	95	2000	2006	X	X	X	X	X				X	X	X	X
414	111.979	2295	105	1996	2000	X	X	X	X	X				X		X	X
414	111.984	2295	105	2000	2006	X	X	X	X	X				X	X	X	X
416 CDI	612.981	2685	115	2000	2006	X	X	X	X	X				X	X	X	X
616 CDI	612.981	2685	115	2000	2006	X	X	X	X	X				X	X	X	X

**Sprinter II W906 2006**

211 CDI	646.985	2148	80	2006		X	X							X	X		
213 CDI	646.989	2148	95	2006		X	X								X		
215 CDI	646.986	2148	110	2006		X	X							X	X		
218 CDI	642.992	2987	135	2006		X	X								X		
224	272.979	3498	190	2006		X	X										
309 CDI	646.984	2148	65	2006		X	X							X	X		
311 CDI	646.985	2148	80	2006		X	X							X	X		
313 CDI	646.989	2148	95	2006		X	X								X		
315 CDI	646.986	2148	110	2006		X	X							X	X		
318 CDI	642.992	2987	135	2006		X	X								X		
324	272.979	3498	190	2006		X	X										
411 CDI	646.985	2148	80	2006		X	X							X	X		
413 CDI	646.989	2148	95	2006		X	X								X		
415 CDI	646.986	2148	110	2006		X	X							X	X		

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Air Cond.	Wir. Diagr.	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine					
<b>MERCEDES-BENZ</b>															
<b>Sprinter II W906 2006</b>															
418 CDI	642.992	2987	135	2006		X	X					X			
424	272.979	3498	190	2006		X									
<b>T1 W601/2 1982 1995</b>															
208 D	601.940	2299	58	1988	1995		X	X						X	X
210	102.945	2298	70	1982	1995		X	X						X	X
210 D	602.940	2874	70	1988	1995		X	X						X	X
308 D	601.940	2299	58	1988	1995		X	X						X	X
310	102.945	2298	70	1982	1995		X	X						X	X
310 D	602.940	2874	70	1998	1995		X	X						X	X
408 D	601.940	2299	58	1988	1995		X	X						X	X
410	102.945	2298	70	1982	1995		X	X						X	X
410 D	602.940	2874	70	1988	1995		X	X						X	X
<b>Vaneo W414 2002 2005</b>															
1.6	166.961	1598	60	2002	2005	X	X	X	X		X	X		X	
1.6	166.961	1598	75	2002	2005	X	X	X	X		X	X		X	
1.7 CDi	668.914	1689	55	2002	2005	X	X	X	X		X	X		X	
1.7 CDi	668.914	1689	67	2002	2005	X	X	X	X		X	X		X	
1.9	166.991	1898	92	2002	2005	X	X	X	X		X	X		X	
<b>Vito / V- W638 1996 2003</b>															
108 CDI	611.980	2151	60	1999	2003	X	X	X	X	X		X	X	X	X
108 D	601.942	2299	58	1996	1999	X	X	X	X	X		X		X	X
110 CDI	611.980	2151	75	1999	2003	X	X	X	X	X		X	X	X	X
110 D	601.970	2299	72	1996	1999	X	X	X	X	X	X		X	X	X
112 CDI	611.980	2151	90	1999	2003	X	X	X	X	X		X	X	X	X
113	111.948	1998	95	1996	1999	X	X	X	X	X	X		X	X	X
113	111.950	1998	95	1999	2003	X	X	X	X	X	X		X	X	X
114	111.980	1998	105	1999	2003	X	X	X	X	X	X		X	X	X
114 KA, KB, 4X2, 3000	111.978	2295	105	1996	1999	X	X	X	X	X	X	X	X	X	X
V 200	111.948	1998	95	1996	1999	X	X	X	X	X	X		X	X	X
V 200	111.950	1998	100	1999	2003	X	X	X	X	X	X		X		X
V 200 CDI	611.980	2151	75	1999	2003	X	X	X	X	X	X		X	X	X
V 220 CDI	611.980	2151	95	1999	2003	X	X	X	X	X	X		X	X	X
V 230	111.978	2295	105	1996	1999	X	X	X	X	X	X	X	X	X	X
V 230	111.980	1998	105	1999	2003	X	X	X	X	X	X		X	X	X
V 230 TD	601.970	2295	72	1996	1999	X	X	X	X	X	X	X	X	X	X
V 280	104.900	2792	128	1996	2003	X	X	X	X	X	X	X	X	X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>MERCEDES-BENZ</b>											
<b>Vito / Viano W639 2003</b>											
Viano 2.0 CDi	646.983	2148	65	2003		X	X	X	X	X	X
Viano 2.2 CDi	646.982	2148	80	2003		X	X	X	X	X	X
Viano 2.5 CDi	646.982	2148	110	2003		X	X	X	X	X	X
Viano 3.0	112.951	3199	140	2003		X	X	X	X	X	X
Viano 3.2	112.951	3199	160	2003	2004	X	X	X	X	X	X
Viano 3.5	112.976	3724	170	2004		X	X	X	X	X	X
Vito 109 CDi	646.983	2148	65	2003		X	X	X	X	X	X
Vito 111 CDi	646.982	2148	80	2003		X	X	X	X	X	X
Vito 115 CDi	646.982	2148	110	2003		X	X	X	X	X	X
Vito 119	112.951	3199	140	2003		X	X	X	X	X	X
Vito 122	112.951	3199	160	2003	2004	X	X	X	X	X	X
Vito 123	112.976	3724	170	2004		X	X	X	X	X	X
<b>MG</b>											
<b>MGF 1995 2002</b>											
1.6 MPI	K16	1588	82	2001	2002	X	X	X	X	X	X
1.8 MPI	K18	1796	88	1995	2002	X	X	X	X	X	X
1.8 VVC	K18VVC	1796	107	1995	2002	X	X	X	X	X	X
Trophy 160	K18VVC	1796	118	2001	2002	X	X	X	X	X	X
<b>RV8 1993 1996</b>											
RV8	V8	3948	142	1993	1996	X	X				
<b>ZR 2001 2004</b>											
100 iDT	20T2N	1994	74	2001	2004	X	X	X	X	X	X
105	14K4F	1396	76	2001	2004	X	X	X	X	X	X
115 iDT	20T2N	1994	83	2001	2004	X	X	X	X	X	X
120	18K4F	1796	86	2001	2004	X	X	X	X	X	X
160	18K4	1795	118	2001	2004	X	X	X	X	X	X
<b>ZS 2001 2005</b>											
100 iDT	20T2N	1994	74	2001	2005	X	X	X	X	X	X
110	16K4F	1588	80	2001	2005	X	X	X	X	X	X
115 iDT	20T2	1994	83	2001	2005	X	X	X	X	X	X
120	18K4F	1796	86	2001	2005	X	X	X	X	X	X
180	25K4F	2497	130	2001	2005	X	X	X	X	X	X
<b>ZT ZT-T 2001 2005</b>											
120	18K4F	1796	88	2001	2005	X	X	X	X	X	X
160 Turbo	18K4G	1796	118	2001	2005	X	X	X	X	X	X
180 V6	25K4F	2497	130	2001	2005	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>MG</b>											
<b>ZT ZT-T 2001 2005</b>											
190 V6	25K4F	2497	140	2001	2005	X	X	X	X	X	X
260 V8	46F2F	4601	191	2001	2005	X	X	X	X	X	X
CDTi 115	204D2 (M47R)	1994	85	2001	2005	X	X	X	X	X	X
CDTi 135	204D2 (M47R)	1994	96	2001	2005	X	X	X	X	X	X
<b>MINI</b>											
<b>Mini R50 2000 2007</b>											
1.4 D	W17	1364	55	2003	2007	X	X	X	X	X	X
1.6 16V Cooper	W10 B16B	1598	85	2000	2007	X	X	X	X	X	X
1.6 16V One	W10 B16A	1598	66	2000	2007	X	X	X	X	X	X
<b>Mini Cooper S R53 2002 2006</b>											
1.6 16V Cooper S	W11 B16A	1598	120	2002	2006	X	X	X	X	X	X
<b>MITSUBISHI</b>											
<b>3000 1992 1999</b>											
GT	6G72	2972	210	1992	1999	X	X	X	X	X	X
<b>Carisma 1995 2004</b>											
1.3 16V SOHC	4G13	1299	55	2002	2004	X	X	X	X	X	X
1.6 16V SOHC	4G92	1597	66	1995	2004	X	X	X	X	X	X
1.8 16V DOHC	4G93	1834	103	1995	1999	X	X	X	X	X	X
1.8 16V GDI	4G93	1834	92	1997	2004	X	X	X	X	X	X
1.8 16V SOHC	4G93	1834	85	1995	1999	X	X	X	X	X	X
1.9 DI-D	F9Q	1870	74	2001	2004	X	X	X	X	X	X
1.9 TD	F8QT	1870	66	1996	2000	X	X	X	X	X	X
<b>Colt 1996 2004</b>											
1.3 12V	4G13	1299	55	1996	2001	X	X	X	X	X	X
1.6 16V	4G92	1597	66	1996	2001	X	X	X	X	X	X
<b>Colt 2005</b>											
1.1 MPI 12V	134.910	1124	55	2005		X	X	X	X	X	X
1.3 MPI 16V	135.930	1332	70	2005		X	X	X	X	X	X
1.5 D-ID 12V	639.939	1493	50	2005		X	X	X	X	X	X
1.5 DI-D 12V	639.939	1493	70	2005		X	X	X	X	X	X
1.5 MPI 16V	135.950	1499	80	2005		X	X	X	X	X	X
1.5 Turbo	4G15	1468	110	2005		X	X	X	X	X	X
<b>Colt 1983 1988</b>											
1.2	4G16	1198	44	1986	1988	X	X	X	X	X	X
1.5	4G15	1468	55	1983	1988	X	X	X	X	X	X
1.5	4G15B	1468	51	1986	1988	X	X	X	X	X	X

Legend: N = new, X = present

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>MITSUBISHI</b>													
<b>Colt 1983 1988</b>													
1.6 Turbo	G32B	1597	77	1986	1988	X	X	X	X		X		X
1.8 D	4D65	1795	44	1983	1988	X	X	X	X		X		X
<b>Colt 1988 1992</b>													
1.3 12V	4G13	1298	55	1990	1992	X	X	X	X		X	X	X
1.3 8V	4G13	1298	51	1988	1990	X	X	X	X		X	X	X
1.8 D	4D65	1796	44	1988	1992	X	X	X	X		X		X
1500 12V	4G15	1468	66	1990	1992	X	X	X	X	X	X		X
1500 12V	4G15	1468	66	1990	1992	X	X	X	X	X	X		X
1500 8V	4G15	1468	62	1988	1990	X	X	X	X	X	X		X
1500 8V	4G15	1468	62	1988	1992	X	X	X	X	X	X		X
1600 GTi-16V	4G61	1596	94	1988	1990	X	X	X	X	X	X		X
1800 GTi 16V	4G67	1836	100	1989	1992	X	X	X	X	X	X		X
<b>Colt 1992 1996</b>													
1.3 i 12V	4G13	1298	55	1992	1996	X	X	X	X	X	X	X	X
1.6 i 16V	4G92	1597	83	1992	1996	X	X	X	X	X	X	X	X
1.6i 4WD	4G92	1597	84	1992	1996	X	X	X	X	X	X	X	X
1.8 GTi 16V	4G93 DOHC	1834	103	1992	1996	X	X	X	X	X	X	X	X
<b>Eclipse 1995 1999</b>													
2.0 16V	4G63 DOHC	1997	107	1995	1999	X		X	X		X		X
<b>Galant 1984 1988</b>													
1.6	4G32	1597	55	1984	1988		X	X	X		X		X
1.8 TD	4D65	1795	55	1984	1988		X	X	X		X		X
2.0	4G63	1997	55	1984	1988		X	X	X		X		X
2.0 Turbo	4G63	1997	110	1984	1988		X	X	X		X		X
<b>Galant 1988 1993</b>													
1.6	4G32	1598	56	1988	1989	X	X	X	X		X		X
1.8	4G37	1755	66	1988	1989	X	X	X	X		X		X
1.8 D	4D65	1796	55	1988	1992	X	X	X	X		X		X
1.8i	4G37	1775	66	1990	1992	X	X	X	X		X		X
2.0	4G63	1997	80	1988	1992	X	X	X	X		X		X
2.0 16V	4G63	1997	106	1988	1992	X	X	X	X		X		X
2.0 GTi 4X4 16V 4WS	4G63	1997	110	1989	1992	X	X	X	X		X		X
2.0i 4X4	4G63	1997	80	1989	1992	X	X	X	X		X		X
<b>Galant 1993 1997</b>													
1.8 i	4G93	1834	93	1993	1997	X	X	X	X	X	X		X X
2.0	4G63	1997	101	1993	1997	X	X	X	X	X	X		X X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>MITSUBISHI</b>											
<b>Galant 1993 1997</b>											
2.0 4WD	4G63	1997	101	1993	1997	X	X	X	X	X	X
2.0 TD	4D68	1998	66	1993	1997	X	X	X	X	X	X
2.0 V6 24V	6A12	1999	110	1993	1997	X	X	X	X	X	X
2.0 V6 24V 4WS	6A12	1999	110	1993	1997	X	X	X	X	X	X
2.5 V6 24V 4WD	6G73	2497	125	1993	1997	X	X	X	X	X	X
<b>Galant 1997 2004</b>											
2.0	4G63	1997	100	1997	2004	X	X	X	X	X	X
2.0 TD	4D68	1998	66	1997	2004	X	X	X	X	X	X
2.5 V6 24V	6A13	2498	120	1997	2004	X	X	X	X	X	X
<b>Grandis 2004</b>											
2.4 16V SOHC	4G69	2378	121	2004		X	X	X			
<b>L200 1997 2006</b>											
2.0 16V	4G63	1997	90	1997	2006	X	X	X		X	X
2.4 16V 4x4	4G64	2351	97	1997	2006	X	X	X		X	X
2.5 D	4D56	2477	55	1997	2001	X	X	X		X	X
2.5 TD 4x4	4D56	2477	73	1997	2001	X	X	X		X	X
<b>L200 KB4T 2006</b>											
2.5 DI-D	4D56	2477	100	2006		X	X	X		X	X
<b>L300 1987 2003</b>											
1.6	4G32	1597	48	1987	1989	X	X	X	X	X	X
1.6	4G32	1597	51	1989	2000	X	X	X	X	X	X
1.6 LWB	4G32	1597	48	1987	1989	X	X	X	X	X	X
1.6 LWB	4G32	1597	51	1989	2000	X	X	X	X	X	X
2.0	4G63	1997	65	1987	1989	X	X	X	X	X	X
2.0	4G63	1997	65	1989	2003	X	X	X	X	X	X
2.0 4x4	4G63	1997	65	1987	1989	X	X	X	X	X	X
2.0 4x4	4G63	1997	65	1989	2003	X	X	X	X	X	X
2.0 Automatic	4G63	1997	65	1991	2003	X	X	X	X	X	X
2.0 LWB	4G63	1997	65	1989	1989	X	X	X	X	X	X
2.0 LWB	4G63	1997	65	1989	2003	X	X	X	X	X	X
2.0 Pick-up	4G63	1997	65	1989	2003	X	X	X	X	X	X
2.0i	4G63	1997	85	1994	2003	X	X	X	X	X	X
2.0i LWB	4G63	1997	85	1994	2003	X	X	X	X	X	X
2.0i Pick-up	4G63	1997	85	1987	2003	X	X	X	X	X	X
2.5 D	4D56	2477	51	1987	1989	X	X	X	X	X	X
2.5 D	4D56	2477	51	1989	2001	X	X	X	X	X	X
2.5 D LWB	4D56	2477	51	1987	1989	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>MITSUBISHI</b>											
<b>L300 1987 2003</b>											
2.5 D LWB	4D56	2477	51	1989	2001	X	X	X	X	X	X
2.5 D LWB	4D56	2477	51	1992	2001	X	X	X	X	X	X
2.5 D Pick-up	4D56	2477	51	1987	2001	X	X	X	X	X	X
2.5 D Pick-up (low pollution)	4D56	2477	51	1987	2001	X	X	X	X	X	X
2.5 Turbo D 4x4	4D56	2477	64	1987	1989	X	X	X	X	X	X
2.5 Turbo D 4x4	4D56	2477	64	1989	2001	X	X	X	X	X	X
2.5 Turbo D LWB 4x4	4D56	2477	64	1991	2001	X	X	X	X	X	X
<b>L400 1995 2001</b>											
2.0	4G63	1997	78	1995	2001	X	X	X	X	X	X
2.0 LWB	4G63	1997	78	1995	2001	X	X	X	X	X	X
2.0i	4G63	1997	85	1995	2001	X	X	X	X	X	X
2.0i LWB	4G63	1997	85	1995	2001	X	X	X	X	X	X
2.4i 4x4	4G64	2351	97	1995	2001	X	X	X	X	X	X
2.5 TD	4D56	2476	64	1995	2001	X	X	X	X	X	X
2.5 TD 4x4	4D56	2476	64	1995	2001	X	X	X	X	X	X
2.5 TD LWB	4D56	2476	64	1995	2001	X	X	X	X	X	X
<b>Lancer 2004</b>											
1.3 16V MPI	4G13	1298	60	2004		X	X	X	X		X
1.6 16V MPI	4G18	1584	72	2004		X	X	X	X		X
2.0 16V MPI	4G63	1997	99	2004		X	X	X	X		X
<b>Lancer 1983 1988</b>											
1.2	4G16	1198	44	1986	1988	X	X	X	X	X	X
1.3 Wagon	4G13	1299	51	1988	1991	X	X	X	X	X	X
1.5	4G15	1468	51	1986	1988	X	X	X	X	X	X
1.5	4G15	1468	55	1986	1988	X	X	X	X	X	X
1.5 Wagon	4G15	1468	55	1985	1988	X	X	X	X	X	X
1.5 Wagon	4G15	1468	60	1988	1991	X	X	X	X	X	X
1.5i Wagon	4G15	1468	60	1988	1991	X	X	X	X	X	X
1.8 4x4 Wagon	4G37	1755	44	1988	1991	X	X	X	X	X	X
1.8 D	4D65	1795	44	1986	1988	X	X	X	X	X	X
1.8 D Wagon	4D65	1795	44	1985	1988	X	X	X	X	X	X
1.8 D Wagon	4D65	1796	44	1988	1991	X	X	X	X	X	X
<b>Lancer 1988 1992</b>											
1.2 SOHC	4G16	1198	40	1988	1992	X	X	X	X	X	X
1.3 12V	4G13	1298	55	1990	1992	X	X	X	X	X	X
1.3 8V	4G13	1298	44	1988	1990	X	X	X	X	X	X
1.3i 8V	4G13	1298	51	1992		X	X	X	X	X	X

Legend: N = new, X = present

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>MITSUBISHI</b>											
<b>Lancer 1988 1992</b>											
1.5	4G15	1468	55	1988	1990	X	X	X	X	X	X
1.5 i 12V	4G15	1468	67	1990	1992	X	X	X	X	X	X
1.5 i 8V	4G15	1468	62	1988	1990	X	X	X	X	X	X
1.6 SOHC	4G92	1597	83	1992		X	X	X	X	X	X
1.6 SOHC 4x4	4G92	1597	83	1992		X	X	X	X	X	X
1.8 D	4D65	1795	44	1988	1992	X	X	X	X	X	X
1.8 DOHC	4G93	1834	104	1992		X	X	X	X	X	X
1.8 GTi 16V	4G67	1755	100	1989	1992	X	X	X	X	X	X
1.8i 4WD	4G37	1755	71	1988	1992	X	X	X	X	X	X
2.0 D	4D68	1998	50	1992		X	X	X	X	X	X
<b>Lancer 1992 1996</b>											
1.3i 12V	4G13	1298	58	1992	1996	X	X	X	X	X	X
1.6i	4G92	1597	83	1992	1996	X	X	X	X	X	X
1.6i 4X4	4G92	1597	83	1992	1996	X	X	X	X	X	X
1.8 GTi 16V	4G93	1836	103	1992	1996	X	X	X	X	X	X
2.0 D	4D68	1998	50	1992	1996	X	X	X	X	X	X
<b>Lancer 1996 2001</b>											
1.3 12V	4G13	1299	55	1996	2003	X	X	X	X	X	X
1.6 16V	4G92	1597	66	1996	2003	X	X	X	X	X	X
<b>Lancer EVO VIII 2002</b>											
EVO VIII	4G63	1997	195	2002		X	X	X			X
<b>Outlander Outlander Sport 2003</b>											
2.0 16V	4G63-7	1997	100	2003		X	X	X		X	X
2.0 16V Turbo	4G63-7	1997	148	2005		X	X	X		X	X
2.4	4G69-2	2378	118	2004		X	X	X		X	X
<b>Pajero Montero 2000 2007</b>											
2.5 TD	4D56	2477	73	2000	2002	X	X	X		X	X
2.5 TD	4D56	2477	85	2002	2007	X	X	X		X	X
3.2 DI-D	4M41	3200	118	2002	2007	X	X	X		X	X
3.2 DI-D	4M41	3200	121	2000	2002	X	X	X		X	X
3.5 V6 GDi	6G74	3496	149	2000	2006	X	X	X		X	X
<b>Pajero Shogun 1983 2000</b>											
2.3 D	4D55	2347	62	1983	1986	X	X	X		X	X
2.4	4G64	2351	82	1991	1994	X	X	X	X	X	X
2.5 D	4D56	2477	62	1986	1990	X	X	X	X	X	X
2.5 TD	4D56	2477	69	1988	1991	X	X	X	X	X	X



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>MITSUBISHI</b>											
<b>Pajero Shogun 1983 2000</b>											
2.5 TD	4D56	2477	70	1989	1991	X	X	X	X	X	X
2.5 TD	4D56	2477	73	1991	2000	X	X	X	X	X	X
2.6	4G54	2555	79	1986	1988	X	X	X	X	X	X
2.6	4G54	2555	79	1988	1991	X	X	X	X	X	X
2.6	G54B	2555	76	1988	1991	X	X	X	X	X	X
2.8 TD	4M40	2835	92	1994	2000	X	X	X	X	X	X
3.0 V6 12V	6G72	2972	104	1989	1991	X	X	X	X	X	X
3.0 V6 12V	6G72	2972	110	1991	1994	X	X	X	X	X	X
3.0 V6 24V	6G72	2972	130	1997	2000	X	X	X	X	X	X
3.0 V6 24V	6G72	2972	134	1994	1997	X	X	X	X	X	X
3.5 V6 24V	6G74	3497	153	1994	2000	X	X	X	X	X	X
<b>Pajero Pinin Montero io 1999 2005</b>											
1.8	4G93	1834	84	2001	2005	X	X	X	X	X	X
1.8 GDi	4G93	1834	88	1999	2001	X	X	X	X	X	X
2.0 GDi	4G94	1999	95	2000	2005	X	X	X	X	X	X
<b>Pajero Sport Montero Sport 1999</b>											
2.5 TD	4D56	2477	73	1999	2002	X	X	X	X	X	X
2.5 TD	4D56	2477	85	2002		X	X	X	X	X	X
3.0 V6	6G72	2972	125	2002		X	X	X	X	X	X
3.0 V6	6G72	2972	130	1999	2002	X	X	X	X	X	X
<b>Sapporo 1986 1990</b>											
2400 i	4G64	2351	91	1987	1990	X	X	X	X	X	X
<b>Sigma 1989 1996</b>											
3.0 V6 24V	6G72 DOHC	2972	154	1989	1996		X	X	X	X	X
3.0 V6 Estate / Wagon	6G72	2972	125	1993	1996		X	X	X	X	X
<b>Space gear 1994 1998</b>											
2.0	4G63	1997	78	1994	1998	X	X	X	X	X	X
2.0i	4G63	1997	85	1994	1998	X	X	X	X	X	X
2.4 i 4x4	4G64	2351	97	1994	1998	X	X	X	X	X	X
2.4i	4G64	2351	97	1994	1998	X	X	X	X	X	X
2.5 D	4D56	2477	64	1994	1998	X	X	X	X	X	X
2.5 D 4x4	4D56	2477	64	1994	1998	X	X	X	X	X	X
2.5 D intercooler	4D56	2477	73	1994	1998	X	X	X	X	X	X
2.5 D intercooler 4x4	4D56	2477	73	1994	1998	X	X	X	X	X	X
<b>Space runner 1998 2004</b>											
1.8 GDi	4G93	1834	110	1998	2004	X	X	X	X	X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>MITSUBISHI</b>													
<b>Space star</b>	<b>1998</b>	<b>2006</b>											
1.3 16V	4G13	1299	63	1998	2006	X	X	X	X	X		X	X
1.8 GDi	4G93	1834	90	1998	2002	X	X	X	X	X		X	X
<b>Space wagon</b>	<b>1998</b>	<b>2004</b>											
2.4 GDi	4G64	2351	108	1998	2004	X	X	X	X	X		X	X
<b>Space wagon</b>	<b>1984</b>	<b>1991</b>											
1.8	4G37	1755	66	1984	1991	X	X	X	X	X		X	X
1.8 TD	4D65T	1796	53	1991	1991	X	X	X	X	X		X	X
1.8 TD	4D65T	1796	55	1985	1991	X	X	X	X	X		X	X
2.0 4WD	4G63	1997	75	1985	1991	X	X	X	X	X		X	X
2.0i	4G63	1997	75	1988	1991	X	X	X	X	X		X	X
2.0i 4WD	4G63	1997	76	1989	1991	X	X	X	X	X		X	X
<b>Space wagon Space Runner / Chariot</b>	<b>1991</b>	<b>1998</b>											
1.8i	4G93	1834	90	1991	1998	X	X	X	X	X		X	X
1.8i 4WD	4G93	1834	89	1991	1998	X	X	X	X	X		X	X
2.0 TD	4D68	1998	60	1992	1998	X	X	X	X	X		X	X
2.0i	4G63	1977	97	1992	1998	X	X	X	X	X		X	X
2.0i 4WD	4G63	1997	97	1992	1998	X	X	X	X	X		X	X
2.4i	4G64	2350	92	1992	1998	X	X	X	X	X		X	X
<b>Starion</b>	<b>1982</b>	<b>1991</b>											
2000 EX Turbo	4G63TC	1997	132	1986	1989	X		X	X			X	
2600 EX Turbo	4G54TB	2554	114	1988	1991	X	X	X	X			X	
<b>NISSAN</b>													
<b>100NX (B13)</b>	<b>1990</b>	<b>1995</b>											
1.6	GA16DS	1597	66	1991	1992	X	X	X	X	X		X	X
1.6	GA16DE	1597	75	1991	1995	X	X	X	X	X		X	X
2.0 GTi	SR20DE	1998	105	1991	1995	X	X	X	X	X		X	X
<b>200SX (S13)</b>	<b>1988</b>	<b>1994</b>											
1.8 Turbo	CA18DET	1809	124	1988	1994	X	X	X	X			X	
<b>200SX (S14)</b>	<b>1994</b>	<b>1999</b>											
2.0 Turbo	SR20DET	1998	148	1994		X	X	X	X	X		X	
<b>300ZX (Z32)</b>	<b>1989</b>	<b>1995</b>											
3.0 Twin Turbo	VG30DETT	2960	208	1989	1995	X	X	X	X	X		X	
<b>350Z (Z33)</b>	<b>2003</b>												
3.5 V6	VQ35DE	3498	213	2003		X	X	X	X			X	
<b>Almera (N15)</b>	<b>1995</b>	<b>2000</b>											
1.4	GA14DE	1392	64	1995	2000	X	X	X	X	X		X	

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>NISSAN</b>											
<b>Almera (N15) 1995 2000</b>											
1.6	GA16DE	1597	73	1995	2000	X	X X	X X		X	X
2.0 D	CD20	1974	55	1995	2000	X	X X	X		X	X
2.0 GTi	SR20DE	1998	105	1996	2000	X	X X	X		X	X
<b>Almera (N16) 2000 2007</b>											
1.5 16V	QG15DE	1497	66	2000	2003	X	X X	X X		X	X X
1.5 16V	QG15DE	1497	72	2003	2007	X	X X	X X		X	X
1.5 dCi	K9K	1461	60	2002	2006	X	X X	X X		X	
1.8 16V	QG18DE	1769	84	2000	2003	X	X X	X X	X	X	X X
1.8 16V	QG18DE	1769	85	2003	2006	X	X X	X X		X	X
2.2 dCi 112	YD22DDT	2184	82	2003	2006	X	X X	X X		X	X
2.2 dCi 136	YD22DDTi	2184	100	2003	2006	X	X X	X X		X	X
2.2 Di	YD22DDT	2184	81	2000	2003	X	X X	X X		X	X X
<b>Almera Tino (V10) 2000 2006</b>											
1.8 16V	QG18DE	1769	84	2000	2003	X	X X	X X	X	X	X X
1.8 16V	QG18DE	1769	85	2003	2006	X	X X	X X		X	X
2.0 16V	SR20DE	1998	104	2000	2003	X	X X	X X	X	X	X X
2.2 dCi 112	YD22DDT	2184	82	2003	2006	X	X X	X X		X	X
2.2 dCi 136	YD22DDTi	2184	100	2003	2006	X	X X	X X		X	X
2.2 Di	YD22DDT	2184	81	2000	2003	X	X X	X X	X	X	X X
<b>Interstar (X70) 2002</b>											
1.9 dTi	F9Q-772	1870	60	2002	2003	X	X X	X X		X	X X
2.2 dTi	G9T-722	2188	66	2002	2003	X	X X	X X		X	X X
2.5 dTi	G9U-720	2463	85	2002	2003	X	X X	X X		X	X
<b>Kubistar (X76) 2003</b>											
1.2 16V	D4F 712	1149	57	2003		X	X X	X		X	X X
1.2 8V	D7F 726	1149	44	2003		X	X X	X		X	X
1.5 dCi	K9K 702	1461	41	2003		X	X X	X		X	X
1.5 dCi	K9K 704	1461	48	2003		X	X X	X		X	X
1.5 dCi	K9K 710	1461	60	2003		X	X X	X		X	X
1.6 16V	K4M 752	1598	72	2003		X	X X	X		X	X
1.6 16V	K4M 753	1598	72	2003		X	X X	X		X	X
<b>Laurel (C32) 1985 1989</b>											
2.0	CA20S	1973	77	1985	1989	X	X X	X X		X	
2.4 E	L24E	2393	94	1985	1989	X	X X	X X		X	X
2.8 D	LD28	2792	62	1985	1987	X	X X	X X		X	X
2.8 D	RD28	2825	66	1987	1989	X	X X	X X		X	X
3.0 E	VG30E	2960	112	1987	1989	X	X X	X X		X	

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diag. Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diag. Fuses & Relays

**NISSAN**

<b>Maxima (J30) 1988 1994</b>																			
3.0 E	VG30E	2960	125	1988	1994	X	X	X	X	X	X			X				X	
<b>Maxima QX (A32) 1994 2000</b>																			
QX 2.0	VQ20DE	1995	103	1994	2000	X	X	X	X	X	X			X				X	
QX 3.0	VQ30DE	2988	142	1994	2000	X	X	X	X	X	X			X				X	
<b>Maxima QX (A33) 2000 2005</b>																			
QX 2.0	VQ20DE	1995	103	2000	2005	X	X	X	X	X				X				X	X
QX 3.0	VQ30DE	2988	142	2000	2005	X	X	X	X	X	N			X				X	X
<b>Micra (K10) 1982 1992</b>																			
1.0	MA10	988	37	1982	1989	X	X	X	X	X				X				X	
1.0	MA10	988	40	1989	1992	X	X	X	X	X				X				X	
1.2	MA12	1235	40	1989	1992	X	X	X	X	X				X				X	
<b>Micra (K11) 1992 2002</b>																			
1.0	CG10DE	998	40	1992	2000	X	X	X	X	X	X			X				X	X
1.0	CG10DE	998	44	2000	2002	X	X	X	X	X				X					
1.3	CG13DE	1275	55	1992	2000	X	X	X	X	X	X			X				X	X
1.4	CGA3DE	1348	60	2000	2002	X	X	X	X	X	X			X					
1.5 D	VJX	1527	42	2001	2002	X	X	X	X	X				X					
1.5 D	VJZ	1527	42	1998	2002	X	X	X	X	X				X					
<b>Micra (K12) 2002</b>																			
1.0 16V	CR10DE	998	48	2002	2005	X	X	X	X	X	X	X		X	X				X
1.2 16V	CR12DE	1240	59	2002		X	X	X	X	X	X	X		X	X			X	X
1.4 16V	CR14DE	1386	65	2002		X	X	X	X	X	X	X		X	X			X	X
1.5 dCi 65	K9K-704	1461	48	2003		X	X	X	X	X				X				X	X
<b>Murano (Z50) 2004</b>																			
3.5 V6	VQ35DE	3500	172	2004		X	X	X	X	X				X					X
<b>Note (E11) 2006</b>																			
1.4 16V	CR14DE	1386	65	2006		X	X	X	X	X				X					X
1.5 dCi	K9K	1461	63	2006		X	X	X	X	X				X					X
1.6 16V	HR16DE	1598	81	2006		X	X	X	X	X				X					X
<b>Pathfinder (R51) 2005</b>																			
2.5 TDi DOHC	YD25DDTi	2448	130	2005		X	X	X	X	X				X					
4.0 V6 DOHC	VQ40DE	3954	200	2005		X	X	X	X	X				X					
<b>Patrol (260/Y60) 1983 1998</b>																			
2.8	L28	2753	89	1983	1989	X	X	X	X	X				X				X	
2.8 D	RD28	2826	68	1991	1997	X	X	X	X	X								X	
2.8 TD	RD28T	2826	85	1988	1997	X	X	X	X	X								X	

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>NISSAN</b>													
<b>Patrol (260/Y60) 1983 1998</b>													
3.0	RB30S	2962	100	1989	1993	X	X	X	X	X			
3.3 D	SD33	3246	70	1983	1989	X	X	X	X	X		X	
3.3 D	SD33T	3246	81	1983	1989	X	X	X	X	X		X	
GR 2.8 TD	RD28T	2826	85	1988	1998	X	X	X	X	X		X	
GR 4.2	TB42E	4169	125	1992	1998	X	X	X	X	X		X	
GR 4.2 D	TD42	4169	91	1993	1998	X	X	X	X	X		X	
<b>Patrol GR (Y61) 1998</b>													
2.8 Turbo D	RD28ETi	2826	95	1998	2000	X	X	X	X	X		X	X
3.0 Turbo Di	ZD30DDTi	2953	116	2000	2004	X	X	X	X	X		X	
<b>Prairie (M10) 1985 1989</b>													
1.5	E15S	1488	55	1987	1989		X	X	X	X		X	
1.8	CA18S	1809	65	1987	1989		X	X	X	X		X	
2.0	CA20S	1974	77	1985	1989		X	X	X	X		X	
<b>Prairie (M11) 1988 1995</b>													
2.0	CA20S	1974	73	1989	1991	X	X	X	X	X		X	
2.0i	CA20E	1974	72	1989	1995	X	X	X	X	X		X	
2.4 12V	KA24E	2389	98	1990	1995	X	X	X	X	X		X	
<b>Primastar (X83) 2002</b>													
1.9 dCi 100	F9Q-760	1870	74	2002	2007	X	X	X	X	X	X	X	X
1.9 dCi 80	F9Q-762	1870	59	2002	2007	X	X	X	X	X	X	X	X
2.0 16V	F4R-720	1998	88	2002	2007	X	X	X	X	X	X	X	X
2.5 dCi 135	G9U-730	2464	99	2003	2007	X	X	X	X	X		X	X
<b>Primera (P10/W10) 1990 1996</b>													
1.6	GA16DS	1597	66	1990	1993	X	X	X	X	X		X	X
1.6 16V	GA16DE	1597	75	1990	1996	X	X	X	X	X	X	X	X
2.0 D	CD20	1974	55	1990	1993	X	X	X	X	X	X	X	X
2.0 D	CD20	1974	55	1993	1996	X	X	X	X	X	X	X	X
2.0 GT	SR20DE	1998	109	1993	1996	X	X	X	X	X		X	X
2.0i	SR20DI	2000	85	1990	1993	X	X	X	X	X		X	X
2.0i	SR20DE	1998	110	1990	1993	X	X	X	X	X	X	X	X
2.0i	SR20DE	1998	91	1993	1996	X	X	X	X	X	X	X	X
<b>Primera (P11) 1996 2000</b>													
1.6	GA16DE	1597	73	1996	2000	X	X	X	X	X		X	X
2.0	SR20DE	1998	96	1996	2000	X	X	X	X	X		X	X
2.0 GT	SR20DE	1998	110	1996	2000	X	X	X	X	X		X	X
2.0 TD	CD20T	1974	66	1996	2000	X	X	X	X	X		X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays		
<b>NISSAN</b>													
<b>Primera (P11-144) 2000 2002</b>													
1.6	GA16DE	1597	74	2000	2001	X	X	X	X	X	X	X	X
1.8	QG18DE	1769	84	2000	2001	X	X	X	X	X	X	X	X
2.0	SR20DE	1998	104	2000	2001	X	X	X	X	X	X	X	X
2.0DT	CD20T	1974	67	2000	2001	X	X	X	X	X	X	X	X
<b>Primera (P12) 2001</b>													
1.6	QG16DE	1597	73	2001		X	X	X	X	X	X	X	X
1.8	QG18DE	1769	85	2001		X	X	X	X	X	X	X	X
2.0	QR20DE	1998	103	2001		X	X	X	X	X	X	X	X
2.2D	YD22DDTI	2184	93	2001		X	X	X	X	X	X	X	X
<b>Serena (C23) 1992 2000</b>													
1.6	GA16DE	1597	71	1992	2000	X	X	X	X	X	X	X	X
2.0	SR20DE	1998	93	1992	2000	X	X	X	X	X	X	X	X
2.0 D	LD20	1952	49	1992	1994	X	X	X	X	X	X	X	X
2.3 D	LD23	2283	55	1994	2000	X	X	X	X	X	X	X	X
<b>Silvia (S12) 1984 1988</b>													
1.8 i Turbo	CA18ET	1809	99	1984	1988	X	X	X	X	X	X	X	X
2.0 i	CA20E	1974	83	1984	1988	X	X	X	X	X	X	X	X
2.0 i	FJ20E	1990	106	1984	1988	X	X	X	X	X	X	X	X
<b>Sunny (B12/N13) 1982 1990</b>													
1.0	E10S	988	37	1986	1990	X	X	X	X	X	X	X	X
1.3	E13S	1270	44	1986	1989	X	X	X	X	X	X	X	X
1.4 12V	GA14S	1392	55	1989	1990	X	X	X	X	X	X	X	X
1.6 12V	E16S	1597	62	1986	1990	X	X	X	X	X	X	X	X
1.6 12V (4x4)	E16S	1597	62	1989	1991	X	X	X	X	X	X	X	X
1.6 GTi 16V	CA16DE	1598	88	1987	1990	X	X	X	X	X	X	X	X
1.6i 12V (4x4)	GA 16i	1597	66	1988	1991	X	X	X	X	X	X	X	X
1.7D	CD17	1681	40	1986	1990	X	X	X	X	X	X	X	X
1.8 GTi	CA18DE	1809	92	1990	1990	X	X	X	X	X	X	X	X
<b>Sunny (N14/Y10) 1990 1994</b>													
1.3	GA13DS	1295	44	1990	1994	X	X	X	X	X	X	X	X
1.4	GA14DS	1392	55	1990	1994	X	X	X	X	X	X	X	X
1.4 N14	GA14DS	1392	55	1990	1994	X	X	X	X	X	X	X	X
1.4 Y10	GA14DS	1392	55	1990	1994	X	X	X	X	X	X	X	X
1.4i 16V	GA14DE	1392	64	1992	1994	X	X	X	X	X	X	X	X
1.6 N14	GA16DS	1597	66	1990	1994	X	X	X	X	X	X	X	X
1.6 Y10	GA16DS	1597	66	1990	1994	X	X	X	X	X	X	X	X
1.6i 16V N14	GA16DE	1597	75	1992	1994	X	X	X	X	X	X	X	X

Legend: N = new, X = present

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>NISSAN</b>											
<b>Sunny (N14/Y10) 1990 1994</b>											
1.6i 16V Y10	GA16DE	1597	75	1992	1994	X	X	X	X	X	X
1.7 D	CD17	1681	40	1990	1994	X	X	X	X	X	X
2.0 D N14	CD20	1974	55	1990	1994	X	X	X	X	X	X
2.0 D Y10	CD20	1974	55	1990	1994	X	X	X	X	X	X
2.0 GTi N14	SR20DE	1998	105	1990	1994	X	X	X	X	X	X
2.0 GTi-R Turbo	SR20DET	1998	162	1990	1994	X	X	X	X	X	X
<b>Terrano I (D21) 1987 1993</b>											
2.4i 4X4	Z24i	2389	74	1987	1993	X	X	X	X	X	X
2.7 TD	TD27T	2664	69	1989	1993	X	X	X	X	X	X
3.0i 4x4	VG30E	2960	95	1987	1991	X	X	X	X	X	X
<b>Terrano II (R20) 1993 2001</b>											
2.4	KA24E	2389	91	1993	2001	X	X	X	X	X	X
2.7 TD	TD27T	2664	92	1993	2001	X	X	X	X	X	X
<b>Urvan (E24) 1986 2001</b>											
2.0	Z20S	1952	64	1986	1994	X	X	X	X	X	X
2.3 D	TD23	2289	51	1986	1989	X	X	X	X	X	X
2.3 D automatic	TD23	2289	51	1986	1989	X	X	X	X	X	X
2.4i	Z24i	2389	76	1994	1996	X	X	X	X	X	X
2.5 D	TD25	2494	55	1989	1996	X	X	X	X	X	X
2.5 D automatic	TD25	2494	55	1989	1994	X	X	X	X	X	X
<b>X-Trail (T30) 2001</b>											
2.0	QR20DE	1998	103	2001	2004	X	X	X	X	X	X
2.0	QR20DE	1998	103	2004		X	X	X	X	X	X
2.2 CDi	YD22DDTi	2184	84	2001	2004	X	X	X	X	X	X
2.2 dCi	YD22DDTi	2184	100	2004		X	X	X	X	X	X
2.5	QR25DE	2448	121	2002	2004	X	X	X	X	X	X
2.5	QR25DE	2448	121	2004		X	X	X	X	X	X
<b>OPEL / VAUXHALL</b>											
<b>Agila 2000</b>											
1.0 12V	Z 10 XE	973	43	2000		X	X	X	X	X	X
1.0 12V	Z 10 XEP	998	44	2004		X	X	X	X	X	X
1.2 16V	Z 12 XE	1199	55	2000		X	X	X	X	X	X
1.3 CDTi 16V	Z 13 DT	1248	51	2004		X	X	X	X	X	X
<b>Antara 2007</b>											
2.0 CDTi	Z 20 DMH	1991	110	2007		X	X	X	X	X	X
2.4	Z 24 XE	2405	103	2007		X	X	X	X	X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>OPEL / VAUXHALL</b>													
<b>Antara 2007</b>													
3.2 V6	Z 32 SE	3195	167	2007		X	X	X					X
<b>Ascona C / Cavalier 1981 1988</b>													
1.6 i	C 16 NZ	1598	55	1987	1988	X	X	X		X			X
1.6 N	C 16 LZ	1598	55	1986	1988	X	X	X		X			X
1.6 S	16 SH	1598	61	1987	1988	X	X	X		X			X
1.6 S	16 SV	1598	60	1981	1986	X	X	X		X			X
1.8	18 SE	1796	82	1986	1988	X	X	X		X			
1.8	C 18 NE	1796	62	1986	1988	X	X	X		X			X
1.8	E 18 NV	1796	62	1987	1988	X	X	X		X			X
1.8 E	18 E	1796	85	1982	1986	X	X	X		X			X
2.0 i ,GT	C 20 NE	1998	85	1986	1988	X	X	X		X			X
20	20 SEH	1998	95	1987	1988	X	X	X		X			X
<b>Astra F 1992 1999</b>													
1.4i	14 SE	1389	60	1993	1998	X	X	X	X	X		X	X
1.4i	X 14 NZ	1389	44	1997	1999	X	X	X	X	X			X
1.4i	C 14 NZ	1389	44	1991	1998	X	X	X	X	X		X	X
1.4i 16V	X 14 XE	1389	66	1996	1998	X	X	X	X	X			X
1.4S	14 NV	1389	55	1992	1993	X		X		X		X	X
1.4Si	C 14 SE	1389	60	1991	1998	X	X	X	X	X		X	X
1.6i	16 LZ2	1598	55	1996	1998	X	X	X	X	X		X	X
1.6i	16 NZR	1598	55	1997	1999	X	X	X		X			X
1.6i	X 16 SZ	1598	52	1993	1998	X	X	X	X	X		X	X
1.6i	X 16 SZR	1598	55	1996	1999	X	X	X	X	X			X
1.6i	C 16 NZ	1598	55	1991	1996	X	X	X	X	X		X	X
1.6i 16V	X 16 XEL	1598	74	1993	1999	X	X	X	X	X		X	X
1.6S	16 SV	1598	60	1992	1992	X	X	X		X			X
1.6Si	C 16 SE	1598	74	1991	1998	X	X	X	X	X		X	X
1.7 D	17 D	1686	42	1992	1992	X	X	X		X		X	X
1.7 D	17 DR	1686	44	1993	1994	X	X	X		X		X	X
1.7 TD	X 17 DTL	1700	50	1995	1998	X	X	X		X		X	X
1.7 TD	17 DT/ TC4EE1	1686	60	1992	1994	X	X	X		X		X	X
1.7 TDS	X 17 DT	1686	60	1995	1998	X	X	X		X			X
1.8i	C 18 NZ	1796	66	1991	1996	X	X	X	X	X		X	X
1.8i 16V	C 18 SEL	1798	85	1996	1998	X	X	X	X	X			X
1.8i 16V	C 18 XEL	1799	85	1995	1997	X	X	X	X	X		X	X
1.8i 16V	X 18 XE	1796	85	1996	1998	X	X	X	X	X			X
1.8i 16V	C 18 XE	1798	92	1993	1996	X	X	X	X	X		X	X



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond. Wir.	Diagr.	
<b>OPEL / VAUXHALL</b>													
<b>Astra F 1992 1999</b>													
2.0i	20 SEH	1998	95	1992	1992	X	X	X	X	X		X	X
2.0i	C 20 NE	1998	85	1991	1998	X	X	X	X	X	X	X	X
2.0i 16V	X 20 XEV	1998	100	1995	1998	X	X	X	X	X	X	X	X
2.0i 16V	C 20 XE	1998	110	1991	1998	X	X	X	X	X	X	X	X
<b>Astra G 1998 2004</b>													
1.2 16V	X 12 XE	1199	48	1998	2001	X	X	X	X	X	X	X	X
1.2 16V	Z 12 XE	1199	55	2001		X	X	X	X	X	X	X	X
1.4 16V	X 14 XE	1389	66	1998	2000	X	X	X	X	X	X	X	X
1.4 16V	Z 14 XE	1389	66	2001		X	X	X	X	X	X	X	X
1.4 16V	Z 14 XEP	1364	66	2004		X	X	X		X	X		X
1.6	X 16 SZR	1598	55	1998	2001	X	X	X	X	X	X	X	X
1.6	Z 16 SE	1598	62	2001		X	X	X	X	X	X	X	X
1.6 16V	X 16 XEL	1598	74	1998	2000	X	X	X	X	X	X	X	X
1.6 16V	Z 16 XE	1598	74	2001		X	X	X	X	X	X	X	X
1.6 16V	Z 16 XEP	1598	76	2003		X	X	X	X	X	X	X	X
1.6 16V CNG	Z 16 YNG	1598	71	2003		X	X	X	X	X	X	X	X
1.7 CDTi 16V	Z 17 DTL	1686	59	2003		X	X	X	X	X	X	X	X
1.7 DTi 16V	Y 17 DT	1686	55	2000		X	X	X	X	X	X	X	X
1.7 TD	X 17 DTL	1700	50	1998	2000	X	X	X	X	X	X	X	X
1.8 16V	X 18 XE1	1796	85	1998	2001	X	X	X	X	X	X	X	X
1.8 16V	Z 18 XE	1796	92	2001		X	X	X	X	X	X	X	X
1.8 16V	Z 18 XEL	1796	85	2001	2001	X	X	X	X	X	X	X	X
2.0 16V	X 20 XEV	1998	100	1998	2000	X	X	X	X	X	X	X	X
2.0 16V OPC	X 20 XER	1998	118	2000	2000	X	X	X		X	X	X	X
2.0 16V Turbo	Z 20 LET	1998	140	2001	2004	X	X	X	X	X	X	X	X
2.0 16V Turbo OPC	Z 20 LET	1998	147	2001	2004	X	X	X	X	X	X	X	X
2.0 Di 16V	X 20 DTL	1995	60	1998	2000	X	X	X	X	X	X	X	X
2.0 Di 16V	Y 20 DTL	1995	60	2001		X	X	X	X	X	X	X	X
2.0 DTi 16V	Y 20 DTH	1995	74	2000		X	X	X	X	X	X	X	X
2.2 16V	Z 22 SE	2198	108	2000		X	X	X	X	X	X	X	X
2.2 DTi 16V	Y 22 DTR	2172	92	2003		X	X	X	X	X	X	X	X
<b>Astra H 2004</b>													
1.2 16V	Z 12 XEP	1229	59	2006		X	X	X	X	X	X		X
1.3 CDTi 16V	Z 13 DTH	1248	66	2006		X	X	X	X	X	X	X	X
1.4 16V	Z 14 XEL	1364	55	2004		X	X	X	X	X	X		X
1.4 16V	Z 14 XEP	1364	66	2004		X	X	X	X	X	X	X	X
1.6 16V	Z 16 XEP	1598	77	2004		X	X	X	X	X	X	X	X

Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diag. Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diag. Fuses & Relays

**OPEL / VAUXHALL**

**Astra H 2004**

1.7 CDTi	Z 17 DTH	1686	74	2004		X	X	X	X	X	X	X	X	X	X	X	X
1.7 CDTi	Z 17 DTL	1686	59	2004		X	X	X	X	X	X	X	X	X	X	X	X
1.8 16V	Z 18 XE	1796	92	2004		X	X	X	X	X	X	X	X	X	X	X	X
1.8 16V	Z 18 XER	1796	103	2006		X	X	X	X	X	N	X	X	X	X	X	X
1.9 CDTi 16V	Z 19 DTH	1910	110	2005		X	X	X	X	X	X	X	X	X	X	X	X
1.9 CDTi 16V	Z 19 DTJ	1910	88	2005	2006	X	X	X	X	X	X	X	X	X	X	X	X
1.9 CDTi 8V	Z 19 DT	1910	88	2006		X	X	X	X	X	N	X	X	X	X	X	X
1.9 CDTi 8V	Z 19 DTL	1910	74	2006		X	X	X	X	X	N	X	X	X	X	X	X
2.0 16V Turbo	Z 20 LEH	1998	177	2005		X	X	X	X	X	N	X	X	X	X	X	X
2.0 16V Turbo	Z 20 LEL	1998	125	2004		X	X	X	X	X	X	X	X	X	X	X	X
2.0 16V Turbo	Z 20 LER	1998	147	2005		X	X	X	X	X	N	X	X	X	X	X	X

**Calibra 1990 1997**

2.0 16V 4x4	C 20 XEH	1998	110	1990	1994	X	X	X	X	X	X	X	X	X	X	X	X
2.0 Turbo 4x4	C 20 LET	1998	150	1990	1997	X	X	X	X	X	X	X	X	X	X	X	X
2.0i	C 20 NE	1998	85	1990	1997	X	X	X	X	X	X	X	X	X	X	X	X
2.0i 16V	C 20 XEH	1998	110	1990	1994	X	X	X	X	X	X	X	X	X	X	X	X
2.0i 4x4	C 20 NE	1998	85	1990	1997	X	X	X	X	X	X	X	X	X	X	X	X
2.5i V6 24V	C 25 XE	2498	125	1993	1997	X	X	X	X	X	X	X	X	X	X	X	X

**Campo 1989 2002**

2.3	4ZD1	2254	66	1989	1994	X	X	X	X	X	X	X	X	X	X	X	X
2.3 i	4ZD1	2254	72	1995	2002	X	X	X	X	X	X	X	X	X	X	X	X
2.5 D	4JA1	2499	56	1992	1995	X	X	X	X	X	X	X	X	X	X	X	X
2.5 TD	4JA1T	2499	56	1996	2002	X	X	X	X	X	X	X	X	X	X	X	X
3.1 TD/TDS	4JG2T	3059	80	1992	2001	X	X	X	X	X	X	X	X	X	X	X	X

**Corsa A / Nova 1982 1993**

1.0S	10 S OHV	993	33	1982	1988	X	X	X	X	X	X	X	X	X	X	X	X
1.2	12 NV	1196	38	1982	1989	X	X	X	X	X	X	X	X	X	X	X	X
1.2i	C 12 NZ	1189	33	1990	1993	X	X	X	X	X	X	X	X	X	X	X	X
1.2N	12 NC	1196	33	1985	1987	X	X	X	X	X	X	X	X	X	X	X	X
1.2N	12 GV OHV	1196	33	1987	1990	X	X	X	X	X	X	X	X	X	X	X	X
1.2S	12 ST OHC	1196	40	1982	1989	X	X	X	X	X	X	X	X	X	X	X	X
1.3i	C 13 N	1297	44	1987	1990	X	X	X	X	X	X	X	X	X	X	X	X
1.3N Euronorm	13 NB OHC	1297	44	1986	1989	X	X	X	X	X	X	X	X	X	X	X	X
1.3S	13 SB OHC	1297	51	1982	1989	X	X	X	X	X	X	X	X	X	X	X	X
1.4	14 NV	1389	53	1990	1993	X	X	X	X	X	X	X	X	X	X	X	X
1.4i	C 14 NZ	1389	44	1989	1990	X	X	X	X	X	X	X	X	X	X	X	X
1.4i	C 14 NZ	1389	44	1990	1993	X	X	X	X	X	X	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>OPEL / VAUXHALL</b>											
<b>Corsa A / Nova 1982 1993</b>											
1.4i	C 14 SE	1389	60	1990	1993	X	X	X	X	X	X
1.5 D	4EC1	1488	38	1987	1990	X	X	X	X	X	X
1.5 D	4EC1	1488	37	1990	1993	X	X	X	X	X	X
1.5 TD	T4EC1	1488	49	1987	1990	X	X	X	X	X	X
1.5 TD	T4EC1	1488	49	1990	1993	X	X	X	X	X	X
1.6 GSi	C 16 SEI	1598	72	1989	1992	X	X	X	X	X	X
1.6 GSi	E 16 SE(C)	1598	74	1990	1993	X	X	X	X	X	X
1.6 GSi	C/E 16 NZ	1598	74	1988	1990	X	X	X	X	X	X
1.6 GSi	E 16 SE	1598	74	1988	1990	X	X	X	X	X	X
<b>Corsa B 1993 2000</b>											
1.0i 12V	X 10 XE	973	40	1997	2000	X	X	X	X	X	X
1.2i	12 NZ	1195	33	1993	2000	X	X	X	X	X	X
1.2i	C 12 NZ	1196	33	1993	1996	X	X	X	X	X	X
1.2i	X 12 SZ	1196	33	1993	1998	X	X	X	X	X	X
1.2i 16V	X 12 XE	1199	48	1998	2000	X	X	X	X	X	X
1.4 Si	C 14 SE	1389	60	1993	1994	X	X	X	X	X	X
1.4i	C 14 NZ	1389	44	1993	1998	X	X	X	X	X	X
1.4i	X 14 SZ	1389	44	1996	2000	X	X	X	X	X	X
1.4i 16V	C 14 SEL	1389	63	1998	2000	X	X	X	X	X	X
1.4i 16V	X 14 VE	1389	67	1994	2000	X	X	X	X	X	X
1.4i 16V	X 14 XE	1389	66	1995	2000	X	X	X	X	X	X
1.5 D	15D / 4EC1	1488	37	1993	1996	X	X	X	X	X	X
1.5 TD	15TD / T4EC1	1488	49	1993	1995	X	X	X	X	X	X
1.6i	C 16 SE	1598	74	1993	1993	X	X	X	X	X	X
1.6i 16V	C 16 SEL	1598	74	1998	2000	X	X	X	X	X	X
1.6i 16V	X 16 XE	1598	78	1995	2000	X	X	X	X	X	X
1.6i 16V	C 16 XE	1598	80	1993	1994	X	X	X	X	X	X
1.7 D	17 D / 4EE1	1686	44	1993	1996	X	X	X	X	X	X
1.7 D	X 17 D / 4EE1	1686	44	1997	2000	X	X	X	X	X	X
<b>Corsa C 2001 2006</b>											
1.0 12V	Z 10 XE	973	43	2001	2006	X	X	X	X	X	X
1.0 12V	Z 10 XEP	998	44	2004	2006	X	X	X	X	X	X
1.2 12V	Z 12 XEP	1229	59	2004	2006	X	X	X	X	X	X
1.2 16V	Z 12 XE	1198	55	2001	2006	X	X	X	X	X	X
1.3 CDTi 16V	Z 13 DT	1248	51	2004	2006	X	X	X	X	X	X
1.4 16V	Z 14 XE	1389	66	2001	2006	X	X	X	X	X	X
1.4 16V	Z 14 XEP	1364	66	2004	2006	X	X	X	X	X	X

Legend: N = new, X = present

Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diagr. Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diagr. Fuses & Relays

**OPEL / VAUXHALL**

OPEL / VAUXHALL		Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times		
Type description	Model description	From	To	From	To	From	To	Identification	Adjustment	Lubricants	ABS	Engine	Air Cond. Wir. Diagr.	Fuses & Relays	
<b>Corsa C 2001 2006</b>															
1.6	Z 16 SE	1598	64	2002	2005	X	X	X	X	X	X	X	X	X	
1.7 CDTi 16V	Z 17 DTH	1686	74	2004	2006	X	X	X	X	X	X	X	X	X	
1.7 Di 16V	Y 17 DTL	1686	48	2001	2005	X	X	X	X	X	X	X	X	X	
1.7 DTi 16V	Y 17 DT	1686	55	2001	2006	X	X	X	X	X	X	X	X	X	
1.8 16V	Z 18 XE	1796	92	2001	2006	X	X	X	X	X	X	X	X	X	
<b>Corsa C Combo 2002</b>															
1.3 CDTi 16V	Z 13 DT	1248	51	2005		X	X	X	X	X	N	X	X		
1.3 CDTi 16V	Z 13 DTJ	1248	55	2006		X	X	X	X	X		X	X		
1.4 16V	Z 14 XEP	1364	66	2005		X	X	X	X	X	N	X	X		
1.6 8V	Z 16 SE	1598	64	2002		X	X	X	X	X	X	X	X	X	
1.6 CNG	Z 16 YNG	1598	71	2005		X	X	X	X	X	N	X	X		
1.7 CDTi 16V	Z 17 DTH	1686	74	2005		X	X	X	X	X	N	X	X		
1.7 Di	Y 17 DTL	1686	48	2002		X	X	X	X	X	X	X	X	X	
1.7 DTi	Y 17 DT	1686	55	2002		X	X	X	X	X	X	X	X	X	
<b>Corsa D 2007</b>															
1.0 12V	Z10XEP	998	44	2007		X	X	X		X	N	X			
1.2 16V	Z12XEP	1229	59	2007		X	X	X		X	N	X			
1.3 CDTi	Z13DTH	1248	66	2007		X	X	X		X	N	X			
1.3 CDTi	Z13DTJ	1248	55	2007		X	X	X		X	N	X			
1.4 16V	Z14XEP	1364	66	2007		X	X	X		X	N	X			
1.6 16V Turbo	Z16LER	1598	141	2007		X	X	X		X	N				
1.7 CDTi	Z17DTR	1686	92	2007		X	X	X		X	N				
<b>Frontera 1992 1998</b>															
2.0	X 20 SE	1998	85	1995	1998	X	X	X	X	X	X	X	X	X	
2.0	C 20 NE	1998	85	1992	1995	X	X	X	X	X	X	X	X	X	
2.2	X 22 XE	2198	100	1995	1998	X	X	X	X	X	X	X	X	X	
2.3 TD	23 DTR	2260	74	1992	1995	X	X	X	X	X		X	X	X	
2.4	C 24 NE	2410	92	1992	1995	X	X	X	X	X		X	X	X	
2.5 TD	VM41B	2499	85	1997	1998	X	X	X	X	X		X	X	X	
2.8 TD	4JB1	2771	82	1995	1996	X	X	X	X			X	X	X	
<b>Frontera B 1999 2004</b>															
2.2 16V	X 22 SE	2198	100	1999	2000	X	X	X	X	X	X	X	X	X	
2.2 16V	Y 22 SE	2198	100	2001	2004	X	X	X	X	X	X	X	X	X	
2.2 16V TD	X 22 DTH	2171	85	1999	2000	X	X	X	X	X	X	X	X	X	
2.2 16V TD	Y 22 DTH	2171	85	2001	2004	X	X	X	X	X	X	X	X	X	
3.2 V6 24V	6VD1-W	3165	151	1999	2004	X	X	X	X	X	X	X	X	X	

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>OPEL / VAUXHALL</b>											
<b>Kadett E 1984 1991</b>											
1.2	12 SC	1196	40	1984	1989	X	X	X	X	X	X
1.3 N	13 N/NB OHC	1297	44	1984	1989	X	X	X	X	X	X
1.3 S	13 S OHC	1297	55	1984	1990	X	X	X	X	X	X
1.3i	C 13 N	1297	44	1985	1989	X	X	X	X	X	X
1.4i	C 14 NZ	1389	44	1989	1991	X	X	X	X	X	X
1.5 TD	15 D/T4E-C1	1488	53	1988	1991	X	X	X	X	X	X
1.6 S	16 S	1598	66	1984	1986	X	X	X	X	X	X
1.6D	16 DA	1598	40	1986	1989	X	X	X	X	X	X
1.6i	C 16 LZ/NZ	1598	55	1986	1991	X	X	X	X	X	X
1.7 D	17 D	1699	42	1989	1991	X	X	X	X	X	X
1.8 N	E 18 NV	1796	62	1987	1989	X	X	X	X	X	X
1.8i	C 18 NT/NZ/SE	1796	82	1985	1991	X	X	X	X	X	X
2.0 GSi	C 20 NE	1998	85	1986	1989	X	X	X	X	X	X
2.0 GSi 16V	C 20 XE	1998	110	1987	1991	X	X	X	X	X	X
<b>Meriva 2003</b>											
1.3 CDTi 16V	Z 13 DT	1248	51	2005		X	X	X	X	X	X
1.3 CDTi 16V	Z 13 DTJ	1250	55	2006		X	X	X	X	X	X
1.4 16V	Z 14 XEP	1364	66	2004		X	X	X	X	X	X
1.6	Z 16 SE	1598	62	2003	2005	X	X	X	X	X	X
1.6 16V	Z 16 XE	1598	74	2003		X	X	X	X	X	X
1.6 16V	Z 16 XEP	1598	77	2006		X	X	X	X	X	X
1.6 16V OPC	Z 16 LET	1598	132	2006		X	X	X	X	X	X
1.7 CDTi 16V	Z 17 DTH	1686	74	2004		X	X	X	X	X	X
1.7 DTi 16V	Y 17 DT	1686	55	2003	2006	X	X	X	X	X	X
1.8 16V	Z 18 XE	1796	92	2003		X	X	X	X	X	X
<b>Monterey 1991 1999</b>											
3.0 DTi 16V	4JX1	2999	117	1998	1999	X	X	X	X	X	X
3.1 TD	4JG2-T	3059	84	1991	1998	X	X	X	X	X	X
3.2 V6 24V	6VD1	3165	130	1991	1998	X	X	X	X	X	X
<b>Movano 1999 2003</b>											
1.9 DTi	F9Q 770	1870	59	2000	2002	X	X	X	X	X	X
1.9 DTi	F9Q 772	1870	60	2002	2003	X	X	X	X	X	X
2.2 DTi	G9T 720	2188	66	2000	2002	X	X	X	X	X	X
2.2 DTi	G9T 722	2188	66	2002	2003	X	X	X	X	X	X
2.5 D	S8U 772	2499	59	1999	2001	X	X	X	X	X	X
2.5 DTi	G9U 720	2464	84	2002	2003	X	X	X	X	X	X
2.5 DTi	G9U 724	2464	84	2003	2003	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagram. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagnr. Fuses & Relays
<b>OPEL / VAUXHALL</b>											
<b>Movano 1999 2003</b>											
2.8 DTi	S9W 700	2799	84	1999	2003	X	X	X	X	X	X
2.8 DTi	S9W 702	2799	84	1999	2003	X	X	X	X	X	X
<b>Movano 2003</b>											
1.9 CDTi	F9Q 774	1870	60	2004	2007	X	X	X	X	N	X
2.2 CDTi	G9T 750	2188	66	2004	2007	X	X	X	X	N	X
2.5 CDTi	G9U 632	2464	107	2007		X	X	X	X	N	X
2.5 CDTi	G9U 650	2464	74	2007		X	X	X	X	N	X
2.5 CDTi	G9U 650	2464	88	2007		X	X	X	X	N	X
2.5 CDTi	G9U 750	2463	84	2004	2007	X	X	X	X	N	X
2.5 CDTi	G9U 754	2463	73	2004	2007	X	X	X	X	N	X
2.5 CDTi	G9U 754	2463	84	2004	2007	X	X	X	X	N	X
3.0 CDTi	ZD3 200	2953	100	2004	2007	X	X	X	X	N	X
3.0 CDTi	ZD3 202	2953	100	2004	2007	X	X	X	X	N	X
<b>Omega A / Carlton 1986 1994</b>											
1.8i	18 SEH	1796	85	1986	1992	X	X	X	X	X	X
1.8N	18 NV	1796	60	1986	1989	X	X	X	X	X	X
1.8S	18 SV	1796	66	1986	1990	X	X	X	X	X	X
2.0i	20 SE	1998	90	1986	1989	X	X	X	X	X	X
2.0i	C 20 NE	1998	85	1986	1989	X	X	X	X	X	X
2.3 D	23 YD	2260	54	1986	1994	X	X	X	X	X	X
2.3 TD	23 DTR	2260	74	1988	1994	X	X	X	X	X	X
2.3 TD	23 YDT	2260	66	1986	1989	X	X	X	X	X	X
2.4i	C 24 NE	2410	92	1988	1994	X	X	X	X	X	X
2.6i	C 26 NE	2594	110	1990	1994	X	X	X	X	X	X
3.0i	C 30 NE	2969	130	1986	1990	X	X	X	X	X	X
3.0i	C 30 NE	2969	130	1990	1994	X	X	X	X	X	X
3.0i 24V	C 30 SE	2969	150	1989	1994	X	X	X	X	X	X
<b>Omega B 1994 2004</b>											
2.0	20 SE	1998	85	1994	1999	X	X	X	X	X	X
2.0	X 20 SE	1998	85	1994	2000	X	X	X	X	X	X
2.0 16V	X 20 XEV	1998	100	1994	2000	X	X	X	X	X	X
2.0 TD 16V	X 20 DTH	1995	74	1998	2000	X	X	X	X	X	X
2.2 16V	Y 22 XE	2198	106	2000	2001	X	X	X	X	X	X
2.2 16V	Z 22 XE	2198	106	2001	2004	X	X	X	X	X	X
2.2 DTi 16V	Y 22 DTH	2171	88	2001	2004	X	X	X	X	X	X
2.5 DTi 24V	Y 25 DT	2497	110	2002	2004	X	X	X	X	X	X
2.5 TD	25 DT	2498	96	1994	1996	X	X	X	X	X	X

Legend: N = new, X = present

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diag. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>OPEL / VAUXHALL</b>											
<b>Omega B 1994 2004</b>											
2.5 TD	X 25 DT	2497	96	1994	2001	X	X X X X	X X X X	X X X X	X	X X X
2.5 V6	X 25 XE	2498	125	1994	2000	X	X X X X	X X X X	X X X X	X	X X X
2.6 V6	Y 26 SE	2597	132	2001	2003	X	X X X X	X X X X	X X X X	X	X X X
3.0 V6	X 30 XE	2962	155	1994	2001	X	X X X X	X X X X	X X X X	X	X X X
3.2 V6	Y 32 SE	3175	160	2001	2004	X	X X X X	X X X X	X X X X	X	X X X
<b>Senator 1986 1994</b>											
2.6i	C 26 NE	2594	110	1990	1994	X	X X X X	X X X X	X X X X	X	X X X
3.0i	C 30 LE/NE	2969	130	1987	1994	X	X X X X	X X X X	X X X X	X	X X X
3.0i 24V	C 30 SE	2969	150	1989	1994	X	X X X X	X X X X	X X X X	X	X X X
<b>Signum 2003</b>											
1.8 16V	Z 18 XE	1796	90	2003	2006	X	X X X X	X X X X	X X X X	X	X X X
1.8 16V	Z 18 XER	1796	103	2006		X	X X X X	X X X X	X X X X	X	X X X
1.9 CDTi	Z 19 DT	1910	88	2004		X	X X X X	X X X X	X X X X	X	X X X
1.9 CDTi	Z 19 DTL	1910	74	2006		X	X X X X	X X X X	X X X X	X	X X X
1.9 CDTi 16V	Z 19 DTH	1910	110	2004		X	X X X X	X X X X	X X X X	X	X X X
2.0 16V Turbo	Z 20 NET	1998	129	2003		X	X X X X	X X X X	X X X X	X	X X X
2.2 DGi 16V	Z 22 YH	2198	114	2003		X	X X X X	X X X X	X X X X	X	X X X
2.2 DTi	Y 22 DTR	2172	92	2003	2006	X	X X X X	X X X X	X X X X	X	X X X
2.8 V6 24V	Z 28 NEL	2792	169	2006		X	X X X X	X X X X	X X X X	X	X X X
3.0 V6 CDTi	Y 30 DT	2958	130	2003	2006	X	X X X X	X X X X	X X X X	X	X X X
3.0 V6 CDTi	Z 30 DT	2958	135	2006		X	X X X X	X X X X	X X X X	X	X X X
3.2 V6	Z 32 SE	3175	155	2003	2006	X	X X X X	X X X X	X X X X	X	X X X
<b>Sintra 1996 1999</b>											
2.2 16V	X 22 XE	2198	104	1996	1999	X	X X X X	X X X X	X X X X	X	X X X
2.2 D	X 22 DTH	2171	85	1998	1999	X	X X X X	X X X X	X X X X	N	X X X
3.0 V6 24V	X 30 XE	2962	148	1996	1999	X	X X X X	X X X X	X X X X	X	X X X
<b>Tigra 1995 2000</b>											
1.4i 16V	C 14 SEL	1389	63	1998	2000	X	X X X X	X X X X	X X X X	X	X X X
1.4i 16V	X 14 XE	1389	66	1995	2000	X	X X X X	X X X X	X X X X	X	X X X
1.6i 16V	C 16 SEL	1589	74	1998	2000	X	X X X X	X X X X	X X X X	X	X X X
1.6i 16V	X 16 XE	1598	78	1995	2000	X	X X X X	X X X X	X X X X	X	X X X
<b>Tigra B 2005</b>											
1.3 CDTi 16V	Z 13 DT	1248	51	2005		X	X X X X	X X X X	X X X X	X	X X X
1.4 16V	Z 14 XEP	1364	66	2005		X	X X X X	X X X X	X X X X	X	X X X
1.8 16V	Z 18 XE	1789	92	2005		X	X X X X	X X X X	X X X X	X	X X X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>OPEL / VAUXHALL</b>											
<b>Vectra A / Cavalier 1988 1995</b>											
1.4S	14 NV	1389	55	1988	1995	X	X	X	X	X	X
1.6i	E/C 16 NZ	1598	55	1988	1995	X	X	X	X	X	X
1.6i	X 16 SZ	1598	52	1988	1995	X	X	X	X	X	X
1.6S	16 SV	1598	44	1988	1995	X	X	X	X	X	X
1.7 D	17 D	1699	42	1988	1995	X	X	X	X	X	X
1.7 TD	17 TC4EE1	1686	60	1990	1995	X	X	X	X	X	X
1.8	18 SV	1796	60	1988	1989	X	X	X	X	X	X
1.8 4x4	E 18 NVR	1796	65	1988	1995	X	X	X	X	X	X
1.8i	C 18 NZ	1796	66	1988	1995	X	X	X	X	X	X
2.0 Turbo 4x4	C 20 LET	1998	150	1992	1995	X	X	X	X	X	X
2.0i	20 SEH	1998	95	1988	1995	X	X	X	X	X	X
2.0i	C 20 NE	1998	85	1988	1995	X	X	X	X	X	X
2.0i 16V	C 20 XE	1998	110	1988	1994	X	X	X	X	X	X
2.0i 16V	X 20 XEV	1998	100	1994	1995	X	X	X	X	X	X
2.0i 16V 4x4	C 20 XE	1998	110	1988	1995	X	X	X	X	X	X
2.0i 4x4	20 SEH	1998	95	1988	1995	X	X	X	X	X	X
2.0i 4x4	C 20 NE	1998	85	1988	1995	X	X	X	X	X	X
2.5 V6	C 25 XE	2495	125	1993	1995	X	X	X	X	X	X
<b>Vectra B 1995 2001</b>											
1.6	16 LZ2	1598	55	1996	2000	X	X	X	X	X	X
1.6	X 16 SZR	1598	55	1995	2000	X	X	X	X	X	X
1.6 16V	X 16 XEL	1598	74	1995	2000	X	X	X	X	X	X
1.6 16V	Y 16 XE	1598	74	2000	2000	X	X	X	X	X	X
1.6 16V	Z 16 XE	1598	74	2001	2001	X	X	X	X	X	X
1.7 TD	X 17 DT	1686	60	1995	1998	X	X	X	X	X	X
1.8 16V	X 18 XE	1799	85	1995	2000	X	X	X	X	X	X
1.8 16V	X 18 XE1	1796	85	1998	2000	X	X	X	X	X	X
1.8 16V	Z 18 XE	1799	85	2001	2001	X	X	X	X	X	X
1.8 16V	Z 18 XEL	1799	85	2001	2001	X	X	X	X	X	X
2.0	20 NEJ	1998	82	1996	2000	X	X	X	X	X	X
2.0 16V	C 20 SEL	1998	100	1997	2001	X	X	X	X	X	X
2.0 16V	X 20 XEV	1998	100	1995	2001	X	X	X	X	X	X
2.0 16V TD	X 20 DTH	1995	74	1998	2000	X	X	X	X	X	X
2.0 16V TD	X 20 DTL	1995	60	1997	2000	X	X	X	X	X	X
2.0 16V TD	Y 20 DTH	1995	74	2001	2001	X	X	X	X	X	X
2.2 16V	C 22 SEL	2198	104	1998	2001	X	X	X	X	X	X
2.2 16V	Z 22 SE	2198	108	2001	2001	X	X	X	X	X	X



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>OPEL / VAUXHALL</b>													
<b>Vectra B 1995 2001</b>													
2.2 16V TD	Y 22 DTR	2171	92	2001	2001	X	X	X	X	X	X	X	X
2.5 V6	X 25 XE	2498	125	1996	2000	X	X	X	X	X	X	X	X
2.6 V6	Y 26 SE	2597	125	2001	2001	X	X	X	X	X	X	X	X
<b>Vectra C 2002</b>													
1.6 16V	Z 16 XE	1598	74	2002	2006	X	X	X	X	X	X	X	X
1.6 16V	Z 16 XEP	1598	77	2006		X	X	X	X	X	X	X	X
1.8 16V	Z 18 XE	1796	90	2002		X	X	X	X	X	X	X	X
1.8 16V	Z 18 XEL	1796	81	2002	2006	X	X	X	X	X	X	X	X
1.8 16V	Z 18 XER	1796	103	2006		X	X	X	X	X	X	X	X
1.9 CDTi	Z 19 DT	1910	88	2004		X	X	X	X	X	X	X	X
1.9 CDTi	Z 19 DTL	1910	74	2006		X	X	X	X	X	X	X	X
1.9 CDTi 16V	Z 19 DTH	1910	110	2004		X	X	X	X	X	X	X	X
2.0 16V Turbo	Z 20 NET	1998	129	2003		X	X	X	X	X	X	X	X
2.0 DTi 16V	Y 20 DTH	1995	74	2002	2006	X	X	X	X	X	X	X	X
2.2 16V	Z 22 SE	2198	108	2002	2006	X	X	X	X	X	X	X	X
2.2 DGi 16V	Z 22 YH	2198	114	2003		X	X	X	X	X	X	X	X
2.2 DTi 16V	Y 22 DTR	2172	92	2002	2006	X	X	X	X	X	X	X	X
2.8 V6 Turbo	Z 28 NEL	2792	169	2006		X	X	X	X	X	X	X	X
2.8 V6 Turbo OPC	Z 28 NET	2792	188	2006		X	X	X	X	X	X	X	X
3.0 V6 CDTi	Y 30 DT	2958	130	2003	2006	X	X	X	X	X	X	X	X
3.0 V6 CDTi	Z 30 DT	2958	135	2006		X	X	X	X	X	X	X	X
3.2 V6	Z 32 SE	3175	155	2002	2006	X	X	X	X	X	X	X	X
<b>Vivaro 2001</b>													
1.9 CDi	F9Q 762	1870	59	2001	2007	X	X	X	X	X	X	X	X
1.9 CDTi	F9Q 760	1870	74	2001		X	X	X	X	X	X	X	X
2.0 16V	F4R 720	1998	88	2001	2007	X	X	X	X	X	X	X	X
2.0 16V	F4R 820	1998	86	2007		X	X	X	X	X	X	X	N
2.0 CDTi 16V	M9R 780	1995	66	2007		X	X	X	X	X	X	X	N
2.0 CDTi 16V	M9R 780	1995	84	2007		X	X	X	X	X	X	X	N
2.5 CDTi	G9U 630	2464	107	2007		X	X	X	X	X	X	X	N
2.5 CDTi	G9U 730	2464	99	2003	2007	X	X	X	X	X	X	X	X
<b>Zafira 1999 2005</b>													
1.6 16V	X 16 XEL	1598	74	1999	2001	X	X	X	X	X	X	X	X
1.6 16V	Z 16 XE	1598	74	2001	2005	X	X	X	X	X	X	X	X
1.6 16V CNG	Z 16 YNG	1595	71	2002	2005	X	X	X	X	X	X	X	X
1.8 16V	X 18 XE1	1796	85	1999	2001	X	X	X	X	X	X	X	X
1.8 16V	Z 18 XE	1796	74	2001	2005	X	X	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diag. Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diag. Fuses & Relays

**OPEL / VAUXHALL**

**Zafira 1999 2005**

2.0 TD 16V	X 20 DTL	1995	60	1999	2001	X	X	X	X	X	X	X	X	X	X	X	X	X
2.0 TD 16V	Y 20 DTH	1995	74	2001	2005	X	X	X	X	X	X	X	X	X	X	X	X	X
2.0 Turbo	Z 20 LET	1998	141	2002	2005	X	X	X	X	X	X	X	X	X	X	X	X	X
2.2 16V	Z 22 SE	2198	100	2001	2005	X	X	X	X	X	X	X	X	X	X	X	X	X
2.2 TD 16V	Y 22 DTR	2198	92	2002	2005	X	X	X	X	X	X	X	X	X	X	X	X	X

**Zafira B 2005**

1.6 16V Twinport	Z 16 XEP	1598	77	2005		X	X	X	X	X	X	X	X	X	X	X	X	X
1.8 16V	Z 18 XER	1796	103	2006		X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 CDTi 16V 110	Z 19 DTH	1910	110	2005		X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 CDTi 8V 110	Z 19 DTL	1910	74	2005		X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 CDTi 8V 120	Z 19 DT	1910	88	2005		X	X	X	X	X	X	X	X	X	X	X	X	X
2.0 16V Turbo	Z 20 LEL	1998	125	2005		X	X	X	X	X	X	X	X	X	X	X	X	X
2.0 16V Turbo	Z 20 LER	1998	147	2005		X	X	X	X	X	X	X	X	X	X	X	X	X
2.2 16V DGi	Z 22 YH	2198	110	2005		X	X	X	X	X	X	X	X	X	X	X	X	X

**PEUGEOT**

**1007 2005**

<b>N</b> 1.4	TU3A (KFV)	1360	55	2005		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
1.4	TU3JP (KFV)	1360	55	2005		X	X	X	X	X	X	X	X	X	X	X	X	X
<b>N</b> 1.4 16V	ET3J4 (KFU)	1360	65	2005		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
1.4 HDi	DV4TD (8HX)	1398	50	2005	2006	X	X	X	X	X	X	X	X	X	X	X	X	X
<b>N</b> 1.4 HDi	DV4TD (8HZ)	1398	50	2006		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
1.6 16V	TU5JP4 (NFU)	1587	80	2005		X	X	X	X	X	X	X	X	X	X	X	X	X
<b>N</b> 1.6 HDiF 16V	DV6TED4 (9HZ)	1560	80	2007		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>

**106 1991 2004**

1.0	TU9 (C1A)	954	33	1991	1994	X	X	X	X	X	X	X	X	X	X	X	X	X
1.0i	TU9M (CDY)	954	33	1994	2000	X	X	X	X	X	X	X	X	X	X	X	X	X
1.0i	TU9M (CDZ)	954	37	1991	1996	X	X	X	X	X	X	X	X	X	X	X	X	X
1.1	TU1/K (H1A)	1124	44	1991	1994	X	X	X	X	X	X	X	X	X	X	X	X	X
1.1	TU1/K (H3A)	1124	44	1991	1994	X	X	X	X	X	X	X	X	X	X	X	X	X
1.1i	TU1JP/L4 (HFX)	1124	44	2000	2004	X	X	X	X	X	X	X	X	X	X	X	X	X
1.1i	TU1M (HDY)	1124	40	1991	2000	X	X	X	X	X	X	X	X	X	X	X	X	X
1.1i	TU1M (HDZ)	1124	44	1991	2000	X	X	X	X	X	X	X	X	X	X	X	X	X
1.3i Rallye	TU2J2 (MFZ)	1294	72	1993	1996	X	X	X	X	X	X	X	X	X	X	X	X	X
1.4	TU3.2TR/K (K5A)	1360	52	1996	1998	X	X	X	X	X	X	X	X	X	X	X	X	X
1.4	TU3.2 (K2D)	1360	55	1991	1994	X	X	X	X	X	X	X	X	X	X	X	X	X
1.4	TU3TR (K3A)	1360	44	1991	1994	X	X	X	X	X	X	X	X	X	X	X	X	X
1.4 D	TUD3/L1 (K9B)	1360	38	1992	1994	X	X	X	X	X	X	X	X	X	X	X	X	X

Legend: N = new, X = present

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>PEUGEOT</b>											
<b>106 1991 2004</b>											
1.4 D	TUD3/Y (K9Y)	1360	38	1992	1995	X	X	X	X	X	X
1.4i	TU3FJ2 (K6B)	1360	72	1991	1994	X	X	X	X	X	X
1.4i	TU3FJ2 (KFZ)	1360	69	1991	1995	X	X	X	X	X	X
1.4i	TU3JP/L3 (KFX)	1361	55	1996	2000	X	X	X	X	X	X
1.4i	TU3JP/L4 (KFW)	1360	55	2000	2004	X	X	X	X	X	X
1.4i	TU3M (KDX)	1360	55	1991	1996	X	X	X	X	X	X
1.4i	TU3M (KDY)	1360	55	1991	1996	X	X	X	X	X	X
1.5 D	TUD5 (VJY)	1527	40	1994	1998	X	X	X	X	X	X
1.5 D	TUD5 (VJZ)	1527	42	1994	2001	X	X	X	X	X	X
1.5 D	TUD5B (VJX)	1527	42	2001	2004	X	X	X	X	X	X
1.6i	TU5J (NFY)	1587	76	1993	1996	X	X	X	X	X	X
1.6i	TU5J2 (NFW)	1587	74	1996	1999	X	X	X	X	X	X
1.6i	TU5JP/Z (NFZ)	1587	65	1995	2004	X	X	X	X	X	X
1.6i 16V	TU5J4/L3 (NFX)	1587	87	1996	2000	X	X	X	X	X	X
1.6i 16V	TU5J4/L4 (NFX)	1587	87	2000	2004	X	X	X	X	X	X
<b>107 2005</b>											
1.0 12V	384F (CFA)	998	50	2005		X	X	X			X
1.4 HDi	DV4TD (8HT)	1398	40	2005		X	X	X		X	X
<b>205 1983 1999</b>											
1.0	TU9A/TU9M/C1A	954	33	1987	1999	X	X	X		X	X
1.0	XV8	954	33	1983	1987	X		X		X	X
1.1	TU1 (H1A)	1124	40	1987	1990	X	X	X		X	X
1.1	TU1M (H1)	1124	44	1989	1997	X	X	X	X		X
1.1	XW7	1124	37	1983	1987	X		X		X	X
1.3 Rallye	TU2.4 (M2A/M4A)	1294	75	1988	1996	X	X	X		X	X
1.4	TU3A (K1G)	1360	51	1989	1998	X	X	X		X	X
1.4	TU3CP	1360	44	1989	1990	X	X	X		X	X
1.4	TU3M (KDY/KDZ)	1360	55	1989	1997	X	X	X	X		X
1.4	XY7 (150 D)	1360	44	1983	1987	X		X		X	X
1.4	XY8 (150 B)	1360	59	1983	1987	X		X		X	X
1.6 Automatic	XU51C (B1A)	1580	58	1987	1991	X	X	X		X	X
1.6 GTi	XU5J (180A)	1580	76	1987	1989	X		X	X		X
1.6 GTi/CTi	XU5JA (B6D)	1580	83	1986	1992	X	X	X	X		X
1.6i	XU5M3 (BDY)	1580	65	1989	1997	X	X	X	X		X
1.8 D	XUD7 (161A)	1768	44	1987	1987	X		X		X	X
1.8 D	XUD7 (A9A)	1768	44	1991	1999	X	X	X		X	X
1.8 Turbo D	XUD7 TE/L (A8D)	1768	58	1991	1998	X	X	X		X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>PEUGEOT</b>											
<b>205 1983 1999</b>											
1.9 CTi	XU9J1 (DFZ)	1905	75	1989	1994	X	X	X	X	X	X
1.9 D	XUD9 (D9A)	1905	47	1987	1999	X	X	X	X	X	X
1.9 GTi	XU9J1 (DFZ)	1905	75	1986	1994	X	X	X	X	X	X
1.9 GTi	XU9JA (D6B)	1905	95	1987	1996	X	X	X	X	X	X
1.9 GTi	XU9JAZ (DKZ)	1905	88	1989	1994	X	X	X	X	X	X
<b>206 1998</b>											
1.1	TU1JP (HFX)	1124	44	2000	2006	X	X	X	X	X	X
1.1	TU1JP (HFX)	1124	40	1998	2001	X	X	X	X	X	X
1.1	TU1JP (HFZ)	1124	44	1998	2000	X	X	X	X	X	X
1.4	TU3A (KFV)	1360	54	2006		X	X	X	X	X	<b>N</b>
1.4	TU3JP (KFW)	1360	55	2000	2006	X	X	X	X	X	X
1.4	TU3JP (KFX)	1360	55	1998	2000	X	X	X	X	X	X
1.4 16V	ET3J4 (KFU)	1361	65	2003	2007	X	X	X	X	X	X
1.4 HDi	DV4TD (8HX)	1398	50	2002		X	X	X	X	X	X
1.6	TU5JP (NFY)	1587	76	1998	2000	X	X	X	X	X	X
1.6	TU5JP (NFZ)	1587	65	1998	2000	X	X	X	X	X	X
1.6 16V	TU5JP4 (NFU)	1587	80	2000		X	X	X	X	X	X
1.6 HDiF 16V	DV6TED4 (9HZ)	1560	80	2004		X	X	X	X	X	X
1.9 D	DW8 (WJZ)	1868	51	1998	2000	X	X	X	X	X	X
1.9 D	DW8B (WJY)	1868	51	2000	2004	X	X	X	X	X	X
2.0 16V GTi	EW10J4 (RFN)	1997	100	2000	2006	X	X	X	X	X	X
2.0 16V GTi	EW10J4 (RFR)	1997	99	1999	2000	X	X	X	X	X	X
2.0 16V GTi 180 (RC)	EW10J4S (RFK)	1997	130	2002	2006	X	X	X	X	X	X
2.0 HDi	DW10TD (RHY)	1996	66	1999	2007	X	X	X	X	X	X
CC 1.6 16V	TU5JP4 (NFU)	1587	80	2000	2007	X	X	X	X	X	X
CC 1.6 HDiF 16V	DV6TED4 (9HZ)	1560	80	2005	2007	X	X	X	X	X	<b>N</b>
CC 2.0 16V	EW10J4 (RFN)	1997	100	2000	2007	X	X	X	X	X	X
<b>207 2006</b>											
1.4	TU3A (KFV)	1360	54	2006		X	X	X	X	X	<b>N</b>
1.4 16V	ET3J4 (KFU)	1360	65	2006		X	X	X	X	X	<b>N</b>
1.4 HDi	DV4TD (8HZ)	1398	50	2006		X	X	X	X	X	<b>N</b>
1.6 16V	TU5JP4 (NFU)	1587	80	2006		X	X	X	X	X	<b>N</b>
1.6 16V THP	EP6DT (5FX)	1587	110	2006		X	X	X	X	X	<b>N</b>
<b>N</b> 1.6 16V THP (RC)	EP6DTS (5FY)	1587	128	2007		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
1.6 HDi 16V	DV6ATED4 (9HX)	1560	66	2006		X	X	X	X	X	<b>N</b>
<b>N</b> 1.6 HDi 16V	DV6TED4 (9HY)	1560	80	2007		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
1.6 HDiF 16V	DV6TED4 (9HZ)	1560	80	2006		X	X	X	X	X	<b>N</b>

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>PEUGEOT</b>											
<b>306 1992 2003</b>											
1.1i	TU1M (HDY)	1124	40	1992	1998	X	X	X	X	X	X
1.1i	TU1M (HDZ)	1124	44	1992	1998	X	X	X	X	X	X
1.4	TU3.2 (K2D)	1360	55	1992	2000	X	X	X	X	X	X
1.4i	TU3JP/K (K6C)	1360	55	2000	2003	X	X	X	X	X	X
1.4i	TU3JP/L3 (KFX)	1360	55	1995	2000	X	X	X	X	X	X
1.4i	TU3JP/L4 (KFW)	1360	55	2000	2003	X	X	X	X	X	X
1.4i	TU3MC (KDX)	1360	55	1992	1995	X	X	X	X	X	X
1.6i	TU5JP/L3 (NFZ)	1587	65	1992	2000	X	X	X	X	X	X
1.6i	TU5JP/L4 (NFT)	1587	73	2000	2003	X	X	X	X	X	X
1.8 D	XUD7/L (A9A)	1768	45	1992	1995	X	X	X	X	X	X
1.8i	XU7JP (LFZ)	1761	74	1992	2000	X	X	X	X	X	X
1.8i	XU7JP/K (L6A)	1761	70	1995	2003	X	X	X	X	X	X
1.8i 16V	XU7JP4/L3 (LFY)	1761	81	1997	2000	X	X	X	X	X	X
1.8i 16V	XU7JP4/L4 (LFY)	1761	81	2000	2003	X	X	X	X	X	X
1.9 D	DW8 (WJZ)	1868	51	1998	2000	X	X	X	X	X	X
1.9 D	DW8B (WJY)	1905	51	2000	2003	X	X	X	X	X	X
1.9 D	XUD9A (DJY)	1905	50	1998	1999	X	X	X	X	X	X
1.9 D	XUD9A/L (D9B)	1905	51	1992	1998	X	X	X	X	X	X
1.9 D	XUD9A/Y (DJZ)	1905	47	1992	1998	X	X	X	X	X	X
1.9 TD	XUD9TE/L (D8A)	1905	68	1992	2000	X	X	X	X	X	X
1.9 TD	XUD9TE/Y (DHY)	1905	66	1995	2000	X	X	X	X	X	X
2.0 HDi	DW10TD (RHY)	1997	66	1999	2003	X	X	X	X	X	X
2.0 S16	XU10J4 (RFY)	1998	112	1992	1996	X	X	X	X	X	X
2.0 S16 GTi	XU10J4RS (RFS)	1998	122	1996	2000	X	X	X	X	X	X
2.0 XSi	XU10J2 (R6D)	1998	89	1992	1996	X	X	X	X	X	X
2.0 XSi	XU10J2C (RFX)	1998	89	1992	1998	X	X	X	X	X	X
2.0i 16V	XU10J4R (RFV)	1998	98	1995	2003	X	X	X	X	X	X
<b>307 2001</b>											
1.4	TU3JP (KFW)	1360	55	2001	2005	X	X	X	X	X	X
1.4 16V	ET3J4 (KFU)	1361	65	2003		X	X	X	X	X	X
1.4 HDi	DV4TD (8HZ)	1398	50	2001	2006	X	X	X	X	X	X
1.6 16V	TU5JP4 (N6A)	1560	78	2005		X	X	X	X	X	X
1.6 16V	TU5JP4 (NFU)	1587	80	2001		X	X	X	X	X	X
1.6 HDi 16V	DV6TED4 (9HY)	1560	80	2004		X	X	X	X	X	X
1.6 HDi 16V 90	DV6ATED4 (9HX)	1560	66	2005		X	X	X	X	X	X
1.6 HDiF 16V	DV6TED4 (9HZ)	1560	80	2004		X	X	X	X	X	X
2.0 16V	EW10A (RFJ)	1997	103	2005		X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays
<b>PEUGEOT</b>												
<b>307 2001</b>												
2.0 16V	EW10J4 (RFN)	1997	100	2001		X	X	X	X	X	X	X
2.0 16V 180	EW10J4S (RFK)	1997	130	2005		X	X	X	X	X	X	X
2.0 HDi 110	DW10ATED (RHZ)	1997	80	2001	2006	X	X	X	X	X	X	X
2.0 HDi 90	DW10TD (RHY)	1998	66	2001	2006	X	X	X	X	X	X	X
2.0 HDiF 110	DW10ATED (RHS)	1997	80	2002	2006	X	X	X	X	X	X	X
2.0 HDiF 16V	DW10BTED4 (RHR)	1997	100	2003		X	X	X	X	X	X	X
CC 1.6 16V	TU5JP4 (NFU)	1587	80	2003		X	X	X	X	X		X
CC 2.0 16V	EW10A (RFJ)	1997	103	2005		X	X	X	X	X		X
CC 2.0 16V	EW10J4 (RFN)	1997	100	2003	2006	X	X	X	X	X	X	X
CC 2.0 16V 180	EW10J4S (RFK)	1997	130	2002		X	X	X	X	X	X	X
CC 2.0 HDiF 16V	DW10BTED4 (RHR)	1998	100	2005		X	X	X	X	X		X
<b>309 1985 1993</b>												
1.1	E1A (1E1A)	1118	40	1985	1989	X	X	X	X	X		X
1.1	TU1/K (H1A/B)	1124	40	1989	1993	X	X	X	X	X		X
1.1i	TU1M (HDZ)	1124	40	1990	1993	X	X	X	X	X		X
1.3	G1A (1G1A)	1294	47	1985	1991	X	X	X	X	X		X
1.4	TU3A	1360	51	1989	1992	X	X	X	X	X		X
1.4	TU3S (K2A/K2B)	1360	62	1989	1993	X	X	X	X	X		X
1.4i	TU3M (KDY/KDZ)	1360	55	1989	1993	X	X	X	X	X		X
1.6	XU5 (KAY)	1580	55	1987	1993	X	X	X	X	X		X
1.6	XU51C (B1A)	1580	58	1985	1989	X	X	X	X	X		X
1.6 Automatic	XU52C (B2A/B2B)	1580	68	1989	1993	X	X	X	X	X		X
1.6i	XU5JA (B6D)	1580	85	1986	1989	X	X	X	X	X		X
1.6i	XU5JA (B6E)	1580	83	1990	1993	X	X	X	X	X		X
1.6i	XU5M (BDZ/BDY)	1580	65	1989	1993	X	X	X	X	X		X
1.8 D	XUD7 (A9A)	1769	44	1986	1989	X	X	X	X	X		X
1.8 Turbo D	XUD7TE (A8B)	1769	58	1989	1993	X	X	X	X	X		X
1.9	XU9M (DDZ)	1905	80	1988	1993	X	X	X	X	X		X
1.9 D	XUD9 (D9A)	1905	48	1989	1993	X	X	X	X	X		X
1.9 D	XUD9 (DJZ)	1905	47	1986	1989	X	X	X	X	X		X
1.9 GTi	XU92C	1905	75	1985	1989	X	X	X	X	X		X
1.9 GTi	XU9J1 (DFZ)	1905	75	1987	1989	X	X	X	X	X		X
1.9 GTi	XU9JA (D6B)	1905	94	1986	1993	X	X	X	X	X		X
1.9 GTi 16V	XU9J4/Z (DFW/D6C)	1905	116	1986	1989	X	X	X	X	X		X
<b>405 1987 1997</b>												
1.4	TU3A (K1A)	1360	47	1989	1992	X	X	X	X	X		X
1.4	TU3A (K1G)	1360	47	1989	1992	X	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>PEUGEOT</b>											
<b>405 1987 1997</b>											
1.4i	TU3MC (KDX)	1360	55	1988	1994	X	X	X	X	X	X
1.6	XU51C (B1E)	1580	53	1987	1989	X		X	X	X	X
1.6	XU52C (B2A)	1580	68	1987	1989	X	X	X	X	X	X
1.6i	XU5M3/L (BDY)	1580	65	1989	1997	X	X	X	X	X	X
1.8 Turbo D	XUD7TE (A8A)	1769	66	1988	1992	X	X	X	X	X	X
1.8i	XU7JPZ/L (LFZ)	1762	74	1992	1997	X	X	X	X	X	X
1.9	XU92C (D2D)	1905	81	1987	1992	X	X	X	X	X	X
1.9 D	XUD9A/L (D9B)	1905	51	1988	1997	X	X	X	X	X	X
1.9 MI16	XU9J4 (D6C)	1905	116	1989	1992	X	X	X	X	X	X
1.9 MI16	XU9J4 (DFW)	1905	108	1989	1992	X	X	X	X	X	X
1.9 MI16	XU9J4/Z (DFW)	1905	116	1987	1992	X	X	X	X	X	X
1.9 Turbo D	XUD9TE/L (D8A)	1905	68	1992	1997	X	X	X	X	X	X
1.9i	XU9J1 (DFZ)	1905	77	1989	1992	X	X	X	X	X	X
1.9i	XU9J2 (D6A)	1905	90	1989	1992	X	X	X	X	X	X
1.9i	XU9JA/Z (DKZ)	1905	88	1988	1992	X	X	X	X	X	X
1.9i	XU9M (DDZ)	1905	81	1989	1992	X	X	X	X	X	X
2.0 MI16	XU10J4Z/L (RFY)	1998	112	1992	1995	X	X	X	X	X	X
2.0 T16 X4	XU10J4TE/Z (RGZ)	1998	144	1993	1996	X	X	X	X	X	X
2.0i	XU10J2C/L (RFX)	1998	89	1992	1997	X	X	X	X	X	X
<b>406 1995 2005</b>											
1.6	XU5JP (BFZ)	1580	65	1995	1999	X	X	X	X	X	X
1.8	XU7JB (LFX)	1761	66	1998	2002	X	X	X	X	X	X
1.8	XU7JP (L6A)	1761	70	1995	2002	X	X	X	X	X	X
1.8 16V	EW7J4 (6FZ)	1749	85	2001	2004	X	X	X	X	X	X
1.8 16V	XU7JP4 (LFY)	1761	81	1995	2001	X	X	X	X	X	X
1.9 D Turbo	XUD9BTF (DHX)	1905	66	1995	2000	X	X	X	X	X	X
1.9 D Turbo	XUD9SD (DHW)	1905	55	1996	2000	X	X	X	X	X	X
1.9 D Turbo	XUD9TF (D8B)	1905	68	1995	2000	X	X	X	X	X	X
2.0 16V	EW10J4 (RFN)	1997	100	2000	2004	X	X	X	X	X	X
2.0 16V	EW10J4 (RFR)	1997	99	1998	2000	X	X	X	X	X	X
2.0 16V	XU10J4R (R6E)	1997	100	1995	2005	X	X	X	X	X	X
2.0 16V	XU10J4R (RFV)	1998	98	1995	2000	X	X	X	X	X	X
2.0 16V HPi	EW10D (RLZ)	1998	103	2000	2004	X	X	X	X	X	X
2.0 HDi	DW10ATED (RHZ)	1997	80	1999	2004	X	X	X	X	X	X
2.0 HDi	DW10TD (RHY)	1997	66	1999	2004	X	X	X	X	X	X
2.0 HDiF	DW10ATED (RHS)	1997	79	2000	2005	X	X	X	X	X	X
2.0 Turbo	XU10J2CTE (RGX)	1998	108	1995	1999	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>PEUGEOT</b>											
<b>406 1995 2005</b>											
2.1 D Turbo	XUD11BTE (P8C)	2088	80	1995	2000	X	X	X	X	X	X
2.2 16V	EW12J4 (3FZ)	2230	116	2002	2004	X	X	X	X	X	X
2.2 16V HDi	DW12TED4 (4HZ)	2179	98	2000	2004	X	X	X	X	X	X
2.2 16V HDiF	DW12TED4 (4HX)	2179	98	2000	2004	X	X	X	X	X	X
3.0 V6	ES9J4 (XFZ)	2946	140	1997	2000	X	X	X	X	X	X
3.0 V6	ES9J4S (XFX)	2946	152	2000	2005	X	X	X	X	X	X
<b>407 2004</b>											
1.6 HDiF 16V	DV6TED4 (9HZ)	1560	80	2004		X	X	X	X	X	X
1.8 16V	EW7J4 (6FZ)	1749	85	2004	2006	X	X	X	X	X	X
2.0 16V	EW10J4 (RFN)	1997	100	2004		X	X	X	X	X	X
2.0 HDiF 16V	DW10BTED4 (RHR)	1997	100	2004		X	X	X	X	X	X
2.2 16V	EW12J4 (3FZ)	2230	116	2004		X	X	X	X	X	X
2.2 HDiF 16V	DW12BTED4 (4HT)	2179	125	2006		X	X	X	X	X	X
2.7 HDiF V6	DT17TED4 (UHZ)	2720	150	2006		X	X	X	X	X	X
3.0 V6	ES9A (XFX)	2946	155	2004		X	X	X	X	X	X
<b>407 Coupe 2005</b>											
2.2 16V	EW12J4 (3FY)	2230	116	2005		X	X	X	X	X	X
2.7 HDiF V6	DT17TED4 (UHZ)	2721	150	2005		X	X	X	X	X	X
3.0 V6	ES9A (XFX)	2946	155	2005		X	X	X	X	X	X
<b>605 1989 2000</b>											
2.0	XU102C/K (R2A)	1998	84	1989	1992	X	X	X	X	X	X
2.0i	XU10J2/K (R6A)	1998	94	1989	1994	X	X	X	X	X	X
2.0i	XU10J2Z (RFZ)	1998	89	1989	1994	X	X	X	X	X	X
2.0i	XU10M/Z (RDZ)	1998	79	1989	1992	X	X	X	X	X	X
2.0i 16V	XU10J4R/L	1998	98	1994	2000	X	X	X	X	X	X
2.0i Turbo	XU10J2TEZ (RGX/RGY)	1998	104	1994	2000	X	X	X	X	X	X
2.1 D	XUD11A/W (P9A)	2138	61	1989	1994	X	X	X	X	X	X
2.1 D Turbo	XUD11ATE/L (P8A)	2088	81	1989	1994	X	X	X	X	X	X
3.0i	ZPJ (S6A)	2975	123	1989	1994	X	X	X	X	X	X
3.0i	ZPJ/Z (SFZ)	2963	123	1994	1996	X	X	X	X	X	X
3.0i SV24	ZPJ4/Z (SKZ)	2975	147	1989	1994	X	X	X	X	X	X
3.0i SV24	ZPJ4/Z (UKZ)	2963	147	1994	1996	X	X	X	X	X	X
3.0i V6 24V	ES9J4 (XFZ)	2946	140	1995	2000	X	X	X	X	X	X
<b>607 2000</b>											
2.0 16V	EW10J4 (RFN)	1997	100	2000	2004	X	X	X	X	X	X
2.0 HDi	DW10ATED (RHZ)	1996	80	2000	2006	X	X	X	X	X	X
2.0 HDiF	DW10ATED (RHS)	1996	79	2000	2006	X	X	X	X	X	X

Legend: N = new, X = present



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>PEUGEOT</b>											
<b>607 2000</b>											
2.0 HDiF 16V	DW10BTED4 (RHR)	1997	100	2005		X	X	X	X	X	X
2.2 16V	EW12J4 (3FY)	2230	120	2005		X	X	X	X	X	X
2.2 16V	EW12J4 (3FZ)	2231	116	2000	2005	X	X	X	X	X	X
2.2 HDiF 16V	DW12BTED4 (4HP)	2179	120	2006		X	X	X	X	X	X
2.2 HDiF 16V	DW12BTED4 (4HT)	2179	125	2006		X	X	X	X	X	X
2.2 HDiF 16V	DW12TED4 (4HX)	2179	98	2000	2006	X	X	X	X	X	X
2.7 V6 HDiF	DT17TED4 (UHZ)	2721	150	2004		X	X	X	X	X	X
3.0 V6	ES9A (XFV)	2946	155	2005		X	X	X	X	X	X
3.0 V6	ES9J4S (XFX)	2946	152	2000	2004	X	X	X	X	X	X
<b>806 1994 2002</b>											
1.8	XU7JP (LFW)	1761	72	1997	1998	X	X	X	X	X	X
1.8	XU7JP/Z (LFZ)	1761	74	1998	1999	X	X	X	X	X	X
1.9 D Turbo	XUD9BTF/Y (DHX)	1905	66	1994	2000	X	X	X	X	X	X
1.9 D Turbo	XUD9TF/L (D8B)	1905	67	1994	2000	X	X	X	X	X	X
2.0	XU10J2C/Z (RFU)	1998	89	1994	2000	X	X	X	X	X	X
2.0 16V	EW10J4 (RFN)	1997	100	2000	2002	X	X	X	X	X	N
2.0 16V	EW10J4 (RFR)	1997	99	2000	2002	X	X	X	X	X	X
2.0 16V	XU10J4R (RFV)	1998	97	2000	2002	X	X	X	X	X	X
2.0 HDi	DW10ATED (RHZ)	1997	80	1999	2001	X	X	X	X	X	X
2.0 HDi 16V	DW10ATED4 (RHW)	1997	80	2001	2002	X	X	X	X	X	X
2.0 Turbo	XU10J2TE/Z (RGX)	1998	108	1994	2000	X	X	X	X	X	X
2.1 D Turbo	XUD11BTE (P8C)	2088	80	1994	1999	X	X	X	X	X	X
<b>807 2002</b>											
2.0 16V	EW10A (RFJ)	1997	103	2005		X	X	X	X	X	N
2.0 16V	EW10J4 (RFN)	1997	100	2002	2005	X	X	X	X	X	X
2.0 HDi 16V	DW10ATED4 (RHW)	1997	80	2002	2006	X	X	X	X	X	X
2.0 HDiF 16V	DW10ATED4 (RHT)	1997	79	2002	2006	X	X	X	X	X	X
2.0 HDiF 16V	DW10BTED4 (RHR)	1997	100	2006		X	X	X	X	X	X
2.2 16V	EW12J4 (3FZ)	2231	116	2002		X	X	X	X	X	X
2.2 HDiF 16V	DW12ATED4 (4HW)	2179	94	2002	2006	X	X	X	X	X	X
3.0 V6 24V	ES9J4S (XFW)	2946	150	2002	2005	X	X	X	X	X	X
<b>Boxer I 1993 2002</b>											
270 1.9 D	XUD9AU/W2 (D9B)	1905	51	1993	2000	X	X	X	X	X	X
270 1.9 Turbo D	XUD9UTF/W2 (D8C)	1905	67	1993	2000	X	X	X	X	X	X
270 1.9 Turbo D	XUD9UTF/X3 (DHX)	1905	67	1993	2000	X	X	X	X	X	X
270 2.0i	XU10J2U/W2 (RFW)	1998	80	1995	1997	X	X	X	X	X	X
270 2.0i	XU10J2U/X3 (RFW)	1998	80	1993	2002	X	X	X	X	X	X

Legend: N = new, X = present

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays
<b>PEUGEOT</b>												
<b>Boxer I 1993 2002</b>												
270 2.5 Turbo D	8140.67 (SOFIM)	2499	62	1999	2002	X	X	X	X	X	X	X
270 2.8 D	8140.63 (SOFIM)	2798	64	1999	2002	X	X	X	X	X	X	X
270 2.8 HDi	8140.43S (SOFIM)	2798	94	1999	2002	X	X	X	X	X	X	X
270 2.8 TDi	8140.43 (SOFIM)	2798	90	1999	2002	X	X	X	X	X	X	X
270 4x4 2.0i	XU10J2U/W2 (RFW)	1998	80	1995	1997	X	X	X	X	X	X	X
270 4x4 2.0i	XU10J2U/X3 (RFW)	1998	80	1993	2002	X	X	X	X	X	X	X
270 4x4 2.5 Turbo D	DJ5T/W2 (T8A)	2445	76	1993	2002	X	X	X	X	X	X	X
310 1.9 D	XUD9AU/W2 (D9B)	1905	51	1993	2002	X	X	X	X	X	X	X
310 1.9 Turbo D	XUD9UTF/W2 (D8C)	1905	67	1993	2000	X	X	X	X	X	X	X
310 1.9 Turbo D	XUD9UTF/X3 (DHX)	1905	67	1995	2000	X	X	X	X	X	X	X
310 2.0i	XU10J2U/W2 (RFW)	1998	80	1995	1997	X	X	X	X	X	X	X
310 2.0i	XU10J2U/X3 (RFW)	1998	80	1993	2002	X	X	X	X	X	X	X
310 2.5 D	DJ5/W2 (T9A)	2445	63	1993	2002	X	X	X	X	X	X	X
310 2.5 TDdi	DJ5TED/W2 (THX)	2445	76	1995	2002	X	X	X	X	X	X	X
310 2.5 Turbo D	DJ5T/W2 (T8A)	2445	76	1993	2002	X	X	X	X	X	X	X
310 2.5 Turbo D	DJ5T/X3 (THZ)	2445	76	1993	2002	X	X	X	X	X	X	X
310 4x4 2.0i	XU10J2U/W2 (RFW)	1998	80	1995	1997	X	X	X	X	X	X	X
310 4x4 2.0i	XU10J2U/X3 (RFW)	1998	80	1993	2002	X	X	X	X	X	X	X
310 4x4 2.5 D	DJ5/W2 (T9A)	2445	63	1993	2002	X	X	X	X	X	X	X
310 4x4 2.5 TDdi	DJ5TED/W2 (THX)	2445	76	1995	2002	X	X	X	X	X	X	X
310 4x4 2.5 Turbo D	DJ5T/W2 (T8A)	2445	76	1993	2002	X	X	X	X	X	X	X
350 2.0i	XU10J2U/W2 (RFW)	1998	80	1995	1997	X	X	X	X	X	X	X
350 2.0i	XU10J2U/X3 (RFW)	1998	80	1993	2002	X	X	X	X	X	X	X
350 2.5 D	DJ5/W2 (T9A)	2445	63	1993	2002	X	X	X	X	X	X	X
350 2.5 TDdi	DJ5TED/W2 (THX)	2445	76	1995	2002	X	X	X	X	X	X	X
350 2.5 Turbo D	DJ5T/W2 (T8A)	2445	76	1993	2002	X	X	X	X	X	X	X
350 2.5 Turbo D	DJ5T/X3 (THZ)	2445	76	1993	2002	X	X	X	X	X	X	X
350 4x4 2.0i	XU10J2U/W2 (RFW)	1998	80	1995	1997	X	X	X	X	X	X	X
350 4x4 2.0i	XU10J2U/X3	1998	80	1993	2002	X	X	X	X	X	X	X
350 4x4 2.5 D	DJ5/W2 (T9A)	2445	63	1993	2002	X	X	X	X	X	X	X
350 4x4 2.5 TDdi	DJ5TED/W2 (THX)	2445	76	1995	2002	X	X	X	X	X	X	X
350 4x4 2.5 Turbo D	DJ5T/W2 (T8A)	2445	76	1993	2002	X	X	X	X	X	X	X
<b>Boxer II 2002 2006</b>												
2.0	XU10J2U (RFL)	1998	81	2002	2006	X	X	X	X	X	X	X
2.0 CNG	XU10J2U (RFW)	1998	90	2002	2006	X	X	X	X	X	X	X
2.0 HDi	DW10UTD (RHV)	1997	62	2002	2006	X	X	X	X	X	X	X
2.0 LPG	XU10J2U (RFL)	1998	81	2002	2006	X	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>PEUGEOT</b>											
<b>Boxer II 2002 2006</b>											
2.2 HDi	DW12UTED (4HY)	2179	74	2002	2006	X	X	X	X	X	X
2.8 HDi	8140.43N (SOFIM-T)	2798	107	2004	2006	X	X	X	X	X	X
2.8 HDi	8140.43S (SOFIM)	2798	94	2002	2006	X	X	X	X	X	X
<b>Boxer III 2006</b>											
2.2 HDi 100	P22DTE (4HV)	2198	74	2006		X	X	X			
2.2 HDi 120	P22DTE+ (4HU)	2198	88	2006		X	X	X			
3.0 HDi	F30DT (SOFIM)	2998	115	2006		X	X	X			
<b>Expert 1995 2007</b>											
1.6 SPi	220 A2.000	1581	58	1995	2006	X	X	X	X	X	X
1.8	XU7JP (LFW)	1761	72	1998	2000	X	X	X	X	X	X
1.9 D	DW8 (WJZ)	1868	51	1999	2003	X	X	X	X	X	X
1.9 D	DW8B (WJY)	1868	51	2000	2007	X	X	X	X	X	X
1.9 D	XUD9A (D9B)	1905	51	1995	1999	X	X	X	X	X	X
1.9 TD	XUD9BTF (DHX)	1905	68	1997	2001	X	X	X	X	X	X
1.9 TD	XUD9TF (D8B)	1905	68	1995	1998	X	X	X	X	X	X
2.0 16V	EW10J4/L3 (RFN)	1997	100	2001	2007	X	X	X	X	X	X
2.0 HDi	DW10ATED (RHZ)	1997	80	2000	2007	X	X	X	X	X	X
2.0 HDi	DW10BTED (RHX)	1997	69	2000	2007	X	X	X	X	X	X
2.0 HDi 16V	DW10ATED4 (RHW)	1997	80	2002	2007	X	X	X	X	X	X
<b>J5 1981 1994</b>											
1000 1.8	XM7T/169B	1796	50	1981	1994	X	X	X	X		X
1000 1.9 D	XUD9A (D9B)	1905	51	1990	1994	X	X	X	X	X	X
1000 2.5 D	CRD93L/U25/661	2500	54	1981	1994	X	X	X	X		X
1300 2.0	XN1T/170B	1971	56	1981	1994	X	X	X	X		X
1300 2.5 D	CRD93L/U25/661	2500	54	1984	1994	X	X	X	X		X
1400 1.9 D	XUD9A (D9B)	1905	51	1990	1994	X	X	X	X	X	X
1400 2.0	XN1T/170B	1971	56	1981	1994	X	X	X	X		X
1400 2.5 Turbo D	CRD93LS/U25/673	2500	70	1987	1994	X	X	X	X		X
1400 4x4 2.5 D	CRD93L/U25/661	2500	54	1989	1994	X	X	X	X		X
1400 4x4 2.5 Turbo D	CRD93LS/U25/673	2500	70	1989	1994	X	X	X	X		X
1500 2.0	XN1T/170B	1971	56	1981	1994	X	X	X	X		X
1500 2.5 D	CRD/93L/U25/661	2500	54	1981	1994	X	X	X	X		X
1800 2.0	XN1TA/170C	1971	62	1989	1994	X	X	X	X		X
1800 2.5 D	CRD93L/U25/661	2500	54	1989	1994	X	X	X	X		X
1800 2.5 Turbo D	CRD93LS/U25/673	2500	70	1989	1994	X	X	X	X		X
Combi 1.8	XM7T/169B	1796	50	1982	1994	X	X	X	X		X
Combi 1.9 D	XUD9A (D9B)	1905	51	1990	1994	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagram. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagn.	Fuses & Relays
<b>PEUGEOT</b>												
<b>J5 1981 1994</b>												
Combi 2.0	XN1T/170B	1971	56	1982	1994	X	X	X	X	X		X
Combi 2.5 D	CRD93L/U25/661	2500	54	1982	1994	X	X	X	X	X		X
Combi 2.5 Turbo D	CRD93LS/U25/673	2500	70	1989	1994	X	X	X	X	X		X
Combi 4x4 2.5 D	CRD93L/U25/661	2500	54	1989	1994	X	X	X	X	X		X
Combi 4x4 2.5 Turbo D	CRD93LS/U25/673	2500	70	1989	1994	X	X	X	X	X		X
<b>Partner 1996</b>												
1.1i	TU1JP (HFX)	1124	44	2000	2006	X	X	X	X	X	X	X
1.1i	TU1M+ (HDY)	1124	44	1996	2002	X	X	X	X	X	X	X
1.1i	TU1M+ (HDZ)	1124	44	1996	2002	X	X	X	X	X	X	X
1.4	TU3.2TR/K (K5A)	1360	51	1996	2002	X	X	X	X	X	X	X
1.4i	TU3A (KFV)	1360	54	2006		X	X	X	X	X		
1.4i	TU3JP (KFW)	1360	55	2000		X	X	X	X	X		X
1.4i	TU3JP (KFX)	1360	55	1996	2000	X	X	X	X	X	X	X
1.4i	TU3JP/K (K6D)	1360	55	2000	2002	X	X	X	X	X	X	X
1.6 HDi 16V	DV6ATED4 (9HX)	1560	66	2005		X	X	X	X	X		X
1.6 HDi 16V	DV6BTED4 (9HW)	1560	55	2005		X	X	X	X	X		X
1.6i 16V	TU5JP4 (NFU)	1587	80	2000		X	X	X	X	X		X
1.8 D	XUD7 (A9A)	1769	44	1996	1999	X	X	X	X	X	X	X
1.8i	XU7JB (LFX)	1761	66	2000	2002	X	X	X	X	X	X	X
1.9 D	DW8 (WJZ)	1868	51	2000	2001	X	X	X	X	X	X	X
1.9 D	DW8B (WJY)	1868	51	2000		X	X	X	X	X		X
1.9 D	XUD9A (D9B)	1905	51	1996	1999	X	X	X	X	X	X	X
1.9 D	XUD9Y (DJY)	1905	50	1996	1999	X	X	X	X	X	X	X
2.0 HDi	DW10TD (RHY)	1997	66	2000		X	X	X	X	X	X	X
<b>PORSCHE</b>												
<b>911 1993 1994 1998</b>												
3.6 Carrera	M64.05/06	3600	200	1994	1996	X	X			X	X	X
3.6 Carrera	M64.21/22	3600	210	1995	1998	X	X					X
3.6 Turbo	M64.60	3600	300	1996	1998	X	X					X
3.7 Carrera RS	M64.20	3746	221	1995	1996	X	X					X
<b>911 1996 1998 2004</b>												
3.4 Carrera	M96.01	3387	221	1998	2001	X	X					X
3.6 Carrera	M96.03	3596	235	2001	2004	X	X					X
3.6 Turbo	M96.70	3596	309	2001		X	X					X
GT2	M96.70S	3600	340	2001	2003	X	X					X
GT3	M79.80	3596	280	2003		X	X					
GT3	M96.76	3600	265	1999	2001	X	X					X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagram. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagnr. Fuses & Relays
<b>PORSCHE</b>											
<b>911 997 2004</b>											
3.6 Carrera	M96.05	3596	239	2004		X	X				
3.8 Carrera S	M97.01	3824	261	2004		X	X				
<b>Boxster 986 1996 2005</b>											
2.5	M96.20	2480	150	1996	1999	X	X	X		X	X
2.7	M96.22	2687	162	1999	2002	X	X				X
2.7	M96.23	2687	168	2002	2005	X	X				X
S (3.2)	M96.21	3179	185	1999	2002	X	X				X
S (3.2)	M96.24	3179	191	2002	2005	X	X				X
<b>Cayenne 2002</b>											
3.2 V6	BFD	3189	184	2002	2007	X	X				X
4.5 V8 S	M48.00	4511	250	2002		X	X				X
4.5 V8 Turbo	M48.50	4511	330	2002	2007	X	X				X
<b>RENAULT</b>											
<b>19 1988 1995</b>											
1.2	C1G-730	1237	40	1988	1995	X	X	X	X	X	X
1.2e	E7F-700/706/730	1171	43	1989	1995	X	X	X	X	X	X
1.2e	E7F-704	1171	43	1989	1995	X	X	X	X	X	X
1.4	C2J-772/776	1397	49	1988	1992	X	X	X	X	X	X
1.4	C3J-710/760	1390	43	1989	1995	X	X	X	X	X	X
1.4e	E6J-700/701	1390	57	1989	1995	X	X	X	X	X	X
1.4e	E7J-700	1390	58	1989	1995	X	X	X	X	X	X
1.4e	E7J-706/740	1390	57	1989	1995	X	X	X	X	X	X
1.4e	E7J-710/711/718/719	1390	57	1989	1995	X	X	X	X	X	X
1.7	F2N-720/722	1721	66	1988	1995	X	X	X	X	X	X
1.7	F2N-728	1721	54	1989	1995	X	X	X	X	X	X
1.7	F3N-740/741	1721	54	1992	1994	X	X	X	X	X	X
1.7	F3N-742	1721	66	1989	1992	X	X	X	X	X	X
1.7	F3N-743	1721	54	1992	1994	X	X	X	X	X	X
1.7	F3N-746	1721	79	1990	1992	X	X	X	X	X	X
1.8	F3P-700	1794	83	1992	1995	X	X	X	X	X	X
1.8	F3P-704/706	1794	70	1992	1995	X	X	X	X	X	X
1.8	F3P-705/707	1794	70	1992	1995	X	X	X	X	X	X
1.8	F3P-708/740/760	1794	70	1992	1995	X	X	X	X	X	X
1.8	F3P-710/714	1794	70	1992	1995	X	X	X	X	X	X
1.8	F3P-712	1794	70	1992	1995	X	X	X	X	X	X
1.8 16V	F7P-700	1764	103	1988	1992	X	X	X	X	X	X
1.8 16V	F7P-704	1764	101	1988	1995	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>RENAULT</b>											
<b>19 1988 1995</b>											
1.8 16V	F7P-720	1764	101	1988	1995	X	X	X	X	X	X
1.8 16V	F7P-722	1764	101	1988	1995	X	X	X	X	X	X
1.9 D	F8Q-706	1870	47	1988	1995	X	X	X	X	X	X
1.9 D	F8Q-742	1870	47	1988	1995	X	X	X	X	X	X
1.9 D	F8Q-764	1870	47	1988	1995	X	X	X	X	X	X
1.9 Turbo D	F8Q-740	1870	68	1993	1995	X	X	X	X	X	X
1.9 Turbo D	F8Q-744	1870	68	1991	1993	X	X	X	X	X	X
<b>21 Nevada 1985 1995</b>											
1.7	F2N-712/716	1721	55	1986	1989	X	X	X	X	X	X
1.7	F2N-754	1721	66	1986	1995	X	X	X	X	X	X
1.7i	F2N-710/720	1721	65	1986	1989	X	X	X	X	X	X
1.7i	F3N-722/723	1721	69	1989	1995	X	X	X	X	X	X
1.7i	F3N-726/718	1721	55	1989	1994	X	X	X	X	X	X
1.9 D	F8Q-706	1870	47	1989	1991	X	X	X	X	X	X
2.0i	J7R-750/751	1995	88	1986	1989	X	X	X	X	X	X
2.0i 12V	J7R-740/754	1995	99	1989	1995	X	X	X	X	X	X
2.0i Turbo	J7R-752/756	1995	129	1988	1990	X	X	X	X	X	X
2.0i Turbo 4x4	J7R-756	1995	129	1990	1992	X	X	X	X	X	X
2.1 D	J8S B704	2068	48	1986	1995	X	X	X	X	X	X
2.1 Turbo D	J8S B714	2068	65	1985	1995	X	X	X	X	X	X
2.2i	J7T-754/755	2165	79	1989	1995	X	X	X	X	X	X
2.2i 4X4	J7T-754/755	2165	79	1987	1989	X	X	X	X	X	X
<b>25 1984 1993</b>											
2.0	J6R-706/707	1995	74	1984	1989	X	X	X	X	X	X
2.0	J7R-722/723	1995	88	1987	1989	X	X	X	X	X	X
2.0i 12V	J7R-754/756	1995	100	1989	1993	X	X	X	X	X	X
2.1 D	J8S-706	2068	46	1984	1993	X	X	X	X	X	X
2.1 D	J8S-736	2068	46	1984	1993	X	X	X	X	X	X
2.1 Turbo D	J8S-708	2068	63	1984	1993	X	X	X	X	X	X
2.2i	J7T-706/707/708/730	2165	89	1984	1992	X	X	X	X	X	X
2.2i	J7T-732/733	2165	81	1986	1993	X	X	X	X	X	X
2.2i	J7T-732/733	2165	81	1986	1993	X	X	X	X	X	X
2.8 V6	Z7W-700/701	2849	118	1988	1992	X	X	X	X	X	X
2.8 V6i	Z7W-706/707	2849	118	1986	1993	X	X	X	X	X	X
V6 Turbo	Z7U-700	2458	151	1989	1992	X	X	X	X	X	X
V6 Turbo	Z7U-702	2458	133	1984	1989	X	X	X	X	X	X
V6i	Z7V-708/709 23362->	2664	110	1988	1992	X	X	X	X	X	X

Legend: N = new, X = present

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>RENAULT</b>													
<b>25 1984 1993</b>													
V6i	Z7V-708/709->23361	2664	104	1984	1988	X	X	X	X	X	X	X	X
<b>5 Super 5 1984 1993</b>													
1.0	C1C-700	956	30	1984	1987	X	X	X	X	X	X	X	X
1.1	C1E-750/752	1108	34	1984	1989	X	X	X	X	X	X	X	X
1.2	C1G-702/703	1237	40	1986	1990	X	X	X	X	X	X	X	X
1.4	C1J-768	1397	43	1984	1989	X	X	X	X	X	X	X	X
1.4	C2J-700/780	1397	49	1984	1990	X	X	X	X	X	X	X	X
1.4	C2J-700/798	1397	49	1987	1990	X	X	X	X	X	X	X	X
1.4	C3J-700/702	1397	44	1984	1993	X	X	X	X	X	X	X	X
1.4	E6J-	1390	45	1989	1991	X	X	X	X	X	X	X	X
1.4 Automatic	C2J780/781/788	1397	49	1984	1987	X	X	X	X	X	X	X	X
1.4 Automatic	C2J-Q781	1397	49	1987	1991	X	X	X	X	X	X	X	X
1.4 GT turbo	C1J782/784/788	1397	88	1984	1991	X	X	X	X	X	X	X	X
1.6 D	F8M-720	1595	40	1984	1991	X	X	X	X	X	X	X	X
1.7	F2N-710/740	1721	65	1987	1990	X	X	X	X	X	X	X	X
1.7i	F3N-702	1721	70	1986	1990	X	X	X	X	X	X	X	X
1.7i	F3N-716/718	1721	55	1986	1990	X	X	X	X	X	X	X	X
1.7i	F3N-722	1721	55	1986	1991	X	X	X	X	X	X	X	X
<b>Avantime 2002 2003</b>													
2.0 16V Turbo	F4R-760	1998	120	2002	2003	X	X	X	X	X	X	X	X
2.2 dCi 16V	G9T-718	2188	110	2002	2003	X	X	X	X	X	X	X	X
2.9 V6 24V	L7X-721/722	2946	152	2002	2003	X	X	X	X	X	X	X	X
<b>Clio 1990 1998</b>													
1.1	C1E-700	1108	35	1990	1994	X	X	X	X	X	X	X	X
1.2	E5F-710/716	1171	43	1990	1994	X	X	X	X	X	X	X	X
1.2 8V	D7F-730	1149	43	1994	1998	X	X	X	X	X	X	X	X
1.2i	C3G-720	1239	40	1991	1994	X	X	X	X	X	X	X	X
1.2i	E7F-700	1171	44	1994	1996	X	X	X	X	X	X	X	X
1.2i	E7F-704	1171	43	1992	1994	X	X	X	X	X	X	X	X
1.2i	E7F-706	1171	43	1990	1994	X	X	X	X	X	X	X	X
1.2i	E7F-708	1171	43	1994	1998	X	X	X	X	X	X	X	X
1.2i	E7F-750/754	1171	40	1991	1994	X	X	X	X	X	X	X	X
1.4i	E6J-712/713	1390	58	1990	1994	X	X	X	X	X	X	X	X
1.4i	E7J-710	1390	58	1994	1996	X	X	X	X	X	X	X	X
1.4i	E7J-711	1390	58	1990	1994	X	X	X	X	X	X	X	X
1.4i	E7J-718/719	1390	58	1994	1998	X	X	X	X	X	X	X	X
1.4i	E7J-754/601	1390	58	1991	1994	X	X	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>RENAULT</b>											
<b>Clio 1990 1998</b>											
1.4i	E7J-756/757	1390	55	1996	1998	X	X	X	X	X	X
1.7	F2N-720/770	1721	67	1990	1994	X	X	X	X	X	X
1.8 RSi	F3P-712	1794	81	1993	1997	X	X	X	X	X	X
1.8i	F3P-710	1794	66	1994	1996	X	X	X	X	X	X
1.8i	F3P-714	1794	69	1991	1994	X	X	X	X	X	X
1.8i	F3P-754	1794	66	1996	1998	X	X	X	X	X	X
1.8i	F3P-755	1794	66	1991	1998	X	X	X	X	X	X
1.8i	F3P-758	1794	69	1994	1998	X	X	X	X	X	X
1.8i 16V	F7P-720	1764	99	1991	1994	X	X	X	X	X	X
1.8i 16V	F7P-722	1764	99	1994	1996	X	X	X	X	X	X
1.9 D	F8Q-676/696	1870	48	1996	1998	X	X	X	X	X	X
1.9 D	F8Q-678	1870	48	1994	1998	X	X	X	X	X	X
1.9 D	F8Q-692	1870	48	1996	1998	X	X	X	X	X	X
1.9 D	F8Q-732	1870	48	1994	1996	X	X	X	X	X	X
1.9 D	F8Q-730	1870	48	1990	1994	X	X	X	X	X	X
2.0i Williams	F7R-700	1998	110	1993	1996	X	X	X	X	X	X
<b>Clio II 1998 2006</b>											
1.2 16V	D4F-706	1149	55	2001	2005	X	X	X	X	X	X
1.2 16V	D4F-712	1149	55	2000	2001	X	X	X	X	X	X
1.2 16V	D4F-728	1149	55	2001		X	X	X	X	X	X
1.2 16V Quickshift 5	D4F-722	1149	55	2001		X	X	X	X	X	X
1.2 8V	D7F-720	1149	43	1998	2001	X	X	X	X	X	X
1.2 8V	D7F-722	1149	43	1999	2001	X	X	X	X	X	X
1.2 8V	D7F-726	1149	43	1998	2001	X	X	X	X	X	X
1.2 8V	D7F-745	1149	43	2000	2002	X	X	X	X	X	X
1.2 8V	D7F-746	1149	43	2000	2002	X	X	X	X	X	X
1.2 8V	D7F-766	1149	43	2002	2006	X	X	X	X	X	X
1.2 8V LPG	D7F-764	1149	43	2002	2006	X	X	X	X	X	X
1.4 16V	K4J-710	1390	72	2000		X	X	X	X	X	X
1.4 16V	K4J-711	1390	72	2000		X	X	X	X	X	X
1.4 16V	K4J-712	1390	70	1999	2000	X	X	X	X	X	X
1.4 16V	K4J-713	1390	70	1999	2000	X	X	X	X	X	X
1.4 16V	K4J-715	1390	70	1999	2000	X	X	X	X	X	X
1.4 8V	E7J-634	1390	55	1999	2000	X	X	X	X	X	X
1.4 8V	E7J-635	1390	55	1999	2000	X	X	X	X	X	X
1.4 8V	E7J-780	1390	55	1998	2000	X	X	X	X	X	X
1.4 8V	K7J-700	1390	55	2000	2003	X	X	X	X	X	X



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>RENAULT</b>											
<b>Clio II 1998 2006</b>											
1.5 dCi 100	K9K-712	1461	74	2003	2006	X	X	X	X	X	X
1.5 dCi 65	K9K-700	1461	47	2001	2003	X	X	X	X	X	X
1.5 dCi 65	K9K-704	1461	47	2001		X	X	X	X	X	X
1.5 dCi 80	K9K-702	1461	60	2001	2003	X	X	X	X	X	X
1.5 dCi 80	K9K-710	1461	60	2003	2006	X	X	X	X	X	X
1.6 16V	K4M-708	1598	79	1998	2001	X	X	X	X	X	X
1.6 16V	K4M-742	1598	79	1998	2001	X	X	X	X	X	X
1.6 16V	K4M-743	1598	79	1998	2001	X	X	X	X	X	X
1.6 16V	K4M-744	1598	79	2001	2006	X	X	X	X	X	X
1.6 16V	K4M-745	1598	79	2001	2006	X	X	X	X	X	X
1.6 16V	K4M-748	1598	79	1998	2001	X	X	X	X	X	X
1.6 8V	K7M-744	1598	66	1998	2000	X	X	X	X	X	X
1.6 8V	K7M-745	1598	66	1998	2000	X	X	X	X	X	X
1.6 8V LPG	K7M-746	1598	66	1999	2000	X	X	X	X	X	X
1.9 D	F8Q-630	1870	47	1998	2001	X	X	X	X	X	X
1.9 D	F8Q-632	1870	47	1999	2001	X	X	X	X	X	X
1.9 D	F8Q-662	1870	47	1998	2001	X	X	X	X	X	X
1.9 DTi	F9Q-780	1870	59	1999	2001	X	X	X	X	X	X
1.9 DTi	F9Q-782	1870	59	2000	2002	X	X	X	X	X	X
2.0 16V Sport	F4R-730	1998	124	1998	2001	X	X	X	X	X	X
2.0 16V Sport	F4R-732	1998	124	2001	2003	X	X	X	X	X	X
2.0 16V Sport	F4R-736	1998	124	2001	2003	X	X	X	X	X	X
2.0 16V Sport	F4R-738	1998	132	2003	2006	X	X	X	X	X	X
<b>Clio III 2005</b>											
1.2 16V (48/55 kW)	D4F-740	1149	48	2005		X	X	X	X	X	X
1.4 16V	K4J-780	1390	72	2005		X	X	X	X	X	X
1.5 dCi 105	K9K-764	1461	78	2005		X	X	X	X	X	X
1.5 dCi 70	K9K-768	1461	50	2005		X	X	X	X	X	X
1.5 dCi 85	K9K-766	1461	63	2005		X	X	X	X	X	X
1.6 16V	K4M-800	1598	82	2005		X	X	X	X	X	X
1.6 16V	K4M-801	1598	82	2005		X	X	X	X	X	X
2.0 16V	M4R-701	1997	105	2006		X	X	X	X	X	X
<b>Espace 1984 1991</b>											
2.0	J6R-234/236	1995	81	1984	1989	X	X	X	X	X	X
2.0	J7R-760	1995	87	1987	1991	X	X	X	X	X	X
2.1 Turbo D	J8S-772	2068	65	1991	1996	X	X	X	X	X	X
2.2	J7T-770	2165	81	1986	1991	X	X	X	X	X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays			
<b>RENAULT</b>														
<b>Espace 1984 1991</b>														
2.2	J7T-772/773	2165	81	1986	1996	X	X	X	X	X	X	X	X	X
2.2 Quadra	J7T-770/772	2165	79	1991	1996	X	X	X	X	X	X	X	X	X
2.8i V6	Z7W-712	2849	110	1991	1996	X	X	X	X	X	X	X	X	X
<b>Espace II 1991 1997</b>														
2.0 8V	J7R-768	1995	77	1991	1995	X	X	X	X	X	X	X	X	X
2.1 Turbo D 8V	J8S-610	2068	65	1991	1997	X	X	X	X	X	X	X	X	X
2.1 Turbo D 8V	J8S-612	2068	65	1991	1997	X	X	X	X	X	X	X	X	X
2.1 Turbo D 8V	J8S-778	2068	65	1991	1997	X	X	X	X	X	X	X	X	X
2.2 8V (79/81 KW)	J7T-772	2165	81	1991	1997	X	X	X	X	X	X	X	X	X
2.2 8V (79/81 KW)	J7T-773	2165	81	1991	1997	X	X	X	X	X	X	X	X	X
2.2 8V (79/81 KW)	J7T-776	2165	81	1991	1997	X	X	X	X	X	X	X	X	X
2.8 V6 12V (110/113 KW)	Z7W-712	2849	113	1991	1997	X	X	X	X	X	X	X	X	X
2.8 V6 12V (110/113 KW)	Z7W-713	2849	113	1991	1997	X	X	X	X	X	X	X	X	X
2.8 V6 12V (110/113 KW)	Z7W-717	2849	113	1991	1997	X	X	X	X	X	X	X	X	X
<b>Espace III 1997 2002</b>														
1.9 DTi	F9Q-722	1870	74	2000	2002	X	X	X	X	X	X	X	X	X
2.0 16V	F4R-700	1998	104	1999	2002	X	X	X	X	X	X	X	X	X
2.0 16V	F4R-701	1998	104	1999	2002	X	X	X	X	X	X	X	X	X
2.0 8V	F3R-728	1998	84	1997	1998	X	X	X	X	X	X	X	X	X
2.0 8V	F3R-729	1998	84	1997	1998	X	X	X	X	X	X	X	X	X
2.0 8V	F3R-768	1998	84	1998	2000	X	X	X	X	X	X	X	X	X
2.0 8V	F3R-769	1998	84	1998	2000	X	X	X	X	X	X	X	X	X
2.0 8V LPG	F3R-742	1998	84	1997	2000	X	X	X	X	X	X	X	X	X
2.2 dCi 16V (85/95 kW)	G9T-710	2188	95	2000	2002	X	X	X	X	X	X	X	X	X
2.2 dT 12V	G8T-714	2188	83	1997	2000	X	X	X	X	X	X	X	X	X
2.2 dT 12V	G8T-716	2188	83	1997	2000	X	X	X	X	X	X	X	X	X
3.0 V6 12V	Z7X-775	2963	123	1997	2000	X	X	X	X	X	X	X	X	X
3.0 V6 24V	L7X-727	2946	144	1998	2002	X	X	X	X	X	X	X	X	X
<b>Espace IV 2002</b>														
1.9 dCi	F9Q-680	1870	89	2002		X	X	X	X	X	X	X	X	X
1.9 dCi	F9Q-820	1870	89	2002		X	X	X	X	X	X	X	X	X
2.0 16V	F4R-790	1998	102	2002		X	X	X	X	X	X	X	X	X
2.0 16V	F4R-792	1998	100	2002		X	X	X	X	X	X	X	X	X
2.0 16V	F4R-796	1998	102	2002		X	X	X	X	X	X	X	X	X
2.0 16V	F4R-797	1998	102	2002		X	X	X	X	X	X	X	X	X
2.0 16V Turbo	F4R-794	1998	122	2002		X	X	X	X	X	X	X	X	X
2.0 16V Turbo	F4R-795	1998	122	2002		X	X	X	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>RENAULT</b>											
<b>Espace IV 2002</b>											
2.2 16V dCi	G9T-642	2188	110	2002	2006	X	X	X	X	X	X
2.2 16V dCi	G9T-742	2188	112	2002	2006	X	X	X	X	X	X
2.2 16V dCi	G9T-743	2188	112	2002	2006	X	X	X	X	X	X
3.0 V6 24V dCi	P9X-701	2958	130	2002	2006	X	X	X	X	X	X
3.5 V6	V4Y-711	3498	177	2002	2006	X	X	X	X	X	X
<b>Express 1985 1997</b>											
1.0	C1C-700/706	956	30	1986	1989	X	X	X	X	X	X
1.1	C1E-750/752/756	1108	34	1986	1991	X	X	X	X	X	X
1.1	C1E-760	1108	34	1987	1991	X	X	X	X	X	X
1.2	C1G-726	1237	40	1991	1994	X	X	X	X	X	X
1.4	C1/2J-768/782	1397	43	1986	1991	X	X	X	X	X	X
1.4	E6J	1390	59	1991	1994	X	X	X	X	X	X
1.4i	C3J-700/702	1397	55	1989	1994	X	X	X	X	X	X
1.4i	C3J-762	1390	44	1991	1997	X	X	X	X	X	X
1.4i	E7J-718	1390	55	1991	1997	X	X	X	X	X	X
1.4i	E7J-770/771	1394	55	1996	1997	X	X	X	X	X	X
1.6 D	F8M-730	1595	40	1986	1991	X	X	X	X	X	X
1.6 D	F8M-760	1595	40	1991	1997	X	X	X	X	X	X
1.9 D	F8Q-706	1870	47	1989	1997	X	X	X	X	X	X
<b>Kangoo 1997</b>											
1.2 16V	D4F-712	1149	55	2002		X	X	X	X	X	X
1.2 16V	D4F-714	1149	55	2002		X	X	X	X	X	X
1.2 16V	D4F-716	1149	55	2002		X	X	X	X	X	X
1.2 8V	D7F-720	1149	43	1998	2000	X	X	X	X	X	X
1.2 8V	D7F-722	1149	43	2000	2005	X	X	X	X	X	X
1.2 8V	D7F-726	1149	43	1998	2000	X	X	X	X	X	X
1.2 8V	D7F-746	1149	43	2000	2002	X	X	X	X	X	X
1.2 8V	D7F-766	1149	43	2002	2005	X	X	X	X	X	X
1.2 8V LPG	D7F-710	1149	43	1997	1999	X	X	X	X	X	X
1.4 8V	E7J-634	1390	55	1997	2000	X	X	X	X	X	X
1.4 8V	E7J-635	1390	55	1998	2000	X	X	X	X	X	X
1.4 8V	E7J-780	1390	55	1997	2000	X	X	X	X	X	X
1.4 8V	K7J-700	1390	55	2001	2003	X	X	X	X	X	X
1.4 8V	K7J-701	1390	55	2000	2003	X	X	X	X	X	X
1.5 dCi 65	K9K-700	1461	47	2001	2003	X	X	X	X	X	X
1.5 dCi 65	K9K-704	1461	47	2003	2005	X	X	X	X	X	X
1.5 dCi 80	K9K-702	1461	60	2002	2003	X	X	X	X	X	X

Legend: N = new, X = present

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>RENAULT</b>													
<b>Kangoo 1997</b>													
1.5 dCi 80	K9K-710	1461	60	2003	2005	X	X	X	X	X	X	X	X
1.6 16V	K4M-708	1598	70	2000	2002	X	X	X	X	X	X	X	X
1.6 16V	K4M-730	1598	70	2001		X	X	X	X	X	X	X	X
1.6 16V	K4M-752	1598	70	2001		X	X	X	X	X	X	X	X
1.6 16V	K4M-753	1598	70	2001		X	X	X	X	X	X	X	X
1.6 16V 4x4	K4M-750	1598	70	2001		X	X	X	X	X	X	X	X
1.6 16V LPG	K4M-732	1598	70	2001		X	X	X	X	X	X	X	X
1.6 16V LPG	K4M-754	1598	70	2001		X	X	X	X	X	X	X	X
1.6 8V	K7M-746	1598	54	1998	2001	X	X	X	X	X	X	X	X
1.9 D	F8Q-630	1870	47	1997	2000	X	X	X	X	X	X	X	X
1.9 D	F8Q-632	1870	47	1998	2000	X	X	X	X	X	X	X	X
1.9 D	F8Q-662	1870	40	1997	2000	X	X	X	X	X	X	X	X
1.9 dCi	F9Q-792	1870	59	2001	2003	X	X	X	X	X	X	X	X
1.9 dCi 4x4	F9Q-790	1870	59	2001		X	X	X	X	X	X	X	X
1.9 dTi	F9Q-780	1870	59	1998	2001	X	X	X	X	X	X	X	X
1.9 dTi	F9Q-782	1870	59	2000	2001	X	X	X	X	X	X	X	X
<b>Laguna 1994 2001</b>													
1.6 16V	K4M-720	1598	79	1998	2001	X	X	X	X	X	X	X	X
1.6 16V	K4M-724	1598	79	1998	2001	X	X	X	X	X	X	X	X
1.8	F3P-670	1783	66	1996	1998	X	X	X	X	X	X	X	X
1.8	F3P-674	1783	66	1995	1998	X	X	X	X	X	X	X	X
1.8	F3P-720	1794	69	1994	1998	X	X	X	X	X	X	X	X
1.8	F3P-724	1794	69	1994	1998	X	X	X	X	X	X	X	X
1.8 16V	F4P-760	1783	88	1998	2001	X	X	X	X	X	X	X	X
1.9 dCi	F9Q-718	1870	79	1999	2001	X	X	X	X	X	X	X	X
1.9 dTi	F9Q-710	1870	72	1998	2001	X	X	X	X	X	X	X	X
1.9 dTi	F9Q-716	1870	72	1998	2001	X	X	X	X	X	X	X	X
1.9 dTi	F9Q-717	1870	72	1998	2001	X	X	X	X	X	X	X	X
2.0	F3R-611	1998	84	1998	2001	X	X	X	X	X	X	X	X
2.0	F3R-722	1998	83	1994	1998	X	X	X	X	X	X	X	X
2.0	F3R-723	1998	83	1994	1998	X	X	X	X	X	X	X	X
2.0	F3R-728	1998	84	1996	2001	X	X	X	X	X	X	X	X
2.0	F3R-729	1998	84	1996	2001	X	X	X	X	X	X	X	X
2.0	F3R-768	1998	84	1998	2001	X	X	X	X	X	X	X	X
2.0	F3R-769	1998	84	1998	2001	X	X	X	X	X	X	X	X
2.0 16V	F4R-780	1998	102	1998	2001	X	X	X	X	X	X	X	X
2.0 16V	N7Q-700	1948	102	1995	1999	X	X	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diag. Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diag. Fuses & Relays

**RENAULT**

							Identification	Adjustment	Lubricants	ABS	Engine	Air Cond. Wir. Diag.	Fuses & Relays
<b>Laguna 1994 2001</b>													
2.0 16V	N7Q-704	1948	102	1995	1999	X	X	X	X	X	X	X	
2.2 D	G8T-706	2188	63	1994	1998	X	X	X	X	X	X	X	
2.2 D	G8T-752	2188	63	1994	1998	X	X	X	X	X	X	X	
2.2 D	G8T-790	2188	63	1994	1998	X	X	X	X	X	X	X	
2.2 D	G8T-792	2188	63	1994	1998	X	X	X	X	X	X	X	
2.2 D	G8T-794	2188	63	1994	1998	X	X	X	X	X	X	X	
2.2 dT	G8T-760	2188	83	1996	2001	X	X	X	X	X	X	X	
2.9 V6 24V	L7X-700	2946	143	1997	2001	X	X	X	X	X	X	X	
2.9 V6 24V	L7X-701	2946	143	1997	2001	X	X	X	X	X	X	X	
3.0 V6	Z7X-760	2963	123	1994	1997	X	X	X	X	X	X	X	
3.0 V6	Z7X-765	2963	123	1994	1997	X	X	X	X	X	X	X	
3.0 V6	Z7X-767	2963	123	1994	1997	X	X	X	X	X	X	X	
<b>Laguna II 2001</b>													
1.6 16V	K4M-710/711	1598	81	2001	2005	X	X	X	X	X	X	X	
1.6 16V	K4M-718	1598	81	2001	2005	X	X	X	X	X	X	X	
1.6 16V LPG	K4M-714	1598	81	2001	2005	X	X	X	X	X	X	X	
1.8 16V	F4P-772	1783	88	2001	2005	X	X	X	X	X	X	X	
1.8 16V	F4P-773	1783	88	2001	2005	X	X	X	X	X	X	X	
1.8 16V	F4P-774	1783	86	2001	2005	X	X	X	X	X	X	X	
1.8 16V	F4P-775	1783	86	2001	2005	X	X	X	X	X	X	X	
1.8 16V (85/89 KW)	F4P-770/771	1783	89	2001	2005	X	X	X	X	X	X	X	
1.9 dCi 100	F9Q-690	1870	68	2002	2006	X	X	X	X	X	X	X	
1.9 dCi 110	F9Q-751	1870	79	2001	2005	X	X	X	X	X	X	X	
1.9 dCi 110	F9Q-752	1870	79	2001	2005	X	X	X	X	X	X	X	
1.9 dCi 110	F9Q-754	1870	79	2001	2005	X	X	X	X	X	X	X	
1.9 dCi 110	F9Q-755	1870	79	2001	2005	X	X	X	X	X	X	X	
1.9 dCi 120	F9Q-750	1870	88	2001	2005	X	X	X	X	X	X	X	
1.9 dCi 120	F9Q-758	1870	88	2002	2005	X	X	X	X	X	X	X	
2.0 16V	F4R-712	1998	102	2001	2005	X	X	X	X	X	X	X	
2.0 16V	F4R-713	1998	102	2001	2005	X	X	X	X	X	X	X	
2.0 16V	F4R-714	1998	103	2005		X	X	X	X	X	X	X	
2.0 16V	F4R-715	1998	103	2005		X	X	X	X	X	X	X	
2.0 16V IDE	F5R-700/701	1998	105	2002	2005	X	X	X	X	X	X	X	
2.0 16V Turbo	F4R-764	1998	121	2002	2005	X	X	X	X	X	X	X	
2.0 16V Turbo	F4R-765	1998	121	2002	2005	X	X	X	X	X	X	X	
2.0 16V Turbo	F4R-786	1998	125	2005		X	X	X	X	X	X	X	
2.0 16V Turbo	F4R-787	1998	125	2005		X	X	X	X	X	X	X	

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays
<b>RENAULT</b>												
<b>Laguna II 2001</b>												
2.2 dCi 16V	G9T-600	2188	103	2005		X	X	X	X	X	X	X
2.2 dCi 16V	G9T-700	2188	107	2002	2005	X	X	X	X	X	X	X
2.2 dCi 16V	G9T-702	2188	107	2002	2005	X	X	X	X	X	X	X
2.2 dCi 16V	G9T-703	2188	107	2002	2005	X	X	X	X	X	X	X
2.2 dCi 16V	G9T-706	2188	110	2005		X	X	X	X	X	X	X
2.2 dCi 16V	G9T-707	2188	110	2005		X	X	X	X	X	X	X
3.0 V6 24V	L7X-731	2946	156	2001	2005	X	X	X	X	X	X	X
3.0 V6 24V	L7X-733	2946	156	2005		X	X	X	X	X	X	X
<b>Master 1986 1998</b>												
2.0	J5R-728 (829 730)	1995	59	1984	1998	X	X	X	X	X	X	X
2.0	J5R-731 (829 731)	1995	59	1984	1998	X	X	X	X	X	X	X
2.1 D	J8S-330	2068	48	1984	1998	X	X	X	X	X	X	X
2.2	J7T-782	2165	70	1984	1998	X	X	X	X	X	X	X
2.2	J7T-788	2165	70	1994	1998	X	X	X	X	X	X	X
2.5 D	S8U-730 (8140 612300)	2445	55	1984	1998	X	X	X	X	X	X	X
2.5 D	S8U-731 (8140 612300)	2445	55	1984	1998	X	X	X	X	X	X	X
2.5 D	S8U-742 (8140 672510)	2499	55	1984	1998	X	X	X	X	X	X	X
2.5 D	S8U-748	2499	55	1986	1998	X	X	X	X	X	X	X
2.5 TD	S9U-700 (8140 272500)	2499	59	1984	1998	X	X	X	X	X	X	X
2.5 TD	S9U-702 (8140 272580)	2499	59	1984	1998	X	X	X	X	X	X	X
2.5 TD	S9U-704 (8140 272510)	2499	59	1984	1998	X	X	X	X	X	X	X
2.5 TD	S9U-714	2499	59	1994	1998	X	X	X	X	X	X	X
2.5 TD	S9U-740	2499	59	1995	1998	X	X	X	X	X	X	X
<b>Master II 1998 2003</b>												
1.9 dCi	F9Q-772	1870	59	2001	2003	X	X	X	X	X	X	X
1.9 dTi	F9Q-770	1870	59	2000	2003	X	X	X	X	X	X	X
2.2 dCi	G9T-720	2188	66	2001	2003	X	X	X	X	X	X	X
2.2 dCi	G9T-722	2188	66	2001	2003	X	X	X	X	X	X	X
2.5 dCi	G9U-720	2463	84	2001	2003	X	X	X	X	X	X	X
2.5 dCi	G9U-724	2188	84	2001	2003	X	X	X	X	X	X	X
2.5 Turbo D	S8U-770	2499	59	1998	2001	X	X	X	X	X	X	X
2.5 Turbo D	S8U-772	2499	59	1998	2001	X	X	X	X	X	X	X
2.8 dTi	S9W-700	2799	84	1998	2003	X	X	X	X	X	X	X
2.8 dTi	S9W-702	2799	84	1998	2003	X	X	X	X	X	X	X
<b>Master II 2003</b>												
1.9 dCi 80	F9Q-774	1870	60	2003		X	X	X	X	X	X	X
2.2 dCi 90	G9T-750	2188	66	2003		X	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagram. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>RENAULT</b>											
<b>Master II 2003</b>											
2.5 dCi 100	G9U-754	2463	73	2003		X	X X	X X	N	X	X X
2.5 dCi 120	G9U-750	2463	84	2003		X	X X	X X	N	X	X
3.0 dCi 140	ZD3-200	2953	100	2003		X	X X	X X	N		X X
3.0 dCi 140	ZD3-202	2953	100	2003		X	X X	X X	N		X X
<b>Megane 1996 2003</b>											
1.4	E7J-626	1390	55	1998	2001	X	X X	X X	X	X	X X
1.4	E7J-764	1390	55	1996	1999	X	X X	X X	X	X	X X
1.4 16V	K4J-714	1390	70	1999	2003	X	X X	X X	X	X	X X
1.4 16V	K4J-750	1390	70	1999	2003	X	X X	X X	X	X	X X
1.4 Eco	E7J-624	1390	51	1996	1999	X	X X	X X	X	X	X X
1.6	K7M-703	1598	66	1996	1999	X	X X	X X	X	X	X X
1.6	K7M-704	1598	54	2001	2003	X	X X	X X	N	X	X
1.6	K7M-720	1598	54	1996	1999	X	X X	X X	X	X	X X
1.6	K7M-790	1598	66	1996	1999	X	X X	X X	X	X	X X
1.6 (LPG)	K7M-702	1598	66	1996	1999	X	X X	X X	X	X	X X
1.6 16V	K4M-700	1598	79	1999	2003	X	X X	X X	X	X	X X
1.6 16V	K4M-706	1598	72	1999	2003	X	X X	X X	N	X	X
1.6 16V	K4M-708	1598	79	1999	2003	X	X X	X X	X	X	X X
1.6 16V	K4M-709	1598	79	2000	2003	X	X X	X X	N	X	X
1.6 16V	K4M-701	1598	79	1999	2003	X	X X	X X	N	X	X X
1.6 16V (LPG)	K4M-704	1598	79	1999	2003	X	X X	X X	X	X	X X
1.6 16V (LPG)	K4M-712	1598	79	2000	2003	X	X X	X X	N	X	X
1.8 16V	F4P-720	1783	85	2000	2003	X	X X	X X	X	X	X X
1.8 16V	F4P-722	1783	85	2000	2003	X	X X	X X	N	X	X X
1.9 D	F8Q-620	1870	47	1996	1999	X	X X	X X	X	X	X X
1.9 D	F8Q-622	1870	50	1998	2001	X	X X	X X	X	X	X X
1.9 D	F8Q-624	1870	47	1996	2001	X	X X	X X	X	X	X X
1.9 D	F8Q-790	1870	47	1999	2003	X	X X	X X	N	X	X X
1.9 dCi	F9Q-732	1870	75	1999	2003	X	X X	X X	X	X	X X
1.9 dCi	F9Q-733	1870	75	1999	2003	X	X X	X X	X	X	X X
1.9 dCi	F9Q-738	1870	59	2000	2003	X	X X	X X	X	X	X
1.9 DT	F8Q-784	1870	66	1996	1997	X	X X	X X	X	X	X X
1.9 DT	F8Q-786	1870	66	1996	1999	X	X X	X X	X	X	X X
1.9 dTi	F9Q-730	1870	72	1999	2002	X	X X	X X	X	X	X X
1.9 dTi	F9Q-731	1870	72	1998	2002	X	X X	X X	X	X	X X
1.9 dTi	F9Q-734	1870	72	1998	2002	X	X X	X X	X	X	X
1.9 dTi	F9Q-736	1870	72	1998	2002	X	X X	X X	X	X	X X

Legend: N = new, X = present

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays
<b>RENAULT</b>												
<b>Megane 1996 2003</b>												
1.9 dTi	F9Q-744	1870	59	2001	2002	X	X	X	X	X	X	X
2.0	F3R-750	1998	84	1996	1999	X	X	X	X	X	X	X
2.0	F3R-751	1998	84	1996	1999	X	X	X	X	X	X	X
2.0	F3R-791	1995	84	1996	1999	X	X	X	X	X	X	X
2.0	F3R-796	1995	84	1996	1999	X	X	X	X	X	X	X
2.0	F3R-797	1995	84	1996	1999	X	X	X	X	X	X	X
2.0	F3R-798	1998	84	1996	1999	X	X	X	X	X	X	X
2.0 16V	F4R-740	1998	103	1999	2003	X	X	X	X	X	X	X
2.0 16V	F4R-741	1998	103	1999	2003	X	X	X	X	X	X	X
2.0 16V	F4R-746	1998	103	1999	2003	X	X	X	X	X	X	X
2.0 16V	F7R-710	1998	108	1996	2003	X	X	X	X	X	X	X
2.0 16V	F7R-714	1998	108	1998	2003	X	X	X	X	X	X	X
<b>Megane II 2003</b>												
1.4 16V	K4J-730	1390	72	2003		X	X	X	X	X	X	X
1.4 16V	K4J-732	1390	60	2003	2006	X	X	X	X	X	X	X
1.5 dCi 100	K9K-728	1461	74	2003	2006	X	X	X	X	X	X	X
1.5 dCi 100	K9K-729	1461	74	2003	2006	X	X	X	X	X	X	X
1.5 dCi 80	K9K-722	1461	60	2003	2005	X	X	X	X	X	X	X
1.6 16V	K4M-760	1598	83	2003		X	X	X	X	X	X	X
1.6 16V	K4M-761	1598	83	2003		X	X	X	X	X	X	X
1.9 dCi 100	F9Q-808	1870	66	2003	2005	X	X	X	X	X	X	X
1.9 dCi 120	F9Q-800	1870	86	2003	2005	X	X	X	X	X	X	X
1.9 dCi 120	F9Q-814	1870	88	2004	2005	X	X	X	X	X	X	X
2.0 16V	F4R-770	1998	99	2003		X	X	X	X	X	X	X
2.0 16V	F4R-771	1998	99	2003		X	X	X	X	X	X	X
2.0 16V Turbo	F4R-776	1998	120	2004		X	X	X	X	X	X	X
2.0 16V Turbo RS	F4R-774	1998	165	2004		X	X	X	X	X	X	X
<b>Megane Coupe Cabrio 1997 2003</b>												
1.4 16V	K4J-714	1390	70	1999	2003	X	X	X	X	X	X	X
1.4 16V	K4J-750	1390	70	1997	2003	X	X	X	X	X	X	X
1.6	K7M-702	1598	66	1996	1999	X	X	X	X	X	X	X
1.6	K7M-703	1598	66	1996	1999	X	X	X	X	X	X	X
1.6 16V	K4M-700	1598	79	1999	2003	X	X	X	X	X	X	X
1.6 16V	K4M-701	1598	79	1999	2003	X	X	X	X	X	X	X
1.6 16V	K4M-708	1598	79	1999	2003	X	X	X	X	X	X	X
1.6 16V	K4M-709	1598	79	1999	2003	X	X	X	X	X	X	X
1.9 dCi	F9Q-732	1870	75	1999	2003	X	X	X	X	X	X	X



Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diag. Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diag. Fuses & Relays

**RENAULT**

**Megane Coupe Cabrio 1997 2003**

1.9 dCi	F9Q-733	1870	75	1999	2003	X	X	X	X	X			X			X	X
1.9 dTi	F9Q-731	1870	72	1998	2003	X	X	X	X	X			X			X	X
1.9 dTi	F9Q-734	1870	72	1998	2003	X	X	X	X	X	X	X	X			X	X
1.9 dTi	F9Q-736	1870	72	1998	2003	X	X	X	X	X			X			X	X
2.0	F3R-750	1998	84	1996	1999	X	X	X	X	X	X	X	X			X	X
2.0	F3R-751	1998	84	1996	1999	X	X	X	X	X	X	X	X			X	X
2.0	F3R-791	1998	84	1996	1999	X	X	X	X	X	X	X	X			X	X
2.0	F3R-796	1998	84	1996	1999	X	X	X	X	X	X	X	X	X		X	X
2.0	F3R-797	1998	84	1996	1999	X	X	X	X	X		X	X			X	X
2.0	F3R-798	1998	84	1996	1999	X	X	X	X	X		X	X			X	X
2.0 16V	F4R-746	1998	103	1999	2003	X	X	X	X	X			X			X	X
2.0 16V	F7R-710	1998	108	1996	1999	X	X	X	X	X	X	X	X	X		X	X
2.0 16V	F7R-714	1998	108	1996	1999	X	X	X	X	X		X	X			X	X
2.0 16V IDE	F5R-740	1998	103	1999	2003	X	X	X	X	X	X		X			X	X

**Megane Scenic 1996 2003**

1.4	E7J-764	1390	55	1996	1999	X	X	X	X	X	X	X	X		X	X	X
1.4 16V	K4J-714	1390	70	2000	2003	X	X	X	X	X	X		X			X	X
1.4 16V	K4J-750	1390	70	1999	2003	X	X	X	X	X	X		X			X	X
1.6	K7M-703	1598	66	1996	2001	X	X	X	X	X	X	X	X	X		X	X
1.6	K7M-720	1598	54	1996	1999	X	X	X	X	X	X	X	X	X		X	X
1.6 (LPG)	K7M-702	1598	66	1996	1999	X	X	X	X	X	X	X	X	X		X	X
1.6 16V	K4M-700	1598	79	1999	2003	X	X	X	X	X	X		X			X	X
1.6 16V	K4M-701	1598	79	1999	2003	X	X	X	X	X	<b>N</b>		X			X	X
1.6 16V	K4M-706	1598	79	1999	2003	X	X	X	X	X			X			X	X
1.6 16V	K4M-707	1598	79	1999	2003	X	X	X	X	X			X			X	X
1.6 16V	K4M-708	1598	79	1999	2003	X	X	X	X	X	X		X			X	X
1.6 16V	K4M-709	1598	79	1999	2003	X	X	X	X	X			X			X	X
1.6 16V (LPG)	K4M-704	1598	79	1999	2003	X	X	X	X	X			X			X	X
1.6 16V (LPG)	K4M-712	1598	79	1999	2003	X	X	X	X	X			X			X	X
1.8 16V	F4P-720	1783	85	2000	2003	X	X	X	X	X	X	X	X			X	X
1.8 16V	F4P-722	1783	85	2000	2003	X	X	X	X	X	<b>N</b>		X			X	X
1.9 D	F8Q-788	1870	47	1999	2003	X	X	X	X	X	X	X	X	X		X	X
1.9 D	F8Q-790	1870	47	1999	2003	X	X	X	X	X	<b>N</b>		X			X	X
1.9 dCi	F9Q-732	1870	75	1999	2003	X	X	X	X	X	X	X	X			X	X
1.9 dCi	F9Q-733	1870	75	1999	2003	X	X	X	X	X	X	X	X			X	X
1.9 dCi	F9Q-738	1870	59	2000	2003	X	X	X	X	X	<b>N</b>		X			X	X
1.9 DT	F8Q-784	1870	66	1996	1999	X	X	X	X	X		X	X	X		X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagram. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays			
<b>RENAULT</b>														
<b>Megane Scenic 1996 2003</b>														
1.9 DT	F8Q-786	1870	66	1996	1999	X	X	X	X	X	X	X	X	X
1.9 dTi	F9Q-730	1870	72	1997	1999	X	X	X	X	X			X	X
1.9 dTi	F9Q-731	1870	72	1999	2003	X	X	X	X	X			X	X
1.9 dTi	F9Q-734	1870	72	1997	1999	X	X	X	X	X	X		X	X
1.9 dTi	F9Q-736	1870	72	1999	2003	X	X	X	X	X			X	X
1.9 dTi	F9Q-744	1870	59	2001	2003	X	X	X	X	X			X	X
2.0	F3R-750	1998	84	1996	1999	X	X	X	X	X	X		X	X
2.0	F3R-751	1998	84	1996	1999	X	X	X	X	X			X	X
2.0	F3R-791	1998	84	1996	1999	X	X	X	X	X	X		X	X
2.0	F3R-796	1998	84	1996	1999	X	X	X	X	X	X		X	X
2.0	F3R-797	1998	84	1996	1999	X	X	X	X	X	X		X	X
2.0	F3R-798	1998	84	1996	1999	X	X	X	X	X	X		X	X
2.0 16V	F4R-740	1998	103	1999	2003	X	X	X	X	X			X	X
2.0 16V	F4R-741	1998	103	1999	2003	X	X	X	X	X				X
2.0 16V	F4R-746	1998	103	2002	2003	X	X	X	X	X				X
2.0 16V	F4R-747	1998	103	1999	2003	X	X	X	X	X	<b>N</b>			X
RX4 1.9 dCi	F9Q-740	1870	75	2000	2003	X	X	X	X	X			X	X
RX4 2.0 16V	F4R-744	1998	103	2000	2003	X	X	X	X	X			X	X
<b>Modus 2004</b>														
1.2 16V (48/55 kW)	D4F-740	1149	48	2004		X	X	X	X	X			X	X
1.4 16V	K4J-770	1390	72	2004		X	X	X	X	X			X	X
1.5 dCi 65	K9K-752	1461	48	2004	2006	X	X	X	X	X				X
1.5 dCi 70	K9K-762	1461	50	2005		X	X	X	X	X				X
1.5 dCi 80	K9K-750	1461	60	2004	2006	X	X	X	X	X				X
1.5 dCi 85	K9K-760	1461	63	2005		X	X	X	X	X				X
1.6 16V	K4M-790	1598	82	2004		X	X	X	X	X			X	X
1.6 16V	K4M-791	1598	82	2004		X	X	X	X	X			X	X
1.6 16V	K4M-794	1598	82	2004		X	X	X	X	X				X
<b>Safrane 1992 2001</b>														
2.0	J7R-732/733	1995	79	1992	1997	X	X	X	X	X	X	X	X	X
2.0 12V	J7R-734/735	1995	99	1992	1997	X	X	X	X	X	X	X	X	X
2.0 12V	J7R-738/739	1995	97	1992	1997	X	X	X	X	X	X	X	X	X
2.0 16V	N7Q-710/711	1948	102	1997	2001	X	X	X	X	X	X	X	X	X
2.1 dT	J8S-760	2068	65	1992	1997	X	X	X	X	X	X	X	X	X
2.2	J7T-762	2165	81	1992	1997	X	X	X	X	X	X	X	X	X
2.2 12V	J7T-760/761	2165	103	1992	1997	X	X	X	X	X	X	X	X	X
2.2 dT	G8T-740	2188	83	1997	2001	X	X	X	X	X	X	X	X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagram. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagnr.	Fuses & Relays
<b>RENAULT</b>												
<b>Safrane 1992 2001</b>												
2.4 20V	N7U-700/701	2435	121	1997	2001	X	X	X	X	X	X	X
2.5 dT	S8U-762/763	2499	83	1992	1997	X	X	X	X	X	X	X
2.9 V6 24V	L7X-713	2946	140	1997	2001	X	X	X	X	X	X	X
3.0 V6	Z7X-721	2963	123	1992	1997	X	X	X	X	X	X	X
3.0 V6	Z7X-722/723	2963	123	1992	1997	X	X	X	X	X	X	X
3.0 V6	Z7X-744	2963	123	1997	2001	X	X	X	X	X	X	X
3.0 V6	Z7X-753	2963	123	1995	1997	X	X	X	X	X	X	X
3.0 V6	Z7X-755	2963	125	1997	2001	X	X	X	X	X	X	X
3.0 V6 Biturbo	Z7X-726	2963	193	1994	1997	X	X	X	X	X	X	X
<b>Scenic II 2003</b>												
1.4 16V	K4J-730	1390	72	2003		X	X	X	X	X	X	X
1.5 dCi 100	K9K-728	1461	74	2004	2005	X	X	X	X	X	X	X
1.5 dCi 100	K9K-729	1461	74	2004	2005	X	X	X	X	X	X	X
1.5 dCi 80	K9K-722	1461	59	2003	2005	X	X	X	X	X	X	X
1.6 16V	K4M-761	1598	83	2003		X	X	X	X	X	X	X
1.6 16V	K4M-782	1598	83	2003		X	X	X	X	X	X	X
1.9 dCi 120	F9Q-812	1870	88	2003	2005	X	X	X	X	X	X	X
2.0 16V	F4R-770	1998	99	2003		X	X	X	X	X	X	X
2.0 16V	F4R-771	1998	99	2003		X	X	X	X	X	X	X
2.0 16V Turbo	F4R-776	1998	120	2004		X	X	X	X	X	X	X
<b>Trafic 1986 2000</b>												
Pxx1	841 J 705	1647	49	1986	1990	X	X	X	X			X
Pxx2	829 E 720	1995	59	1986	1990	X	X	X	X			X
Pxx2	J5R-726	1995	59	1986	1990	X	X	X	X		X	X
Pxx2	J5R-726	1995	59	1991	1995	X	X	X	X		X	X
Pxx3	852 C 720	2068	43	1986	1990	X	X	X	X	X	X	X
Pxx3	852 C 720	2068	43	1991	1995	X	X	X	X	X	X	X
Pxx4	8140 61 240 (S8U-722)	2445	55	1986	1990	X	X	X	X		X	X
Pxx8	F1N-722	1721	50	1986	1990	X	X	X	X		X	X
Pxx8	F1N-722	1721	50	1991	1995	X	X	X	X		X	X
PxxF	J8S-620	2068	47	1991	1995	X	X	X	X	X	X	X
PxxF	J8S-620	2068	47	1996	2000	X	X	X	X	X	X	X
Txx0	847 D 700	1397	35	1986	1990	X	X	X	X	X		X
Txx0	C1J-700	1397	35	1991	1995	X	X	X	X	X	X	X
Txx1	A1M P 707	1647	49	1986	1990	X	X	X	X			X
Txx1 Automatic	A1M Q 708	1647	49	1986	1990	X	X	X	X			X
Txx2	J5R-716	1995	59	1986	1990	X	X	X	X		X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>RENAULT</b>											
<b>Traffic 1986 2000</b>											
Txx2	J5R-716	1995	59	1991	1995	X	X	X	X	X	X
Txx3	852 D 750	2068	43	1986	1990	X	X	X	X	X	X
Txx3	852 D 750	2068	43	1991	1995	X	X	X	X	X	X
Txx4	8140 672 500 (S8U-750)	2445	55	1986	1990	X	X	X	X	X	X
Txx4	8140 672 500 (S8U-750)	2499	55	1991	1995	X	X	X	X	X	X
Txx8	F1N-720	1721	50	1986	1990	X	X	X	X	X	X
Txx8	F1N-724	1721	50	1991	1995	X	X	X	X	X	X
TxxA	J7T-780	2165	70	1986	1990	X	X	X	X	X	X
TxxA	J7T-780	2165	70	1991	1995	X	X	X	X	X	X
TxxB	8140 672 580 (S8U-752)	2445	55	1986	1990	X	X	X	X	X	X
TxxB	8140 672 580 (S8U-752)	2499	50	1991	1995	X	X	X	X	X	X
TxxE	J7T-600	2165	70	1991	1995	X	X	X	X	X	X
TxxE	J7T-600	2165	74	1996	2000	X	X	X	X	X	X
TxxF	J8S-758	2068	47	1991	1995	X	X	X	X	X	X
TxxF	J8S-758	2068	47	1996	2000	X	X	X	X	X	X
TxxG	S8U-758	2449	55	1996	2000	X	X	X	X	X	X
TxxG	S8U-758	2499	55	1991	1995	X	X	X	X	X	X
TxxK	J8S-622	2068	48	1996	2000	X	X	X	X	X	X
Vxx1	A1M P 707	1647	49	1986	1990	X	X	X	X	X	X
Vxx2	J5R-716	1995	59	1986	1990	X	X	X	X	X	X
Vxx2	J5R-716	1995	59	1991	1995	X	X	X	X	X	X
Vxx3	852 D 750	2068	43	1986	1990	X	X	X	X	X	X
Vxx3	852 D 750	2068	43	1991	1995	X	X	X	X	X	X
Vxx4	8140 672 500 (S8U-750)	2445	55	1986	1990	X	X	X	X	X	X
Vxx4	8140 672 500 (S8U-750)	2499	55	1991	1995	X	X	X	X	X	X
VxxA	J7T-780	2165	70	1986	1990	X	X	X	X	X	X
VxxA	J7T-780	2165	70	1991	1995	X	X	X	X	X	X
VxxB	8140 672 580 (S8U-752)	2445	55	1986	1990	X	X	X	X	X	X
VxxB	8140 672 580 (S8U-752)	2499	55	1991	1995	X	X	X	X	X	X
VxxE	J7T-600	2165	74	1991	1995	X	X	X	X	X	X
VxxE	J7T-600	2165	74	1996	2000	X	X	X	X	X	X
VxxG	S8U-758	2449	55	1996	2000	X	X	X	X	X	X
VxxG	S8U-758	2499	55	1991	1995	X	X	X	X	X	X
<b>Traffic II 2001</b>											
1.9 dCi 100	F9Q-760	1870	74	2001		X	X	X	X	X	X
1.9 dCi 80	F9Q-762	1870	59	2001	2007	X	X	X	X	X	X
2.0 16V	F4R-720	1998	88	2001	2007	X	X	X	X	X	X

Legend: N = new, X = present

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagram	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagram	
<b>RENAULT</b>													
<b>Trafic II 2001</b>													
2.5 dCi 140	G9U-730	2464	99	2002	2007	X	X	X	X	X	N	X	X
<b>Twingo 1993 2007</b>													
1.2	C3G-700	1238	40	1992	1998	X	X	X	X	X	X	X	X
1.2	C3G-702	1238	40	1994	1997	X	X	X	X	X	X	X	X
1.2 16V	D4F-700	1149	55	2000	2007	X	X	X	X	X	X	X	X
1.2 16V	D4F-702	1149	55	2000	2007	X	X	X	X	X	X	X	X
1.2 16V Quickshift 5	D4F-708	1149	55	2001	2007	X	X	X	X	X	X	X	X
1.2 8V	D7F-700	1149	44	1996	2001	X	X	X	X	X	X	X	X
1.2 8V	D7F-701	1149	44	1996	2001	X	X	X	X	X	X	X	X
1.2 8V	D7F-702	1149	43	1998	2001	X	X	X	X	X	X	X	X
1.2 8V	D7F-703	1149	43	2001	2007	X	X	X	X	X	X	X	X
1.2 8V	D7F-706	1149	43	1998	2007	X	X	X	X	X	X	X	X
1.2 8V	D7F-720	1149	44	1996	1998	X	X	X	X	X	X	X	X
1.2 Easy	C3G-700	1238	40	1994	1998	X	X	X	X	X	X	X	X
<b>Vel Satis 2002</b>													
2.0 16V Turbo	F4R-762	1998	120	2002	2005	X	X	X	X	X	N	X	X
2.0 16V Turbo	F4R-763	1998	120	2002	2005	X	X	X	X	X	X	X	X
2.0 16V Turbo	F4R-766	1998	125	2005		X	X	X	X	X	N	X	X
2.0 16V Turbo	F4R-767	1998	125	2003		X	X	X	X	X	X	X	X
2.2 dCi 16V	G9T-702	2188	110	2002	2005	X	X	X	X	X	X	X	X
2.2 dCi 16V	G9T-703	2188	110	2002		X	X	X	X	X	N	X	X
3.0 dCi V6 24V	P9X-701	2958	130	2002	2005	X	X	X	X	X	X	X	X
3.5 V6 24V	V4Y-701	3498	177	2002	2005	X	X	X	X	X	X	X	X
3.5 V6 24V	V4Y-711	3498	177	2005		X	X	X	X	X	N	X	X
<b>ROVER</b>													
<b>100 / Metro 1990 1998</b>													
1.4 MPi	K8-1.4	1396	55	1996	1998	X	X	X	X	X	X	X	X
111	K8-1.1	1120	44	1990	1996	X	X	X	X	X	X	X	X
111 C, L, S, Cabriolet	K8-1.1	1120	44	1990	1996	X	X	X	X	X	X	X	X
111 MPi	K8-1.1	1120	44	1996	1998	X	X	X	X	X	X	X	X
114 D	K9A (TUD3)	1360	38	1992	1994	X	X	X	X	X	X	X	X
114 Gta / Gti-16V	K16-1.4	1396	66	1990	1996	X	X	X	X	X	X	X	X
114 Gta, Gtr, Windsor	K8-1.4	1396	55	1990	1992	X	X	X	X	X	X	X	X
114 GTi-16V	K16-1.4	1396	76	1992	1996	X	X	X	X	X	X	X	X
114 i	K8-1.4	1396	55	1990	1996	X	X	X	X	X	X	X	X
115 D	VJY (TUD5)	1527	40	1995	1998	X	X	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>ROVER</b>											
<b>200 1984 1990</b>											
213 S, SE	EV 2	1342	54	1984	1990	X	X	X	X	X	X
216 S, SE	16 HD 94	1598	63	1985	1989	X	X	X	X	X	X
216 S, SX	16 HE 58	1598	63	1989	1990	X	X	X	X	X	X
216 SE, Vitesse EFI	16 H (S)	1598	75	1985	1989	X	X	X	X	X	X
<b>200 1995 1999</b>											
200 Vi	18K4K	1796	107	1995	1999	X	X	X	X	X	X
211	11K8	1119	45	1998	1999	X	X	X	X	X	X
214 8V	14K8/K4	1396	55	1995	1999	X	X	X	X	X	X
214 Si 16V	14K4F	1396	76	1995	1999	X	X	X	X	X	X
216 Si 16V	16K4F	1589	82	1995	1999	X	X	X	X	X	X
218 Si 16V	18K4K	1796	90	1997	1999	X	X	X	X	X	X
220 D	20T2R	1994	63	1995	1999	X	X	X	X	X	X
220 SDi	20T2N	1994	77	1995	1999	X	X	X	X	X	X
BRM	18K4K	1796	107	1995	1999	X	X	X	X	X	X
<b>200 / 400 1989 1995</b>											
214i / 414i	14K2	1397	55	1989	1995	X	X	X	X	X	X
214i / 414i	14K4	1396	68	1990	1995	X	X	X	X	X	X
214i / 414i	14K4F	1397	76	1992	1995	X	X	X	X	X	X
214S / 414S	14K2	1397	56	1989	1992	X	X	X	X	X	X
216 / 416 DOHC	D16A8	1590	90	1992	1995	X	X	X	X	X	X
216 / 416 SOHC	D16A6	1590	82	1990	1995	X	X	X	X	X	X
216 Coupé, Cabrio, Tourer	16K16	1589	86	1992	1995	X	X	X	X	X	X
216i / 416i DOHC	D16A9	1590	96	1989	1995	X	X	X	X	X	X
216i / 416i DOHC Aut.	D16Z4	1590	91	1989	1995	X	X	X	X	X	X
216i / 416i SOHC	D16A7	1590	85	1990	1995	X	X	X	X	X	X
216i / 416i SOHC Aut.	D16Z2	1590	82	1990	1995	X	X	X	X	X	X
218 / 418 SD	XUD9 (D9A)	1905	49	1993	1995	X	X	X	X	X	X
218 TD / 418 TD	XUD7TE (A8A)	1769	66	1991	1995	X	X	X	X	X	X
218 VVC Coupé, Cabrio, Tourer	18K16	1796	87	1992	1995	X	X	X	X	X	X
220 Coupe Turbo	20T4 GG23/24	1994	147	1992	1995	X	X	X	X	X	X
220 GTi	20M4F	1994	103	1991	1995	X	X	X	X	X	X
220i / 420i	20T4H	1994	100	1992	1995	X	X	X	X	X	X
<b>25 1999 2004</b>											
1.1 16V	11K4F	1119	55	2002	2004	X	X	X	X	X	X
1.4 16V	14K4M	1396	62	1999	2004	X	X	X	X	X	X
1.4 16V +	14K4F	1396	76	1999	2004	X	X	X	X	X	X
1.6 16V	16K4F	1588	80	1999	2004	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays	
<b>ROVER</b>												
<b>25 1999 2004</b>												
1.8 16V	18K4F	1796	86	1999	2004	X	X	X	X	X	X	X
1.8 16V VVC	18K4K	1796	107	1999	2004	X	X	X	X	X	X	X
2.0 iDT	20T2N	1994	74	1999	2004	X	X	X	X	X	X	X
2.0 iDT	20T2N	1994	83	2002	2004	X	X	X	X	X	X	X
<b>400 1995 1999</b>												
414 i, Si 16V	14K4F	1396	76	1995	1999	X	X	X	X	X	X	X
416 Si	D16Y3	1590	83	1995	1997	X	X	X	X	X	X	X
416 Si 16V	16K4F	1589	82	1995	1999	X	X	X	X	X	X	X
416 Si 16V	D16B2	1590	86	1997	1999	X	X	X	X	X	X	X
420 D	20T2R	1994	63	1996	1999	X	X	X	X	X	X	X
420 SDi, Di	20T2N	1994	77	1996	1999	X	X	X	X	X	X	X
420 Si	20T4H	1994	100	1995	1999	X	X	X	X	X	X	X
<b>45 1999 2005</b>												
1.4 16V	14K4F	1396	76	2001	2005	X	X	X	X	X	X	X
1.6 16V	16K4F	1588	80	2001	2005	X	X	X	X	X	X	X
1.8 16V	18K4F	1796	86	2001	2005	X	X	X	X	X	X	X
2.0 iDT 100	20T2N	1994	74	2001	2005	X	X	X	X	X	X	X
2.0 iDT 113	20T2	1994	83	2001	2005	X	X	X	X	X	X	X
<b>600 1993 1999</b>												
618	F18A3	1850	85	1996	1999	X	X	X	X	X	X	X
620 Di	20T2N	1994	77	1995	1999	X	X	X	X	X	X	X
620 i	F20-Z2	1997	85	1993	1997	X	X	X	X	X	X	X
620 Si,SLi,GSi	F20-Z1	1997	96	1993	1999	X	X	X	X	X	X	X
620 Ti	20T4G	1994	145	1994	1999	X	X	X	X	X	X	X
623 i	H23A3	2259	116	1993	1999	X	X	X	X	X	X	X
<b>75 1998 2005</b>												
1.8	18K4F	1796	88	1998	2005	X	X	X	X	X	X	X
2.0 CDT	204D2 (M47R)	1950	85	1998	2005	X	X	X	X	X	X	X
2.0 V6	20K4F	1997	110	1998	2005	X	X	X	X	X	X	X
2.5 V6	25K4F	2497	130	1998	2005	X	X	X	X	X	X	X
<b>800 1986 1998</b>												
820	20 H	1994	74	1990	1992	X	X	X	X	X	X	X
820 E	20 HD	1996	88	1986	1990	X	X	X	X	X	X	X
820 i	20T4H	1994	100	1992	1998	X	X	X	X	X	X	X
820 i, Si	20 HD-M16	1994	103	1986	1992	X	X	X	X	X	X	X
820 i, Si 16V	20 HD	1994	102	1991	1991	X	X	X	X	X	X	X
820 Ti	20T4G	1994	147	1994	1998	X	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>ROVER</b>											
<b>800 1986 1998</b>											
820 Ti 16V	20T4G	1994	132	1992	1998	X	X	X	X	X	X
820 Turbo	20M4G	1994	132	1991	1991	X	X	X	X	X	X
825 D	425 SLI ER	2498	89	1996	1998	X	X	X	X	X	X
825 D, SD	4924 SLI RR	2499	87	1992	1998	X	X	X	X	X	X
825 i	C25A	2494	127	1986	1990	X	X	X	X	X	X
825 Si, Sterling V6 24V	25K4F	2497	127	1996	1998	X	X	X	X	X	X
825 TD	9424 SHI	2498	96	1990	1992	X	X	X	X	X	X
827 i V6	C27A1	2675	124	1991	1991	X	X	X	X	X	X
827 i, Si V6	C27A1	2675	130	1988	1992	X	X	X	X	X	X
827 Si V6 24V	C27A1	2675	124	1992	1998	X	X	X	X	X	X
<b>CityRover 2003 2005</b>											
1.4	475	1405	63	2003	2005	X	X	X	X	X	X
<b>Maestro 1983 1995</b>											
1.3	12HC32,36	1275	50	1983	1989	X	X	X	X	X	X
1.3	12HC35	1275	50	1983	1989	X	X	X	X	X	X
1.3	12HC47,34	1275	50	1983	1989	X	X	X	X	X	X
1.3	12HC52,53	1275	50	1984	1989	X	X	X	X	X	X
1.3	12HE16	1275	50	1983	1989	X	X	X	X	X	X
1.3	12HE19	1275	50	1984	1989	X	X	X	X	X	X
1.3	12HE43	1275	47	1988	1993	X	X	X	X	X	X
1.3	12HE76,77	1275	51	1988	1993	X	X	X	X	X	X
1.3	12HE78,94	1275	51	1988	1993	X	X	X	X	X	X
1.3	12HE79	1275	47	1988	1992	X	X	X	X	X	X
1.3 Cat	12HF44,45	1275	49	1990	1993	X	X	X	X	X	X
1.3 L, LS	12H	1275	49	1983	1989	X	X	X	X	X	X
1.6	16HE54,55	1598	63	1988	1993	X	X	X	X	X	X
1.6	16HE56/57	1598	63	1988	1993	X	X	X	X	X	X
1.6 L, HLS, Vandenplas, Mayfair	16HC37,38	1598	63	1983	1988	X	X	X	X	X	X
1.6 L, HLS, Vandenplas, Mayfair	16HC55,56	1598	63	1983	1988	X	X	X	X	X	X
1.6 L, HLS, Vandenplas, Mayfair	16HC60/62	1598	63	1983	1988	X	X	X	X	X	X
1.6 L, HLS, Vandenplas, Mayfair	16HD73	1598	63	1983	1988	X	X	X	X	X	X
1.6 L, HLS, Vandenplas, Mayfair	16HE04,05	1598	63	1983	1988	X	X	X	X	X	X
1.6 L, HLS, Vandenplas, Mayfair	16HE06,07	1598	63	1983	1988	X	X	X	X	X	X
1.6 L, HLS, Vandenplas, Mayfair	16HE08	1598	63	1983	1988	X	X	X	X	X	X
2.0 D	MDi	1994	44	1990	1992	X	X	X	X	X	X
2.0 D Turbo	MDi	1994	60	1992	1995	X	X	X	X	X	X
2.0 MG Efi	20 HB (O)	1994	83	1984	1989	X	X	X	X	X	X



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>ROVER</b>													
<b>Maestro 1983 1995</b>													
2.0i	20HE99	1994	85	1989	1993	X	X	X	X	X		X	X
Turbo	20H	1994	112	1989	1991	X	X	X	X	X		X	X
<b>Metro 1980 1990</b>													
1.0 Saloons & Vans	99HB87P	998	34	1986	1988	X	X	X	X	X		X	
1.0 Saloons & Vans	99HB88P	998	34	1986	1988	X	X	X	X	X		X	
1.0 Saloons & Vans	99HB89P	998	34	1986	1988	X	X	X	X	X		X	
1.0 Saloons & Vans	99HB90P	998	34	1986	1986	X	X	X	X	X		X	
1.0 Saloons & Vans	99HB91P	998	34	1986	1986	X	X	X	X	X		X	
1.0 Saloons & Vans	99HB92P	998	34	1986	1986	X	X	X	X	X		X	
1.0 Saloons & Vans	99HB93P	998	34	1986	1986	X	X	X	X	X		X	
1.0 Saloons & Vans	99HB95P	998	34	1986	1988	X	X	X	X	X		X	
1.0 Saloons & Vans	99HB96P	998	34	1986	1986	X	X	X	X	X		X	
1.0 Saloons & Vans	99HB97P	998	34	1986	1986	X	X	X	X	X		X	
1.0 Saloons & Vans	99HB98P	998	34	1986	1986	X	X	X	X	X		X	
1.0 Saloons & Vans	99HB99P	998	34	1986	1986	X	X	X	X	X		X	
1.0 Saloons & Vans	99HD27,29	998	34	1987	1989	X	X	X	X	X		X	
1.0 Saloons & Vans	99HD27P	998	34	1987	1989	X	X	X	X	X		X	
1.0 Saloons & Vans	99HD28P	998	34	1987	1989	X	X	X	X	X		X	
1.0 Saloons & Vans	99HD29P	998	34	1987	1989	X	X	X	X	X		X	
1.0 Saloons & Vans	99HD30,31	998	34	1987	1989	X	X	X	X	X		X	
1.0 Saloons & Vans	99HD30,31P	998	34	1986	1988	X	X	X	X	X		X	
1.0 Saloons & Vans	99HD32,33	998	34	1989	1989	X	X	X	X	X		X	
1.0 Saloons & Vans	99HD32P	998	34	1987	1988	X	X	X	X	X		X	
1.0 Saloons & Vans	99HD33P	998	34	1987	1988	X	X	X	X	X		X	
1.0 Saloons & Vans	99HD34P	998	34	1987	1988	X	X	X	X	X		X	
1.0 Saloons & Vans	99HD35P	998	34	1987	1988	X	X	X	X	X		X	
1.0 Saloons & Vans	99HE35,67	998	34	1989	1989	X	X	X	X	X		X	
1.0 Saloons & Vans	99HE38,39	998	34	1989	1989	X	X	X	X	X		X	
1.0 Saloons & Vans	99HE68,69	998	34	1989	1989	X	X	X	X	X		X	
1.0 Saloons & Vans	99HE70,76	998	34	1989	1989	X	X	X	X	X		X	
1.0 Saloons & Vans	99HE94	998	34	1989	1989	X	X	X	X	X		X	
1.3 (CH)	12HC12AA	1275	38	1986	1986	X	X	X	X	X		X	
1.3 (CH)	12HC13AA	1275	38	1986	1986	X	X	X	X	X		X	
1.3 MG Turbo	12HC16AA	1275	68	1983	1989	X	X	X	X	X		X	
1.3 MG Turbo	12HD26	1275	68	1983	1989	X	X	X	X	X		X	
1.3 MG Turbo	12HD26AA	1275	68	1983	1989	X	X	X	X	X		X	
1.3 MG, Vanden Plas	12HC14AA	1275	53	1982	1989	X	X	X	X	X		X	

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>ROVER</b>											
<b>Metro 1980 1990</b>											
1.3 MG, Vanden Plas	12HC15	1275	53	1982	1989	X	X	X	X	X	X
1.3 MG, Vanden Plas	12HD17,24	1275	53	1982	1989	X	X	X	X	X	X
1.3 MG, Vanden Plas	12HD17AA	1275	53	1982	1989	X	X	X	X	X	X
1.3 MG, Vanden Plas	12HD25,24	1275	53	1982	1989	X	X	X	X	X	X
1.3 Saloons	12HC01AA	1275	38	1986	1986	X	X	X	X	X	X
1.3 Saloons	12HC02AA	1275	38	1986	1986	X	X	X	X	X	X
1.3 Saloons	12HC03AA	1275	38	1986	1986	X	X	X	X	X	X
1.3 Saloons	12HC04AA	1275	38	1986	1986	X	X	X	X	X	X
1.3 Saloons	12HC05AA	1275	38	1986	1986	X	X	X	X	X	X
1.3 Saloons	12HC06AA	1275	38	1986	1986	X	X	X	X	X	X
1.3 Saloons	12HC07AA	1275	38	1986	1986	X	X	X	X	X	X
1.3 Saloons	12HC08AA	1275	38	1986	1986	X	X	X	X	X	X
1.3 Saloons	12HD09,10	1275	38	1986	1986	X	X	X	X	X	X
1.3 Saloons	12HD09AA	1275	38	1987	1988	X	X	X	X	X	X
1.3 Saloons	12HD10AA	1275	38	1987	1988	X	X	X	X	X	X
1.3 Saloons	12HD11,12	1275	38	1986	1986	X	X	X	X	X	X
1.3 Saloons	12HD11AA	1275	38	1987	1988	X	X	X	X	X	X
1.3 Saloons	12HD12AA	1275	38	1987	1988	X	X	X	X	X	X
1.3 Saloons	12HD13,21	1275	38	1986	1986	X	X	X	X	X	X
1.3 Saloons	12HD13AA	1275	38	1987	1988	X	X	X	X	X	X
1.3 Saloons	12HD21AA	1275	38	1987	1988	X	X	X	X	X	X
1.3 Saloons	12HD22AA	1275	38	1987	1988	X	X	X	X	X	X
1.3 Saloons	12HE25	1275	38	1989	1989	X	X	X	X	X	X
1.3 Saloons & Vanden Plas A/T	12HC11AA	1275	38	1986	1986	X	X	X	X	X	X
1.3 Saloons & Vanden Plas A/T	12HD23	1275	38	1986	1986	X	X	X	X	X	X
1.3 Saloons & Vanden Plas A/T	12HD23AA	1275	38	1986	1986	X	X	X	X	X	X
1.3 Saloons & Vans	12HC17AA	1275	38	1986	1989	X	X	X	X	X	X
1.3 Saloons & Vans	12HC18AA	1275	38	1986	1989	X	X	X	X	X	X
1.3 Saloons & Vans	12HC19AA	1275	38	1986	1989	X	X	X	X	X	X
1.3 Saloons & Vans	12HD18	1275	38	1986	1989	X	X	X	X	X	X
1.3 Saloons & Vans	12HD18AA	1275	38	1986	1989	X	X	X	X	X	X
1.3 Saloons A/T	12HE25	1275	38	1989	1989	X	X	X	X	X	X
1.3 Vans	12HC09AA	1275	38	1986	1986	X	X	X	X	X	X
1.3 Vans	12HC10AA	1275	38	1986	1986	X	X	X	X	X	X
1.3 Vans	12HD14,15	1275	38	1987	1989	X	X	X	X	X	X
1.3 Vans	12HD14AA	1275	38	1987	1989	X	X	X	X	X	X
1.3 Vans	12HD15AA	1275	38	1987	1989	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>ROVER</b>											
<b>Metro 1980 1990</b>											
1.3 Vans	12HD19,20	1275	38	1987	1989	X	X	X	X	X	X
1.3 Vans	12HD19AA	1275	38	1987	1989	X	X	X	X	X	X
1.3 Vans	12HD20AA	1275	38	1987	1989	X	X	X	X	X	X
1.3 Vans	12HE41,42	1275	38	1987	1989	X	X	X	X	X	X
<b>Mini 1983 2000</b>											
1.3 Cat	12A2BG03	1275	37	1992	1994	X	X	X	X	X	X
1.3 Cat	12A2BG05	1275	37	1992	1994	X	X	X	X	X	X
1.3 Cooper/Cabriolet	12A2EF77	1275	46	1991	2000	X	X	X	X	X	X
1.3 MPi	12A2LK70	1275	47	1996	2000	X	X	X	X	X	X
1.3i	12A2EK71	1275	47	1996	2000	X	X	X	X	X	X
1.3i	12A2EK72	1275	47	1996	2000	X	X	X	X	X	X
1.3i Cat	12A2DF75	1275	39	1991	1996	X	X	X	X	X	X
1.3i Cat	12A2DF76	1275	39	1991	1996	X	X	X	X	X	X
1.3i Cat	12A2DF77	1275	39	1991	1996	X	X	X	X	X	X
1000	99H	998	31	1983	1989	X	X	X	X	X	X
1000	99HE22	998	31	1989	1992	X	X	X	X	X	X
1000 & 1000 Cat	99HE20,D81	998	31	1989	1992	X	X	X	X	X	X
Cooper	12A2AF53	1275	45	1990	1992	X	X	X	X	X	X
Turbo	12HD26AA	1275	68	1989	1990	X	X	X	X	X	X
<b>Montego Estate 1984 1994</b>											
1.3	12HE17,18	1275	51	1984	1989	X	X	X	X	X	X
1.3	12HE19,44	1275	47	1989	1991	X	X	X	X	X	X
1.3	12HE80	1275	51	1989	1993	X	X	X	X	X	X
1.6	16H (S)	1598	61	1984	1992	X	X	X	X	X	X
1.6	16HE33,34	1598	61	1989	1993	X	X	X	X	X	X
1.6	16HE60,66	1598	63	1989	1993	X	X	X	X	X	X
1.6	16HE86,91	1598	63	1989	1990	X	X	X	X	X	X
1.6	16HE89,93	1598	63	1989	1991	X	X	X	X	X	X
2.0	20HE	1998	76	1989	1995	X	X	X	X	X	X
2.0	20HE09,11	1998	77	1984	1989	X	X	X	X	X	X
2.0 EFi	20H	1994	83	1985	1989	X	X	X	X	X	X
2.0 EFi	20HE51,52	1994	77	1990	1995	X	X	X	X	X	X
2.0 TD	MDi	1993	60	1988	1991	X	X	X	X	X	X
2.0 TD	MDi	1994	60	1989	1994	X	X	X	X	X	X
2.0 Turbo	20H	1994	110	1985	1988	X	X	X	X	X	X
2.0 Turbo	20HE50	1994	112	1990	1992	X	X	X	X	X	X
2.0i	20H	1994	85	1984	1991	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays	
<b>ROVER</b>												
<b>Montego Estate 1984 1994</b>												
2.0i	20HE13,14	1994	85	1989	1993	X	X	X	X	X	X	X
2.0i	20HE99	1994	85	1989	1993	X	X	X	X	X	X	X
2.0i MEMS	20HE36,37	1994	85	1989	1993	X	X	X	X	X	X	X
MG Turbo	20HE15	1994	112	1989	1991	X	X	X	X	X	X	X
<b>Streetwise 2003 2005</b>												
1.4i	14K4F	1396	76	2003	2005	X	X	X	X	X	X	X
1.6i	16K4F	1588	80	2003	2005	X	X	X	X	X	X	X
1.8i	18K4F	1796	86	2003	2005	X	X	X	X	X	X	X
2.0 iDT	20T2N	1994	74	2003	2005	X	X	X	X	X	X	X
<b>SAAB</b>												
<b>90 1984 1987</b>												
2.0	B 201 C	1985	74	1984	1987	X	X	X	X	X	X	X
<b>900 1983 1994</b>												
2.0	B201 C	1985	73	1984	1988	X	X	X	X	X	X	X
2.0	B201T	1985	79	1983	1988	X	X	X	X	X	X	X
2.0i	B201i	1985	87	1984	1988	X	X	X	X	X	X	X
2.0i 16V Forty	B202i	1985	94	1988	1993	X	X	X	X	X	X	X
2.0i 16V kat	B202i	1985	92	1985	1993	X	X	X	X	X	X	X
2.0i kat	B201i	1985	81	1983	1993	X	X	X	X	X	X	X
2.0i Turbo	B201 S	1985	114	1985	1986	X	X	X	X	X	X	X
2.0i Turbo 16V	B202 L	1985	129	1984	1990	X	X	X	X	X	X	X
2.0i Turbo 16V	B202 L	1985	129	1989	1993	X	X	X	X	X	X	X
2.0i Turbo 16V	B202 LTT	1985	107	1989	1993	X	X	X	X	X	X	X
2.0i Turbo 16V	B202 S	1985	129	1987	1990	X	X	X	X	X	X	X
2.0i Turbo 16V kat	B202 L	1985	107	1988	1993	X	X	X	X	X	X	X
2.0i Turbo APC kat	B201 S	1985	103	1986	1987	X	X	X	X	X	X	X
2.0i Turbo H-APC	B201 S	1985	107	1984	1989	X	X	X	X	X	X	X
2.0i Turbo, Cabriolet 16V,16S	B202 S/Si Kat.	1985	118	1990	1993	X	X	X	X	X	X	X
2.1i Cabriolet	B212i	2119	103	1990	1994	X	X	X	X	X	X	X
<b>900 1993 1998</b>												
2.0 SE Turbo 16V	B204 L	1985	136	1993	1998	X	X	X	X	X	X	X
2.0 Si	B206i	1985	98	1993	1998	X	X	X	X	X	X	X
2.0i	B204i	1985	96	1994	1998	X	X	X	X	X	X	X
2.3 Si	B234i	2290	110	1993	1998	X	X	X	X	X	X	X
2.5i V6	B258i	2498	131	1993	1997	X	X	X	X	X	X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>SAAB</b>											
<b>9000 1984 1998</b>											
2.0i 16V	B 202i	1985	96	1985	1988	X	X	X	X	X	X
2.0i 16V	B 202i	1985	99	1988	1993	X	X	X	X	X	X
2.0i 16V	B 204 i	1985	96	1993	1998	X	X	X	X	X	X
2.0i 16V CD Turbo	B 202 L	1985	118	1985	1988	X	X	X	X	X	X
2.0i 16V CD Turbo	B 202 L	1985	129	1984	1992	X	X	X	X	X	X
2.0i 16V kat	B 202i	1985	92	1985	1988	X	X	X	X	X	X
2.0i 16V kat	B 202i	1985	96	1988	1993	X	X	X	X	X	X
2.0i 16V Turbo	B 202 L2	1985	121	1988	1993	X	X	X	X	X	X
2.0i 16V Turbo	B 204 E	1985	110	1995	1998	X	X	X	X	X	X
2.0i 16V Turbo	B 204 S	1985	110	1993	1998	X	X	X	X	X	X
2.0i 16V Turbo Ecopower	B 202 S	1985	110	1991	1998	X	X	X	X	X	X
2.0i 16V Turbo Ecopower	B 204 L	1985	136	1993	1995	X	X	X	X	X	X
2.3i 16V	B 234i	2290	108	1993	1996	X	X	X	X	X	X
2.3i 16V	B 234i	2290	110	1989	1993	X	X	X	X	X	X
2.3i 16V Turbo	B 234 E	2290	125	1993	1997	X	X	X	X	X	X
2.3i 16V Turbo	B 234 L	2290	147	1990	1997	X	X	X	X	X	X
2.3i 16V Turbo	B 234 L	2290	147	1993	1997	X	X	X	X	X	X
2.3i 16V Turbo	B 234 R	2290	165	1993	1997	X	X	X	X	X	X
2.3i 16V Turbo CS Aero	B 234 R	2290	166	1992	1993	X	X	X	X	X	X
3.0i V6 24V	B 308i	2961	155	1994	1997	X	X	X	X	X	X
<b>9-3 1998 2003</b>											
2.0 t	B204E	1985	113	1999	2001	X	X	X	X	X	X
2.0 t	B205E	1985	110	2001	2003	X	X	X	X	X	X
2.0 T	B204L	1985	136	1998	2000	X	X	X	X	X	X
2.0 T	B204R	1985	147	1999	2000	X	X	X	X	X	X
2.0 T	B205L	1985	136	2000	2003	X	X	X	X	X	X
2.0 T	B205R	1985	151	2000	2003	X	X	X	X	X	X
2.0i	B204i	1985	96	1998	2001	X	X	X	X	X	X
2.2 TiD	D223L	2172	85	1998	2002	X	X	X	X	X	X
2.2 TiD	D223L	2172	92	2001	2003	X	X	X	X	X	X
2.3 T Viggen	B235R	2290	169	1999	2003	X	X	X	X	X	X
2.3i	B234i	2290	110	1998	1999	X	X	X	X	X	X
<b>9-3 2003</b>											
1.8	Z18XE	1796	92	2004		X	X	X	X	X	X
1.8 t	B207E	1998	110	2003		X	X	X	X	X	X
1.9 TiD	Z19DT	1910	88	2005		X	X	X	X	X	X
1.9 TiD 16V	Z19DTH	1910	110	2005		X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>SAAB</b>													
<b>9-3 2003</b>													
2.0 t	B207L	1998	129	2003		X	X	X	X	X	X	X	X
2.0 Turbo	B207R	1998	154	2003		X	X	X	X	X	X	X	X
2.2 TiD	D223L	2171	92	2003	2004	X	X	X	X	X	X	X	X
2.8t V6	B284E	2792	171	2005		X	X	X	X	X			
2.8T V6	B284L	2792	184	2005		X	X	X	X	X			
<b>9-5 1998</b>													
1.9 TiD 16V	Z19DTH	1910	110	2006		X	X	X	X	X	X	X	X
2.0 t	B205E	1985	110	1998		X	X	X	X	X	X	X	X
2.0 t BioPower	B205E	2290	137	2006		X	X	X	X	X	X	X	X
2.0 Turbo	B205F	1985	129	1998	2003	X	X	X	X	X	X	X	X
2.0 Turbo 185	B205E	1985	136	2002		X	X	X	X	X	X	X	X
2.2 TiD	D223L	2172	88	2002	2005	X	X	X	X	X	X	X	X
2.3 t	B235E	2290	136	1998		X	X	X	X	X	X	X	X
2.3 Turbo	B235L	2290	162	2004		X	X	X	X	X	X	X	X
2.3 Turbo 230	B235R	2290	169	2000	2002	X	X	X	X	X	X	X	X
2.3 Turbo 250	B235R	2290	184	2002		X	X	X	X	X	X	X	X
2.3 Turbo 280	B235R	2290	206	2004		X	X	X	X	X	X	X	X
2.3 Turbo 305	B235R	2290	224	2004		X	X	X	X	X	X	X	X
3.0 V6 t	B308E	2962	147	1998	2003	X	X	X	X	X	X	X	X
3.0 V6 TiD	D308L	2958	130	2002	2005	X	X	X	X	X	X	X	X
<b>SEAT</b>													
<b>Alhambra 1995</b>													
1.8 Turbo	AJH	1781	110	1998	2000	X	X	X	X	X	X	X	X
1.8 Turbo	AWC	1781	110	2000		X	X	X	X	X	X	X	X
1.9 TDi	1Z	1896	66	1996	1996	X	X	X	X	X	X	X	X
1.9 TDi	AFN	1896	81	1997	2000	X	X	X	X	X	X	X	X
1.9 TDi	AHU	1896	66	1996	2000	X	X	X	X	X	X	X	X
1.9 TDi	ANU	1896	66	1999		X	X	X	X	X	X	X	X
1.9 TDi	ASZ	1781	96	2002		X	X	X	X	X	X	X	X
1.9 TDi	AUY	1896	85	2000		X	X	X	X	X	X	X	X
1.9 TDi	AVG	1896	81	1999	2000	X	X	X	X	X	X	X	X
2.0	ADY	1984	85	1996	2000	X	X	X	X	X	X	X	X
2.0	ATM	1984	85	2000		X	X	X	X	X	X	X	X
VR6	AAA	2792	128	1995	1998	X	X	X	X	X	X	X	X
VR6	AMY	2792	128	1998	2000	X	X	X	X	X	X	X	X
VR6	AYL	2792	150	2000		X	X	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays				
<b>SEAT</b>															
<b>Altea 2004</b>															
1.6	BGU	1595	75	2004	2005	X	X	X	X	X	X	X	X	X	N
1.9 TDi	BJB	1896	77	2004		X	X	X	X	X	X	X	X	X	N
1.9 TDi	BKC	1896	77	2004		X	X	X	X	X	X	X	X	X	N
1.9 TDi	BLS	1896	77	2006		X	X	X	X	X	X	X	X	X	N
2.0 16V FSi	AXW	1984	110	2004	2005	X	X	X	X	X	X	X	X	X	N
2.0 16V FSi	BLR	1984	110	2005		X	X	X	X	X	X	X	X	X	N
2.0 16V FSi	BLY	1984	110	2005		X	X	X	X	X	X	X	X	X	N
2.0 16V TDi	AZV	1968	100	2005		X	X	X	X	X	X	X	X	X	N
2.0 16V TDi	BKD	1968	103	2004		X	X	X	X	X	X	X	X	X	N
2.0 TDi	BMM	1968	100	2006		X	X	X	X	X	X	X	X	X	N
<b>Arosa 1997 2005</b>															
1.0	AER	999	37	1997	1999	X	X	X	X	X	X	X	X	X	X
1.0	AHT	999	37	1997	2000	X	X	X	X	X	X	X	X	X	X
1.0	ALD	999	37	1999	2000	X	X	X	X	X	X	X	X	X	X
1.0	ANV	999	37	1999	2000	X	X	X	X	X	X	X	X	X	X
1.0	AUC	999	37	2000	2002	X	X	X	X	X	X	X	X	X	X
1.4	AEX	1390	44	1997	1998	X	X	X	X	X	X	X	X	X	X
1.4	AKK	1390	44	1999	2000	X	X	X	X	X	X	X	X	X	X
1.4	AUD	1390	44	1999	2005	X	X	X	X	X	X	X	X	X	X
1.4	ANW	1390	44	1999	2000	X	X	X	X	X	X	X	X	X	X
1.4 16V	AFK	1390	74	1999	2000	X	X	X	X	X	X	X	X	X	X
1.4 16V	AQQ	1390	74	1999	2000	X	X	X	X	X	X	X	X	X	X
1.4 16V	AUB	1390	74	2000	2005	X	X	X	X	X	X	X	X	X	X
1.4 TDi	AMF	1422	44	1997	2002	X	X	X	X	X	X	X	X	X	X
1.7 SDi	AKU	1716	44	1997	2002	X	X	X	X	X	X	X	X	X	X
<b>Cordoba 1993 2000</b>															
1.3	2G	1272	40	1993	1994	X	X	X	X	X	X	X	X	X	X
1.3	AAV	1272	40	1993	1994	X	X	X	X	X	X	X	X	X	X
1.4	AEX	1390	44	1995	1998	X	X	X	X	X	X	X	X	X	X
1.4	APQ	1390	44	1997	1998	X	X	X	X	X	X	X	X	X	X
1.4	ABD	1391	44	1993	1996	X	X	X	X	X	X	X	X	X	X
1.4 16V	AFH	1390	74	1997	1999	X	X	X	X	X	X	X	X	X	X
1.6	1F	1595	55	1994	1998	X	X	X	X	X	X	X	X	X	X
1.6	AEE	1598	55	1997	1999	X	X	X	X	X	X	X	X	X	X
1.6	AFT	1595	74	1995	1999	X	X	X	X	X	X	X	X	X	X
1.6	ALM	1595	55	1997	1999	X	X	X	X	X	X	X	X	X	X
1.6	ABU	1598	55	1993	1999	X	X	X	X	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays
<b>SEAT</b>												
<b>Cordoba 1993 2000</b>												
1.7 SDi	AHB	1718	42	1996	1999	X	X	X	X	X	X	X
1.8	ACC	1781	66	1996	1999	X	X	X	X	X	X	X
1.8	ADZ	1781	66	1994	1999	X	X	X	X	X	X	X
1.8	ABS	1781	66	1993	1996	X	X	X	X	X	X	X
1.8 16V	ADL	1781	95	1994	1999	X	X	X	X	X	X	X
1.9 D	1Y	1896	47	1993	1999	X	X	X	X	X	X	X
1.9 SDi	AEY	1896	47	1996	1999	X	X	X	X	X	X	X
1.9 TD	AAZ	1896	55	1993	1997	X	X	X	X	X	X	X
1.9 TDi	1Z	1896	66	1996	1997	X	X	X	X	X	X	X
1.9 TDi	AFN	1896	81	1996	1999	X	X	X	X	X	X	X
1.9 TDi	AHU	1896	66	1996	1999	X	X	X	X	X	X	X
2.0	AGG	1984	85	1996	1999	X	X	X	X	X	X	X
2.0	2E	1984	85	1993	1999	X	X	X	X	X	X	X
2.0 16V	ABF	1984	110	1996	1999	X	X	X	X	X	X	X
<b>Cordoba 1999 2002</b>												
1.0	ALD	999	37	1999	2002	X	X	X	X	X	X	X
1.0	ANV	999	37	1999	2002	X	X	X	X	X	X	X
1.0	AUC	999	37	2000	2002	X	X	X	X	X	X	X
1.0 16V	AFR	999	51	2000	2002	X	X	X	X	X	X	X
1.0 16V	AVZ	999	51	2000	2002	X	X	X	X	X	X	X
1.4	AKK	1390	44	1999	2002	X	X	X	X	X	X	X
1.4	ANW	1390	44	1999	2002	X	X	X	X	X	X	X
1.4	AUD	1390	44	1999	2002	X	X	X	X	X	X	X
1.4 16V	APE	1390	55	1999	2002	X	X	X	X	X	X	X
1.4 16V	AQQ	1390	74	1999	2002	X	X	X	X	X	X	X
1.4 16V	AUA	1390	55	2000	2002	X	X	X	X	X	X	X
1.4 16V	AUB	1390	74	2001	2002	X	X	X	X	X	X	X
1.6	AEH	1595	74	1999	2002	X	X	X	X	X	X	X
1.6	AKL	1595	74	1999	2002	X	X	X	X	X	X	X
1.6	ALM	1595	55	1999	2002	X	X	X	X	X	X	X
1.6	APF	1595	74	1999	2000	X	X	X	X	X	X	X
1.6	AUR	1595	74	2000	2002	X	X	X	X	X	X	X
1.8 20V Turbo	AQX	1781	115	1999	2002	X	X	X	X	X	X	X
1.8 20V Turbo	AYP	1781	115	2000	2002	X	X	X	X	X	X	X
1.9 SDi	AGP	1896	50	1999	2002	X	X	X	X	X	X	X
1.9 SDi	AQM	1896	50	1999	2002	X	X	X	X	X	X	X
1.9 TDi	AGR	1896	66	1999	2002	X	X	X	X	X	X	X

Legend: N = new, X = present



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>SEAT</b>											
<b>Cordoba 1999 2002</b>											
1.9 TDi	ALH	1896	81	1999	2002	X	X	X	X	X	X
1.9 TDi	ASV	1896	81	1999	2002	X	X	X	X	X	X
<b>Cordoba 2003</b>											
1.2 16V	AZQ	1198	47	2003		X	X	X		X	X
1.4 16V	AUB	1390	74	2003		X	X	X		X	X
1.4 16V	BBY	1390	55	2003		X	X	X		X	X
1.4 16V	BBZ	1390	74	2003		X	X	X		X	X
1.4 TDi	AMF	1422	55	2003		X	X	X		X	X
1.9 SDi	ASY	1896	47	2003		X	X	X		X	X
1.9 TDi	ASZ	1896	96	2003		X	X	X		X	X
1.9 TDi	ATD	1896	74	2003		X	X	X		X	X
<b>Ibiza 1999 2002</b>											
1.0	ALD	999	37	1999	2002	X	X	X	X	X	X
1.0	ANV	999	37	1999	2002	X	X	X	X	X	X
1.0	AUC	999	37	2000	2002	X	X	X	X	X	X
1.0 16V	AFR	999	51	2000	2002	X	X	X	X	X	X
1.0 16V	AVZ	999	51	2000	2002	X	X	X	X	X	X
1.4	AKK	1390	44	1999	2002	X	X	X	X	X	X
1.4	ANW	1390	44	1999	2002	X	X	X	X	X	X
1.4	AUD	1390	44	1999	2002	X	X	X	X	X	X
1.4 16V	APE	1390	55	1999	2000	X	X	X	X	X	X
1.4 16V	AQQ	1390	74	1999	2000	X	X	X	X	X	X
1.4 16V	AUA	1390	55	2000	2002	X	X	X	X	X	X
1.4 16V	AUB	1390	74	2001	2002	X	X	X	X	X	X
1.6	AEH	1595	74	1999	2002	X	X	X	X	X	X
1.6	AKL	1595	74	1999	2002	X	X	X	X	X	X
1.6	ALM	1598	55	1999	2002	X	X	X	X	X	X
1.6	APF	1595	74	1999	2000	X	X	X	X	X	X
1.6	AUR	1595	74	2000	2002	X	X	X	X	X	X
1.8 20V Turbo	AQX	1781	115	1999	2002	X	X	X	X	X	X
1.8 20V Turbo	AYP	1781	115	2000	2002	X	X	X	X	X	X
1.9 SDi	AGP	1896	50	1999	2002	X	X	X	X	X	X
1.9 SDi	AQM	1896	50	1999	2002	X	X	X	X	X	X
1.9 TDi	AGR	1896	66	1999	2002	X	X	X	X	X	X
1.9 TDi	ALH	1896	81	1999	2002	X	X	X	X	X	X
1.9 TDi (Cupra)	ASV	1896	81	1999	2002	X	X	X	X	X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Air Cond.	Wir. Diagr.	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine					
<b>SEAT</b>															
<b>Ibiza 2002</b>															
1.2 12V	AZQ	1198	47	2002	2005	X	X	X	X	X	X	X	X	X	X
1.4 16V	AUB	1390	74	2002	2003	X	X	X	X	X	X	X	X	X	X
1.4 16V	BBY	1390	55	2002	2004	X	X	X	X	X	X	X	X	X	X
1.4 16V	BBZ	1390	74	2002		X	X	X	X	X	X	X	X	X	X
1.4 TDi	AMF	1422	55	2003		X	X	X	X	X	X	X	X	X	X
1.8 20V Turbo	BJX	1781	110	2005		X	X	X	X	X	N	X	X	X	X
1.8 20V Turbo	BKV	1781	110	2005		X	X	X	X	X	N	X	X	X	X
1.8 20V Turbo	BLZ	1781	132	2005		X	X	X	X	X	N	X	X	X	X
1.8 20V Turbo Cupra	BBU	1781	132	2004		X	X	X	X	X	N	X	X	X	X
1.9 SDi	ASY	1896	47	2002		X	X	X	X	X	X	X	X	X	X
1.9 TDi	ASZ	1896	96	2002		X	X	X	X	X	X	X	X	X	X
1.9 TDi	ATD	1896	74	2002		X	X	X	X	X	X	X	X	X	X
2.0	AZL	1984	85	2003	2005	X	X	X	X	N	X	X	X	X	X
2.0	BBX	1984	85	2003		X	X	X	X	X	N	X	X	X	X
<b>Ibiza 1984 1993</b>															
0.9	146A.000	903	32	1986	1993	X	X	X	X	X	X	X	X	X	X
1.2	021A.1000	1193	46	1984	1993	X	X	X	X	X	X	X	X	X	X
1.2 i	021C.1000	1193	52	1990	1993	X	X	X	X	X	X	X	X	X	X
1.5	021A.2000	1461	63	1984	1993	X	X	X	X	X	X	X	X	X	X
1.5 i	021C.2000	1461	66	1989	1993	X	X	X	X	X	X	X	X	X	X
1.5 SXi	021B.2000	1461	74	1988	1993	X	X	X	X	X	X	X	X	X	X
1.7 D	138A.5000	1714	41	1984	1993	X	X	X	X	X	X	X	X	X	X
1.7 i	021C3.000	1675	72	1991	1993	X	X	X	X	X	X	X	X	X	X
<b>Ibiza 1993 2000</b>															
1.0	AAU	1043	33	1993	1999	X	X	X	X	X	X	X	X	X	X
1.0	AER	999	37	1996	1999	X	X	X	X	X	X	X	X	X	X
1.3	2G	1272	40	1993	1994	X	X	X	X	X	X	X	X	X	X
1.3	AAV	1272	40	1993	1994	X	X	X	X	X	X	X	X	X	X
1.4	AEX	1390	44	1996	1998	X	X	X	X	X	X	X	X	X	X
1.4	APQ	1391	44	1997	1999	X	X	X	X	X	X	X	X	X	X
1.4	ABD	1391	44	1993	1996	X	X	X	X	X	X	X	X	X	X
1.4 16V	AFH	1391	74	1997	1999	X	X	X	X	X	X	X	X	X	X
1.6	1F	1595	55	1994	1997	X	X	X	X	X	X	X	X	X	X
1.6	AEE	1598	55	1997	1999	X	X	X	X	X	X	X	X	X	X
1.6	AFT	1595	74	1996	1999	X	X	X	X	X	X	X	X	X	X
1.6	ABU	1598	55	1993	1999	X	X	X	X	X	X	X	X	X	X
1.7 SDi	AHB	1718	42	1997	1999	X	X	X	X	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays
<b>SEAT</b>												
<b>Ibiza</b>	<b>1993</b>	<b>2000</b>										
1.8	ACC	1781	63	1994	1999	X	X	X	X	X		X
1.8	ADZ	1781	66	1994	1999	X	X	X	X	X	X	X
1.8	ABS	1781	66	1993	1999	X	X	X	X	X	X	X
1.8 16V	ADL	1781	95	1993	1999	X	X	X	X	X	X	X
1.9 D	1Y	1896	47	1993	1999	X	X	X	X	X	X	X
1.9 SDi	AEY	1896	47	1995	1999	X	X	X	X	X	X	X
1.9 TD	AAZ	1896	55	1993	1997	X	X	X	X	X	X	X
1.9 TDi	1Z	1896	66	1996	1997	X	X	X	X	X	X	X
1.9 TDi	AFN	1896	81	1997	1999	X	X	X	X	X	X	X
1.9 TDi	AHU	1896	66	1997	1999	X	X	X	X	X	X	X
2.0	2E	1984	85	1993	1997	X	X	X	X	X	X	X
2.0	AGG	1984	85	1996	1999	X	X	X	X	X	X	X
2.0 16V	ABF	1984	110	1996	1999	X	X	X	X	X	X	X
<b>Inca</b>												
<b>1995</b>	<b>2002</b>											
1.4	AEX	1390	44	1996	1998	X	X	X	X	X	X	X
1.4	AKV	1390	44	1996	2000	X	X	X	X	X	X	X
1.4	APQ	1390	44	1998	2002	X	X	X	X	X	X	X
1.4	AUD	1390	44	2000	2002	X	X	X	X	X	X	X
1.4 16V	AUA	1390	55	2000	2002	X	X	X	X	X	X	X
1.6	1F	1598	55	1996	1998	X	X	X	X	X	X	X
1.6	AEE	1598	55	1996	2000	X	X	X	X	X	X	X
1.6	ALM	1598	55	1996	2000	X	X	X	X	X	X	X
1.7 SDi	AHB	1718	42	1996	2000	X	X	X	X	X	X	X
1.9 D	1Y	1896	47	1996	2002	X	X	X	X	X	X	X
1.9 SDi	AEY	1896	47	1996	2002	X	X	X	X	X	X	X
1.9 SDi	AGP	1896	50	2000	2002	X	X	X	X	X	X	X
1.9 SDi	AYQ	1896	47	2000	2002	X	X	X	X	X	X	X
<b>Leon</b>												
<b>1999</b>	<b>2005</b>											
1.4 16V	AHW	1390	55	1999	2005	X	X	X	X	X	X	X
1.4 16V	APE	1390	55	1999	2000	X	X	X	X	X	X	X
1.4 16V	AUA	1390	55	2000	2005	X	X	X	X	X	X	X
1.4 16V	AXP	1390	55	2000	2002	X	X	X	X	X	X	X
1.4 16V	BCA	1390	55	2002	2002	X	X	X	X	X	X	X
1.6	AEH	1595	74	1999	2005	X	X	X	X	X	X	X
1.6	AKL	1595	74	1999	2005	X	X	X	X	X	X	X
1.6	APF	1595	74	2000	2005	X	X	X	X	X	X	X
1.6 16V	ATN	1597	77	2000	2005	X	X	X	X	X	X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>SEAT</b>											
<b>Leon 1999 2005</b>											
1.6 16V	AUS	1597	77	2000	2001	X	X	X	X	X	X
1.6 16V	AZD	1597	77	2000	2002	X	X	X	X	X	X
1.6 16V	BCB	1597	77	2002	2005	X	X	X	X	X	X
1.8 20V	AGN	1781	92	1999	2005	X	X	X	X	X	X
1.8 20V	APG	1781	92	2000	2005	X	X	X	X	X	X
1.8 20V	APT	1781	92	2000	2005	X	X	X	X	X	X
1.8 20V Turbo	AJQ	1781	132	2000	2001	X	X	X	X	X	X
1.8 20V Turbo	APP	1781	132	1999	2005	X	X	X	X	X	X
1.8 20V Turbo	ARY	1781	132	2000	2002	X	X	X	X	X	X
1.8 20V Turbo	AUQ	1781	132	2000	2005	X	X	X	X	X	X
1.8 20V Turbo (Cupra-R)	AMK	1781	154	2002	2005	X	X	X	X	X	X
1.9 SDi	AQM	1896	50	2000	2002	X	X	X	X	X	X
1.9 TDi	AGR	1896	66	1999	2005	X	X	X	X	X	X
1.9 TDi	AHF	1896	81	1999	2002	X	X	X	X	X	X
1.9 TDi	ALH	1896	66	1999	2005	X	X	X	X	X	X
1.9 TDi	ARL	1896	110	2000	2002	X	X	X	X	X	X
1.9 TDi	ASV	1896	81	1999	2005	X	X	X	X	X	X
1.9 TDi	ASZ	1896	96	2003	2005	X	X	X	X	X	X
2.3 VR5	AGZ	2324	110	1998	2000	X	X	X	X	X	X
2.3 VR5	AQN	2324	125	2000	2005	X	X	X	X	X	X
2.8 Cupra 24V	AUE	2792	150	2001	2002	X	X	X	X	X	X
2.8 Cupra 24V	BDE	2792	150	2001	2002	X	X	X	X	X	X
<b>Leon 2006</b>											
1.6 MPi	BGU	1596	75	2006		X	X	X	X	X	X
1.6 MPi	BSE	1596	75	2006		X	X	X	X	X	X
1.9 TDi	BKC	1886	77	2006		X	X	X	X	X	X
1.9 TDi	BLS	1886	77	2006		X	X	X	X	X	X
2.0 16V FSi	BLR	1984	110	2006		X	X	X	X	X	X
2.0 16V FSi	BVY	1984	110	2006		X	X	X	X	X	X
2.0 16V FSi	BWA	1984	147	2006		X	X	X	X	X	X
2.0 16V TDi	AZV	1968	100	2006		X	X	X	X	X	X
2.0 16V TDi	BKD	1968	103	2006		X	X	X	X	X	X
2.0 TDi	BMM	1968	103	2006		X	X	X	X	X	X
<b>Malaga 1985 1992</b>											
1.2	021A.1000	1193	46	1985	1988	X	X	X	X	X	X
1.2 i	021C.1000	1193	52	1989	1993	X	X	X	X	X	X
1.5	021A.2000	1461	63	1985	1989	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>SEAT</b>											
<b>Malaga 1985 1992</b>											
1.5 i	021A/B2000	1461	66	1986	1989	X	X	X	X	X	X
1.5 i	021A/B2000	1461	66	1989	1992	X	X	X	X	X	X
1.7 D	138A.5000	1714	40	1985	1992	X	X	X	X	X	X
<b>Marbella 1987 2000</b>											
0.8	08NCA	843	25	1990	2000	X	X	X	X	X	X
0.8	100GL(DG)	843	25	1987	1990	X	X	X	X	X	X
0.9	09-NCA	903	29	1990	2000	X	X	X	X	X	X
0.9	100GL-7000	903	29	1987	1990	X	X	X	X	X	X
<b>Terra 1987 2000</b>											
0.9	09 NCA	903	29	1987	1990	X	X	X	X	X	X
0.9	09 NCA	903	29	1990	2000	X	X	X	X	X	X
1.3 D	MN	1272	33	1990	1994	X	X	X	X	X	X
1.4 D	1W	1398	35	1990	2000	X	X	X	X	X	X
<b>Toledo 1991 1999</b>											
1.6	1F	1595	52	1991	1994	X	X	X	X	X	X
1.6	1F	1595	55	1994	1998	X	X	X	X	X	X
1.6	ABN	1595	55	1992	1994	X	X	X	X	X	X
1.6	AFT	1595	74	1996	1999	X	X	X	X	X	X
1.6	AKS	1595	74	1997	1999	X	X	X	X	X	X
1.6	EZ	1595	55	1991	1994	X	X	X	X	X	X
1.8	ABS	1781	66	1993	1999	X	X	X	X	X	X
1.8	ACC	1781	63	1994	1999	X	X	X	X	X	X
1.8	ADZ	1781	66	1994	1999	X	X	X	X	X	X
1.8	RP	1781	66	1991	1994	X	X	X	X	X	X
1.8 16V	KR	1781	102	1991	1994	X	X	X	X	X	X
1.8 16V	PL	1781	95	1991	1994	X	X	X	X	X	X
1.9 D	1Y	1896	50	1991	1999	X	X	X	X	X	X
1.9 TD	AAZ	1896	55	1991	1997	X	X	X	X	X	X
1.9 TDi	1Z	1896	66	1995	1999	X	X	X	X	X	X
1.9 TDi	AFN	1896	81	1996	1998	X	X	X	X	X	X
1.9 TDi	AHU	1896	66	1996	1998	X	X	X	X	X	X
2.0	2E	1984	85	1991	1994	X	X	X	X	X	X
2.0	2E	1984	85	1994	1999	X	X	X	X	X	X
2.0	AGG	1984	85	1996	1999	X	X	X	X	X	X
2.0 16V	ABF	1984	110	1994	1999	X	X	X	X	X	X
<b>Toledo 1999 2005</b>											
1.4	APE	1390	55	1999	2000	X	X	X	X	X	X

Legend: N = new, X = present

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>SEAT</b>											
<b>Toledo</b>	<b>1999</b>	<b>2005</b>									
1.4 16V	AHW	1390	55	1999	2002	X	X	X	X	X	X
1.4 16V	AUA	1390	55	2000	2005	X	X	X	X	X	X
1.4 16V	AXP	1390	55	2000	2005	X	X	X	X	X	X
1.4 16V	BCA	1390	55	2002	2002	X	X	X	X	X	X
1.6	AEH	1595	74	1998	2005	X	X	X	X	X	X
1.6	AKL	1595	74	1998	2005	X	X	X	X	X	X
1.6	APF	1595	74	1999	2005	X	X	X	X	X	X
1.6 16V	AUS	1597	77	2000	2001	X	X	X	X	X	X
1.6 16V	AZD	1597	77	2000	2002	X	X	X	X	X	X
1.6 16V	BCB	1597	77	2002	2005	X	X	X	X	X	X
1.8 20V	AGN	1781	92	1998	2005	X	X	X	X	X	X
1.8 20V	APG	1781	92	1999	2005	X	X	X	X	X	X
1.8 20V	APT	1781	92	2000	2005	X	X	X	X	X	X
1.8 20V Turbo	AJQ	1781	132	2000	2005	X	X	X	X	X	X
1.8 20V Turbo	AMK	1781	154	2002	2005	X	X	X	X	X	X
1.8 20V Turbo	AUQ	1781	132	2002	2005	X	X	X	X	X	X
1.9 SDi	AQM	1896	50	2000	2002	X	X	X	X	X	X
1.9 TDi	AGR	1896	66	1999	2005	X	X	X	X	X	X
1.9 TDi	AHF	1896	81	1999	2002	X	X	X	X	X	X
1.9 TDi	ALH	1896	66	2000	2005	X	X	X	X	X	X
1.9 TDi	ARL	1896	110	2000	2003	X	X	X	X	X	X
1.9 TDi	ASV	1896	81	2000	2005	X	X	X	X	X	X
1.9 TDi	ASZ	1896	96	2003	2005	X	X	X	X	X	X
2.3 VR5	AGZ	2324	110	1998	2000	X	X	X	X	X	X
2.3 VR5	AQN	2324	125	2000	2005	X	X	X	X	X	X
<b>Toledo 2005</b>											
1.6 MPi	BGU	1595	75	2005		X	X	X	X	X	X
1.6 MPi	BSE	1596	75	2005		X	X	X	X	X	X
1.6 MPi	BSF	1596	75	2005		X	X	X	X	X	X
1.9 TDi	BJB	1896	77	2005		X	X	X	X	X	X
1.9 TDi	BKC	1896	77	2005		X	X	X	X	X	X
1.9 TDi	BLS	1896	77	2006		X	X	X	X	X	X
2.0 16V FSi	BLR	1984	110	2005		X	X	X	X	X	X
2.0 16V FSi	BLY	1984	110	2005		X	X	X	X	X	X
2.0 16V FSi	BVY	1984	110	2005		X	X	X	X	X	X
2.0 16V FSi	BVZ	1984	110	2005		X	X	X	X	X	X
2.0 16V TDi	AZV	1968	100	2005		X	X	X	X	X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagram	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>SEAT</b>													
<b>Toledo 2005</b>													
2.0 16V TDi	BKD	1968	103	2005		X	X	X		X	X		X
2.0 TDi	BMM	1968	103	2005		X	X	X		X	X		X
<b>SKODA</b>													
<b>Fabia 2000 2007</b>													
1.0	AQV	997	37	2001	2003	X	X	X	X	X	X		X
1.0	ARV	997	37	2001	2003	X	X	X	X	X	X	X	X
1.0	ATY	997	37	1999	2003	X	X	X	X	X	X	X	X
1.2	AWY	1198	40	2002	2004	X	X	X	X	N	X	X	X
1.2	BMD	1198	40	2004	2007	X	X	X	X	N	X	X	X
1.2 12V	AZQ	1198	47	2003	2005	X	X	X	X	N	X	X	X
1.2 12V	BME	1198	47	2004	2007	X	X	X	X	N	X	X	X
1.4	AME	1397	50	1999	2003	X	X	X	X	X	X	X	X
1.4	AQW	1397	50	2000	2003	X	X	X	X	X	X	X	X
1.4	ATZ	1397	50	1999	2000	X	X	X	X	X	X	X	X
1.4	AZE	1397	44	2000	2003	X	X	X	X	X	X	X	X
1.4	AZF	1397	44	2000	2003	X	X	X	X	X	X	X	X
1.4 16V	AUA	1390	55	2000	2002	X	X	X	X	X	X	X	X
1.4 16V	AUB	1390	74	1999	2002	X	X	X	X	X	X	X	X
1.4 16V	BBY	1390	55	2002	2004	X	X	X	X	X	X	X	X
1.4 16V	BBZ	1390	74	2002	2007	X	X	X	X	X	X	X	X
1.4 16V	BKY	1390	55	2004	2007	X	X	X	X	N	X	X	X
1.4 16V	BUD	1390	59	2006	2007	X	X	X	X	N	X	X	X
1.4 TDi	AMF	1422	55	2003	2006	X	X	X	X	N	X	X	X
1.4 TDi	BNM	1422	51	2005	2007	X	X	X	X	N	X	X	X
1.4 TDi	BNV	1422	59	2005	2007	X	X	X	X	N	X	X	X
1.9 SDi	ASY	1896	47	1999	2007	X	X	X	X	X	X	X	X
1.9 TDi	ATD	1896	74	2000	2005	X	X	X	X	X	X	X	X
1.9 TDi	AXR	1896	74	2005	2007	X	X	X	X	N	X	X	X
1.9 TDi RS	ASZ	1896	96	2003	2006	X	X	X	X	N	X	X	X
1.9 TDi RS	BLT	1896	96	2005	2007	X	X	X	X	N	X	X	X
2.0	AZL	1984	85	2000	2007	X	X	X	X	X	X	X	X
<b>Fabia II 2007</b>													
1.2	BBM	1198	44	2007		X	X	X		X	X		
1.2 12V	BZG	1198	51	2007		X	X	X		X	X		
1.4 16V	BXW	1390	63	2007		X	X	X		X	X		
1.4 TDi	BNM	1422	51	2007		X	X	X		X	X		
1.4 TDi	BNV	1422	59	2007		X	X	X		X	X		

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>SKODA</b>											
<b>Fabia II 2007</b>											
1.4 TDi DPF	BMS	1422	59	2007		X	X	X	X	X	X
1.6 16V	BTS	1598	77	2007		X	X	X	X	X	X
1.9 TDi	BSW	1896	77	2007		X	X	X	X	X	X
1.9 TDi DPF	BLS	1896	77	2007		X	X	X	X	X	X
<b>Favorit 1989 1994</b>											
1.3	135	1289	46	1988	1991	X	X	X	X	X	X
1.3	135B	1289	40	1993	1994	X	X	X	X	X	X
1.3	135E	1289	40	1991	1993	X	X	X	X	X	X
<b>Felicia 1994 2000</b>											
1.3	135	1289	42	1994	1998	X	X	X	X	X	X
1.3i	135B	1289	40	1994	1997	X	X	X	X	X	X
1.3i	136B	1289	50	1994	1997	X	X	X	X	X	X
1.6i	AEE	1598	55	1995	2000	X	X	X	X	X	X
1.9 D	AEF	1896	47	1995	2000	X	X	X	X	X	X
<b>Octavia II 2004</b>											
1.4	BCA	1390	55	2004	2007	X	X	X	X	X	X
<b>N</b> 1.4	BUD	1390	59	2006		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
1.6	BGU	1595	75	2004	2006	X	X	X	X	X	X
<b>N</b> 1.6	BSE	1595	75	2005		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
<b>N</b> 1.6	BSF	1595	75	2005		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
1.6 FSi	BLF	1598	85	2004		X	X	X	X	<b>N</b>	X
1.9 TDi	BJB	1896	77	2004		X	X	X	X	X	X
1.9 TDi	BKC	1896	77	2004	2007	X	X	X	X	X	X
<b>N</b> 1.9 TDi	BXE	1896	77	2006		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
<b>N</b> 1.9 TDi DPF	BLS	1896	77	2006		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
2.0 16V FSi	BLR	1984	110	2004	2006	X	X	X	X	<b>N</b>	X
2.0 16V FSi	BLX	1984	110	2004	2006	X	X	X	X	<b>N</b>	X
2.0 16V FSi	BLY	1984	110	2004	2006	X	X	X	X	<b>N</b>	X
<b>N</b> 2.0 16V FSi	BVX	1984	110	2005		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
<b>N</b> 2.0 16V FSi	BVY	1984	110	2005		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
<b>N</b> 2.0 16V FSi	BVZ	1984	110	2005		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
2.0 16V TDi	AZV	1968	100	2004		X	X	X	X	X	X
2.0 16V TDi	BKD	1968	103	2004		X	X	X	X	X	X
<b>N</b> 2.0 16V TDi DPF	BMN	1968	125	2006		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
<b>N</b> 2.0 TDi DPF	BMM	1968	103	2005		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>
<b>N</b> 2.0 TFSI	BWA	1984	147	2005		<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>



Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diag. Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diag. Fuses & Relays

**SKODA**

**Octavia Tour 1996**

1.4 16V	AXP	1390	55	2000	2002	X	X	X	X	X	X	X	X	X	X	X	X	X
1.4 16V	BCA	1390	55	2002		X	X	X	X	X	N			X	X		X	X
1.4 8V	AMD	1396	44	1999	2001	X	X	X	X	X	X	X	X	X	X	X	X	X
1.6 8V	AEE	1598	55	1996	2004	X	X	X	X	X	X	X	X	X	X	X	X	X
1.6 8V	AEH	1595	74	1997	2004	X	X	X	X	X	X	X	X	X	X	X	X	X
1.6 8V	AKL	1595	74	1997	2004	X	X	X	X	X	X	X	X	X	X	X	X	X
1.6 8V	AVU	1595	75	2000	2002	X	X	X	X	X	X	X	X	X	X	X	X	X
1.6 8V	BFQ	1595	75	2002		X	X	X	X	X				X	X		X	X
1.8 20V	AGN	1781	92	1996	1999	X	X	X	X	X	X	X	X	X	X	X	X	X
1.8 20V Turbo	AGU	1781	110	1998		X	X	X	X	X	X	X	X	X	X	X	X	X
1.8 20V Turbo	ARZ	1781	110	1999	2000	X	X	X	X	X	X	X	X	X	X	X	X	X
1.8 20V Turbo	AUM	1781	110	2000		X	X	X	X	X	X	X	X	X	X	X	X	X
1.8 20V Turbo 4x4	ARX	1781	110	2000	2004	X	X	X	X	X	X	X	X	X	X	X	X	X
1.8 20V Turbo RS	AUQ	1781	132	2000	2004	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 SDi	AGP	1896	50	1997	2001	X	X	X	X	X			X	X	X	X	X	X
1.9 SDi	AQM	1896	50	2000	2004	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	AGR	1896	66	1996	2004	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	AHF	1896	81	1997	2004	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	ALH	1896	66	2000	2004	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	ASV	1896	81	1999	2004	X	X	X	X	X	N	X	X	X	X	X	X	X
1.9 TDi	ASZ	1896	96	2002	2004	X	X	X	X	X				X	X		X	X
1.9 TDi 4x4	ATD	1896	74	2000		X	X	X	X	X	X	X	X	X	X	X	X	X
2.0 8V	AEG	1984	85	2001	2004	X	X	X	X	X	X	X	X	X	X	X	X	X
2.0 8V	APK	1984	85	2000	2004	X	X	X	X	X	X	X	X	X	X	X	X	X
2.0 8V	AQY	1984	85	1999	2002	X	X	X	X	X	X	X	X	X	X	X	X	X
2.0 8V	AZJ	1984	85	2002	2004	X	X	X	X	X	N			X	X		X	X
2.0 8V 4x4	AZH	1984	85	2000	2002	X	X	X	X	X	X	X	X	X	X	X	X	X

**Superb 2002**

1.8 Turbo	AWT	1781	110	2002		X	X	X	X	X				X	X		X	X
1.9 TDi	AVB	1896	74	2002	2006	X	X	X	X	X	X			X	X		X	X
1.9 TDi	AVF	1896	96	2004		X	X	X	X	X	N			X	X		X	X
1.9 TDi	AWX	1896	96	2002		X	X	X	X	X	X			X	X		X	X
N 1.9 TDi	BPZ	1896	85	2007		N		N	N	N				N	N			
1.9 TDi	BSV	1896	77	2005		X		N	X	N				N	N			
2.0	AZM	1984	85	2002		X	X	X	X	X	X			X	X		X	X
2.0 TDi DPF	BSS	1968	103	2005		X		N	X	N	N			N	N		N	
2.5 V6 TDi	AYM	2496	114	2002	2004	X	X	X	X	X	X			X	X		X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagram	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond. Wir.	Diagr.	
<b>SKODA</b>													
<b>Superb 2002</b>													
2.5 V6 TDi	BDG	2496	120	2003		X	X	X	X	X	N	X	X
2.8 V6 30V	AMX	2771	142	2002		X	X	X	X	X	X	X	X
2.8 V6 30V	BBG	2771	140	2002		X	X	X	X	X	X	X	X
<b>SMART</b>													
<b>W450 Fortwo 1998 2007</b>													
0.6	160.910	599	33	1998	2001	X	X	X	X		X	X	
0.6	160.910	599	40	1998	2001	X	X	X	X		X	X	
0.6	160.910	599	45	2001	2003	X	X	X	X		X	X	
0.6	160.920	599	33	1998	2001	X	X	X	X		X	X	
0.6	160.920	599	40	1998	2001	X	X	X	X		X	X	
0.6	160.920	599	45	2001	2003	X	X	X	X		X	X	
0.7	160.910	698	37	2003	2007	X	X	X	X		X		
0.7	160.920	698	37	2003	2007	X	X	X	X		X		
0.7 BRABUS	160.910	698	55	2003	2007	X	X	X	X		X		
0.7 BRABUS	160.920	698	55	2003	2007	X	X	X	X		X		
0.8 CDi	660.940	799	30	1999	2007	X	X	X	X	X	X	X	
<b>W452 Roadster 2003 2005</b>													
0.7	160.921	698	45	2003	2005	X	X	X	X		X		
0.7	160.922	698	60	2003	2005	X	X	X	X		X		
0.7 BRABUS	160.923	698	75	2003	2005	X	X	X	X		X		
<b>W454 Forfour 2004 2006</b>													
1.1 12V	134.910	1124	55	2004	2006	X	X	X	N	X	X	X	
1.1 12V	134.911	1124	47	2004	2006	X	X	X	N	X	X	X	
1.3 16V	135.930	1332	70	2004	2006	X	X	X	N	X	X	X	
1.5 12V CDi	639.939	1499	50	2004	2006	X	X	X	N	X	X	X	
1.5 12V CDi	639.939	1499	70	2004	2006	X	X	X	N	X	X	X	
1.5 16V	135.950	1499	80	2004	2006	X	X	X	N	X	X	X	
1.5 Turbo (Brabus)	122.950	1468	130	2005	2006	X	X	X	N	X	X	X	
<b>SSANGYONG</b>													
<b>Kyron 2005</b>													
M200 XDi	D20DT	1998	104	2005		X	X	X	X	X			
M270 XDi	D27DT	2696	122	2006		X	X	X	X	X			
M320	G32D	3199	162	2006		X	X	X	X	X			
<b>Musso MJ 1995 2006</b>													
2.0 16V	M161	1998	94	1997	1999	X		X	X	X	X	X	
2.0 16V	M161.940	1998	94	1999	2006	X	X	X	X	X	X	X	

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagram. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagnr. Fuses & Relays
<b>SSANGYONG</b>											
<b>Musso MJ 1995 2006</b>											
2.3 16V	M161	2295	103	1997	2001	X	X	X	X	X	X
2.3 16V	M161.970	2295	110	2001	2006	X	X	X	X	X	X
2.3 D	OM661 (NA)	2299	58	1996	1999	X	X		X	X	X
2.3 TD	OM661 (LA)	2299	74	1999	2006	X	X	X	X		X
2.9 D	OM662 (NA)	2874	70	1996	1999	X	X		X	X	X
2.9 TD	OM662 (LA)	2874	88	1999	2006	X	X	X	X		X
3.2 24V	M162	3199	162	1995	1999	X	X	X	X	X	X
3.2 24V	M162.990	3199	164	1999	2006	X	X	X	X		X
<b>Rexton 2001 2006</b>											
230	G23D (M161)	2295	110	2001	2006	X	X	X	X		
270 XDi	D27DT	2696	121	2004	2006	X	X	X	X		
290 TD	D29ST	2874	88	2001	2006	X	X	X	X		
320	G32D (M162)	3199	162	2001	2006	X	X	X	X		
<b>Rexton II 2006</b>											
270 XDi	D27DT	2696	121	2006		X	X		X		
270 XVT	D27DTP	2696	137	2006		X	X		X		
320	G32D	3199	162	2006		X	X		X		
<b>SUBARU</b>											
<b>Forester 1997 2002</b>											
2.0 16V	EJ20	1994	92	1998	2000	X	X	X	X	X	
2.0 16V	EJ20	1994	92	2000	2002	X	X	X	X	X	
2.0 16V	EJ20J	1994	90	1997	1998	X	X	X	X	X	X
2.0 16V Turbo	EJ205	1994	130	2000	2002	X	X	X	X	X	
2.0 16V Turbo	EJ20G	1994	125	1997	2000	X	X	X	X	X	X
<b>Forester 2003</b>											
2.0 16V	EJ201	1994	92	2003		X	X	X	X	X	X
2.0 16V Turbo	EJ205	1994	130	2003		X	X	X	X	X	X
2.5 16V	EJ251	2457	115	2003		X	X	X	X	X	X
2.5 16V Turbo	EJ255	2457	155	2004		X	X	X	X	X	X
<b>Impreza 1993 2000</b>											
1.6 16V	EJ161	1597	70	1998	2000	X	X	X	X	X	X
1.6 16V	EJ16E	1597	66	1993	1996	X	X	X	X	X	X
1.6 16V	EJ16J	1597	66	1997	1998	X	X	X	X	X	X
1.8 16V	EJ18E	1820	76	1993	1996	X	X	X	X	X	X
1.8 16V	EJ18E	1820	79	1997	1998	X	X	X	X	X	X
2.0 16V	EJ201	1994	92	1998	2000	X	X	X	X	X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>SUBARU</b>													
<b>Impreza 1993 2000</b>													
2.0 16V	EJ20E	1994	85	1995	1996	X	X	X	X	X	X	X	X
2.0 16V	EJ20E	1994	88	1997	1998	X	X	X	X	X	X	X	X
2.0 16V Turbo	EJ205	1994	160	1998	2000	X	X	X	X	X	X	X	X
2.0 16V Turbo	EJ20G	1994	155	1994	1996	X	X	X	X	X	X	X	X
2.0 16V Turbo	EJ20G	1994	155	1997	1998	X	X	X	X	X	X	X	X
<b>Impreza 2001 2006</b>													
1.6 16V	EJ161	1597	70	2001	2006	X	X	X	X	X	X	X	X
2.0 16V	EJ201	1994	92	2001	2006	X	X	X	X	X	X	X	X
2.0 16V WRX STi	EJ207	1994	195	2003	2006	X	X	X	X	X	X	X	X
2.0 16V WRX Turbo	EJ205	1994	160	2001	2003	X	X	X	X	X	X	X	X
2.0 16V WRX Turbo	EJ205	1994	165	2003	2006	X	X	X	X	X	X	X	X
2.5 16V	EJ251	2475	112	2002	2006	X	X	X	X	X	X	X	X
<b>Justy 1984 1988</b>													
1.0	EF10	997	40	1984	1988	X	X	X	X	X	X	X	X
1.0 4x4	EF10	997	40	1984	1988	X	X	X	X	X	X	X	X
1.2	EF12	1189	45	1987	1988	X	X	X	X	X	X	X	X
1.2 4x4	EF12	1189	45	1987	1988	X	X	X	X	X	X	X	X
<b>Justy 1988 1995</b>													
1.0	EF10	997	37	1988	1995	X	X	X	X	X	X	X	X
1.2	EF12	1189	45	1988	1992	X	X	X	X	X	X	X	X
1.2i 9V	EF12 MUJ	1189	54	1993	1995	X	X	X	X	X	X	X	X
<b>Justy 1995 2003</b>													
1.3i	G13BA	1298	50	1995	2003	X	X	X	X	X	X	X	X
<b>Justy G3X 2004</b>													
1.3 16V	M13A	1328	69	2004		X	X	X	X	X	X	X	X
1.5 16V	M15A	1490	73	2004		X	X	X	X	X	X	X	X
<b>Legacy 1989 1993</b>													
1.8 16V	EJ18	1820	76	1989	1991	X	X	X	X	X	X	X	X
1.8i 16V	EJ18	1820	76	1989	1993	X	X	X	X	X	X	X	X
2.0i 16V	EJ20E	1994	85	1991	1993	X	X	X	X	X	X	X	X
2.0i 16V Turbo	EJ20G	1994	147	1991	1993	X	X	X	X	X	X	X	X
2.2i 16V	EJ22E	2212	100	1989	1993	X	X	X	X	X	X	X	X
<b>Legacy 1994 1998</b>													
2.0i 16V	EJ20	1994	85	1994	1997	X	X	X	X	X	X	X	X
2.0i 16V	EJ20	1994	85	1997	1998	X	X	X	X	X	X	X	X
2.2i 16V	EJ22	2212	94	1994	1997	X	X	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>SUBARU</b>											
<b>Legacy 1994 1998</b>											
2.2i 16V	EJ22	2212	96	1997	1998	X	X	X	X	X	X
2.5i 16V	EJ25D	2457	110	1997	1998	X	X	X	X	X	X
<b>Legacy 1999 2003</b>											
2.0 16V	EJ20	1994	92	1998	2000	X	X	X	X	X	X
2.0 16V	EJ20	1994	92	2001	2003	X	X	X	X	X	X
2.5 16V	EJ251	2457	115	1998	2003	X	X	X	X	X	X
3.0 24V	EZ30D	2999	154	2000	2003	X	X	X			
<b>Legacy 2004</b>											
2.0 16V	EJ20	1994	101	2004		X	X	X		X	
2.0 16V GT	EJ20X	1994	180	2004		X	X	X		X	
2.0 16V GT	EJ20Y	1994	190	2005		X	X	X		X	
2.5 16V	EJ25	2457	121	2004		X	X	X		X	
3.0 24V R	EZ30D	3000	180	2004		X	X	X			
<b>Leone 1984 1994</b>											
1.3	EA65	1298	48	1984	1989	X	X	X		X	X
1.3	EA65	1298	48	1990	1994	X	X	X		X	
1.6	EA71	1595	54	1987	1989	X	X	X		X	X
1.6	EA71	1595	55	1990	1994	X	X	X		X	
1.6 4X4	EA71	1595	54	1987	1989	X	X	X		X	X
1.6 4X4	EA71	1595	55	1990	1994	X	X	X		X	
1.8	EA81	1782	66	1986	1989	X	X	X		X	X
1.8 4X4	EA81	1781	66	1990	1994	X	X	X		X	X
1.8 4X4 AM/AN	EA81/82	1781	66	1984	1989	X	X	X		X	X
1.8i	EA82	1781	77	1986	1989	X	X	X		X	X
1.8i 4X4	EA82	1781	72	1990	1994	X	X	X		X	
1.8i 4X4 Turbo	EA82T	1781	96	1990	1994	X	X	X		X	X
1.8i 4X4 Turbo	EA82T	1781	100	1984	1993	X	X	X		X	X
<b>Mini jumbo 1982 1993</b>											
0.7	EK42	665	27	1988	1989	X	X	X		X	X
0.8	EN08	758	31	1989	1993	X	X	X		X	X
<b>SVX 1992 1996</b>											
3.3i	EG33	3319	169	1992	1996	X	X	X		X	X
<b>Vivio 1993 2001</b>											
0.6i	EN07	658	32	1993	2001	X	X	X		X	X
0.6i 4X4	EN07	658	32	1993	2001	X	X	X		X	X
0.6i ECVT	EN07	658	32	1993	2001	X	X	X		X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance		Techn. Drawings		Motor Manag.	Wiring Diagr.	Service Reset	Repair Times		
						Identification	Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	Fuses & Relays		
<b>SUBARU</b>															
<b>XT 1986 1991</b>															
Turbo Coupé	EA82	1781	100	1986	1991		X	X	X	X			X		X
Turbo Coupé 4x4	EA82	1781	100	1986	1991		X	X	X	X			X		X
<b>SUZUKI</b>															
<b>Alto 1986 1994</b>															
0.8 GA,GL	F8B/Y64	796	29	1986	1989	X	X	X	X	X			X		X
0.8 GLX	F8B/Y64	796	29	1989	1994	X	X	X	X	X			X		X
<b>Alto 1994 2002</b>															
1.0i	G10B	993	39	1994	2002	X	X	X		X	N		X		X
<b>Alto 2002</b>															
1.1	F10D	1061	46	2002		X	X	X		X			X		X
<b>Baleno 1995 2000</b>															
1.3i 16V	G13BB	1298	63	1995	2000	X	X	X	X	X			X		X
1.6i 16V	G16B	1590	71	1997	2000	X	X	X	X	X			X		X
1.6i 16V	G16B	1590	73	1995	1997	X	X	X	X	X			X		X
1.8i 16V	J18A	1839	89	1996	2000	X	X	X	X	X			X		X
<b>Baleno 2000 2003</b>															
1.3 16V	G13BB	1298	63	2000	2003	X	X	X	X	X			X		X
1.6 16V	G16B	1590	70	2000	2003	X	X	X	X	X			X		X
1.6 16V 4WD	G16B	1590	70	2000	2003	X	X	X	X	X			X		X
1.8 16V	J18A	1839	89	2000	2003	X	X	X	X	X			X		X
1.8 16V 4WD	J18A	1839	89	2000	2003	X	X	X	X	X			X		X
<b>Cappucino 1994 1999</b>															
SX306	F6A	657	47	1993		X	X	X							X
<b>Carry 1999 2005</b>															
1.3 16V	G13BB	1298	59	1999	2005	X	X	X		X					X
<b>Grand Vitara 1998 2005</b>															
1.6 16V	G16B	1590	69	1998	2005	X	X	X	X	X			X		X
2.0 16V	J20A	1995	94	1998	2005	X	X	X	X	X			X		X
2.0 TD	RF	1998	64	1998	2001	X	X	X	X	X			X		X
2.0 TDi	RHZ	1997	80	2000	2003	X	X	X	X	X			X		X
2.0 TDi 16V	RHW	1997	80	2002	2005	X	X	X	X	X			X		X
2.5 V6	H25A	2493	106	1998	2001	X	X	X	X	X			X		X
2.5 V6	H25A	2493	116	2001	2005	X	X	X	X	X			X		X
XL7 2.0 TDi 16V	RHW	1998	80	2003	2005	X	X	X	X	X			X		X
XL7 2.7 V6	H27A	2736	127	2001	2005	X	X	X	X	X			X		X
XL7 2.7 V6	H27B	2736	135	2003	2005	X	X	X	X	X			X		X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>SUZUKI</b>											
<b>Grand Vitara 2005</b>											
N	1.6 16V	M16A	1586	78	2005	X	X	X	X	X	X
N	1.9 DDiS	F9Q	1870	95	2007	N	N	N	N	N	N
	2.0 16V	J20A	1995	103	2005	X	X	X	X	X	X
N	2.7 V6	H27A	2736	138	2007	N	N	N	N	N	N
<b>Ignis 2000 2003</b>											
	1.3 16V	M13A	1328	61	2000	2003	X	X	X	X	X
	1.5 VVT	M15A	1490	80	2003	2003	X	X	X	X	X
<b>Ignis 2003</b>											
	1.3 VVT	M13A	1328	69	2003		X	X	X	X	X
	1.5 VVT	M15A	1490	73	2003		X	X	X	X	X
<b>Jimny 1999</b>											
	1.3	G13BB	1298	59	1999	2001	X	X	X	X	X
	1.3 16V	M13A	1328	63	2001		X	X	X	X	X
	1.5 DDiS	K9K	1461	48	2004		X	X	X	X	X
<b>Liana 2001</b>											
	1.3i	M13A	1328	66	2001		X	X	X	X	X
	1.6i	M16A	1586	78	2001		X	X	X	X	X
<b>Samurai 1988 2000</b>											
	1.3 SJ50	G13BA	1298	51	1988	2000	X	X	X	X	X
	1.3 SJ70	G13A	1324	43	1988	1990	X	X	X	X	X
	1.3i	G13BA	1298	51	1988	1990	X	X	X	X	X
<b>SJ 1980 1988</b>											
	410	F 10A	970	33	1980	1988	X	X	X	X	X
	413	G 13A	1324	47	1984	1988	X	X	X	X	X
<b>Swift 1984 1989</b>											
	1.0	G 10	993	37	1986	1989	X	X	X	X	X
	1.3	G 13	1324	50	1984	1989	X	X	X	X	X
	1.3	G 13A	1324	50	1986	1989	X	X	X	X	X
	1.3 GTi/GXi	G 13B	1298	74	1986	1989	X	X	X	X	X
<b>Swift 1989 2003</b>											
	1.0i	G 10A	993	39	1991	2003	X	X	X	X	X
	1.3	G 13B	1298	49	1989	1991	X	X	X	X	X
	1.3i	G 13BA	1298	50	1991	2000	X	X	X	X	X
	1.3i GTi	G 13B	1298	74	1989	1996	X	X	X	X	X
	1.6i 16V	G 16B	1590	68	1989	2001	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>SUZUKI</b>											
<b>Swift 2004</b>											
1.3	M13A	1328	68	2004		X	X X X X X			X	X
1.3 DDiS	Z13DT	1248	51	2004		X	X X X X X			X	X X
1.5	M15A	1490	75	2004		X	X X X X X			X	X
<b>SX4 2006</b>											
1.5 16V	M15A	1490	73	2006		X	X X X X X			X	
1.6 16V VVT	M16A	1586	79	2006		X	X X X X X			X	
1.9 TD	D19AA	1910	88	2006		X	X X X X X			X	
<b>Vitara 1988 1998</b>											
1.6	G16A	1590	55	1988	1993	X	X X X X X			X	X X
1.6i	G16A	1590	59	1991	1998	X	X X X X X	X		X	X X
1.6i 16V	G16B	1590	71	1994	1998	X	X X X X X	X		X	X X
2.0 TD	RF	1998	52	1996	1998	X	X X X X X			X	X X
2.0i V6	H20A	1997	100	1995	1998	X	X X X X X				X X
<b>Wagon R+ 1997 2000</b>											
1.0 16V	K10A	996	48	1997	2000	X	X X X X X			X	X X
1.2 16V	K12A	1171	51	1998	2000	X	X X X X X			X	X X
<b>Wagon R+ 2000</b>											
1.0 12V	G10	993	39	2004		X	X X X X X			X	
1.0 12V	G10A	993	39	2000	2004	X	X X X X X			X	
1.3 16V	G13BB	1298	56	2000	2004	X	X X X X X				X
1.3 16V VVT	M13	1328	69	2004		X	X X X X X			X	X
1.3 DDiS	Z13DT	1248	51	2004		X	X X X X X				X
<b>TOYOTA</b>											
<b>4-Runner 1989 1995</b>											
2.4 TD	2L-T	2446	66	1990	1995	X	X X X X X			X	N X
3.0	3VZ-E	2959	105	1989	1995	X	X X X X X			X	X X
3.0 TD	1KZ-T	2982	92	1993	1995	X	X X X X X			X	X X
3.0i	3VZ-FE	2959	104	1993	1995	X	X X X X X			X	X X
<b>Auris 2007</b>											
1.4 16V VVT-i	4ZZ-FE	1398	71	2007		X	X X X X X	N			
1.4 D-4D	1ND-TV	1364	66	2007		X	X X X X X	N			
1.6 16V Dual VVT-i	1ZR-FE	1598	91	2007		X	X X X X X	N			
2.0 16V D-4D	1AD-FTV	1998	93	2007		X	X X X X X	N			
<b>Avensis 1998 2003</b>											
1.6 16V VVT-i	3ZZ-FE	1598	81	2000	2003	X	X X X X X	X		X	X X
1.6i 16V	4A-FE	1587	81	1998	2001	X	X X X X X	X		X	X X

Legend: N = new, X = present



Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>TOYOTA</b>													
<b>Avensis 1998 2003</b>													
1.6i 16V Lean Burn	4A-FE	1587	74	1998	2001	X	X	X	X	X	X	X	X
1.8 16V VVT-i	1ZZ-FE	1794	91	2000	2003	X	X	X	X	X	X	X	X
1.8i 16V Lean Burn	7A-FE	1762	81	1998	2001	X	X	X	X	X	X	X	X
2.0 D4-D	1CD-FTV	1995	85	2000	2003	X	X	X	X	X	X	X	X
2.0 TD	2C-TE	1975	66	1998	2001	X	X	X	X	X	X	X	X
2.0i 16V	3S-FE	1998	94	1998	2001	X	X	X	X	X	X	X	X
2.0i 16V VVT-i D4	1AZ-FE	1998	110	2001	2003	X	X	X	X	X	X	X	X
2.0i 16V VVT-i D4	1AZ-FSE	1998	110	2000	2003	X	X	X	X	X	X	X	X
<b>Avensis 2003</b>													
1.6 16V VVT-i	3ZZ-FE	1598	81	2003		X	X	X	X	X	X	X	X
1.8 16V VVT-i	1ZZ-FE	1794	95	2003		X	X	X	X	X	X	X	X
2.0 16V	1AZ-FNE	1998	100	2003	2006	X	X	X	X	X	X	X	X
2.0 16V VVT-i	1AZ-FE	1998	108	2003		X	X	X	X	X	X	X	X
2.0 16V VVT-i	1AZ-FSE	1998	108	2003		X	X	X	X	X	X	X	X
2.0 D-4D	1AD-FTV	1998	93	2005		X	X	X	X	X	X	X	X
2.0 D-4D	1CD-FTV	1995	85	2003	2006	X	X	X	X	X	X	X	X
2.2 D-4D	2AD-FTV	2231	110	2005		X	X	X	X	X	X	X	X
2.2 D-4D D-CAT	2AD-FHV	2231	130	2005		X	X	X	X	X	X	X	X
2.4 16V VVT-i	2AZ-FSE	2362	120	2004		X	X	X	X	X	X	X	X
<b>Avensis Verso 2001 2006</b>													
1.6 VVT-i	3ZZ-FE	1598	81	2001	2006	X	X	X	X	X	X	X	X
1.8 VVT-i	1ZZ-FE	1794	95	2001	2006	X	X	X	X	X	X	X	X
2.0 D4-D	1CD-FTV	1995	85	2001	2006	X	X	X	X	X	X	X	X
2.0 VVT-i	1AZ-FE	1998	110	2001	2006	X	X	X	X	X	X	X	X
<b>Aygo 2005</b>													
1.0 VVT-i	1KR-FE	998	50	2005		X	X	X	N	X	N	X	X
1.4 DI-D	2WZ-TV	1398	40	2005		X	X	X	N	X	N	X	X
<b>Camry 1986 1992</b>													
1.8	1S	1832	66	1986	1988	X	X	X	X	X	X	X	X
2.0 TD	2C-T	1974	62	1986	1991	X	X	X	X	X	X	X	X
2.0i	3S-FE	1998	94	1986	1991	X	X	X	X	X	X	X	X
2.0i 16V 4WD	3S-FE	1998	86	1987	1991	X	X	X	X	X	X	X	X
2.5i V6	2VZ-FE	2507	118	1988	1991	X	X	X	X	X	X	X	X
<b>Camry 1992 1996</b>													
2.2i	5S-FE	2164	100	1991	1996	X	X	X	X	X	X	X	X
2.2i 16V	5S-FE	2164	100	1991	1996	X	X	X	X	X	X	X	X
3.0i V6 24V	3VZ-FE	2959	136	1991	1996	X	X	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagram. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagnr.	Fuses & Relays
<b>TOYOTA</b>												
<b>Camry 1996 2001</b>												
2.2 16V	5S-FE	2164	96	1996	2001	X	X	X	X	X	X	X
3.0 24V	1MZ-FE	2995	140	1996	2001	X	X	X	X	X	X	X
<b>Camry 2001 2004</b>												
2.0 16V VVT-i	1AZ-FE	1998	110	2001		X	X	X	X	X		X
2.4 16V VVT-i	2AZ-FE	2362	112	2001		X	X	X	X	X		X
3.0 24V VVT-i	1MZ-FE	2995	137	2001		X	X	X	X	X		X
<b>Carina 1984 1988</b>												
1.6	4A-L	1587	62	1984	1988	X	X	X	X	X		X
1.8 i	1S-EL	1832	73	1985	1988	X	X	X	X	X		X
2.0 D	2C	1974	53	1984	1988	X	X	X	X	X		X
<b>Carina 1988 1992</b>												
1.6 16V	4A-F	1588	70	1988	1992	X	X	X	X	X		X
1.6i	4A-FE	1587	70	1990	1992	X	X	X	X	X		X
2.0 D	2C	1974	54	1989	1992	X	X	X	X	X		X
2.0i	3S-FE	1998	94	1988	1992	X	X	X	X	X		X
<b>Carina 1992 1998</b>												
1.6 16V	4A-FE	1587	85	1992	1998	X	X	X	X	X		X
1.6i 16V	4A-FE	1587	79	1992	1998	X	X	X	X	X		X
1.6i 16V Wagon	4A-FE	1587	79	1992	1998	X	X	X	X	X		X
1.8i 16V	7A-FE	1762	77	1994	1995	X	X	X	X	X		X
1.8i 16V	7A-FE	1762	77	1996	1998	X	X	X	X	X		X
1.8i 16V Automatic	7A-FE	1762	77	1994	1995	X	X	X	X	X		X
2.0 D	2C	1975	54	1992	1998	X	X	X	X	X		X
2.0 GTi 16V	3S-GE	1998	116	1992	1998	X	X	X	X	X		X
2.0i 16V	3S-FE	1998	98	1992	1998	X	X	X	X	X		X
<b>Celica 1989 1994</b>												
1.6i 16V	4A-FE	1587	77	1989	1994	X	X	X	X	X		X
2.0i	3S-FE	1998	115	1989	1995	X	X	X	X	X		X
2.0i GTi 16V	3S-GE	1998	115	1989	1994	X	X	X	X	X		X
2.0i Turbo 4WD 16V	3S-GTE	1998	150	1989	1994	X	X	X	X	X		X
2.2i GTi 16V	5S-FE	2164	100	1993	1995	X	X	X	X	X		X
<b>Celica 2000 2006</b>												
1.8 VVT-i	1ZZ-FE	1794	105	2000	2006	X	X	X	X	X		X
1.8 VVTL-i	2ZZ-GE	1796	141	2001	2006	X	X	X	X	X		X
<b>Celica 1985 1989</b>												
1.6 ST	4A-L	1587	63	1985	1989	X	X	X	X	X		X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>TOYOTA</b>													
<b>Celica 1985 1989</b>													
2.0 GTi 16V T.C.	3S-GE	1998	110	1985	1988	X	X	X	X	X		X	X
2.0i Turbo 4x4 16V	3S-GTE	1998	138	1987	1989	X	X	X	X	X		X	X
<b>Celica 1994 2000</b>													
1.8i	7A-FE	1762	85	1994	2000	X	X	X	X	X		X	X
2.0i	3S-FE	1998	115	1995	2000	X	X	X	X	X		X	X
2.0i GT	3S-GE	1998	127	1994	2000	X	X	X	X	X		X	X
2.2i	5S-FE	2164	101	1995	2000	X	X	X	X	X		X	X
<b>Corolla 1997 2000</b>													
1.3 16V	4E-FE	1332	63	1997	2000	X	X	X	X	X		X	X
1.6 16V	4A-FE	1587	79	1997	2000	X	X	X	X	X		X	X
1.6 16V	4A-FE	1587	81	1997	2000	X	X	X	X	X		X	X
1.8 16V	7A-FE	1762	81	1997	2000	X	X	X	X	X		X	X
1.9 D	1WZ	1867	51	1999	2000	X	X	X	X	X		X	X
2.0 D	2C-E	1975	53	1997	1999	X	X	X	X	X		X	X
<b>Corolla 1987 1992</b>													
1.3	2E	1295	55	1987	1992	X	X	X	X	X		X	X
1.3i 12V	2E-E	1295	60	1990	1992	X	X	X	X	X		X	X
1.3i 12V	2E-E	1295	60	1990	1992	X	X	X	X	X		X	X
1.6	4A-F	1587	66	1987	1992	X	X	X	X	X		X	X
1.6 4WD	4A-F	1587	69	1988	1991	X	X	X	X	X		X	X
1.6 4WD Wagon	4A-F	1587	69	1988	1991	X	X	X	X	X		X	X
1.6 GTi	4A-GE	1587	92	1987	1992	X	X	X	X	X		X	X
1.6i 16V	4A-FE	1587	77	1989	1992	X	X	X	X	X		X	X
1.6i 16V	4A-FE	1587	77	1990	1992	X	X	X	X	X		X	X
1.6i 4WD Sedan	4A-FE	1587	77	1987	1992	X	X	X	X	X		X	X
1.6i 4WD Wagon	4A-FE	1587	77	1987	1992	X	X	X	X	X		X	X
1.8 D	1C	1839	47	1987	1992	X	X	X	X	X		X	X
1.8 D Wagon	1C	1839	47	1990	1992	X	X	X	X	X		X	X
<b>Corolla 1992 1997</b>													
1.3 16V	4E-FE	1332	65	1992	1997	X	X	X	X	X		X	X
1.3 16V wagon	4E-FE	1332	65	1992	1997	X	X	X	X	X		X	X
1.6 16V	4A-FE	1587	84	1992	1997	X	X	X	X	X		X	X
1.6 16V wagon	4A-FE	1587	84	1992	1997	X	X	X	X	X		X	X
1.8 16V	7A-FE	1762	87	1993	1997	X	X	X	X	X		X	X
2.0 D	2C	1975	54	1992	1997	X	X	X	X	X		X	X
2.0 D wagon	2C	1975	54	1992	1997	X	X	X	X	X		X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>TOYOTA</b>											
<b>Corolla 2000 2002</b>											
1.4 VVT-i	4ZZ-FE	1398	71	2000	2002	X	X	X	X	X	X
1.6 VVT-i	3ZZ-FE	1598	81	2000	2002	X	X	X	X	X	X
1.9 D	1WZ	1867	51	2000	2001	X	X	X	X	X	X
2.0 D4-D	1CD-FTV	1995	66	2000	2002	X	X	X	X	X	X
<b>Corolla 2001</b>											
1.4 VVT-i	4ZZ-FE	1398	71	2001		X	X	X	X	X	X
1.6 VVT-i	3ZZ-FE	1598	81	2001		X	X	X	X	X	X
1.6 VVT-i	3ZZ-FNE	1598	79	2001	2003	X	X	X	X	X	X
1.8 VVT-i	1ZZ-FE	1794	99	2001		X	X	X	X	X	X
1.8 VVTL-i	2ZZ-GE	1796	141	2001		X	X	X	X	X	X
2.0 D4-D 110	1CD-FTV	1995	81	2001	2003	X	X	X	X	X	X
2.0 D4-D 116	1CD-FTV	1995	85	2003		X	X	X	X	X	X
2.0 D4-D 90	1CD-FTV	1995	66	2001		X	X	X	X	X	X
<b>Corolla Verso 2001 2004</b>											
1.4 VVT-i	4ZZ-FE	1398	71	2001	2004	X	X	X	X	X	X
1.6 VVT-i	3ZZ-FE	1598	81	2001	2004	X	X	X	X	X	X
1.8 VVT-i	1ZZ-FE	1794	99	2001	2004	X	X	X	X	X	X
1.8 VVTL-i	2ZZ-GE	1796	141	2001	2004	X	X	X	X	X	X
2.0 D4-D 90	1CD-FTV	1995	66	2001	2004	X	X	X	X	X	X
<b>Corolla Verso 2004</b>											
1.6 16V VVT-i	3ZZ-FE	1598	81	2004		X	X	X	X	X	X
1.8 16V VVT-i	1ZZ-FE	1794	95	2004		X	X	X	X	X	X
2.0 D-4D	1CD-FTV	1995	85	2004	2006	X	X	X	X	X	X
2.2 D-4D	2AD-FTV	2231	100	2005		X	X	X	X	X	X
2.2 D-4D D-CAT	2AD-FHV	2231	130	2005		X	X	X	X	X	X
<b>Hi-Ace RCH &amp; KLH 2001 2006</b>											
2.4 (RCH12,22)	2RZ-E	2438	85	2001	2004	X		X	X	X	X
2.5 D-4D (KLH12,18,22,28)	2KD-FTV	2494	65	2001	2006	X	X	X	X	X	N
2.5 D-4D (KLH12,18,22,28)	2KD-FTV	2494	75	2001	2006	X	X	X	X	X	N
2.7 (RCH13,19,22,23,39)	3RZ-FE	2694	106	2001	2006	X	X	X	X	X	
<b>Hi-Ace RCH &amp; LXH 1996 2002</b>											
2.4 (RCH12,13,19,23,29)	2RZ-E	2438	85	1999	2002	X	X	X	X	X	X
2.4 (RCH12,18)	2RZ-E	2438	85	1996	1997	X	X	X	X	X	X
2.4 (RCH12,18,22,28)	2RZ-E	2438	85	1997	1999	X	X	X	X	X	X
2.4 D (LXH12,18)	2L	2446	58	1996	1997	X	X	X	X	X	X
2.4 D (LXH12,18,22,28)	2L	2446	58	1997	1999	X	X	X	X	X	X
2.4 D (LXH12,18,22,28)	2L	2446	58	1999	2002	X	X	X	X	X	X

Legend: N = new, X = present

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>TOYOTA</b>											
<b>Hi-Ace RCH &amp; LXH 1996 2002</b>											
2.4 D (LXH12,18,22,28)	2L-T	2446	66	1999	2002	X	X	X	X	X	X
2.4 DT (LHX18,22,28)	2L-T	2446	66	1997	1999	X	X	X	X	X	X
2.4 DT (LXH12,18)	2L-T	2446	66	1996	1997	X	X	X	X	X	X
2.7 (RCH13,19,23,29)	3RZ-FE	2694	106	1999	2002	X	X	X	X	X	X
<b>Hi-Ace RZH &amp; LH 1989 1996</b>											
2.0 (RZH 102/112)	1RZ	1998	74	1989	1996	X	X	X	X	X	X
2.4 (RZH)	2RZ	2438	88	1989	1996	X	X	X	X	X	X
2.4 D (LH)	2L	2446	57	1989	1996	X	X	X	X	X	X
2.4 D 4x4 (LH 109/119)	2L	2446	57	1989	1996	X	X	X	X	X	X
2.4 i 4x4 (RZH 108/118)	2RZ-E	2438	88	1989	1996	X	X	X	X	X	X
2.4i (RZH)	2RZ-E	2446	88	1989	1996	X	X	X	X	X	X
2.8 D (LH)	3L	2779	67	1989	1996	X	X	X	X	X	X
<b>Hi-lux 1984 1997</b>											
1.8	2Y	1812	58	1984	1988	X	X	X	X	X	X
2.2 4x4	4Y	2237	68	1989	1993	X	X	X	X	X	X
2.2i 4x4	4Y-E	2237	72	1989	1997	X	X	X	X	X	X
2.3 4x4	22R	2366	81	1988	1997	X	X	X	X	X	X
2.3i 4x4	22R-E	2366	81	1988	1997	X	X	X	X	X	X
2.4 D	2L	2446	55	1985	1988	X	X	X	X	X	X
2.4 D	2L	2446	60	1989	1997	X	X	X	X	X	X
2.4 D 4x4	2L	2446	55	1984	1988	X	X	X	X	X	X
2.4 D 4x4	2L	2446	60	1989	1997	X	X	X	X	X	X
<b>Land Cruiser 100 1998</b>											
4.2 TD (HDJ100)	1HD-FTE	4164	150	1998		X	X	X	X	X	X
4.7 V8 (UZJ100)	2UZ-FE	4664	173	1998		X	X	X	N	X	X
<b>Land Cruiser 300 / Prado 2002</b>											
2.7 (RZJ120,125)	3RZ-FE	2694	110	2002	2004	X	X	X	X	X	X
2.7 (TRJ120,125)	2TR-FE	2694	120	2004		X	X	X	X	X	X
3.0 (KZJ120)	1KZ-TE	2982	96	2002		X	X	X	X	X	X
3.0 (LJ120,125)	5L-E	2986	70	2002		X	X	X	X	X	X
3.0 TD (KDJ120,125)	1KD-FTV	2982	120	2002		X	X	X	X	X	X
4.0 V6 (GRJ120,125)	1GR-FE	3956	183	2003		X	X	X	X	X	X
<b>Land Cruiser 70 1984 1999</b>											
2.4 (RJ70,73)	22R	2366	81	1984	1995	X	X	X	X	X	X
2.4 D (LJ70,72,73)	2L	2446	55	1985	1995	X	X	X	X	X	X
2.4 TD (LJ70,72,73)	2L-T	2446	66	1990	1995	X	X	X	X	X	X
3.4 D (BJ60,70,73,75)	3B	3431	66	1984	1990	X	X	X	X	X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>TOYOTA</b>											
<b>Land Cruiser 70 1984 1999</b>											
3.4 TD (BJ60,70,73,75)	13B-T	3431	92	1986	1990	X	X	X	X	X	X
3.5 D (PZJ70,73,75)	1PZ	3469	85	1990	1998	X	X	X	X	X	X
4.0 D (HJ60,61,75)	2H	3980	74	1986	1990	X	X	X	X	X	X
4.0 TD (HJ60,61,75)	12H-T	3980	100	1987	1990	X	X	X	X	X	X
4.2 D (HZJ70,73,75)	1HZ	4164	96	1990	1999	X	X	X	X	X	X
4.2 TD (HZJ70,73,75)	1HD-T	4164	123	1990	1998	X	X	X	X	X	X
4.5i (FZJ70,73,75)	1FZ-FE	4477	158	1994	1999	X	X	X	X	X	X
<b>Land Cruiser 80 1990 1998</b>											
4.2 D (HZJ80)	1HZ	4164	96	1990	1998	X	X	X	X	X	X
4.2 TD (HDJ80)	1HD-T	4164	123	1990	1995	X	X	X	X	X	X
4.2 TD (HZJ80)	1HD-FT	4164	125	1996	1998	X	X	X	X	X	X
4.5 (FZJ80)	1FZ-F	4477	145	1992	1998	X	X	X	X	X	X
4.5i (FZJ80)	1FZ-FE	4477	158	1992	1998	X	X	X	X	X	X
<b>Land Cruiser 90 / Prado 1996 2002</b>											
2.7 (RZJ90,95)	3RZ-F	2694	97	1996	2000	X	X	X	X	X	X
2.7 (RZJ90,95)	3RZ-FE	2694	112	1996	2002	X	X	X	X	X	X
2.8 D (LJ90,95)	3L	2779	65	1996	2002	X	X	X	X	X	X
3.0 D4-D (KDJ90,95)	1KD-FTV	2982	120	2001	2002	X	X	X	X	X	X
3.0 TD (KZJ90,95)	1KZ-T	2982	88	1996	2001	X	X	X	X	X	X
3.0 TD (KZJ90,95)	1KZ-TE	2982	92	1996	2002	X	X	X	X	X	X
3.4 V6 (VZJ90,95)	5VZ-FE	3378	131	1996	2002	X	X	X	X	X	X
<b>Lite Ace 1992 1996</b>											
1.5	5K	1486	52	1992	1996	X	X	X	X	X	X
2.0	3Y	1998	65	1992	1996	X	X	X	X	X	X
2.0 D	2C	1975	51	1992	1996	X	X	X	X	X	X
2.2	4Y-E	2236	75	1992	1996	X	X	X	X	X	X
<b>MR2 1984 1990</b>											
1.6i	4A-GE	1600	91	1984	1989	X	X	X	X	X	X
1.6i	4A-GE	1587	85	1986	1990	X	X	X	X	X	X
<b>MR2 1990 1994</b>											
2.0 GTi 16V	3S-GE	1998	115	1990	1994	X	X	X	X	X	X
2.0i	3S-FE	1998	88	1990	1994	X	X	X	X	X	X
<b>MR2 1999 2006</b>											
1.8	1ZZ-FE	1794	103	1999	2006	X	X	X	X	X	X
<b>Paseo 1996 1999</b>											
1.5i	5E-FE	1497	55	1996	1999	X	X	X	X	N	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagram. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>TOYOTA</b>											
<b>Picnic 1996 2001</b>											
2.0 16V	3S-FE	1998	94	1996	2001	X	X	X	X	X	N
2.2 TD	3C-TE	2184	66	1997	2001	X	X	X	X	X	N
<b>Previa 1990 2000</b>											
2.4i	2TZ-FE	2438	99	1990	2000	X	X	X	X	X	N
<b>Previa 2000 2006</b>											
2.0 D4-D	1CD-FTV	1995	85	2001	2006	X	X	X	X	X	N
2.4 VVT-i	2AZ-FE	2362	115	2000	2006	X	X	X	X	X	N
<b>Prius NHW11 2000 2004</b>											
1.5 16V	1NZ-FXE	1497	53	2000	2004	X	X	X		X	N
<b>Prius NHW20 2004</b>											
1.5 16V	1NZ-FXE	1497	57	2004		X	X	X		X	N
<b>RAV4 2000 2006</b>											
1.8 VVT-i	1ZZ-FE	1794	92	2000	2006	X	X	X	X	X	N
2.0 D4-D	1CD-FTV	1995	85	2001	2006	X	X	X	X	X	N
2.0 VVT-i	1AZ-FE	1998	110	2000	2006	X	X	X	X	X	N
<b>RAV4 2006</b>											
2.0 16V	1AZ-FE	1998	112	2006		X	X	X		X	N
2.2 16V D-4D	2AD-FTV	2231	100	2006		X	X	X		X	N
2.2 16V D-4D D-CAT	2AD-FHV	2231	130	2006		X	X	X		X	N
2.4 16V	2AZ-FE	2362	125	2006		X	X	X		X	N
<b>RAV4 1994 2000</b>											
2.0i	3S-FE	1998	96	1994	2000	X	X	X	X	X	N
<b>Starlet 1984 1989</b>											
1.0	1E-L	999	40	1984	1989	X	X	X	X	X	N
1.3 12V	2E	1295	55	1984	1989	X	X	X	X	X	N
1.5 D	1N	1453	40	1986	1989	X	X	X	X	X	N
<b>Starlet 1989 1996</b>											
1.0	1E-L	999	40	1989	1992	X	X	X	X	X	N
1.3 i	2E-E	1296	55	1989	1995	X	X	X	X	X	N
1.5 D	1N	1453	40	1990	1996	X	X	X	X	X	N
<b>Starlet 1996 1999</b>											
1.3i 16V	4E-FE	1332	55	1996	1999	X	X	X	X	X	N
<b>Supra 1986 1993</b>											
2.8 i T.C.	5M-GE	2759	125	1982	1984		X	X		X	N
2.8 i T.C.	5M-GE	2759	125	1985	1986		X	X		X	N
3.0 i T.C.	7M-GE	2954	150	1987	1989		X	X		X	N

Legend: N = new, X = present

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>TOYOTA</b>													
<b>Supra 1986 1993</b>													
3.0 i Turbo	7M-GTE	2954	173	1986	1993		X	X		X		X	
<b>Supra 1993 1999</b>													
3.0 i Turbo	2JZ-GTE	2997	243	1993	1996	X		X	X	X		X	X
<b>Yaris 2006</b>													
1.0 12V	1KR-FE	998	51	2005		X	X	X				X	N
1.3 16V	2NZ-FE	1298	63	2005		X	X	X		N		X	N
1.3 16V	2SZ-FE	1298	64	2005		X	X	X	N			X	N
1.4 D-4D	1ND-TV	1364	66	2005		X	X	X		N		X	N
1.5 16V	1NZ-FE	1497	80	2005		X	X	X		N		X	N
1.8 16V TS	2ZR-FE	1798	97	2006		X	X	X	N				N
<b>Yaris 1999 2006</b>													
1.0 VVT-i	1SZ-FE	998	50	1999	2006	X	X	X	X	X		X	X
1.3 VVT-i	2NZ-FE	1299	63	1999	2006	X	X	X	X	X		X	X
1.3 VVT-i	2SZ-FE	1298	64	2004	2006	X	X	X	X	X		X	X
1.4 D4-D	1ND-TV	1364	55	2002	2006	X	X	X	X	N		X	X
1.5 VVT-i	1NZ-FE	1497	78	1999	2006	X	X	X	X	X		X	X
<b>Yaris Verso 1999 2006</b>													
1.3 VVT-i	2NZ-FE	1299	63	1999	2006	X	X	X	X	X		X	X
1.4 D4-D	1ND-TV	1364	55	2002	2006	X	X	X	X	N		X	X
1.5 VVT-i	1NZ-FE	1497	78	1999	2006	X	X	X	X	X		X	X
<b>TVR</b>													
<b>Chimaera 1992 2002</b>													
4.0	V8	3952	175	1992	2002	X		X				X	
5.0	V8	4997	240	1997	2002	X		X				X	
<b>Griffith 1990 2002</b>													
4.0	4.0 V8	3952	175	1990	2002	X		X				X	
500	5.0 V8	4998	240	1990	2002	X		X				X	
<b>VOLKSWAGEN</b>													
<b>Bora 1999 2005</b>													
1.4 16V	AHW	1390	55	1998	2005	X	X	X	X	X	X	X	X
1.4 16V	AKQ	1390	55	1998	2000	X	X	X	X	X	X	X	X
1.4 16V	APE	1390	55	1999	2000	X	X	X	X	X	X		X
1.4 16V	AXP	1390	55	2000	2001	X	X	X	X	X	X		X
1.4 16V	BCA	1390	55	2001		X	X	X	X	X	X		X
1.6	AEH	1595	74	1998	2005	X	X	X	X	X	X	X	X
1.6	AKL	1595	74	1998	2005	X	X	X	X	X	X	X	X



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diag. Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diag. Fuses & Relays

**VOLKSWAGEN**

**Bora 1999 2005**

1.6	APF	1595	74	1998	2005	X	X	X	X	X	X	X	X	X	X	X	X	X
1.6	AVU	1597	75	2000	2002	X	X	X	X	X	X	X	X	X	X	X	X	X
1.6	BFQ	1595	75	2002	2005	X	X	X	X	X	X	X	X	X	X	X	X	X
1.6 16V	ATN	1595	77	1999	2000	X	X	X	X	X	X	X	X	X	X	X	X	X
1.6 16V	AUS	1597	77	2000	2000	X	X	X	X	X	X	X	X	X	X	X	X	X
1.6 16V	AZD	1597	77	2000	2001	X	X	X	X	X	X	X	X	X	X	X	X	X
1.6 16V	BCB	1595	77	2001	2005	X	X	X	X	X	X	X	X	X	X	X	X	X
1.6 FSi	BAD	1595	81	2001	2005	X	X	X	X	X	X	X	X	X	X	X	X	X
1.8	AGN	1781	92	1998	2000	X	X	X	X	X	X	X	X	X	X	X	X	X
1.8 Turbo	AGU	1781	110	2000	2005	X	X	X	X	X	X	X	X	X	X	X	X	X
1.8 Turbo	AQA	1781	110	1999	2005	X	X	X	X	X	X	X	X	X	X	X	X	X
1.8 Turbo	ARZ	1781	110	1999	2005	X	X	X	X	X	X	X	X	X	X	X	X	X
1.8 Turbo	AUM	1781	110	2000	2005	X	X	X	X	X	X	X	X	X	X	X	X	X
1.8 Turbo	AUQ	1781	132	2002	2005	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 SDi	AGP	1896	50	2000	2001	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 SDi	AQM	1896	50	1998	2005	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	AGR	1896	66	1998	2002	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	AHF	1896	81	1998	2005	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	AJM	1896	85	1998	2001	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	ALH	1896	66	1998	2005	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	ARL	1896	110	2000	2005	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	ASV	1896	81	2000	2005	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	ASZ	1896	96	2001	2005	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	ATD	1896	74	2000		X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	AUY	1896	85	2000	2001	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	AXR	1896	74	2001	2005	X	X	X	X	X	X	X	X	X	X	X	X	X
2.0	APK	1984	85	1998		X	X	X	X	X	X	X	X	X	X	X	X	X
2.0	AQY	1984	85	1998		X	X	X	X	X	X	X	X	X	X	X	X	X
2.0	AZH	1984	85	2000	2001	X	X	X	X	X	X	X	X	X	X	X	X	X
2.0	AZJ	1984	85	2001		X	X	X	X	X	X	X	X	X	X	X	X	X
VR5	AGZ	2298	110	1998	2001	X	X	X	X	X	X	X	X	X	X	X	X	X
VR5	AQN	2324	125	2000		X	X	X	X	X	X	X	X	X	X	X	X	X
VR6	AQP	2792	150	1999	2000	X	X	X	X	X	X	X	X	X	X	X	X	X
VR6	AUE	2792	150	2000	2001	X	X	X	X	X	X	X	X	X	X	X	X	X
VR6	BDE	2792	150	2001	2005	X	X	X	X	X	X	X	X	X	X	X	X	X

**Caddy 1996 2003**

1.4	AEX	1390	44	1996	1998	X	X	X	X	X	X	X	X	X	X	X	X	X
-----	-----	------	----	------	------	---	---	---	---	---	---	---	---	---	---	---	---	---

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Air Cond.	Wir. Diagr.	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine					
<b>VOLKSWAGEN</b>															
<b>Caddy 1996 2003</b>															
1.4	AUD	1390	44	2000	2003	X	X	X	X	X	X	X	X	X	X
1.4	AKV	1390	44	1997	2000	X	X	X	X	X	X	X	X	X	X
1.4 16V	AUA	1390	55	2000	2003	X	X	X	X	X	X	X	X	X	X
1.6	1F	1598	55	1996	1997	X	X	X	X	X	X	X	X	X	X
1.6	AEE	1598	55	1996	2001	X	X	X	X	X	X	X	X	X	X
1.7 SDi	AHB	1718	42	1996	2000	X	X	X	X	X	X	X	X	X	X
1.9 D	1Y	1896	47	1996	2003	X	X	X	X	X	X	X	X	X	X
1.9 SDi	AEY	1896	47	1996	2000	X	X	X	X	X	X	X	X	X	X
1.9 SDi	AYQ	1896	47	2000	2003	X	X	X	X	X	X	X	X	X	X
1.9 TDi	ALE	1896	66	1997	2000	X	X	X	X	X	X	X	X	X	X
<b>Caddy 2004</b>															
1.4 16V	BCA	1390	55	2004	2007	X	X	X	X	X	X	X	X	X	N
1.4 16V	BUD	1390	59	2006		X	X	X	X	X	X	X	X	X	N
1.6	BGU	1595	75	2004	2006	X	X	X	X	X	X	X	X	X	N
1.6	BSE	1595	75	2005		X	X	X	X	X	X	X	X	X	N
1.6	BSF	1595	75	2005		X	X	X	X	X	X	X	X	X	N
1.9 TDi	BJB	1896	77	2004		X	X	X	X	X	X	X	X	X	N
1.9 TDi	BKC	1896	77	2005		X	X	X	X	X	X	X	X	X	N
1.9 TDi	BLS	1896	77	2005		X	X	X	X	X	X	X	X	X	N
1.9 TDi	BSU	1896	55	2005		X	X	X	X	X	X	X	X	X	N
2.0 CNG	BSX	1984	80	2006		X	X	X	X	X	X	X	X	X	N
2.0 SDi	BDJ	1968	51	2004		X	X	X	X	X	X	X	X	X	N
2.0 SDi	BST	1968	51	2006		X	X	X	X	X	X	X	X	X	N
<b>Corrado 1988 1995</b>															
1.8 16V	KR	1781	100	1988	1995	X	X	X	X	X	X	X	X	X	X
1.8 G60	PG	1781	118	1988	1995	X	X	X	X	X	X	X	X	X	X
2.0	2E	1984	85	1993	1995	X	X	X	X	X	X	X	X	X	X
2.0	ADY	1984	85	1994	1995	X	X	X	X	X	X	X	X	X	X
2.0 16V	9A	1984	100	1991	1995	X	X	X	X	X	X	X	X	X	X
2.8 VR6	AAA	2792	132	1991	1995	X	X	X	X	X	X	X	X	X	X
2.9 VR6	ABV	2861	140	1991	1995	X	X	X	X	X	X	X	X	X	X
<b>Crafter 2006</b>															
2.5 TDi 10V	BJJ	2459	65	2006		X	X							X	
2.5 TDi 10V	BJK	2459	80	2006		X	X							X	
2.5 TDi 10V	BJL	2459	100	2006		X	X							X	
2.5 TDi 10V	BJM	2459	120	2006		X	X							X	

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>VOLKSWAGEN</b>											
<b>Eos 2006</b>											
1.6 16V FSi	BLF	1598	85	2006		X	X	X	X	X	X
2.0 16V FSi	BVY	1984	110	2006		X	X	X	X	X	X
2.0 16V FSi	BVZ	1984	110	2006		X	X	X	X	X	X
2.0 TDi	BMM	1968	103	2006		X	X	X	X	X	X
2.0 TFSi	BWA	1984	147	2006		X	X	X	X	X	X
3.2 V6	BUB	3189	184	2006		X	X	X	X	X	X
<b>Fox 2004</b>											
1.0 8V	AQZ	999	53	2004	2005	X	X	X	X	X	X
1.2 6V	BMD	1198	40	2005		X	X	X	X	X	X
1.4 8V	BKR	1390	55	2005		X	X	X	X	X	X
1.4 TDi	BNM	1422	51	2005		X	X	X	X	X	X
1.6 8V	BAH	1598	74	2004	2005	X	X	X	X	X	X
1.6 8V	BJA	1598	74	2004	2005	X	X	X	X	X	X
1.6 8V	BLH	1598	74	2004	2005	X	X	X	X	X	X
<b>Golf II 1983 1992</b>											
1.0	GN	1043	33	1983	1986	X	X	X	X	X	X
1.0	HZ	1043	37	1985	1986	X	X	X	X	X	X
1.3	HW	1272	37	1983	1986	X	X	X	X	X	X
1.3	2G	1272	40	1987	1991	X	X	X	X	X	X
1.3	GT	1272	43	1984	1987	X	X	X	X	X	X
1.3	HK	1272	40	1983	1986	X	X	X	X	X	X
1.3	MH	1272	40	1983	1991	X	X	X	X	X	X
1.3	NU	1272	40	1983	1991	X	X	X	X	X	X
1.3	NZ	1272	40	1989	1991	X	X	X	X	X	X
1.6	EZA	1595	51	1983	1992	X	X	X	X	X	X
1.6	EZ	1595	55	1983	1989	X	X	X	X	X	X
1.6	HM	1595	55	1984	1988	X	X	X	X	X	X
1.6	PN	1595	51	1986	1991	X	X	X	X	X	X
1.6	RF	1595	55	1983	1989	X	X	X	X	X	X
1.6 D	JPA	1588	37	1983	1991	X	X	X	X	X	X
1.6 D	JP	1588	40	1983	1991	X	X	X	X	X	X
1.6 D Kat.	1V	1588	44	1989	1991	X	X	X	X	X	X
1.6 Kat.	RF	1595	51	1983	1992	X	X	X	X	X	X
1.6 TD	JR	1588	51	1983	1991	X	X	X	X	X	X
1.6 TD	MF	1588	51	1983	1991	X	X	X	X	X	X
1.6 TD	RA	1588	60	1989	1991	X	X	X	X	X	X
1.6 TD	SB	1588	60	1989	1991	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>VOLKSWAGEN</b>											
<b>Golf II 1983 1992</b>											
1.8	2H	1781	72	1989	1992	X	X	X	X		
1.8	HT	1781	77	1985	1986	X	X	X	X	X	
1.8	RG	1781	79	1989	1992	X	X	X	X	X	
1.8	EV	1781	82	1983	1993	X	X	X	X	X	X
1.8	GU	1781	66	1983	1991	X	X	X	X	X	X
1.8	GX	1781	66	1983	1991	X	X	X	X	X	X
1.8	HV	1781	66	1984	1991	X	X	X	X	X	X
1.8	PB	1781	82	1987	1991	X	X	X	X	X	X
1.8	PF	1781	82	1987	1991	X	X	X	X	X	X
1.8	RD	1781	79	1983	1993	X	X	X	X	X	X
1.8	RH	1781	62	1987	1990	X	X	X	X	X	X
1.8	RP	1781	66	1987	1991	X	X	X	X	X	X
1.8 16V	KR	1781	102	1985	1989	X	X	X	X	X	X
1.8 16V	PL	1781	95	1985	1991	X	X	X	X	X	X
1.8 G60	PG	1781	118	1989	1991	X	X	X	X	X	X
1.8 GTi	GZ	1781	82	1984	1986	X		X	X	X	
1.8 Kat.	RV	1781	77	1987	1991	X	X	X	X	X	X
1.8 Rallye	1H	1781	118	1989	1989	X	X	X	X	X	X
1.8 Syncro	GX	1781	66	1986	1988	X	X	X	X	X	X
1.8 Syncro Country	1P	1781	72	1988	1991	X	X	X	X	X	X
1.8 Syncro G60	PG	1781	118	1990	1991	X	X	X	X	X	X
<b>Golf III (Cabrio 1998-&gt;) 1991 1998</b>											
1.4 (40/44 kW)	ABD	1391	44	1991	1995	X	X	X	X	X	X
1.4 (40/44 kW)	AEX	1390	44	1995	1998	X	X	X	X	X	X
1.4 (40/44 kW)	APQ	1390	44	1997	1998	X	X	X	X	X	X
1.6	AEA	1598	55	1994	1995	X	X	X	X	X	X
1.6	AFT	1595	74	1996	2000	X	X	X	X	X	X
1.6	AKS	1595	74	1997	2000	X	X	X	X	X	X
1.6	ABU	1598	55	1992	1994	X	X	X	X	X	X
1.6	AEE	1598	55	1995	1998	X	X	X	X	X	X
1.6	AEK	1595	74	1994	1996	X	X	X	X	X	X
1.8	ANN	1781	55	1998	2000	X	X	X	X	X	X
1.8	ANP	1781	66	1998	2000	X	X	X	X	X	X
1.8	AAM	1781	55	1991	2000	X	X	X	X	X	X
1.8	ABS	1781	66	1991	1995	X	X	X	X	X	X
1.8	ADZ	1781	66	1994	2000	X	X	X	X	X	X
1.9 D	1Y	1896	47	1991	1999	X	X	X	X	X	X

Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diag. Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diag. Fuses & Relays

**VOLKSWAGEN**

**Golf III (Cabrio 1998->) 1991 1998**

1.9 SDi	AEY	1896	47	1995	2000	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TD	AAZ	1896	55	1991	1999	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	1Z	1896	66	1993	1997	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	AFN	1896	81	1996	1999	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	AHU	1896	66	1996	2000	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	ALE	1896	66	1996	2001	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	AVG	1896	81	1999	2000	X	X	X	X	X	X	X	X	X	X	X	X
2.0	AGG	1984	85	1995	2002	X	X	X	X	X	X	X	X	X	X	X	X
2.0	AKR	1984	85	1997	2000	X	X	X	X	X	X	X	X	X	X	X	X
2.0	ATU	1984	85	1999	2000	X	X	X	X	X	X	X	X	X	X	X	X
2.0	AWF	1984	85	2000	2002	X	X	X	X	X	X	X	X	X	X	X	X
2.0	AWG	1984	85	2000	2002	X	X	X	X	X	X	X	X	X	X	X	X
2.0	2E	1984	85	1991	1994	X	X	X	X	X	X	X	X	X	X	X	X
2.0	ADY	1984	85	1994	1997	X	X	X	X	X	X	X	X	X	X	X	X
2.0 16V	ABF	1984	110	1992	1998	X	X	X	X	X	X	X	X	X	X	X	X
2.8 VR6	AAA	2792	128	1992	1998	X	X	X	X	X	X	X	X	X	X	X	X
2.9 VR6	ABV	2861	140	1994	1998	X	X	X	X	X	X	X	X	X	X	X	X

**Golf IV 1998 2003**

1.4 16V	AHW	1390	55	1998	2003	X	X	X	X	X	X	X	X	X	X	X	X
1.4 16V	AKQ	1390	55	1997	2000	X	X	X	X	X	X	X	X	X	X	X	X
1.4 16V	APE	1390	55	1999	2000	X	X	X	X	X	X	X	X	X	X	X	X
1.4 16V	AXP	1390	55	2000	2001	X	X	X	X	X	X	X	X	X	X	X	X
1.4 16V	BCA	1390	55	2001	2003	X	X	X	X	X	X	X	X	X	X	X	X
1.6	AEH	1595	74	1998	2003	X	X	X	X	X	X	X	X	X	X	X	X
1.6	AKL	1595	74	1997	2003	X	X	X	X	X	X	X	X	X	X	X	X
1.6	APF	1595	74	1998	2003	X	X	X	X	X	X	X	X	X	X	X	X
1.6	AVU	1595	75	2000	2002	X	X	X	X	X	X	X	X	X	X	X	X
1.6	BFQ	1595	75	2002	2003	X	X	X	X	X	X	X	X	X	X	X	X
1.6 16V	ATN	1597	77	1999	2000	X	X	X	X	X	X	X	X	X	X	X	X
1.6 16V	AUS	1597	77	2000	2000	X	X	X	X	X	X	X	X	X	X	X	X
1.6 16V	AZD	1597	77	2000	2001	X	X	X	X	X	X	X	X	X	X	X	X
1.6 16V	BCB	1597	77	2001	2003	X	X	X	X	X	X	X	X	X	X	X	X
1.6 FSi	BAD	1597	81	2002	2003	X	X	X	X	X	X	X	X	X	X	X	X
1.8	AGN	1781	92	1997	2000	X	X	X	X	X	X	X	X	X	X	X	X
1.8 Turbo	AGU	1781	110	1997	2003	X	X	X	X	X	X	X	X	X	X	X	X
1.8 Turbo	AQA	1781	110	1998	2000	X	X	X	X	X	X	X	X	X	X	X	X
1.8 Turbo	ARZ	1781	110	1999	2000	X	X	X	X	X	X	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diag. Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diag. Fuses & Relays

**VOLKSWAGEN**

**Golf IV 1998 2003**

1.8 Turbo	AUM	1781	110	2000	2003	X	X	X	X	X	X	X	X	X			X	X
1.8 Turbo (GTi)	AUQ	1781	132	2001	2003	X	X	X	X	X	X			X	X		X	X
1.9 SDi	AGP	1896	50	1997	2001	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 SDi	AQM	1896	50	1998	2003	X	X	X	X	X	X	X	X	X	X		X	X
1.9 TDi	AGR	1896	66	1997	2003	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	AHF	1896	81	1997	2003	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	AJM	1896	85	1999	2001	X	X	X	X	X	X	X	X	X	X		X	X
1.9 TDi	ALH	1896	66	1997	2003	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi	ARL	1896	110	2000	2003	X	X	X	X	X	X	X	X	X	X		X	X
1.9 TDi	ASV	1896	81	2000	2003	X	X	X	X	X	X	X	X	X	X		X	X
1.9 TDi	ASZ	1896	96	2001	2003	X	X	X	X	X	X			X	X		X	X
1.9 TDi	ATD	1896	74	2000	2003	X	X	X	X	X	X	X	X	X	X		X	X
1.9 TDi	AUY	1896	85	2000	2000	X	X	X	X	X	X	X	X	X	X		X	X
1.9 TDi	AXR	1896	74	2001	2003	X	X	X	X	X	X			X	X		X	X
2.0	APK	1984	85	1998	2003	X	X	X	X	X	X	X	X	X	X		X	X
2.0	AQY	1984	85	1998	2003	X	X	X	X	X	X	X	X	X	X		X	X
2.0	AZH	1984	85	2000	2001	X	X	X	X	X	X	X	X	X	X		X	X
2.0	AZJ	1984	85	2001	2003	X	X	X	X	X	X			X	X		X	X
2.0 LPG (75/85kW)	BEH	1984	85	2002	2003	X	X	X	X	X	X			X	X		X	X
R32	BFH	3189	177	2002	2004	X	X	X	X	X				X	X		X	X
R32	BJS	3189	177	2003	2004	X	X	X	X					X	X			X
R32	BML	3189	177	2003	2004	X	X	X	X					X	X			X
VR5	AGZ	2324	110	1997	2001	X	X	X	X	X	X	X	X	X	X	X	X	X
VR5	AQN	2324	125	2000	2003	X	X	X	X	X	X			X	X		X	X
VR6	AQP	2792	150	1999	2000	X	X	X	X	X		X	X	X	X		X	X
VR6	AUE	2792	150	2000	2001	X	X	X	X	X	X	X	X	X	X		X	X
VR6	BDE	2792	150	2001	2003	X	X	X	X	X				X	X		X	X

**Golf V 2003**

1.4 16V	BCA	1390	55	2003	2006	X	X	X	X	X				X	X		X	X
1.4 16V FSi	BKG	1390	66	2003	2005	X	X	X	X	X				X	X		X	X
1.4 16V FSi	BLN	1390	66	2004	2007	X	X	X	X	X				X	X		X	X
1.4 16V TSi	BLG	1390	125	2005		X	X	X	X					X			X	X
1.4 16V TSi	BMY	1390	103	2006		X	X	X	X					X				X
1.6	BGU	1595	75	2003	2006	X	X	X	X	X				X	X		X	X
1.6	BSE	1595	75	2004		X	X	X	X					X	X		X	X
1.6	BSF	1595	75	2005		X	X	X	X					X	X			X
1.6 16V FSi	BAG	1598	85	2003	2005	X	X	X	X	X				X	X		X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagram. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>VOLKSWAGEN</b>											
<b>Golf V 2003</b>											
1.6 16V FSi	BLF	1598	85	2004		X	X	X	X	X	X
1.6 16V FSi	BLP	1598	85	2004	2006	X	X	X	X	X	X
1.9 TDi	BJB	1896	77	2003		X	X	X	X	X	X
1.9 TDi	BKC	1896	77	2003	2007	X	X	X	X	X	X
1.9 TDi	BRU	1896	66	2003	2007	X	X	X	X	X	X
1.9 TDi	BXE	1896	77	2006		X	X	X	X	X	X
1.9 TDi	BXF	1896	66	2006		X	X	X	X	X	X
1.9 TDi (DPF)	BLS	1896	77	2005		X	X	X	X	X	X
2.0	BHY	1984	85	2004		X	X	X	X	X	X
2.0 16V FSi	AXW	1984	110	2003	2005	X	X	X	X	X	X
2.0 16V FSi	BLR	1984	110	2004	2006	X	X	X	X	X	X
2.0 16V FSi	BLX	1984	110	2003	2006	X	X	X	X	X	X
2.0 16V FSi	BLY	1984	110	2005	2006	X	X	X	X	X	X
2.0 16V FSi	BVX	1984	110	2005		X	X	X	X	X	X
2.0 16V FSi	BVY	1984	110	2005		X	X	X	X	X	X
2.0 16V FSi	BVZ	1984	110	2005		X	X	X	X	X	X
2.0 16V TDi	AZV	1968	100	2003		X	X	X	X	X	X
2.0 16V TDi	BKD	1968	103	2003		X	X	X	X	X	X
2.0 16V TDi (DPF)	BMN	1968	125	2005		X	X	X	X	X	X
2.0 SDi	BDK	1968	55	2003		X	X	X	X	X	X
2.0 TDi (DPF)	BMM	1968	103	2004		X	X	X	X	X	X
GTi (2.0 TFSi)	AXX	1968	147	2004		X	X	X	X	X	X
GTi (2.0 TFSi)	BWA	1984	147	2005		X	X	X	X	X	X
R32 (3.2 VR6)	BUB	3189	184	2005		X	X	X	X	X	X
<b>Golf Plus 2005</b>											
1.4 16V	BCA	1390	55	2005	2007	X	X	X	X	X	X
1.4 16V FSi	BLN	1390	66	2005	2007	X	X	X	X	X	X
1.4 16V TSi	BMY	1390	103	2006		X	X	X	X	X	X
1.6	BSE	1595	75	2005		X	X	X	X	X	X
1.6	BSF	1595	75	2005		X	X	X	X	X	X
1.6 16V FSi	BLF	1598	85	2005		X	X	X	X	X	X
1.6 16V FSi	BLP	1598	85	2005	2006	X	X	X	X	X	X
1.9 TDi	BKC	1896	77	2005	2007	X	X	X	X	X	X
1.9 TDi	BRU	1896	66	2005	2007	X	X	X	X	X	X
1.9 TDi	BXE	1896	77	2006		X	X	X	X	X	X
1.9 TDi	BXF	1896	66	2006		X	X	X	X	X	X
1.9 TDi (DPF)	BLS	1896	77	2006		X	X	X	X	X	X

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>VOLKSWAGEN</b>													
<b>Golf Plus 2005</b>													
2.0 16V FSi	BLR	1984	110	2005	2006	X	X	X	X	X	X	X	X
2.0 16V FSi	BLY	1984	110	2005	2006	X	X	X	X	X	X	X	X
2.0 16V FSi	BVY	1984	110	2006		X	X	X	X	X	X	X	X
2.0 16V FSi	BVZ	1984	110	2006		X	X	X	X	X	X	X	X
2.0 16V TDi	AZV	1968	100	2005		X	X	X	X	X	X	X	X
2.0 16V TDi	BKD	1968	103	2005		X	X	X	X	X	X	X	X
2.0 TDi (DPF)	BMM	1968	103	2006		X	X	X	X	X	X		X
<b>Jetta 2005</b>													
1.6	BSE	1595	75	2005		X	X	X	X	X	X	X	
1.6	BSF	1595	75	2005		X	X	X	X	X	X	X	
1.6 16V FSi	BLF	1598	85	2005		X	X	X	X	X	X	X	
1.9 TDi	BKC	1896	77	2005		X	X	X	X	X	X	X	
1.9 TDi (DPF)	BLS	1896	77	2005		X	X	X	X	X	X	X	
2.0 16V FSi	BLR	1984	110	2005		X	X	X	X	X	X	X	
2.0 16V FSi	BLY	1984	110	2005		X	X	X	X	X	X	X	
2.0 16V FSi	BVY	1984	110	2005		X	X	X	X	X	X	X	
2.0 16V FSi	BVZ	1984	110	2005		X	X	X	X	X	X	X	
2.0 16V TDi	AZV	1968	100	2005		X	X	X	X	X	X	X	
2.0 16V TDi	BKD	1968	103	2005		X	X	X	X	X	X	X	
2.0 16V TDi (DPF)	BMN	1968	125	2006		X	X	X	X	X	X	X	
2.0 TDi (DPF)	BMM	1968	103	2005		X	X	X	X	X	X	X	
2.0 TFSi	BWA	1984	147	2005		X	X	X	X	X	X	X	
<b>Jetta II 1984 1992</b>													
1.0	HZ	1043	37	1986	1992	X	X	X	X	X	X		
1.3	2G	1272	40	1986	1989	X	X	X	X	X	X	X	
1.3	GT	1272	43	1984	1987	X	X	X	X	X	X	X	
1.3	HK	1272	40	1984	1989	X	X	X	X	X	X	X	
1.3	MH	1272	40	1985	1988	X	X	X	X	X	X	X	
1.3	NZ	1272	40	1987	1992	X	X	X	X	X	X	X	
1.6	EZ	1595	55	1984	1989	X	X	X	X	X	X	X	
1.6	EZA	1595	55	1984	1989	X	X	X	X	X	X	X	
1.6	HM	1595	55	1984	1988	X	X	X	X	X	X	X	
1.6	PN	1595	51	1986	1992	X	X	X	X	X	X	X	
1.6	RF	1595	55	1984	1989	X	X	X	X	X	X	X	
1.6 D	JP	1588	40	1984	1992	X	X	X	X	X	X	X	
1.6 D Kat.	1V	1588	44	1989	1992	X	X	X	X	X	X	X	
1.6 Kat.	EZ	1595	51	1983	1992	X	X	X	X	X	X	X	



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>VOLKSWAGEN</b>											
<b>Jetta II 1984 1992</b>											
1.6 Kat.	EZA	1595	51	1983	1992	X	X	X	X	X	X
1.6 Kat.	RF	1595	51	1983	1992	X	X	X	X	X	X
1.6 TD	JR	1588	51	1984	1992	X	X	X	X	X	X
1.6 TD	MF	1588	51	1984	1992	X	X	X	X	X	X
1.6 TD	RA	1588	60	1989	1992	X	X	X	X	X	X
1.6 TD	SB	1588	60	1989	1992	X	X	X	X	X	X
1.8	EV	1781	79	1985	1986	X	X	X	X	X	X
1.8	GU	1781	66	1984	1987	X	X	X	X	X	X
1.8	GX	1781	66	1986	1992	X	X	X	X	X	X
1.8	HV	1781	66	1984	1987	X	X	X	X	X	X
1.8	PB	1781	82	1987	1992	X	X	X	X	X	X
1.8	PF	1781	82	1987	1992	X	X	X	X	X	X
1.8	RD	1781	79	1986	1992	X	X	X	X	X	X
1.8	RP	1781	66	1987	1992	X	X	X	X	X	X
1.8 16V	PL	1781	95	1987	1992	X	X	X	X	X	X
1.8 16V	KR	1781	102	1986	1992	X	X	X	X	X	X
1.8 Syncro	GU	1781	66	1986	1992	X	X	X	X	X	X
1.8 Syncro	GX	1781	66	1986	1988	X	X	X	X	X	X
1.8 Syncro G60	PG	1781	118	1990	1992	X	X	X	X	X	X
<b>LT 1996 2006</b>											
2.3	AGL	2295	105	1996	2001	X	X	X	X	X	X
2.5 SDi	AGX	2461	55	1996	2001	X	X	X	X	X	X
2.5 TDi	AHD	2461	75	1996	1999	X	X	X	X	X	X
2.5 TDi	ANJ	2461	80	1999		X	X	X	X	X	X
2.5 TDi	APA	2461	66	1999	2001	X	X	X	X	X	X
2.5 TDi	BBE	2461	61	2001		X	X	X	X	X	X
2.5 TDi	BBF	2461	70	2001		X	X	X	X	X	X
2.8 TDi	AGK	2799	92	1997	1999	X	X	X	X	X	X
2.8 TDi	ATA	2799	96	1999	2002	X	X	X	X	X	X
2.8 TDi	AUH	2799	116	2002		X	X	X	X	X	X
<b>LT 1983 1996</b>											
2.4	DL	2383	66	1983	1986	X	X	X	X	X	X
2.4	DL	2383	66	1986	1992	X	X	X	X	X	X
2.4	HS	2383	61	1983	1986	X	X	X	X	X	X
2.4D	1S	2383	51	1988	1992	X	X	X	X	X	X
2.4D	ACT	2383	51	1992	1996	X	X	X	X	X	X
2.4D	DW	2383	55	1983	1992	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagram. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>VOLKSWAGEN</b>											
<b>LT 1983 1996</b>											
2.4i	1E	2383	69	1988	1996	X	X	X	X	X	X
2.4TD	ACL	2383	70	1991	1996	X	X	X	X	X	X
2.4TD	1G	2383	68	1989	1992	X	X	X	X	X	X
2.4TD	DV	2383	75	1983	1992	X	X	X	X	X	X
<b>Lupo 1998 2005</b>											
1.0	AER	999	37	1998	2002	X	X	X	X	X	X
1.0	AHT	999	37	1998	2002	X	X	X	X	X	X
1.0	ALD	999	37	1999	2002	X	X	X	X	X	X
1.0	ALL	999	37	1998	2002	X	X	X	X	X	X
1.0	ANV	999	37	1999	2002	X	X	X	X	X	X
1.0	AUC	999	37	2000	2005	X	X	X	X	X	X
1.2 TDi (3L)	ANY	1191	45	1999	2002	X	X	X	X	X	X
1.2 TDi (3L)	AYZ	1191	45	2000	2005	X	X	X	X	X	X
1.4	AUD	1390	44	2000	2005	X	X	X	X	X	X
1.4 16V	AFK	1390	74	1999	2002	X	X	X	X	X	X
1.4 16V	AHW	1390	55	1998	2005	X	X	X	X	X	X
1.4 16V	AKQ	1390	55	1998	2002	X	X	X	X	X	X
1.4 16V	APE	1360	55	1999	2002	X	X	X	X	X	X
1.4 16V	AQQ	1390	74	1999	2002	X	X	X	X	X	X
1.4 16V	AUA	1390	55	2000	2002	X	X	X	X	X	X
1.4 16V	AUB	1390	74	2000	2005	X	X	X	X	X	X
1.4 16V	BBY	1390	55	2002	2005	X	X	X	X	X	X
1.4 16V (FSi)	ARR	1398	77	2000	2004	X	X	X	X	X	X
1.4 TDi	AMF	1422	55	1999	2005	X	X	X	X	X	X
1.6 16V (GTi)	AVY	1598	92	2000	2005	X	X	X	X	X	X
1.7 SDi	AKU	1716	44	1998	2005	X	X	X	X	X	X
<b>New Beetle 1998</b>											
1.4 16V	BCA	1390	55	2001	2004	X	X	X	X	X	X
1.6	AWH	1595	74	1999	2001	X	X	X	X	X	X
1.6	AYD	1595	75	2000		X	X	X	X	X	X
1.6	BFS	1595	75	2002		X	X	X	X	X	X
1.8 Turbo	AVC	1781	110	1999	2001	X	X	X	X	X	X
1.8 Turbo	AWU	1781	110	2000		X	X	X	X	X	X
1.9 TDi	ALH	1896	66	1998	2004	X	X	X	X	X	X
1.9 TDi	ATD	1896	74	2000	2004	X	X	X	X	X	X
1.9 TDi	AXR	1896	74	2003		X	X	X	X	X	X
2.0	AQY	1984	85	1998	2003	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>VOLKSWAGEN</b>											
<b>New Beetle 1998</b>											
2.0	AZJ	1984	85	2001		X	X X X X	X X X X		X X	X X
3.2 RSi	AXJ	3188	165	2000	2001	X	X X X X	X X X X		X X	X X
VR5	AQN	2324	125	2000	2004	X	X X X X	X X X X		X X	X X
<b>Passat II 1985 1988</b>											
1.3	EP	1296	44	1984	1986	X	X X X X	X X X X		X X	X X
1.6	DT/DTA/RL	1595	55	1984	1988	X	X X X X	X X X X		X X	X X
1.6 D	JK	1588	40	1982	1988	X	X X X X	X X X X		X X	X X
1.6 Kat.	PP	1595	51	1987	1987	X	X X X X	X X X X	X	X X	X X
1.6 TD	CY	1588	51	1982	1988	X	X X X X	X X X X		X X	X X
1.8	DS/JN	1781	66	1984	1988	X	X X X X	X X X X		X X	X X
2.0i	JS	1994	85	1984	1986	X	X X X X	X X X X		X X	X X
<b>Passat III 1988 1993</b>											
1.6	ABN	1588	55	1991	1992	X	X X X X	X X X X		X X	X X X
1.6	ABN	1595	55	1988	1991	X	X X X X	X X X X		X X	X X X
1.6	EZ	1595	55	1988	1991	X	X X X X	X X X X	X	X X	X X X
1.6 Kat.	1F	1595	53	1988	1990	X	X X X X	X X X X		X X	X X X
1.6 Kat.	ABN	1595	53	1988	1990	X	X X X X	X X X X		X X	X X X
1.6 Kat.	RF	1595	53	1988	1989	X	X X X X	X X X X	X	X X	X X X
1.6 TD	RA	1588	59	1988	1989	X	X X X X	X X X X		X X	X X X
1.6 TD	SB	1588	59	1988	1993	X	X X X X	X X X X		X X	X X X
1.8	DS	1781	66	1988	1993	X	X X X X	X X X X		X X	X X X
1.8	AAM	1781	55	1990	1993	X	X X X X	X X X X		X X	X X X
1.8	ABS	1781	79	1991	1993	X	X X X X	X X X X	X	X X	X X X
1.8	PB	1781	79	1988	1990	X	X X X X	X X X X		X X	X X X
1.8	PF	1781	79	1988	1990	X	X X X X	X X X X		X X	X X X
1.8	RP	1781	66	1988	1990	X	X X X X	X X X X		X X	X X X
1.8	RP	1781	66	1990	1991	X	X X X X	X X X X		X X	X X X
1.8 16V	KR	1781	102	1988	1989	X	X X X X	X X X X		X X	X X X
1.8 G60 Syncro	PG	1781	118	1988	1993	X	X X X X	X X X X		X X	X X X
1.8 Kat.	AAM	1781	55	1990	1993	X	X X X X	X X X X	X	X X	X X X
1.9 D	1Y	1896	50	1989	1993	X	X X X X	X X X X		X X	X X X
1.9 TD	AAZ	1896	55	1991	1993	X	X X X X	X X X X		X X	X X X
1.9 TDi	1Z	1896	66	1991	1993	X	X X X X	X X X X		X X	X X X
2.0	2E	1984	85	1990	1993	X	X X X X	X X X X	X	X X	X X X
2.0	AAW	1984	85	1991	1993	X	X X X X	X X X X		X X	X X X
2.0 16V	9A	1984	100	1988	1993	X	X X X X	X X X X		X X	X X X
2.0 Syncro	2E	1984	85	1990	1993	X	X X X X	X X X X	X	X X	X X X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays
<b>VOLKSWAGEN</b>												
<b>Passat III 1988 1993</b>												
2.8 VR6	AAA	2792	128	1991	1993	X	X	X	X	X	X	X
<b>Passat III 1993 1996</b>												
1.6	AFT	1595	74	1995	1997	X	X	X	X	X	X	X
1.6	AEK	1595	74	1994	1996	X	X	X	X	X	X	X
1.8	ABS	1781	66	1993	1996	X	X	X	X	X	X	X
1.8	ADZ	1781	66	1994	1996	X	X	X	X	X	X	X
1.8	AAM	1781	55	1993	1996	X	X	X	X	X	X	X
1.9 TDi	1Z	1896	66	1993	1996	X	X	X	X	X	X	X
2.0	ADY	1984	85	1995	1996	X	X	X	X	X	X	X
2.0	2E	1984	85	1993	1996	X	X	X	X	X	X	X
2.0 16V	ABF	1984	110	1993	1996	X	X	X	X	X	X	X
2.8 VR6	AAA	2792	128	1993	1997	X	X	X	X	X	X	X
<b>Passat IV 1997 2005</b>												
1.6	ADP	1595	74	1997	1997	X	X	X	X	X	X	X
1.6	AHL	1595	74	1996	2000	X	X	X	X	X	X	X
1.6	ALZ	1595	75	2000	2005	X	X	X	X	X	X	X
1.6	ANA	1595	74	1999	2000	X	X	X	X	X	X	X
1.6	ARM	1595	74	1999	2000	X	X	X	X	X	X	X
1.8	ADR	1781	92	1996	1999	X	X	X	X	X	X	X
1.8	APT	1781	92	1999	2000	X	X	X	X	X	X	X
1.8	ARG	1781	92	1999	2001	X	X	X	X	X	X	X
1.8 Turbo	AEB	1781	110	1996	1999	X	X	X	X	X	X	X
1.8 Turbo	ANB	1781	110	1999	2000	X	X	X	X	X	X	X
1.8 Turbo	APU	1781	110	1999	2000	X	X	X	X	X	X	X
1.8 Turbo	AWT	1781	110	2000	2005	X	X	X	X	X	X	X
1.9 TDi	AFN	1896	81	1996	1999	X	X	X	X	X	X	X
1.9 TDi	AHH	1896	66	1998	2000	X	X	X	X	X	X	X
1.9 TDi	AHU	1896	66	1996	2000	X	X	X	X	X	X	X
1.9 TDi	AJM	1896	85	1999	2000	X	X	X	X	X	X	X
1.9 TDi	ATJ	1896	85	2000	2001	X	X	X	X	X	X	X
1.9 TDi	AVB	1896	74	2000	2005	X	X	X	X	X	X	X
1.9 TDi	AVF	1896	96	2000	2005	X	X	X	X	X	X	X
1.9 TDi	AVG	1896	81	1999	2000	X	X	X	X	X	X	X
1.9 TDi	AWX	1896	96	2000	2005	X	X	X	X	X	X	X
2.0	ALT	1984	96	2001	2005	X	X	X	X	X	X	X
2.0	AZM	1984	85	2000	2005	X	X	X	X	X	X	X
2.5 V6 TDi	AFB	2496	110	1998	2000	X	X	X	X	X	X	X

Legend: N = new, X = present

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays
<b>VOLKSWAGEN</b>												
<b>Passat IV 1997 2005</b>												
2.5 V6 TDi	AKN	2496	110	1999	2003	X	X	X	X	X	X	X
2.5 V6 TDi	BAU	2496	132	2003	2005	X	X	X	X	X	X	X
2.5 V6 TDi	BDH	2496	132	2003	2005	X	X	X	X	X	X	X
2.8 V6 30V	ACK	2771	142	1996	1999	X	X	X	X	X	X	X
2.8 V6 30V	AGE	2771	132	1997	1999	X	X	X	X	X	X	X
2.8 V6 30V	ALG	2771	142	1997	1999	X	X	X	X	X	X	X
2.8 V6 30V	AMX	2771	142	2000	2005	X	X	X	X	X	X	X
2.8 V6 30V	APR	2771	142	1999	2000	X	X	X	X	X	X	X
2.8 V6 30V	AQD	2771	142	1999	2000	X	X	X	X	X	X	X
2.8 V6 30V	ATX	2771	140	1999	2000	X	X	X	X	X	X	X
2.8 V6 30V	BBG	2771	140	2000	2005	X	X	X	X	X	X	X
4.0 W8	BDN	3999	202	2001	2005	X	X	X	X	X	X	X
VR5	AGZ	2327	110	1996	2000	X	X	X	X	X	X	X
VR5	AZX	2327	125	2001	2005	X	X	X	X	X	X	X
<b>Passat V 2005</b>												
1.6	BSE	1595	75	2005		X	X	X	X	X	X	X
1.6	BSF	1595	75	2005		X	X	X	X	X	X	X
1.6 FSi	BLF	1598	85	2005		X	X	X	X	X	X	X
1.6 FSi	BLP	1598	85	2005		X	X	X	X	X	X	X
1.9 TDi	BKC	1896	77	2005		X	X	X	X	X	X	X
1.9 TDi	BXE	1896	77	2006		X	X	X	X	X	X	X
1.9 TDi (DPF)	BLS	1896	77	2005		X	X	X	X	X	X	X
2.0 16V FSi	BLR	1984	110	2005	2006	X	X	X	X	X	X	X
2.0 16V FSi	BLX	1984	110	2005	2006	X	X	X	X	X	X	X
2.0 16V FSi	BLY	1984	110	2005	2006	X	X	X	X	X	X	X
2.0 16V FSi	BVX	1984	110	2006		X	X	X	X	X	X	X
2.0 16V FSi	BVY	1984	110	2005		X	X	X	X	X	X	X
2.0 16V FSi	BVZ	1984	110	2005		X	X	X	X	X	X	X
2.0 16V TDi	BKP	1968	103	2005		X	X	X	X	N	X	X
2.0 16V TDi	BMA	1968	100	2005		X	X	X	X	N	X	X
2.0 16V TDi	BVE	1968	90	2005	2006	X	X	X	X	X	X	X
2.0 16V TDi	BWV	1968	88	2005	2006	X	X	X	X	X	X	X
2.0 16V TDi (DPF)	BMR	1968	125	2006		X	X	X	X	N	X	X
2.0 16V TDi (DPF)	BUZ	1968	120	2005		X	X	X	X	N	X	X
2.0 TDi (DPF)	BMP	1968	103	2005		X	X	X	X	N	X	X
2.0 TFSi	AXX	1984	147	2005		X	X	X	X	X	X	X
2.0 TFSi	BPY	1984	147	2006		X	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays
<b>VOLKSWAGEN</b>												
<b>Passat V 2005</b>												
2.0 TFSi	BWA	1984	147	2005		X	X	X	X	X	X	X
3.2 VR6 FSi	AXZ	3189	184	2005		X	X	X	X	X	X	X
3.6 VR6 FSi	BLV	3580	206	2006		X	X	X	X	X	X	X
<b>Phaeton 2002</b>												
3.2 VR6	AYT	3189	177	2002		X	X	X	X	X	X	X
3.2 VR6	BKL	3189	177	2003		X	X	X	X	X	X	X
3.2 VR6	BRK	3189	177	2004		X	X	X	X	X	X	X
4.2 V8	BGH	4172	246	2003		X	X	X	X	X	X	X
4.2 V8	BGJ	4172	246	2003		X	X	X	X	X	X	X
5.0 V10 TDi	AJS	4921	230	2003		X	X	X	X	X	X	X
6.0 W12	BAN	5998	309	2002		X	X	X	X	X	X	X
6.0 W12	BAP	5998	309	2003		X	X	X	X	X	X	X
<b>Polo II 1981 1994</b>												
1.0	AAK	1043	33	1990	1990	X	X	X	X	X	X	X
1.0	AAU	1043	33	1990	1994	X	X	X	X	X	X	X
1.0	ACM	1043	33	1990	1994	X	X	X	X	X	X	X
1.0	GL	1043	29	1981	1983	X	X	X	X	X	X	X
1.0	GL	1043	29	1983	1989	X	X	X	X	X	X	X
1.0	HZ	1043	33	1984	1986	X	X	X	X	X	X	X
1.0	HZ	1043	33	1986	1994	X	X	X	X	X	X	X
1.3	NU	1272	40	1983	1989	X	X	X	X	X	X	X
1.3	2G	1272	40	1989	1994	X	X	X	X	X	X	X
1.3	3F	1272	57	1990	1994	X	X	X	X	X	X	X
1.3	AAV	1272	40	1991	1994	X	X	X	X	X	X	X
1.3	GK	1272	55	1982	1983	X	X	X	X	X	X	X
1.3	GT	1272	43	1983	1988	X	X	X	X	X	X	X
1.3	HK	1272	40	1983	1990	X	X	X	X	X	X	X
1.3	HW	1272	40	1983	1990	X	X	X	X	X	X	X
1.3	MH	1272	40	1983	1989	X	X	X	X	X	X	X
1.3	NZ	1272	40	1986	1994	X	X	X	X	X	X	X
1.3 D	MN	1272	33	1986	1990	X	X	X	X	X	X	X
1.3 G40	MK	1272	83	1990	1994	X	X	X	X	X	X	X
1.3 G40	MK	1272	85	1985	1989	X	X	X	X	X	X	X
1.3 G40	PY	1272	85	1987	1990	X	X	X	X	X	X	X
1.4 D	1W	1398	35	1990	1994	X	X	X	X	X	X	X
<b>Polo III 1994 2001</b>												
1.0	AER	999	39	1996	2000	X	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diag. Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diag. Fuses & Relays

**VOLKSWAGEN**

<b>Polo III 1994 2001</b>																		
1.0	AEV	1043	33	1994	1996	X	X	X	X	X	X	X	X	X	X	X	X	X
1.0	ALD	999	37	1999	2001	X	X	X	X	X	X	X	X	X	X	X	X	X
1.0	ALL	999	37	1997	2000	X	X	X	X	X	X	X	X	X	X	X	X	X
1.0	AUC	999	37	1999	2001	X	X	X	X	X	X	X	X	X	X	X	X	X
1.3	ADX	1298	40	1994	1997	X	X	X	X	X	X	X	X	X		X	X	
1.4	AKK	1390	44	1999	2001	X	X	X	X	X	X	X	X	X	X	X	X	
1.4	AKV	1390	44	1997	1999	X	X	X	X	X	X	X	X	X	X	X	X	
1.4	ANX	1390	40	1998	2000	X	X	X	X	X	X	X	X	X	X	X	X	
1.4	AUD	1390	44	1999	2001	X	X	X	X	X	X	X	X	X	X	X	X	
1.4 (40/44 kW)	AEX	1390	44	1995	1998	X	X	X	X	X	X	X	X	X	X	X	X	
1.4 (40/44 kW)	AKP	1390	40	1999	2001	X	X	X	X	X	X	X	X	X	X	X	X	
1.4 (40/44 kW)	APQ	1390	44	1997	2000	X	X	X	X	X	X	X	X	X	X	X	X	
1.4 16V	AFH	1390	74	1996	2000	X	X	X	X	X	X	X	X	X	X	X	X	
1.4 16V	AFK	1390	55	1999	2001	X	X	X	X	X	X	X	X	X	X	X	X	
1.4 16V	AHW	1390	55	1999	2001	X	X	X	X	X	X	X	X	X	X	X	X	
1.4 16V	APE	1390	55	1999	2000	X	X	X	X	X	X	X	X	X			X	
1.4 16V	AQQ	1390	74	1999	2000	X	X	X	X	X	X	X	X	X		X	X	
1.4 16V	AUA	1390	55	1999	2002	X	X	X	X	X	X	X	X	X	X	X	X	
1.4 16V	AUB	1390	74	2000	2002	X	X	X	X	X	X	X	X	X	X	X	X	
1.4 TDi	AMF	1422	55	1999	2001	X	X	X	X	X	X	X	X	X	X	X	X	
1.6	AEA	1598	55	1994	1995	X	X	X	X	X	X	X	X	X		X	X	
1.6	AEE	1598	55	1995	2000	X	X	X	X	X	X	X	X	X		X	X	
1.6 16V	ARC	1598	92	1999	2001	X	X	X	X	X	X	X	X	X	X	X	X	
1.6 16V	AVY	1598	92	2000	2001	X	X	X	X	X	X	X	X	X		X	X	
1.6 16V GTi	AJV	1598	88	1998	2000	X	X	X	X	X	X	X	X	X	X	X	X	
1.7 SDi	AHG	1718	42	1997	2000	X	X	X	X	X	X	X	X	X	X	X	X	
1.7 SDi	AKU	1718	44	1997	2000	X	X	X	X	X	X	X	X	X	X	X	X	
1.9 D	AEF	1896	47	1994	2001	X	X	X	X	X	X	X	X	X	X	X	X	
1.9 SDi	AGD	1896	47	1996	2001	X	X	X	X	X	X	X	X	X	X	X	X	
1.9 SDi	ASX	1896	47	1999	2001	X	X	X	X	X	X	X	X	X		X	X	
<b>Polo IV 2001</b>																		
1.2	AWY	1198	40	2002	2004	X	X	X	X	X	X	X	X	X		X	X	
1.2	BMD	1198	40	2004		X	X	X	X	X	X	X	X	X		X	X	
1.2 12V	AZQ	1198	47	2001	2005	X	X	X	X	X	X	X	X	X		X	X	
1.2 12V	BME	1198	47	2004		X	X	X	X	X	X	X	X	X		X	X	
1.4	BLM	1390	61	2003	2005	X	X	X	X	X	X	X	X	X			X	
1.4 16V	AUA	1390	55	2001	2002	X	X	X	X	X	X	X	X	X		X	X	

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>VOLKSWAGEN</b>											
<b>Polo IV 2001</b>											
1.4 16V	AUB	1390	74	2001	2002	X	X	X	X	X	X
1.4 16V	BBY	1390	55	2001		X	X	X	X	X	X
1.4 16V	BBZ	1390	74	2002		X	X	X	X	X	X
1.4 16V	BKY	1390	55	2004		X	X	X	X	X	X
1.4 FSi 16V	AXU	1390	63	2002		X	X	X	X	X	X
1.4 TDi	AMF	1422	55	2001	2005	X	X	X	X	X	X
1.4 TDi	BAY	1422	55	2001	2005	X	X	X	X	X	X
1.6	BAH	1598	74	2002	2005	X	X	X	X	X	X
1.9 SDi	ASY	1896	47	2001	2006	X	X	X	X	X	X
1.9 TDi	ASZ	1896	96	2003	2005	X	X	X	X	X	X
1.9 TDi	ATD	1896	74	2001	2005	X	X	X	X	X	X
1.9 TDi	AXR	1896	74	2001		X	X	X	X	X	X
1.9 TDi	BLT	1896	96	2004		X	X	X	X	X	X
GTi 1.8 Turbo	BJX	1781	110	2006		X		X		X	
<b>Polo Classic (Estate 1998-&gt;) 1995 2002</b>											
1.4	AEX	1390	44	1995	1998	X	X	X	X	X	X
1.4	AKK	1390	44	1999	2001	X	X	X	X	X	X
1.4	ANW	1390	44	1999	2000	X	X	X	X	X	X
1.4	AUD	1390	44	2000	2002	X	X	X	X	X	X
1.4 16V	APE	1390	55	1999	2000	X	X	X	X	X	X
1.4 16V	AUA	1390	55	1999	2002	X	X	X	X	X	X
1.6	1F	1595	55	1995	1997	X	X	X	X	X	X
1.6	AEE	1595	55	1996	2000	X	X	X	X	X	X
1.6	AEH	1595	74	1999	2001	X	X	X	X	X	X
1.6	AFT	1595	74	1995	1999	X	X	X	X	X	X
1.6	AKL	1595	74	1999	2001	X	X	X	X	X	X
1.6	ALM	1595	55	1998	2001	X	X	X	X	X	X
1.6	APF	1595	74	2000	2000	X	X	X	X	X	X
1.6	AUR	1595	74	2000	2001	X	X	X	X	X	X
1.7 SDi	AHB	1718	42	1996	2000	X	X	X	X	X	X
1.7 SDi	AKW	1718	44	1997	1999	X	X	X	X	X	X
1.8	ADZ	1791	66	1997	2002	X	X	X	X	X	X
1.9 D	1Y	1896	47	1996	2000	X	X	X	X	X	X
1.9 SDi	AEY	1896	47	1995	2000	X	X	X	X	X	X
1.9 SDi	AGP	1896	50	1999	2001	X	X	X	X	X	X
1.9 SDi	AQM	1896	50	1999	2001	X	X	X	X	X	X
1.9 TDi	AFN	1896	81	1996	1999	X	X	X	X	X	X



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>VOLKSWAGEN</b>													
<b>Polo Classic (Estate 1998-&gt;) 1995 2002</b>													
1.9 TDi	AGR	1896	66	1999	2001	X	X	X	X	X	X	X	X
1.9 TDi	AHU	1896	66	1997	2000	X	X	X	X	X	X	X	X
1.9 TDi	ALE	1896	66	1997	1999	X	X	X	X	X	X	X	X
1.9 TDi	ALH	1896	66	1999	2002	X	X	X	X	X	X	X	X
1.9 TDi	ASV	1896	81	1999	2001	X	X	X	X	X	X	X	X
<b>Scirocco 1982 1992</b>													
1.6	EG	1588	81	1982	1982	X	X	X	X				X
1.6	EW	1595	55	1984	1987	X	X	X	X	X			X
1.6 Kat.	EW	1595	51	1983	1992	X	X	X	X	X			X
1.8	JH	1781	70	1983	1992	X	X	X	X	X		X	X
1.8	DX	1781	82	1984	1987	X	X	X	X	X			X
1.8	EX	1781	66	1983	1991	X	X	X	X	X			X
1.8 16V	KR	1781	102	1987	1989	X	X	X	X	X		X	X
1.8 16V Kat.	PL	1781	95	1987	1989	X	X	X	X	X		X	X
<b>Sharan 1995</b>													
1.8 Turbo	AJH	1781	110	1997	2000	X	X	X	X	X	X	X	X
1.8 Turbo	AWC	1781	110	2000		X	X	X	X	X	X	X	X
1.9 TDi	1Z	1896	66	1995	2001	X	X	X	X	X	X	X	X
1.9 TDi	AFN	1896	81	1997	2001	X	X	X	X	X	X	X	X
1.9 TDi	AHU	1896	66	1996	2001	X	X	X	X	X	X	X	X
1.9 TDi	ANU	1781	66	1999		X	X	X	X	X			X
1.9 TDi	ASZ	1781	96	2002		X	X	X	X	X			X
1.9 TDi	AUY	1896	85	2000		X	X	X	X	X			X
1.9 TDi	AVG	1781	81	1999	2000	X	X	X	X	X			X
2.0	ADY	1984	85	1995	2001	X	X	X	X	X	X	X	X
2.0	ATM	1984	85	2000		X	X	X	X	X			X
VR6	AAA	2792	128	1995	1998	X	X	X	X	X	X	X	X
VR6	AMY	2792	128	1998	2001	X	X	X	X	X	X	X	X
VR6	AYL	2792	150	2000		X	X	X	X	X	X	X	X
<b>Taro 1989 1992</b>													
1.8	2Y	1812	61	1989	1992	X	X	X	X				X
2.2 4x4	4Y	2237	69	1989	1992	X	X	X	X				X
2.4 D	2L	2446	61	1989	1992	X	X	X	X				X
2.4 D 4x4	2L	2446	61	1989	1992	X	X	X	X				X
<b>Touareg 2002</b>													
2.5 TDi	BAC	2460	128	2003		X	X	X	X		X		X
2.5 TDi	BLK	2460	120	2003	2004	X	X	X	X		X		X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diagr. Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diagr. Fuses & Relays

**VOLKSWAGEN**

**Touareg 2002**

2.5 TDi	BPD	2460	120	2004		X	X	X	X	X			X	X			X
3.2 VR6	AZZ	3189	162	2002		X	X	X	X	X	X		X	X		X	X
3.2 VR6	BAA	3189	162	2003	2004	X	X	X	X	X	X		X	X			X
3.2 VR6	BKJ	3189	162	2002	2003	X	X	X	X	X	X		X	X		X	X
3.2 VR6	BMV	3189	177	2004		X	X	X	X	X	<b>N</b>		X	X			X
3.2 VR6	BMX	3189	177	2004		X	X	X	X	X			X	X			X
3.2 VR6	BRJ	3189	162	2003		X	X	X	X	X	<b>N</b>		X	X			X
4.2 V8	AXQ	4172	162	2003		X	X	X	X	X	X		X	X		X	X
4.2 V8	BHX	4172	228	2003		X	X	X	X	X			X	X		X	X
5.0 V10 TDi	AYH	4921	230	2002	2004	X	X	X	X	X				X		X	X
5.0 V10 TDi	BKW	4921	230	2003		X	X	X	X	X				X			X
5.0 V10 TDi	BLE	4921	230	2004		X	X	X	X	X				X			X
6.0 W12	BJN	5998	331	2004		X	X		X				X	X			X

**Touran 2003**

1.4 16V TSi	BMY	1390	103	2006		X	X	X	X	X				X		X	<b>N</b>
1.6	BGU	1595	75	2003	2006	X	X	X	X	X	X		X	X		X	X
1.6	BSE	1595	75	2005		X	X	X	X	X			X	X		X	X
1.6	BSF	1595	75	2005		X	X	X	X	X			X	X		X	X
1.6 16V FSi	BAG	1598	85	2003	2005	X	X	X	X	X	X		X	X		X	X
1.6 16V FSi	BLF	1598	85	2005		X	X	X	X	X			X	X		X	X
1.6 16V FSi	BLP	1598	85	2004	2006	X	X	X	X	X	X		X	X		X	X
1.9 TDi	AVQ	1896	74	2003	2005	X	X	X	X	X	X		X	X		X	X
1.9 TDi	BKC	1896	77	2003	2007	X	X	X	X	X	X		X	X		X	X
1.9 TDi	BRU	1896	66	2004	2006	X	X	X	X	X	X		X	X		X	X
1.9 TDi	BXE	1896	77	2006	2007	X	X	X	X	X			X	X			X
1.9 TDi	BXF	1896	66	2006		X	X	X	X	X			X	X			X
1.9 TDi (DPF)	BLS	1896	77	2005		X	X	X	X	X			X	X			X
2.0 16V FSi	AXW	1984	110	2003	2005	X	X	X	X	X	X		X	X		X	X
2.0 16V FSi	BLR	1984	110	2005	2006	X	X	X	X	X			X	X		X	X
2.0 16V FSi	BLX	1984	110	2004	2006	X	X	X	X	X	X		X	X		X	X
2.0 16V FSi	BLY	1984	110	2004	2006	X	X	X	X	X	X		X	X		X	X
2.0 16V FSi	BVY	1984	110	2005		X	X	X	X	X			X	X			X
2.0 16V FSi	BVZ	1984	110	2005		X	X	X	X	X			X	X			X
2.0 16V TDi	AZV	1968	100	2003		X	X	X	X	X	X		X	X		X	X
2.0 16V TDi	BKD	1968	103	2004		X	X	X	X	X	X		X	X		X	X
2.0 16V TDi (DPF)	BMN	1968	125	2005		X	X	X	X	X			X	X		X	X
2.0 TDi (DPF)	BMM	1968	103	2005		X	X	X	X	X			X	X		X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diagr. Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diagr. Fuses & Relays

**VOLKSWAGEN**

**Transporter T3 1980 1990**

1.6 D	CS	1588	37	1980	1987	X	X	X	X	X			X			X	
1.6 TD	JX	1588	51	1984	1990	X	X	X	X	X			X			X	
1.7 D	KY	1715	42	1987	1990	X	X	X	X	X			X			X	
1.9	DG	1913	57	1985	1987	X	X	X	X	X			X			X	
1.9	DG	1913	57	1987	1992	X	X	X	X	X			X			X	
1.9	SP	1913	54	1986	1987	X	X	X	X	X			X			X	
1.9	DG	1913	57	1982	1985	X	X	X	X	X			X			X	
1.9	SP	1913	54	1987	1988	X	X	X	X	X			X			X	
1.9	DF	1913	44	1982	1992	X	X	X	X	X			X			X	
1.9	EY	1913	41	1982	1989	X	X	X	X	X			X			X	
1.9 i	GW	1913	66	1983	1984	X	X	X	X	X			X			X	
1.9 i	GW	1913	66	1984	1985	X	X	X	X	X			X			X	
1.9 i	DH	1913	63	1983	1989	X	X	X	X	X			X			X	
2.1 i	DJ	2109	82	1985	1992	X	X	X	X	X			X			X	
2.1 i	MV	2109	70	1985	1992	X	X	X	X	X			X			X	
2.1 i	SR	2109	64	1986	1990	X	X	X	X	X			X			X	
2.1 i	SS	2109	68	1989	1992	X	X	X	X	X			X			X	

**Transporter T4 1990 2003**

1.8	PD	1781	49	1990	1992	X	X	X	X	X			X	X		X	
1.9 D	1X	1896	45	1990	1996	X	X	X	X	X			X	X		X	X
1.9 TD	ABL	1896	50	1992	2003	X	X	X	X	X	X		X	X		X	X
2.0	AAC	1968	62	1990	2003	X	X	X	X	X	X		X	X		X	X
2.4 D	AJA	2370	55	1997	2003	X	X	X	X	X			X	X		X	X
2.4 D	AAB	2370	57	1990	1998	X	X	X	X	X			X	X		X	X
2.5	AAF	2461	81	1990	1994	X	X	X	X	X	X		X	X		X	X
2.5	ACU	2461	81	1994	1996	X	X	X	X	X	X	X	X	X		X	X
2.5	AET	2461	85	1996	2003	X	X	X	X	X	X	X	X	X		X	X
2.5	APL	2461	85	1999	2000	X	X	X	X	X	X		X	X		X	X
2.5	AVT	2461	85	1999	2003	X	X	X	X	X	X		X	X		X	X
2.5 TDi	ACV	2460	75	1995	2003	X	X	X	X	X	X		X	X		X	X
2.5 TDi	AHY	2496	111	1998	2000	X	X	X	X	X	X		X	X		X	X
2.5 TDi	AJT	2460	65	1998	2003	X	X	X	X	X	X		X	X		X	X
2.5 TDi	AUF	2461	75	1999	2003	X	X	X	X	X	X		X	X		X	X
2.5 TDi	AXG	2496	111	2000	2003	X	X	X	X	X	X		X	X		X	X
2.5 TDi	AXL	2461	75	2001	2003	X	X	X	X	X	X		X	X		X	X
2.5 TDi	AYC	2461	75	2001	2003	X	X	X	X	X	X		X	X		X	X
VR6	AES	2792	103	1996	2000	X	X	X	X	X	X		X	X		X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description Engine code Capacity Output From To Maintenance Techn. Drawings Motor Manag. Wiring Diag. Service Reset Repair Times  
 Identification Adjustment Lubricants ABS Engine Air Cond. Wir. Diag. Fuses & Relays

**VOLKSWAGEN**

<b>Transporter T4 1990 2003</b>		AMV	2792	150	2000	2003	X	X	X	X	X	X			X	X		X	X
<b>Transporter T5 2003</b>																			
1.9 TDi		AXB	1896	77	2003		X	X	X	X	X	X			X	X		X	X
1.9 TDi		AXC	1896	63	2003		X	X	X	X	X	X			X			X	X
2.0		AXA	1984	85	2003		X	X	X	X	X	X			X			X	X
2.5 TDi		AXD	2460	96	2003		X	X	X	X	X	X			X	X		X	X
2.5 TDi		AXE	2460	128	2003		X	X	X	X	X	X			X	X		X	X
2.5 TDi		BLJ	2460	120	2003		X	X	X	X	X	X			X	X			X
3.2 VR6		BKK	3189	173	2003		X	X	X	X	X	X			X	X		X	X
3.2 VR6		BDL	3189	173	2003		X	X	X	X	X	X			X	X		X	X
<b>Vento 1991 1998</b>																			
1.4 (40/44kW)		ABD	1391	44	1992	1995	X	X	X	X	X	X	X	X	X	X	X	X	X
1.4 (40/44kW)		AEX	1390	44	1995	1998	X	X	X	X	X	X	X	X	X	X	X	X	X
1.6		AEA	1598	74	1994	1995	X	X	X	X	X	X	X	X	X	X	X	X	X
1.6		AEE	1598	55	1995	1998	X	X	X	X	X	X	X	X	X	X	X	X	X
1.6		AFT	1598	74	1996	1998	X	X	X	X	X	X	X	X	X	X	X	X	X
1.6		AKS	1598	74	1997	1998	X	X	X	X	X	X	X	X	X	X	X	X	X
1.6		ABU	1598	55	1992	1994	X	X	X	X	X	X	X	X	X	X	X	X	X
1.6		AEK	1595	74	1994	1996	X	X	X	X	X	X	X	X	X	X	X	X	X
1.8		AAM	1781	55	1992	1998	X	X	X	X	X	X	X	X	X	X	X	X	X
1.8		ABS	1781	66	1992	1994	X	X	X	X	X	X	X	X	X	X	X	X	X
1.8		ADZ	1781	66	1994	1998	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 D		1Y	1896	47	1992	1998	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 SDi		AEY	1896	47	1995	1998	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TD		AAZ	1896	55	1992	1998	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi		1Z	1896	66	1993	1996	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi		AFN	1896	81	1996	1998	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi		ALE	1896	66	1997	1998	X	X	X	X	X	X	X	X	X	X	X	X	X
1.9 TDi		AHU	1896	66	1996	1998	X	X	X	X	X	X	X	X	X	X	X	X	X
2.0		AGG	1984	85	1995	1998	X	X	X	X	X	X	X	X	X	X	X	X	X
2.0		AKR	1984	85	1997	1998	X	X	X	X	X	X	X	X	X	X	X	X	X
2.0		2E	1984	85	1992	1994	X	X	X	X	X	X	X	X	X	X	X	X	X
2.0 16V		ABF	1984	110	1992	1998	X	X	X	X	X	X	X	X	X	X	X	X	X
2.0 GT		ADY	1984	85	1994	1997	X	X	X	X	X	X	X	X	X	X	X	X	X
2.8 VR6		AAA	2792	128	1992	1998	X	X	X	X	X	X	X	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>VOLVO</b>											
<b>240 1982 1993</b>											
2.0	B 200 K	1986	74	1984	1989	X	X	X	X	X	X
2.0i	B 200 E	1990	86	1984	1993	X	X	X	X	X	X
2.0i	B 200 F	1986	82	1990	1993	X	X	X	X	X	X
2.3i	B 230 A	2316	81	1984	1988	X	X	X	X	X	X
2.3i	B 230 E	2316	96	1990	1993	X	X	X	X	X	X
2.3i	B 230 F	2316	85	1987	1992	X	X	X	X	X	X
2.3i	B 230 K	2316	85	1986	1988	X	X	X	X	X	X
2.4 D	D 24	2383	60	1982	1991	X	X	X	X	X	X
<b>340 / 360 1982 1991</b>											
1.4	B 14.4E	1397	51	1988	1992	X	X	X	X	X	X
1.4	B 14.4S	1397	53	1983	1991	X	X	X	X	X	X
1.6 D	D 16	1596	40	1984	1991	X	X	X	X	X	X
1.7	B 172 K/KD	1721	60	1985	1991	X	X	X	X	X	X
2.0	B 200 K/KD	1986	76	1983	1989	X	X	X	X	X	X
2.0i	B 200 E/F	1986	86	1983	1989	X	X	X	X	X	X
2.0i	B 200 F/K	1986	76	1984	1991	X	X	X	X	X	X
<b>440 / 460 1989 1997</b>											
1.6i	B 16 F	1596	61	1991	1997	X	X	X	X	X	X
1.7	B 18 K	1721	59	1989	1992	X	X	X	X	X	X
1.7	B 18 KP	1721	66	1989	1992	X	X	X	X	X	X
1.7 Kat.	B 18 KPD	1721	64	1989	1992	X	X	X	X	X	X
1.7i	B 18 E	1721	80	1989	1990	X	X	X	X	X	X
1.7i	B 18 EP	1721	78	1990	1995	X	X	X	X	X	X
1.7i	B 18 F	1721	70	1989	1990	X	X	X	X	X	X
1.7i	B 18 FP	1721	75	1989	1995	X	X	X	X	X	X
1.7i Turbo	B 18 FT	1721	88	1989	1997	X	X	X	X	X	X
1.8i	B 18 U	1794	66	1991	1997	X	X	X	X	X	X
1.9 Turbo D	D 19 T	1870	66	1994	1997	X	X	X	X	X	X
2.0i	B 20 F	1998	80	1993	1997	X	X	X	X	X	X
<b>480 1986 1995</b>											
1.7i	B 18 E/ED	1721	80	1986	1989	X	X	X	X	X	X
1.7i	B 18 F	1721	80	1988	1990	X	X	X	X	X	X
1.7i	B 18 FP	1721	75	1989	1992	X	X	X	X	X	X
1.7i Turbo	B 18 FT	1721	88	1988	1995	X	X	X	X	X	X
2.0i	B 20 F/FM	1998	81	1992	1995	X	X	X	X	X	X
<b>740 / 760 1982 1992</b>											
740 2.0	B 200 K	1986	78	1984	1989	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>VOLVO</b>											
<b>740 / 760</b>	<b>1982</b>	<b>1992</b>									
740 2.0i	B 200 E	1986	87	1988	1989	X	X	X	X	X	X
740 2.0i	B 200 F	1986	82	1989	1992	X	X	X	X	X	X
740 2.0i 16V	B 204 E	1986	102	1988	1991	X	X	X	X	X	X
740 2.0i Turbo	B 200 ET	1986	120	1984	1988	X	X	X	X	X	X
740 2.0i Turbo 16V	B 204 GT/FT	1991	147	1989	1991	X	X	X	X	X	X
740 2.3	B 230 K	2316	84	1984	1986	X	X	X	X	X	X
740 2.3	B 230 KH	2316	85	1987	1991	X	X	X	X	X	X
740 2.3i	B 230 E	2316	96	1984	1989	X	X	X	X	X	X
740 2.3i	B 230 F	2316	85	1986	1991	X	X	X	X	X	X
740 2.3i 16V	B 234 F	2316	114	1988	1992	X	X	X	X	X	X
740 2.3i Turbo	B 230 ET	2316	130	1984	1989	X	X	X	X	X	X
740 2.3i Turbo	B 230 FT/GT	2316	119	1987	1991	X	X	X	X	X	X
740 2.4 D	D 24	2383	60	1984	1992	X	X	X	X	X	X
740 2.4 Turbo D	D 24 T	2383	81	1984	1991	X	X	X	X	X	X
740 2.4 Turbo D Intercooler	D 24 TIC	2383	90	1987	1991	X	X	X	X	X	X
760 2.3i Turbo	B 23 ET/230 ET	2316	130	1982	1990	X	X	X	X	X	X
760 2.3i Turbo	B 230 FT/GT	2316	125	1988	1991	X	X	X	X	X	X
760 2.4 D	D 24	2383	60	1982	1984	X	X	X	X	X	X
760 2.4 Turbo D	T 24 D	2383	80	1986	1989	X	X	X	X	X	X
760 2.4 Turbo D Intercooler	D 24TIC	2383	90	1986	1991	X	X	X	X	X	X
760 2.8i V6	B 28 E	2849	115	1982	1986	X	X	X	X	X	X
760 2.8i V6	B 280 E	2849	125	1986	1991	X	X	X	X	X	X
760 2.8i V6	B 280 F	2849	108	1986	1991	X	X	X	X	X	X
<b>780</b>	<b>1986</b>	<b>1991</b>									
2.4 Turbo D	D 24T	2383	90	1987	1991	X	X	X	X	X	X
2.8i V6	B 280 E/F	2849	125	1986	1991	X	X	X	X	X	X
<b>850 / S70 / V70</b>											
<b>1992</b>	<b>2000</b>										
2.0 10V	B 5202 FS/S	1984	93	1995	1999	X	X	X	X	X	X
2.0 20V	B 5204 FS	1984	105	1992	1996	X	X	X	X	X	X
2.0 20V Turbo	B 5204 T	1984	155	1994	1997	X	X	X	X	X	X
2.0 20V Turbo	B 5204 T2	1984	132	1996	1998	X	X	X	X	X	X
2.0 20V Turbo	B 5204 T3	1984	166	1997	2000	X	X	X	X	X	X
2.0 20V Turbo	B 5204 T4	1984	132	1999	2000	X	X	X	X	X	X
2.3 20V	B 5234 FS/S	2319	120	1994	1999	X	X	X	X	X	X
2.3 20V	B 5234 T2	2319	160	1995	1998	X	X	X	X	X	X
2.3 20V R	B 5234 T4	2319	184	1996	1998	X	X	X	X	X	X
2.3 20V R AWD	B 5234 T6	2319	176	1998	1998	X	X	X	X	X	X

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagram. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>VOLVO</b>											
<b>850 / S70 / V70</b>	<b>1992</b>	<b>2000</b>									
2.3 20V T-5	B 5234 T	2319	166	1994	1997	X	X	X	X	X	X
2.3 20V T-5 R	B 5234 T3	2319	176	1997	2000	X	X	X	X	X	X
2.3 20V T-5 R	B 5234 T5	2319	176	1995	1997	X	X	X	X	X	X
2.4 20V	B 5244 S	2435	125	2000	2000	X	X	X	X	X	X
2.4 20V	B 5244 S2	2435	103	2000	2000	X	X	X	X	X	X
2.4 20V Bi-Fuel	B 5244 SG	2435	103	2000	2000	X	X	X	X	X	X
2.4 20V Bi-Fuel	B 5244 SG2	2435	103	2000	2000	X	X	X	X	X	X
2.4 20V R	B 5244 T2	2435	195	2000	2000	X	X	X	X	X	X
2.5 10V	B 5252 FS/S	2435	103	1993	1999	X	X	X	X	X	X
2.5 10V	B 5252 IS/S	2435	103	1993	1999	X	X	X	X	X	X
2.5 20V	B 5254 FS	2435	125	1992	1996	X	X	X	X	X	X
2.5 20V	B 5254 S	2435	125	1996	1999	X	X	X	X	X	X
2.5 20V LPT	B 5254 T	2435	142	1997	1999	X	X	X	X	X	X
2.5 TDi	D 5252 T	2460	103	1996	2000	X	X	X	X	X	X
<b>940/960/S90/V90</b>	<b>1991</b>	<b>1998</b>									
2.0	B 200 F	1986	82	1991	1995	X	X	X	X	X	X
2.0 16V	B 204 E	1986	114	1991	1992	X	X	X	X	X	X
2.0 16V Turbo	B 204 FT	1986	140	1991	1994	X	X	X	X	X	X
2.0 16V Turbo	B 204 GT	1986	147	1991	1998	X	X	X	X	X	X
2.0 Turbo	B 200 FT	1986	114	1991	1998	X	X	X	X	X	X
2.3	B 230 F	2316	85	1991	1994	X	X	X	X	X	X
2.3	B 230 FB	2316	96	1991	1995	X	X	X	X	X	X
2.3 16V	B 234 F	2316	114	1991	1992	X	X	X	X	X	X
2.3 LPT	B 230 FK	2316	99	1995	1998	X	X	X	X	X	X
2.3 Turbo	B 230 FT	2316	121	1991	1998	X	X	X	X	X	X
2.3 Turbo	B 230 GT	2316	125	1991	1994	X	X	X	X	X	X
2.4 D	D 24	2383	60	1992	1993	X	X	X	X	X	X
2.4 TD	D 24 T	2383	80	1991	1993	X	X	X	X	X	X
2.4 TD Intercooler	D 24 TIC	2383	90	1991	1996	X	X	X	X	X	X
2.5 24V	B 6254 FS/S	2473	125	1995	1998	X	X	X	X	X	X
3.0 24V	B 6304 FS/S	2922	150	1991	1994	X	X	X	X	X	X
3.0 24V	B 6304 S2	2922	132	1997	1998	X	X	X	X	X	X
<b>C30 2007</b>											
1.6 16V	B 4164 S3	1596	74	2007		X	X	X	N	X	N
1.6 16V TD	D 4164 T	1560	81	2007		X	X	X	N	X	N
1.8 16V	B 4184 S11	1798	92	2007		X	X	X	N	X	N
1.8 16V	B 4184 S8	1798	92	2007		X	X	X	N	X	N

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>VOLVO</b>											
<b>C30 2007</b>											
2.0 16V	B 4204 S3	1999	107	2007		X	X X	X N X		X	N
2.0 16V TD	D 4204 T	1997	100	2007		X	X X	X N X		X	N
2.0 16V TD	D 4204 T2	1997	96	2007		X	X X	X N X		X	N
2.4 20V	B 5244 S4	2435	125	2007		X	X X	X N X		X	N
2.4 20V D5	D 5244 T8	2400	132	2007		X	X X	X N X		X	N
2.4 20V D5	D 5244 T9	2400	120	2007		X	X X	X N X		X	N
2.5 20V T5	B 5254 T3	2521	162	2007		X	X X	X N X		X	N
<b>C70 1998 2006</b>											
2.0 20V Turbo	B 5204 T2	1984	132	1998	1999	X	X X	X X X	X	X X	X X
2.0 20V Turbo	B 5204 T3	1984	166	1998	2000	X	X X	X X X	X	X X	X X
2.0 20V Turbo	B 5204 T4	1984	120	1999	2006	X	X X	X X X		X X	X X
2.3 20V T5	B 5234 T3	2319	176	1998	2002	X	X X	X X X	X	X X	X X
2.3 20V Turbo	B 5234 T9	2319	180	2003	2006	X	X X	X X X		X X	
2.4 20V	B 5244 S	2435	125	2000	2000	X	X X	X X X		X X	X
2.4 20V Turbo	B 5244 T	2435	142	2000	2002	X	X X	X X X		X X	X X
2.4 20V Turbo	B 5244 T7	2435	147	2003	2006	X	X X	X X X		X X	X
2.5 20V	B 5254 S	2435	125	1999	1999	X	X X	X X X		X X	X X
2.5 20V LPT	B 5254 T	2435	142	1998	1999	X	X X	X X X	X	X X	X X
<b>C70 2006</b>											
2.4 20V	B 5244 S4	2435	103	2006		X	X X	X X		X	N
2.4 20V	B 5244 S5	2435	125	2006		X	X X	X X		X	N
2.4 20V D5	D 5244 T8	2521	132	2007		X	X X	X X		X	N
2.4 20V D5	D 5244 T9	2521	132	2007		X	X X	X X		X	N
2.5 20V T5	B 5254 T3	2521	162	2006		X	X X	X X		X	N
<b>S40 / V40 1996 2004</b>											
1.6 16V	B 4164 S	1587	77	1997	1999	X	X X	X X X	X	X X	X X
1.6 16V	B 4164 S2	1587	80	2000	2004	X	X X	X X X	X	X X	X X
1.8 16V	B 4184 S	1731	85	1996	1999	X	X X	X X X	X	X X	X X
1.8 16V	B 4184 S2	1731	90	2000	2004	X	X X	X X X		X X	X X
1.8 16V	B 4184 S3	1783	85	2000	2004	X	X X	X X X		X X	X X
1.8 16V Bi-Fuel	B 4184 S10	1731	90	2001	2004	X	X X	X X X		X X	X
1.8 16V Bi-Fuel	B 4184 S9	1731	90	2001	2004	X	X X	X X X		X X	X X
1.8 16V GDi	B 4184 SJ	1834	90	2001	2004	X	X X	X X X		X X	X X
1.8 16V GDi	B 4184 SM	1834	92	1998	2001	X	X X	X X X	X	X X	X X
1.9 16V T4	B 4194 T	1855	147	1998	1999	X	X X	X X X	X	X X	X X
1.9 16V T4	B 4194 T2	1855	147	2000	2000	X	X X	X X X	X	X X	X X
1.9 16V T4	B 4194 T5	1855	147	2001	2004	X	X X	X X X		X X	X X

Legend: N = new, X = present



All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr. Fuses & Relays
<b>VOLVO</b>											
<b>S40 / V40 1996 2004</b>											
1.9 TD	D 4192 T	1870	66	1996	1999	X	X	X	X	X	X
1.9 TD	D 4192 T2	1870	70	1999	2000	X	X	X	X	X	X
1.9 TD	D 4192 T3	1870	85	2001	2004	X	X	X	X	X	X
1.9 TD	D 4192 T4	1870	75	2001	2004	X	X	X	X	X	X
2.0 16V	B 4204 S	1948	103	1996	1999	X	X	X	X	X	X
2.0 16V	B 4204 S2	1948	100	2000	2004	X	X	X	X	X	X
2.0 16V LPT	B 4204 T	1948	118	1998	1999	X	X	X	X	X	X
2.0 16V Turbo	B 4204 T2	1948	118	2000	2000	X	X	X	X	X	X
2.0 16V Turbo	B 4204 T3	1948	121	2001	2004	X	X	X	X	X	X
2.0 16V Turbo	B 4204 T5	1948	147	2001	2003	X	X	X	X	X	X
<b>S40 / V50 2004</b>											
1.6 16V	B 4164 S3	1596	74	2005		X	X	X	X	X	N
1.6 16V TD	D 4164 T	1560	81	2005		X	X	X	X	X	N
1.8 16V	B 4184 S11	1798	92	2005		X	X	X	X	X	X
1.8 16V	B 4184 S8	1798	92	2005		X	X	X	X	X	X
2.0 16V	B 4204 S3	1999	107	2007		X	X	X	X	X	N
2.0 16V TD	D 4204 T	1997	100	2004		X	X	X	X	X	X
2.0 16V TD	D 4204 T2	1997	96	2004		X	X	X	X	X	X
2.4 20V	B 5244 S4	2435	125	2004		X	X	X	X	X	X
2.4 20V	B 5244 S5	2435	103	2004		X	X	X	X	X	X
2.4 20V T D5	D 5244 T8	2400	132	2006		X	X	X	X	X	N
2.4 20V T D5	D 5244 T9	2400	120	2007		X	X	X	X	X	N
2.5 20V T5	B 5254 T3	2521	162	2004		X	X	X	X	X	X
<b>S60 2001</b>											
2.0 20V Turbo	B 5204 T5	1984	132	2001		X	X	X	X	X	X
2.3 20V T5	B 5234 T3	2319	184	2001	2004	X	X	X	X	X	X
2.3 20V Turbo	B 5234 T7	2319	147	2001	2004	X	X	X	X	X	X
2.4 20V	B 5244 S	2435	125	2001		X	X	X	X	X	X
2.4 20V	B 5244 S2	2435	103	2001		X	X	X	X	X	X
2.4 20V D5	D 5244 T	2401	120	2001		X	X	X	X	X	X
2.4 20V D5	D 5244 T4	2401	136	2006		X	X	X	X	X	X
2.4 20V D5	D 5244 T5	2401	120	2006		X	X	X	X	X	X
2.4 20V T5	B 5244 T5	2400	191	2005		X	X	X	X	X	X
2.4 20V TD	D 5244 T2	2401	96	2002		X	X	X	X	X	X
2.4 20V TD	D 5244 T6	2401	90	2006		X	X	X	X	X	X
2.4 20V TD	D 5244 T7	2401	92	2006		X	X	X	X	X	X
2.4 20V Turbo	B 5244 T3	2435	147	2001	2003	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Identification	Maintenance	Techn. Drawings	Motor Manag.	Wiring Diagr.	Service Reset	Repair Times	Fuses & Relays
							Adjustment	Lubricants	ABS	Engine	Air Cond.	Wir. Diagr.	
<b>VOLVO</b>													
<b>S60 2001</b>													
2.4 20V Turbo R	B 5254 T4	2521	220	2004		X	X	X	X	X	X	X	X
2.4 Bi-Fuel	B 5244 SG	2435	103	2002		X	X	X	X	X	X		X
2.4 Bi-Fuel	B 5244 SG2	2435	103	2002	2005	X	X	X	X	X	X	X	X
2.5 20V Turbo	B 5254 T2	2521	154	2003		X	X	X	X	X	X	X	X
<b>S80 1999 2006</b>													
2.0 T5	B 5204 T3	1984	166	1999	2000	X	X	X	X	X	X	X	X
2.0 Turbo	B 5204 T4	1984	120	1999	2000	X	X	X	X	X	X	X	X
2.0 Turbo	B 5204 T5	1984	132	2000	2006	X	X	X	X	X	X	X	X
2.3 Turbo	B 5234 T7	2319	147	2000	2004	X	X	X	X	X	X		X
2.4	B 5244 S	2435	125	1999	2006	X	X	X	X	X	X	X	X
2.4	B 5244 S2	2435	103	1999	2006	X	X	X	X	X	X	X	X
2.4 Bi-Fuel	B 5244 SG	2435	103	2001	2006	X	X	X	X	X	X		X
2.4 Bi-Fuel	B 5244 SG2	2435	103	2001	2005	X	X	X	X	X	X	X	X
2.4 TD	D 5244 T2	2401	96	2002	2006	X	X	X	X	X	X	X	X
2.4 Turbo	B 5244 T3	2435	147	2001	2003	X	X	X	X	X	X	X	X
2.4 Turbo D5	D 5244 T	2401	120	2001	2006	X	X	X	X	X	X	X	X
2.5 TD	D 5252 T	2460	103	1999	2001	X	X	X	X	X	X	X	X
2.5 Turbo	B 5254 T2	2435	154	2003	2006	X	X	X	X	X	X	X	X
2.8 T6	B 6284 T	2783	200	1999	2001	X	X	X	X	X	X	X	X
2.9	B 6294 S	2922	147	2000	2002	X	X	X	X	X	X	X	X
2.9	B 6294 S2	2922	144	2003	2006	X	X	X	X	X	X	X	X
2.9 T6	B 6294 T	2922	200	2002	2006	X	X	X	X	X	X	X	X
3.0	B 6304 S3	2922	150	1999	1999	X	X	X	X	X	X	X	X
<b>S80 2006</b>													
2.4 20V D5	D 5244 T4	2401	136	2006		X	X	X	X		X		N
2.4 20V TD	D 5244 T5	2401	120	2006		X	X	X	X		X		N
2.5 20V Turbo	B 5254 T6	2521	147	2006		X	X	X	X		X		N
3.2 24V	B 6324 S	3192	175	2006		X	X	X	X		X		N
4.4 V8 32V	B 8444 S	4413	232	2006		X	X	X	X		X		N
<b>V70 /XC70 2000</b>													
2.0 20V Turbo	B 5204 T5	1984	132	2000		X	X	X	X	X	X		X
2.3 20V T5	B 5234 T3	2319	184	2000	2004	X	X	X	X	X	X	X	X
2.3 20V Turbo	B 5234 T7	2319	147	2001	2005	X	X	X	X	X	X		X
2.4 20V	B 5244 S	2435	125	2000		X	X	X	X	X	X	X	X
2.4 20V	B 5244 S2	2435	103	2000		X	X	X	X	X	X	X	X
2.4 20V Bi-Fuel	B 5244 SG	2435	103	2001		X	X	X	X	X	X	X	X
2.4 20V Bi-Fuel	B 5244 SG2	2435	103	2001	2005	X	X	X	X	X	X	X	X

Legend: N = new, X = present

All Cars 2008Q2

20-3-2008

Make description

Model description From To

Type description	Engine code	Capacity	Output	From	To	Maintenance Identification	Techn. Drawings Adjustment	Motor Manag. Lubricants	Wiring Diagr. ABS	Service Reset Engine	Repair Times Air Cond. Wir. Diagr.	Fuses & Relays						
<b>VOLVO</b>																		
<b>V70 / XC70 2000</b>																		
2.4 20V D5	D 5244 T	2401	120	2001	2006	X	X	X	X	X	X	X						
2.4 20V D5	D 5244 T4	2401	136	2006		X	X	X	X	X		N						
2.4 20V D5	D 5244 T5	2401	120	2006		X	X	X	X	X		N						
2.4 20V T5	B 5244 T5	2400	191	2005		X	X	X	X	X	X	X						
2.4 20V TD	D 5244 T2	2401	96	2002	2006	X	X	X	X	X	X	X						
2.4 20V TD	D 5244 T6	2401	90	2006		X	X	X	X	X		N						
2.4 20V TD	D 5244 T7	2401	92	2006		X	X	X	X	X		N						
2.4 20V Turbo	B 5244 T3	2435	147	2000	2003	X	X	X	X	X	X	X						
2.5 20V R	B 5254 T4	2521	220	2004		X	X	X	X	X	X	X						
2.5 20V Turbo	B 5254 T2	2521	154	2003		X	X	X	X	X	X	X						
2.5 TD	D 5252 T	2461	103	2000	2001	X	X	X	X	X	X	X						
<b>XC90 2003</b>																		
2.4 D5	D 5244 T	2401	120	2003	2006	X	X	X	X	X	X	X						
2.4 TD	D 5244 T4	2401	136	2006		X	X	X	X	X		X						
2.5 Turbo	B 5254 T2	2521	154	2003		X	X	X	X	X	X	X						
2.9 T6	B 6294 T	2922	200	2003	2006	X	X	X	X	X	X	X						
3.2	B 6324 S	3192	175	2007		X	X	X	X	X		N						
4.4 V8	B 8444 S	4414	232	2005		X	X	X	X	X		N						
137 6942						6885	6839	6865	6261	6687	3356	1891	2286	6125	2949	1640	5715	5310